

# CBF300NA

1. General Information

2. Fuel & Engine







4. Electrical System







This book is Specific Shop Manual. Refer to "Basic Shop Manual" for basic and common maintenance instructions. CBF300NA-J (2018) CBF300NA-K (2019)

A Few Words About Safety ·······	1-2
How To Use This Manual	1-3
MODEL IDENTIFICATION ······	1-5
SPECIFICATIONS	1-6
TORQUE VALUE ······1·	·12

SPECIAL TOOL LIST ······ 1-18
CABLE & HARNESS ROUTING1-19
TECHNICAL FEATURES ·······1-28
MAINTENANCE SCHEDULE ··········1-31





# A Few Words About Safety

# **Service Information**

The service and repair information contained in this manual is intended for use by qualified, professional technicians.

Attempting service or repairs without the proper training, tools, and equipment could cause injury to you or others. It could also damage the vehicle or create an unsafe condition.

This manual describes the proper methods and procedures for performing service, maintenance and repairs. Some procedures require the use of specially designed tools and dedicated equipment. Any person who intends to use a replacement part, service procedure or a tool that is not recommended by Honda, must determine the risks to their personal safety and the safe operation of the vehicle.

If you need to replace a part, use genuine Honda parts with the correct part number or an equivalent part. We strongly recommend that you do not use replacement parts of inferior quality.

# For Your Customer's Safety

Proper service and maintenance are essential to the customer's safety and the reliability of the vehicle. Any error or oversight while servicing a vehicle can result in faulty operation, damage to the vehicle, or injury to others.

# 

Improper service or repairs can create an unsafe condition that can cause your customer to be

seriously hurt or killed.

Follow the procedures and precautions in this manual and other service materials carefully.

# For Your Safety

Because this manual is intended for the professional service technician, we do not provide warnings about many basic shop safety practices (e.g., Hot parts–wear gloves). If you have not received shop safety training or do not feel confident about your knowledge of safe servicing practice, we recommended that you do not attempt to perform the procedures described in this manual.

Some of the most important general service safety precautions are given below. However, we cannot warn you of every conceivable hazard that can arise in performing service and repair procedures. Only you can decide whether or not you should perform a given task.

# 

Failure to properly follow instructions and precautions can cause you to be seriously hurt or killed.

Follow the procedures and precautions in this manual carefully.

# **Important Safety Precautions**

Make sure you have a clear understanding of all basic shop safety practices and that you are wearing appropriate clothing and using safety equipment. When performing any service task, be especially careful of the following:

- Read all of the instructions before you begin, and make sure you have the tools, the replacement or repair parts, and the skills required to perform the tasks safely and completely.
- Protect your eyes by using proper safety glasses, goggles or face shields any time you hammer, drill, grind, pry or work around pressurized air or liquids, and springs or other stored-energy components. If there is any doubt, put on eye protection.
- Use other protective wear when necessary, for example gloves or safety shoes. Handling hot or sharp parts can cause severe burns or cuts. Before you grab something that looks like it can hurt you, stop and put on gloves.
- Protect yourself and others whenever you have the vehicle up in the air. Any time you lift the vehicle, either with a hoist or a jack, make sure that it is always securely supported. Use jack stands.

Make sure the engine is off before you begin any servicing procedures, unless the instruction tells you to do otherwise. This will help eliminate several potential hazards:

- Carbon monoxide poisoning from engine exhaust. Be sure there is adequate ventilation whenever you run the engine
- · Burns from hot parts or coolant. Let the engine and exhaust system cool before working in those areas.
- Injury from moving parts. If the instruction tells you to run the engine, be sure your hands, fingers and clothing are out of the way.

Gasoline vapors and hydrogen gases from batteries are explosive. To reduce the possibility of a fire or explosion, be careful when working around gasoline or batteries.

- Use only a nonflammable solvent, not gasoline, to clean parts.
- Never drain or store gasoline in an open container.
- Keep all cigarettes, sparks and flames away from the battery and all fuel-related parts.

# How To Use This Manual

This manual is "Spec (Specific)" Service Manual. The service and repair information for this model is described in this manual as specific information. Refer to "Basic" Service Manual for basic/common service information and instructions.

Follow the Maintenance Schedule recommendations to ensure that the vehicle is in peak operating condition. Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Find the section you want on this page, then turn to the table of contents on the first page of the section.

Your safety, and the safety of others, is very important. To help you make informed decisions we have provided safety messages and other information throughout this manual. Of course, it is not practical or possible to warn you about all the hazards associated with servicing this vehicle.

You must use your own good judgement.

You will find important safety information in a variety of forms including:

· Safety Labels - on the vehicle

• Safety Messages – preceded by a safety alert symbol 🔨 and one of three signal words, DANGER, WARNING, or CAUTION. These signal words mean:

ADANGER You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

AWARNING You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

**ACAUTION** You CAN be HURT if you don't follow instructions.

• Instructions – how to service this vehicle correctly and safely.

As you read this manual, you will find information that is preceded by a **NOTICE** symbol. The purpose of this message is to help prevent damage to your vehicle, other property, or the environment.

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. Honda Motor Co., Ltd. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATSOEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON Honda MOTORCYCLES, MOTOR SCOOTERS OR ATVS.

### © Honda Motor Co., Ltd. SERVICE PUBLICATION OFFICE

Date of Issue: December, 2017



# SYMBOLS

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it would be explained specifically in the text without the use of the symbols.

# INSTRUCTION SYMBOL

	Removal or Disassembly procedure. Disconnect the connector.		Installation or Assembly procedure. Connect the connector.
	Order of removal/disassembly with a point of note.	1	Order of installation/assembly with a point of note.
5	Tighten specified torque.	New	Replace with a new one before assembly.
	Check the part for an inspection.	//	Measure the part for an inspection.
	Turn ignition switch to OFF.		Turn ignition switch to ON.
<b>(\$)</b>	Start the engine.		Measure a resistance or check continuity.
V Ø	Measure a voltage.	A Ø	Measure an ampere.
SP tool	Use the Honda special tool.	Basic	Refer to "Basic" Service Manual for the instruc- tion.

# LUBRICATION AND SEAL SYMBOL

	Use the recommend engine oil.	Apply molybdenum oil solution (mixture of an engine oil and molybdenum grease in a ration of 1:1).
Grease	Apply a specified grease. Use a multi-purpose grease unless otherwise specified.	Apply a liquid sealant.
Lock	Apply a locking agent. Use a medium strength one unless otherwise specified.	BF Use DOT 3 or DOT 4 brake fluid.
Fork	Use a specified fork oil or suspension fluid.	



# MODEL IDENTIFICATION

• Model name: CBF300NA-J

TYPE CODE	DESTINATION CODE	REGION	FRONT TURN SIGNAL/ POSITION LIGHT	EVAP	SIDESTAND SWITCH
CBF300NA	KO	Korea	0	0	0
CBF300NA	TH	Thailand	-	0	-

• Model name: CBF300NA-K

TYPE CODE	DESTINATION CODE	REGION	FRONT TURN SIGNAL/ POSITION LIGHT	EVAP	SIDESTAND SWITCH
CBF300NA	U	Australia, New zealand	0	-	0



VEHICLE IDENTIFICATION NUMBER



ENGINE SERIAL NUMBER







# SPECIFICATIONS GENERAL SPECIFICATIONS

ITEM			SPECIFICATIONS
DIMENSIONS	IMENSIONS Overall length TH model		2,012 mm
		KO,U model	2,020 mm
	Overall width	TH model	888 mm
		KO,U model	805 mm
	Overall height	TH model	1,052 mm
		KO,U model	1,050 mm
	Wheelbase	TH model	1,352 mm
		KO,U model	1,355 mm
	Seat height	TH, KO model	801 mm
		U model	800 mm
	Footpeg height		331 mm
	Ground clearance	TH model	151 mm
		KO,U model	150 mm
	Curb weight	TH model	143 kg
		KO model	145 kg
		U model	144 kg
	Maximum weight capacity	TH model	130 kg
		KO model	150 kg
		U model	180 kg
FRAME	Frame type		Diamond type
	Front suspension		Telescopic fork
	Front wheel travel		118 mm
	Rear suspension		Swingarm
	Rear wheel travel		132 mm
	Front tire size		110/70R17M/C 54H
	Rear tire size		150/60R17M/C 66H
	Front tire brand		GPR-300F M (DUNLOP)
	Rear tire brand		GPR-300 M (DUNLOP)
	Front brake		Hydraulic disc brake
	Rear brake		Hydraulic disc brake
	Caster angle		24°44'
	Trail length		93 mm
	Fuel tank capacity	TH model	10.0 liters
		KO,U model	10.1 liters

i

ITEM			SPECIFICATIONS			
ENGINE	Cylinder arrangement			Single cylinder 20° inclined from vertical		
	Bore and stroke	TH model		76.000 x 63.047 mm		
		KO,U model		76.0 x 63.0 mm		
	Displacement	TH model		286.01 cm <sup>3</sup>		
		KO,U mo	odel	286 cm <sup>3</sup>		
	Compression ratio			10.7 : 1		
	Valve train			Chain driven, DOHC		
	Intake valve opens			19° BTDC at 1 mm lift		
		closes		34° ABDC at 1 mm lift		
	Exhaust valve	opens		40° BBDC at 1 mm lift		
		closes		0° TDC at 1 mm lift		
	Lubrication system			Forced pressure and wet sump		
	Oil pump type			Trochoid		
	Cooling system			Liquid cooled		
	Air filtration			Viscous paper filter		
	Engine dry weight			35.4 kg		
	Emission control system			Crankcase emission control system		
				Secondary air supply system		
				Three-way catalytic converter		
				Evaporative emission control system (Except U type)		
FUEL SYSTEM	Туре			PGM-FI		
	Throttle bore			38 mm		
DRIVE TRAIN	Clutch system			Multi-plate, wet		
	Clutch operation system			Cable operating		
	Transmission			6 speed		
	Primary reduction			2.807 (73/26)		
	Final reduction			2.571 (36/14)		
	Gear ratio		1st	3.416 (41/12)		
			2nd	2.250 (36/16)		
			3rd	1.650 (33/20)		
			4th	1.350 (27/20)		
			5th	1.166 (28/24)		
			6th	1.038 (27/26)		
	Gearshift pattern			Left foot operated return system		
				1 - N - 2 - 3 - 4 - 5 - 6		
ELECTRICAL	Ignition system			Full transistorized		
	Starting system			Electric starter motor		
	Charging system			Triple phase output alternator		
	Regulator/rectifier			SCR shorted, triple phase full-wave		
				rectification		
	Lighting system			Battery		



# **FUEL & ENGINE SPECIFICATIONS**

# FUEL SYSTEM

ITEM	SPECIFICATIONS
Throttle body identification number	GQ9SA
Idle speed	1,400 ± 100 rpm
Throttle grip freeplay	2 – 6 mm
Fuel pressure at idle	267 – 326 kPa
Fuel pump flow (at 12 V)	103 cm <sup>3</sup> minimum/10 seconds

### LUBRICATION SYSTEM

Unit: mm

IT	EM	STANDARD	LIMIT
Engine oil capacity	After draining	1.4 liters	-
	After draining/filter change	1.5 liters	-
	After disassembly	1.8 liters	-
Recommended engine oil		Honda "4-stroke motorcycle oil" or an equivalent motor oil. API service classification: SG or higher JASO T903 standard: MA Viscosity: SAE 10W-30	_
Oil pump rotor	Tip clearance	0.15	0.20

# **COOLING SYSTEM**

ITEM			SPECIFICATIONS
Coolant capacity	Replacement		0.71 liters
	After disass	embly	0.79 liters
Radiator cap relief pressure			107.9 – 137.3 kPa
Thermostat Begin to open Fully open		en	81 – 84°C
			95°C
	Valve lift		4.5 mm minimum
Recommended antifreeze		TH model	Honda PRE-MIX Coolant
		KO,U model	High quality ethylene glycol antifreeze containing silicatefree corrosion inhibitors
Standard coolant concentration	on	KO,U model	1:1 (mixture with distilled water)

# CYLINDER HEAD/VALVE

					Unit: mm
ITEM				STANDARD	LIMIT
Cylinder compression				1,294 kPa at 490 rpm	_
Valve clearance			IN	0.16 ± 0.03	-
EX			EX	0.27 ± 0.03	-
Camshaft	Cam lobe h	eight	IN	30.931 – 31.171	30.9
	Ē		EX	30.839 – 31.079	30.8
	Oil clearance			0.020 - 0.062	0.10
Rocker arm, rocker arm	er arm Shaft O.D. Arm I.D.		IN/EX	9.972 – 9.987	_
shaft			IN/EX	10.000 – 10.015	10.06
Valve, valve guide	Valve stem O.D.		IN	4.475 - 4.490	4.465
			EX	4.465 - 4.480	4.455
	Valve guide I.D.		IN/EX	4.500 – 4.512	4.54
	Valve guide projection above cylinder head		IN/EX	13.8 – 14.0	-
	Valve seat	width	IN/EX	0.90 – 1.10	1.50
Valve spring free length Inner Outer		Inner		34.58	33.9
			40.37	39.6	
Cylinder head warpage				_	0.10
Exhaust pipe stud bolt height				21.5 – 22.5	_



# CYLINDER/PISTON

н.		
Uľ	וד:	mm

ITEM			STANDARD	LIMIT
Cylinder	I.D.		76.000 – 76.010	76.1
	Warpage		-	0.10
Piston, Piston pin	Piston, Piston pin Piston O.D. Piston pin bore I.D. Piston pin O.D.		75.960 – 75.980 at 11 mm from bottom of skirt	75.88
			17.002 – 17.008	17.02
			16.994 – 17.000	16.98
Piston rings	Piston rings Piston ring end gap		0.28 – 0.38	0.5
		Second	0.40 – 0.55	0.7
		Oil (side rail)	0.20 – 0.70	0.9
	Piston ring-to-ring	Тор	0.040 - 0.080	-
	groove clearance	Second	0.015 – 0.050	-
Connecting rod small end I.D.		17.016 – 17.034	17.04	

# CLUTCH/GEARSHIFT LINKAGE

			Unit: mm
ITEM		STANDARD	LIMIT
Clutch lever freeplay		10 – 20	-
Clutch	Disc thickness	2.30 - 2.50	2.10
	Plate warpage	-	0.10
	Clutch spring free length	36.8	36.1
Clutch outer guide I.D.		19.978 – 19.992	-
Mainshaft O.D. at clutch outer guide		19.966 – 19.980	-

# ALTERNATOR/STARTER CLUTCH

Unit: mm

ITEM		STANDARD	LIMIT
Starter driven gear	I.D.	36.000 – 36.013	-
	0.D.	51.705 – 51.718	-

# CRANKCASE/CRANKSHAFT/BALANCER

Unit: mm ITEM STANDARD LIMIT Connecting rod Side clearance 0.05 - 0.50 0.60 Radial clearance 0.004 - 0.016 0.05 Crankshaft Runout Right 0.03 \_ Left 0.02 \_ Main journal oil clearance 0.018 – 0.045 0.065 Main journal O.D. 33.985 - 34.000 33.975 Main journal bearing area I.D. 38.000 - 38.018 38.036



# TRANSMISSION

Unit: mm

	ITEM		STANDARD	LIMIT
Transmission	Gear I.D.	M5, M6	23.000 – 23.021	-
		C1	23.020 – 23.041	-
		C2	25.000 – 25.021	-
		C3, C4	28.000 – 28.021	-
	Gear bushing O.D.	M5, M6	22.959 – 22.980	-
		C1	22.984 - 23.005	-
		C2	24.959 - 24.980	-
		C3, C4	27.959 – 27.980	-
	Gear bushing I.D.	M5, C1	20.000 – 20.021	-
		C2	22.000 – 22.021	-
		C3	25.000 – 25.021	-
	Mainshaft O.D.	at M5 bushing	19.959 – 19.980	-
	Countershaft O.D.	at C1 bushing	19.959 – 19.980	-
		at C2 bushing	21.959 – 21.980	-
		at C3 bushing	24.959 - 24.980	-
Shift fork,	Fork I.D.		12.000 – 12.018	-
shift fork	Fork shaft O.D.		11.957 – 11.968	-
shaft	Fork claw thickness		4.93 - 5.00	4.83
Shift drum	Shift drum O.D.	Left side	13.966 – 13.984	13.94
	Shift drum journal I.D.	Left side	14.000 – 14.027	14.06
	Shift drum-to-shift drum journal clear- ance	Left side	0.016 – 0.061	0.08

# FRAME & CHASSIS SPECIFICATIONS

# FRONT WHEEL/SUSPENSION/STEERING

Unit: mm

ITEM		STANDARD	LIMIT	
Cold tire pres-	Driver only		200 kPa	-
sure	Driver and passenger		200 kPa	-
Axle runout			-	0.2
Wheel rim	Radial		-	2.0
runout	Axial		-	2.0
Wheel balance weight		60 g maximum	-	
Fork	Spring free length	Right	312.1	305.9
		Left	372.3	364.9
Recommended fluid		Honda Ultra Cushion Oil 10W or equivalent	_	
	Fluid level	Right	99	-
FI		Left	111	-
	Fluid capacity	Right	$513 \pm 2.5 \text{ cm}^3$	-
		Left	$425 \pm 2.5 \text{ cm}^3$	-

### **REAR WHEEL/SUSPENSION**

Unit: mm

ITEM		STANDARD	LIMIT	
Cold tire pressure	Driver only		225 kPa	-
	Driver and passenger		225 kPa	-
Axle runout		-	0.2	
Wheel rim runout	Radial		-	2.0
	Axial		-	2.0
Shock absorber pre-load adjuster standard position		2nd position from minimum	-	
Wheel balance weight		60 g maximum	-	
Drive chain slack		30 – 40	50	
Drive chain size/link		DID	DID 520VF-108LE	-
		RK	RK 520KLO2-108LE	-

# HYDRAULIC BRAKE

			Unit: mm
	ITEM	STANDARD	LIMIT
Front	Specified brake fluid	DOT 3 or 4 brake fluid	-
	Brake disc thickness	4.5 ± 0.2	3.5
	Brake disc warpage	-	0.30
	Master cylinder I.D.	12.700 – 12.743	-
	Master piston O.D.	12.657 – 12.684	-
	Caliper cylinder I.D.	25.400 - 25.450	-
	Caliper piston O.D.	25.318 - 25.368	-
Rear	Specified brake fluid	DOT 3 or 4 brake fluid	-
	Brake disc thickness	5.0 ± 0.2	4.0
	Brake disc warpage	-	0.30
	Master cylinder I.D.	12.700 – 12.743	-
	Master piston O.D.	12.657 – 12.684	-
	Caliper cylinder I.D.	33.960 - 34.010	-
	Caliper piston O.D.	33.878 – 33.928	-

# **ELECTRICAL SYSTEM SPECIFICATIONS**

# PGM-FI SYSTEM

ITEM	SPECIFICATIONS
IACV resistance (25°C)	110 – 150 Ω
IAT sensor resistance (40°C)	1.0 – 1.3 kΩ
ECT sensor resistance (20°C)	2.3 – 2.6 kΩ
Fuel injector resistance (20°C)	11 – 13 Ω
O <sub>2</sub> sensor heater resistance (20°C)	13 – 19 Ω
PAIR control solenoid valve resistance (20°C)	20 – 24 Ω
EVAP purge control solenoid valve resistance (20°C)	37 – 44 Ω

### **ABS SYSTEM**

	ITEM	SPECIFICATIONS
Air gap	Front (between the wheel sensor bracket of the fork and pulser ring)	0.58 – 1.10 mm
	Rear (between the caliper bracket and pulser ring)	0.89 – 1.34 mm



# **IGNITION SYSTEM**

ITEM	SPECIFICATIONS
Spark plug	SIMR8A9 (NGK)
Spark plug gap	0.8 – 0.9 mm
Ignition coil peak voltage	100 V minimum
CKP sensor peak voltage	0.7 V minimum
Ignition timing ("F"mark)	10° BTDC at idle speed

### **BATTERY/CHARGING SYSTEM**

ITEM			SPECIFICATIONS
Battery	Туре		YTZ8V
	Capacity		12 V – 7 Ah (10 HR)
	Voltage Fully charged		12.8 V minimum
		Needs charging	Below 12.3 V
	Charging	Normal	0.7 A/5 – 10 h
	current	Quick	3.5 A/1 h
Current leakage			0.05 mA maximum
Alternator Capacity Charging coil resistance (20°C) C			0.34 kW/5,000 rpm
		esistance (20°C)	0.1 – 1.0 Ω

### LIGHTS/METERS/SWITCHES

	ITEM		SPECIFICATIONS		
Fuse	Main fuse		30 A		
	Sub fuse		10 A x 3		
	Sub fuse		7.5 A x 3		
	ABS MOTOR fuse		30 A		
	ABS SOL fuse		20 A		
ABS ECU fuse		9	7.5 A		
Fuel level sensor	resistance	Full	5.5 – 8.5 Ω		
		Empty	385 – 395 Ω		

# **TORQUE VALUE**

- Each fastener should be tightened to the standard torque value except the fasteners specified torque value.
  Q'TY: Quantity, DIA: Thread diameter (mm), TRQ: Tightening torque (N·m)

# STANDARD TIGHTENING TORQUE

FASTENER TYPE	TRQ	FASTENER TYPE	TRQ
5 mm hex bolt and nut	5.2	5 mm screw	4.2
6 mm hex bolt and nut	10	6 mm screw	9.0
8 mm hex bolt and nut	22	6 mm flange bolt	12
10 mm hex bolt and nut	34	8 mm flange bolt and nut	27
12 mm hex bolt and nut	54	10 mm flange bolt and nut	39

# FUEL PUMP UNIT

ITEM	Q'TY	DIA	TRQ	REMARKS
Fuel pump setting plate nut	4	6	12	<b>→</b> 2-4

### **FUEL TANK**

ITEM	Q'TY	DIA	TRQ	REMARKS
Fuel filler cap bolt	3	4	1.8	

### **AIR CLEANER**

ITEM	Q'TY	DIA	TRQ	REMARKS
Fuel tank bracket mount bolt	4	6	12	
Air cleaner cover screw	4	5	1.1	
Air cleaner element screw	2	5	1.1	



# THROTTLE BODY

ITEM	Q'TY	DIA	TRQ	REMARKS
Throttle cable A lock nut (throttle body side)	1	6	4.5	
Throttle cable B lock nut (throttle body side)	1	6	4.5	
Sensor unit torx screw	3	5	3.4	
IACV setting plate torx screw	2	4	2.1	
Throttle cable holder screw	2	5	3.4	
Hose clamp stay screw	1	5	3.4	
Fuel hose stay screw	1	5	3.4	
Injector joint mounting bolt	2	5	5.1	

### SECONDARY AIR SUPPLY SYSTEM

ITEM	Q'TY	DIA	TRQ	REMARKS
PAIR check valve cover bolt	2	5	5.2	

### LUBRICATION SYSTEM

ITEM	Q'TY	DIA	TRQ	REMARKS
Oil drain bolt	1	12	24	

# **COOLING SYSTEM**

ITEM	Q'TY	DIA	TRQ	REMARKS
Cooling fan nut	1	3	1.0	Apply locking agent.
Fan motor shroud bolt	2	6	8.4	
Fan motor screw	3	4	2.7	
Water pump impeller	1	7	10	

# **CYLINDER HEAD**

ITEM	Q'TY	DIA	TRQ	REMARKS
Crankshaft hole cap	1	30	8.0	Apply engine oil.
Timing hole cap	1	14	6.0	Apply engine oil.
Cylinder head cover bolt	2	6	10	
Cam chain tensioner lifter plug	1	6	4.2	
Camshaft holder mounting bolt	8	6	12	Apply engine oil.
Cylinder head mounting nut	4	10	45	Apply engine oil.
Cylinder head sealing bolt	2	12	15	

### **CYLINDER/PISTON**

ITEM	Q'TY	DIA	TRQ	REMARKS
Cylinder stud bolt	4	10	-	→2-29

### **CLUTCH/GEARSHIFT LINKAGE**

ITEM	Q'TY	DIA	TRQ	REMARKS
Clutch center lock nut	1	16	108	Lock nut; replace with a new one and stake. Apply engine oil.
Clutch lifter plate bolt	5	6	12	
Primary drive gear lock nut	1	16	108	Apply engine oil.
Shift drum stopper arm bolt	1	6	10	Apply locking agent.
Shift drum stopper plate bolt	1	6	10	Apply locking agent.

### ALTERNATOR/STARTER CLUTCH

ITEM	Q'TY	DIA	TRQ	REMARKS
Starter clutch socket bolt	6	8	30	Apply locking agent.
Flywheel bolt	1	12	128	Apply engine oil.
CKP sensor mounting socket bolt	2	6	10	Apply locking agent. Coating width: 6.5 ± 1.0 mm from tip
Stator mounting socket bolt	3	6	10	



# CRANKCASE/TRANSMISSION/BALANCER

ITEM	Q'TY	DIA	TRQ	REMARKS
Cam chain tensioner pivot bolt	1	6	10	Apply locking agent. Coating width: 6.5 ± 1.0 mm from tip
Balancer shaft nut	1	14	44	Apply engine oil.

### **ENGINE UNIT**

ITE	Μ	Q'TY	DIA	TRQ	REMARKS
Engine hanger plate b	olt	2	10	54	
Engine hanger nut	Front upper	1	10	54	
	Front lower	1	10	54	
	Rear upper	1	10	54	
	Rear lower	1	10	54	
Drive sprocket fixing p	late bolt	2	6	10	

### **BODY PANELS**

ITEM	Q'TY	DIA	TRQ	REMARKS
Fuel tank cover mounting socket bolt (front)	2	5	4.2	
Fuel tank cover mounting socket bolt (side)	2	5	4.2	
Fuel tank cover mounting socket bolt	1	6	10	
(upper)				
Fuel tank cover mounting socket bolt (rear)	2	6	10	
Fuel tank inner cover screw	4	4	0.9	
Fuel tank inner cover socket bolt	2	5	4.2	
Radiator cover socket bolt	2	5	4.2	
Radiator cover inner cover socket bolt (front)	4	6	10	
Radiator cover inner cover socket bolt (rear)	2	5	4.2	
Under cowl socket bolt	2	6	10	
Under cowl screw	1	5	4.2	
Rear cowl socket bolt	2	5	4.2	
Rear center cover screw	2	5	0.9	
Drive chain case socket bolt	4	6	10	
License light stay socket bolt	4	6	10	
Rear fender A bolt	4	5	4.2	
Rear fender under cover socket bolt	1	5	4.2	
License light screw	2	4	1.2	
License light cover screw	4	4	0.9	
Reflector nut	1	5	1.5	Self lock nut
Front reflector nut	2	6	1.5	Self lock nut
Rear fender B socket bolt	2	6	10	
Rearview mirror lock nut	2	10	20	Left-hand threads
Rearview mirror adaptor bolt	2	10	20	
Single seat socket bolt	2	6	10	
Front fender socket bolt	6	6	10	
Step bracket socket bolt	2	8	35	
Step bolt	2	8	27	Pre-coated (ALOC) bolt, re- place with a new one.
Swingarm pivot nut	1	14	88	Self lock nut
Pillion step mounting socket bolt	4	8	27	
· · · · · · · · · · · · · · · · · · ·		-	I	

# SIDESTAND

ITEM	Q'TY	DIA	TRQ	REMARKS
Sidestand pivot bolt	1	10	10	
Sidestand pivot nut	1	10	44	Self lock nut
Sidestand switch bolt	1	6	10	Pre-coated (ALOC) bolt, re- place with a new one.



# EXHAUST PIPE/MUFFLER

ITEM	Q'TY	DIA	TRQ	REMARKS
Exhaust pipe stud bolt	2	8	-	<b>→</b> 3-15
Exhaust pipe joint nut	2	8	18	
Exhaust pipe mounting nut	1	8	27	
Muffler mounting nut	1	8	27	
Muffler band bolt	1	8	22.5	
Muffler cover bolt	1	6	10	
Muffler protector bolt	1	6	10	

# **FRONT WHEEL**

ITEM	Q'TY	DIA	TRQ	REMARKS
Front axle nut	1	14	59	
Front axle holder bolt	2	8	24	
Front brake disc bolt	5	8	35	Pre-coated (ALOC) bolt, re- place with a new one.

# FORK

ITEM	Q'TY	DIA	TRQ	REMARKS
Top bridge pinch bolt	2	8	22	
Bottom bridge pinch bolt	2	10	32	
Fork socket bolt	1	8	20	Apply locking agent.
Fork cap	2	45	35	
Fork rod nut	2	_	20	

# HANDLEBAR

ITEM	Q'TY	DIA	TRQ	REMARKS
Left handlebar switch screw	2	5	2.5	
Right handlebar switch screw	2	5	2.5	
Handlebar upper holder bolt	4	8	27	
Lower handlebar holder nut	2	8	27	Self lock nut

# STEERING STEM

ITEM	Q'TY	DIA	TRQ	REMARKS
Steering stem nut	1	24	103	
Steering stem adjusting nut	1	26	-	→3-23
Top bridge pinch bolt	2	8	22	
Headlight stay bolt	2	6	10	

# **REAR WHEEL**

ITEM	Q'TY	DIA	TRQ	REMARKS
Rear axle nut	1	16	88	Self lock nut
Drive chain adjuster lock nut	2	8	21	
Driven sprocket nut	6	10	65	Self lock nut
Rear brake disc bolt	4	8	42	Pre-coated (ALOC) bolt, re- place with a new one.
Pulser ring mounting bolt	4	5	7.0	Pre-coated (ALOC) bolt, re- place with a new one.

### **REAR SUSPENSION**

ITEM	Q'TY	DIA	TRQ	REMARKS
Shock absorber upper nut	1	10	44	Self lock nut
Shock absorber lower nut	1	10	44	Self lock nut
Swingarm pivot nut	1	14	88	Self lock nut
Drive chain slider bolt	1	5	5	Pre-coated (ALOC) bolt, re-
				place with a new one.



# FRONT BRAKE

ITEM	Q'TY	DIA	TRQ	REMARKS
Front brake hose oil bolt	2	10	34	
Front master cylinder bolt	2	6	12	
Front master cylinder reservoir cover screw	2	4	1.5	
Brake lever pivot bolt	1	6	1.0	
Brake lever pivot nut	1	6	5.9	
Front brake light switch screw	1	4	1.2	
Front brake caliper mounting bolt	2	10	45	Pre-coated (ALOC) bolt, re- place with a new one.
Front brake caliper bleed valve	1	8	5.4	
Front brake caliper assembly torx bolt	3	8	27	Apply locking agent.

### **REAR BRAKE**

ITEM	Q'TY	DIA	TRQ	REMARKS
Rear brake hose oil bolt	2	10	34	
Rear master cylinder bolt	2	6	12	
Rear master cylinder reservoir cover screw	2	4	1.5	
Rear master cylinder hose joint screw	1	4	1.5	Apply locking agent.
Rear master cylinder push rod lock nut	1	8	17	
Rear brake pad hanger pin	1	10	17	
Rear brake caliper bleed valve	1	8	5.4	

### **PGM-FI SYSTEM**

ITEM	Q'TY	DIA	TRQ	REMARKS
ECT sensor	1	12	25	
O <sub>2</sub> sensor	1	12	25	
Bank angle sensor mounting bolt	2	6	10	

### **IGNITION SYSTEM**

ITEM	Q'TY	DIA	TRQ	REMARKS
Spark plug	1	10	16	

### ELECTRICAL STARTER

ITEM	Q'TY	DIA	TRQ	REMARKS
Neutral switch	1	10	12	
Negative brush screw	1	5	3.7	
Starter motor assembly bolt	2	5	4.9	

# ABS

ITEM	Q'TY	DIA	TRQ	REMARKS
Modulator cover socket bolt	2	5	4.2	
Brake pipe joint nut	3	10	14	
Brake hose oil bolt	1	10	34	

### **BATTERY/CHARGING SYSTEM**

ITEM	Q'TY	DIA	TRQ	REMARKS
Starter relay switch nut	1	6	4.9	
Fuel tank mount socket bolt	2	6	12	
Battery band bolt	1	6	10	

### LIGHTING SYSTEM

ITEM	Q'TY	DIA	TRQ	REMARKS
Brake/taillight nut	2	6	9.0	
Headlight cover socket bolt	6	5	4.2	
Meter cover socket bolt	2	5	4.2	



# COMBINATION METER

ITEM	Q'TY	DIA	TRQ	REMARKS
Meter screw	3	5	1.0	

### ELECTRICAL COMPONENT

ITEM	Q'TY	DIA	TRQ	REMARKS
Ignition switch bolt	2	8	26	One-way bolt, replace with a
				new one.
Sidestand switch bolt	1	6	10	Pre-coated (ALOC) bolt, re-
				place with a new one.

### OTHERS

ITEM	Q'TY	DIA	TRQ	REMARKS
Throttle cable A lock nut (handlebar side)	1	10	1.5	
Throttle cable A adjusting lock nut	1	7	3.8	
(handlebar side)				
Throttle cable B lock nut (handlebar side)	1	12	1.5	
Clutch lever pivot bolt	1	6	1.0	
Clutch lever pivot nut	1	6	6.0	
Harness stay screw (headlight)	2	5	1.0	
Bank sensor bolt	2	6	11	
Gearshift spindle return spring pin	1	8	30	Apply locking agent.



# SPECIAL TOOL LIST

TITLE	TOOL No.	TOOL NAME
	07406-0040004	Fuel pressure gauge
	070MJ-K260100	Fuel pressure gauge attachment
	070MF-KVS0300	Fuel pump case remover
	070PZ-ZY30100	SCS connector
	07709-0010001	Timing cap wrench
	070MG-0010100	Cam chain tensioner lifter stopper
	07757-0010000	Valve spring compressor
	07959-KM30101	Valve spring compressor attachment
	07HMH-ML00101	Valve guide reamer, 4.5 mm
Fuel & Engine	07HMD-ML00101	Valve guide driver, 4.3 mm
	07743-0020000	Valve guide driver
	07724-0050002	Clutch center holder
	07724-0010200	Gear holder, M1.5
	07PAF-0010620	Pilot collar, 16 mm
	07746-0050200	Bearing remover head, 10 mm
	07725-0040001	Flywheel holder
	07733-0020001	Flywheel puller
	07724-0010100	Gear holder, M2.5
	070MF-KYJ0100	Metal installer set
	07746-0050400	Bearing remover head, 15 mm
	07746-0050100	Bearing remover shaft
	07746-0010300	Attachment, 42 x 47 mm
	07746-0040300	Pilot 15 mm
	07749-0010000	Driver
	070MA-MGP0100	Fork cap wrench
	07YMD-MCF0100	Fork seal driver, 43.2 mm
	07916-3710101	Steering stem socket
	070MF-MBZC120	Damper rod holder
Frame & Chassis	070MF-MBZC110	Spring collar holder
	070MF-MBZC130	Stopper plate
	07953-MJ10100	Remover attachment
	07953-MJ10200	Remover handle
	07946-3710500	Bearing remover
	07946-MB00000	Driver, 30 mm I.D.
	07746-0050500	Remover head, 17 mm
	07746-0010200	Attachment, 37 x 40 mm
	07746-0040400	Pilot 17 mm
	07746-0040500	Pilot 20 mm
	07914-SA50001	Snap ring pliers
Electrical System	07HGJ-0020100	Peak voltage adapter

# **CABLE & HARNESS ROUTING**

KO, U model shown:















 $(\mathbf{i})$ 





Except U model:



U model:





# TECHNICAL FEATURES FUEL PUMP SYSTEM WITH A FUEL FILTER BLOCKAGE REMINDER FUNCTION



The fuel pump system of this model consists of the following components:

- Fuel pump chamber
- Fuel filter
- Breather passage
- Breather filter

Under normal condition, the fuel pump chamber sucks fuel through the fuel filter and then supplies it to the injector.

When the fuel filter is clogged, the fuel is sucked into the pump chamber through the breather passage in order to keep the vehicle running. The breather filter is located in the upper inner side of fuel tank. When the fuel is consumed to the point where the breather filter is exposed above the fuel level, a certain amount of air will be drawn into the pump chamber via the breather filter and breather passage. This incoming air produces "a lack of fuel", which impairs engine performance in order to notify the rider of the fuel filter blockage. This symptom works as a reminder for the filter replacement.

This system eliminates the need of fuel filter replacement according to a fixed interval, as the rider will experience the symptom and notice the filter blockage during vehicle usage.

The driveability remains normal as long as the fuel level in tank is maintained above the breather filter because no air will be drawn into the pump chamber, even when the fuel filter is clogged.

If the fuel in tank is sufficient but such symptom as poor engine performance, lack of fuel, or engine start failure exist, perform the fuel supply test.  $\rightarrow$  2-3

# **MIL SYSTEM**

# **MIL INDICATION**

In the existing PGM-FI system, if the existing PGM-FI system detects the malfunction at the present, the MIL blinks the number of trouble code with idle engine speed or sidestand switch ON. But in this PGM-FI system, when the system detects the malfunction, it turns the MIL ON without blinking unless otherwise the SCS circuit short (reading DTC with DLC connector).

		Existing PGM-F	1		This PGM-FI	
	At Idle	Riding	SCS short	At Idle	Riding	SCS short
Current trouble	Blinking	ON	Blinking	ON	ON	Blinking
Past trouble	OFF	OFF	Blinking	*ON	*ON	*Blinking

\* This system turn off the MIL if the system does not detect the same trouble again in three driving cycle (three times repeat of ignition-ON, riding and ignition-OFF).

# EVAP CANISTER DRAIN CLOSURE STRUCTURE (TH model only)

# OVERVIEW

The model is equipped with a EVAP canister drain cap.

The EVAP canister drain is plugged with a drain cap in order to prevent water entry when the canister is placed under water due to high water level.

Also, the breather hose opening is located high enough to prevent water entry in case when the water level exceeds the height of the canister.





# ABS (ANTI-LOCK BRAKE SYSTEM) WITH IMU (INERTIAL MEASUREMENT UNIT)

# SUMMARY

This model is equipped with ABS (Anti-lock brake system).

The system calculates estimated speed from the front wheel speed sensor and rear wheel speed sensor.

When the system detects that the front wheel or rear wheel is about to lock when the estimated speed is high, the ABS modulator prevents front wheel or rear wheel locking up by controlling the front brake or rear wheel caliper fluid pressure.

This vehicle is also equipped with IMU (Inertial Measurement Unit) to prevent rear wheel lifting during hard braking. The IMU detects the vertical and horizontal acceleration and computes the inertia affecting on the center of gravity of the vehicle.

When the vehicle experiences nose dive caused by abrupt brake application, resulting in measured direction and/or speed of the acceleration reaching a certain threshold, it prevents rear wheel lifting by slightly reducing the brake fluid pressure in ABS modulator.



# MAINTENANCE SCHEDULE

# TH model

- Perform the Pre-ride inspection in the Owner's Manual at each scheduled maintenance period.
- I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.
- The following items require some mechanical knowledge. Certain items (particularly those marked \* and \*\*) may
  require more technical information and tools. Consult a dealer.



Refer to "Basic" Service Manual for each maintenance instruction except the instructions described in this manual.

			FREQUENCY (NOTE 1)									REFER	
ITEMS		NOTE	X1,000 km	1	6	12	18	24	30	36			TO
			X1,000 mi	0.6	4	8	12	16	20	24	UNEUK	REFLACE	PAGE
*	FUEL LINE					Ι		I		Ι	I		
*	THROTTLE					1		1		1			
	OPERATION					I		1		I	I		
*	AIR CLEANER	NOTE2					R			R			<b>→</b> 2-7
	CRANKCASE				C	C	C	C	C	C			
	BREATHER	NOTES			C	C	C	0	C	C			
*	SPARK PLUG			ΕV	′ERY	24,00	)0 km	(16,0	00 mi	i) I,			
				EVERY 48,000 km (32,000 mi) R									
*	VALVE CLEARANCE							-					→2-22
	ENGINE OIL			R		R		R		R	R		<b>→</b> 2-15
	ENGINE OIL FILTER			R				R					
*	ENGINE IDLE SPEED									I	I		
	RADIATOR COOLANT	NOTE4								I	I	3 years	
*	COOLING SYSTEM					I				I	I		
*	SECONDARY AIR							-					
	SUPPLY SYSTEM							1					
*	EVAPORATIVE												
	EMISSION CONTROL												
	SYSTEM												
	DRIVE CHAIN			Every 1000 km (600 mi) I, L									
	DRIVE CHAIN SLIDER												
	BRAKE FLUID	NOTE4						-	I	I		2 years	
	BRAKE PADS WEAR				Ι	Ι	I	Ι	-	Ι	I		
	BRAKE SYSTEM					Ι		Ι		Ι	I		
	BRAKE LIGHT					1		1		I			
	SWITCH					1		-		1	•		
	HEADLIGHT AIM					Ι		-		Ι	I		<b>→</b> 4-55
	CLUTCH SYSTEM					Ι	I	-	Ι	Ι			
	SIDESTAND					I				Ι			
*	SUSPENSION					I					I		
*	NUTS, BOLTS,					1		1		1	1		
	FASTENERS										I		
**	WHEELS/TIRES					Ι		Ι		Ι	I		
**	STEERING HEAD					I		I		I			
	BEARINGS												

• \* Should be serviced by a dealer, unless the owner has proper tools and service data and is mechanically qualified.

• \*\* In the interest of safety, we recommend these items be serviced only by a dealer.

• Honda recommends that a dealer should road test the vehicle after each periodic maintenance is carried out.

NOTES:

- 1. At higher odometer readings, repeat at the frequency interval established here.
- 2. Service more frequently when riding in unusually wet or dusty areas.
- 3. Service more frequently when riding in rain or at full throttle.
- 4. Replacement requires mechanical skill.



# KO, U model

- Perform the Pre-ride inspection in the Owner's Manual at each scheduled maintenance period.
- I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.
- The following items require some mechanical knowledge. Certain items (particularly those marked \* and \*\*) may require more technical information and tools. Consult a dealer.



Refer to "Basic" Service Manual for each maintenance instruction except the instructions described in this manual.

ITEMS			FRI	EQUE	NCY (	(NOTE			REFER		
		NOTE	X1,000 km	1	12	24	36	48		REPLACE	ТО
			X1,000 mi	0.6	8	16	24	32	CHECK		PAGE
* FUEL LINE							I	Ι	I		
*	THROTTLE OPERATION						I	Ι	I		
*	AIR CLEANER	NOTE2				R		R			<b>→</b> 2-7
	CRANKCASE BREATHER	NOTE3			С	С	С	С			
*	SPARK PLUG							R			
*	VALVE CLEARANCE							I			→2-22
	ENGINE OIL			R	R	R	R	R	R		→2-15
	ENGINE OIL FILTER			R		R		R			
*	ENGINE IDLE SPEED							I	I		
	RADIATOR COOLANT	NOTE4						I	I	3 years	
*	COOLING SYSTEM						I	I			
*	SECONDARY AIR SUPPLY										
	SYSTEM					1					
*	EVAPORATIVE EMISSION										
	CONTROL SYSTEM					I I		I			
	(KO model only)										
DRIVE CHAIN				Every 1000 km (600 mi) I, L							
	DRIVE CHAIN SLIDER						I	Ι			
	BRAKE FLUID	NOTE4			I			Ι	I	2 years	
	BRAKE PADS WEAR					I	I	I	I		
	BRAKE SYSTEM					I	I	I	I		
	BRAKE LIGHT SWITCH					I		I	I		
	HEADLIGHT AIM						I	I	I		<b>→</b> 4-55
	CLUTCH SYSTEM					I			I		
	SIDESTAND							I	I		
*	SUSPENSION							I	I		
*	NUTS, BOLTS, FASTENERS							I	I		
**	WHEELS/TIRES							I	I		
**	STEERING HEAD				1	1	1	1			
	BEARINGS								I		

• \* Should be serviced by a dealer, unless the owner has proper tools and service data and is mechanically qualified.

• \*\* In the interest of safety, we recommend these items be serviced only by a dealer.

Honda recommends that a dealer should road test the vehicle after each periodic maintenance is carried out.

NOTES:

1. At higher odometer readings, repeat at the frequency interval established here.

- 2. Service more frequently when riding in unusually wet or dusty areas.
- 3. Service more frequently when riding in rain or at full throttle.
- 4. Replacement requires mechanical skill.

# 2. FUEL & ENGINE

FUEL LINE 2-2
FUEL PUMP UNIT····· 2-4
FUEL TANK ······ 2-6
AIR CLEANER ······ 2-7
THROTTLE BODY ····· 2-8
SECONDARY AIR SUPPLY SYSTEM···2-12
EVAP SYSTEM ·····2-13
LUBRICATION SYSTEM2-14

COOLING SYSTEM ······2-17
CYLINDER HEAD ······ 2-22
CYLINDER/PISTON ·····2-29
CLUTCH/GEARSHIFT LINKAGE ······· 2-30
ALTERNATOR/STARTER CLUTCH ····· 2-33
CRANKCASE/CRANKSHAFT/ BALANCER·····2-35
TRANSMISSION ·····2-39
ENGINE UNIT 2-40





# FUEL LINE









- This vehicle uses resin for the parts of materials in the fuel hose. Do not bend or twist the fuel hose.
- Fuel tank lifting →4-52
- 1 Fuel pump 5P connector
- Let the engine idle until it stops.
- Battery negative (–) cable →4-52
- Do not use tools in removal. If the connector does not move, alternately pull and push the connector until it comes off easily.
- Check the fuel quick connect fitting for dirt, and clean if necessary.
- Place a shop towel over the quick connect fitting.
- 1 Push the retainer tab forward.
- 2 Press down the retainer and disconnect the connector from the fuel joint.
- Check the retainer condition and replace the fuel hose if necessary.
- To prevent damage and keep foreign matter out, cover the disconnected connector and pipe end with the plastic bags.



S

**(**\$)

V

- Press the connector onto the fuel joint until the retainer locks with a "CLICK". If it is hard to
- connect, put a small amount of engine oil on the pipe end.Make sure the connection is secure; check visually and by
- pulling the connector.After installing the removed parts, turn the ignition switch ON. (Do not start the engine.)

The fuel pump will run for about 2 seconds, and fuel pressure will rise. Repeat 2 or 3 times, and check that there is no leakage in the fuel supply system.



# FUEL SUPPLY TEST If the fuel in tank is sufficient but such symptom as poor engine performance, lack of fuel, or engine start failure exist, perform the following. Perform the fuel pressure test. →2-3 If the fuel pressure is within specification, perform the fuel flow inspection. →2-3 Perform the fuel flow inspection in the specified fuel quantity. →2-3

# FUEL PRESSURE TEST



# FUEL FLOW INSPECTION



- Quick connect fitting (fuel pump side)
- Attach the fuel pressure gauge and attachment.
   [A] Fuel pressure gauge: 07406-0040004
   [B] Fuel pressure gauge attachment: 070MJ-K260100
- Temporarily connect the negative cable to the battery and fuel pump 5P connector.
- Start the engine and let it idle, and read the fuel pressure. **Standard: 267 326 kPa**
- If the fuel pressure is higher than specified, replace the fuel pump assembly. →2-4
- If the fuel pressure is lower than specified, inspect the following.
  - Fuel line leaking
  - Any erratic swing or vibration of the gauge needle in the pressure gauge reading.
    - If the needle is swing or vibration, replace the fuel filter. →2-5
    - If the needle is stable, replace the fuel pump unit. →2-4
- Quick connect fitting (injector side) →2-2
- Place the end of the hose into an approved gasoline container. Wipe off spilled out gasoline.
- The fuel pump operates for 2 seconds. Repeat 5 times to meet the total measuring time.

# Standard: 103 cm<sup>3</sup> minimum/10 seconds

- If fuel flow is less than specified, inspect the following:
   Clogged fuel hose
  - Fuel pump unit
- 1 Place the vehicle on the level ground with its sidestand. Adjust the fuel in the tank so that the fuel gauge segment is positioned the specified range [A], and inspect the fuel flow.
  - If the fuel flow is above specification, check for other malfunctioning parts.
  - If the fuel flow is under specification, replace the fuel filter. →2-5

# 2-3


#### **FUEL PUMP UNIT**





- Quick connect fitting (fuel pump side) →2-2
- Fuel tank →2-6
- 1 Loosen the nuts in a crisscross pattern in several steps.
- Carefully remove the fuel pump unit from the fuel tank to prevent damaging the fuel level sensor.
- Install a new outer packing onto the fuel pump unit groove by aligning its tab with the boss.
   Install fuel pump into the fuel tank by aligning the triangle marks of the setting plate and fuel tank. •
- 3 Set the setting plate onto the fuel pump by aligning its hole with the boss.
- Tighten the fuel pump setting plate nuts in the specified sequence as shown.
- 5 Make sure that the outer packing tab can see in the setting plate hole.
- Fuel pump malfunction and inspection

Basic



#### **FUEL FILTER**



· Fuel clog or excessively damaged

- If the fuel filter is clogged, replace it with a new one.
- To prevent dirt and debris from entering the fuel pump unit, always clean it before disassembly. Clean the fuel pump unit and fuel pump filter with clean gasoline. Never use commercially available carburetor cleaners.
  - •
  - Fuel pump motor wires (Y and G wire)
     Release the hooks from the stoppers by slightly spreading the hooks. • Fuel pump case remover: 070MF-KVS0300
- Before installing the fuel pump filter, check the fuel pump unit for dirt. If necessary, clean the fuel pump unit with compressed air. Do not blow into the fuel pump unit.
- If the R or BI wire connector is disconnected, replace the fuel level sensor with a new one.
- 1 Make sure the "CLICK" and install the four tabs securely when the fuel pump unit is assembled.
- $\boxed{2}$  Connect the fuel pump motor wires to the specified angle.
- 3 Route the fuel pump motor wires and fuel level sensor wires to the guide and terminals properly. •





Fuel tank cover →3-9
Quick connect fitting (fuel pump side) →2-2



- A pressure release can be heard when opening the fuel filler cap, but this is not blockage of the passage. If checking for clog in the passage of the fuel tank side is necessary, apply air pressure to the breather hose end with the fuel filler cap opened.
- If remove the fuel filler cap, replace the breather seal with a new one.



# AIR CLEANER







- Air cleaner →2-7
  Quick connect fitting (injector side) →2-2



• TP sensor reset procedure →2-10

Throttle body cleaning and inspection

**FUEL & ENGINE** 



- The throttle body is factory pre-set. Do not disassemble in a way other than shown in this manual.
- Do not loosen or tighten the white painted fasteners. Loosening or tightening it can cause throttle body malfunction. ٠
- Do not hold the throttle drum when installing the sensor unit.

#### Sensor unit

Throttle body →2-8

Fuel tank lifting →4-52



1 Install the sensor unit to the throttle body by aligning the clip of the sensor unit and boss of the throttle valve.

Perform the TP sensor reset procedure.  $\rightarrow$  2-10

IACV



•

- 2 Install the IACV by aligning its slide valve slot with the pin in the throttle body.
   3 Install the set plate by aligning its slot with the IACV tab.



FUEL & ENGINE

#### **TP SENSOR RESET PROCEDURE**





# INJECTOR





• Quick connect fitting (injector side) →2-2

• 1 Install the set plate by aligning its slot with the IACV tab.



## SECONDARY AIR SUPPLY SYSTEM





Basic

PAIR control solenoid valve inspection



- Battery box →4-53
  Right radiator cover →3-8
- PAIR check valve inspection

Basic



# **EVAP SYSTEM**





## SYSTEM DIAGRAM



#### ENGINE OIL LEVEL CHECK



- Place the vehicle on the level ground with its sidestand.
- Let it idle for 3 5 minutes.
- Wait for 2 3 minutes.
- Support the motorcycle in an upright position on a level surface.
- If the level is below the lower level line, remove the oil filler cap and fill the crankcase with the recommended engine oil up to the upper level line.
- Check that the O-ring on the filler cap is in good condition, replace it if necessary.
- RECOMMENDED ENGINE OIL:

Honda "4-stroke motorcycle oil" or an equivalent motor oil.

API service classification: SG or higher JASO T903 standard: MA Viscosity: SAE 10W-30

#### **ENGINE OIL CHANGE**



- Drain oil completely.
- Fill the crankcase with the recommended engine oil.
- ENGINE OIL CAPACITY: 1.4 liters after draining 1.5 liters after oil filter change 1.8 liters after disassembly

#### **ENGINE OIL FILTER CHANGE**





1 Install the oil filter with the "OUT-SIDE" mark facing out. Installing the oil filter backwards will result in severe engine damage.





# ENGINE OIL STRAINER SCREEN/OIL PUMP





Right crankcase cover →2-30

Oil pump inspection

# **COOLING SYSTEM** SYSTEM DIAGRAM



#### **COOLANT REPLACEMENT**

Coolant drain



· Cooling system testing and inspection



#### Air bleeding/Adding



- Radiator cover →3-8
- Fill the system with the coolant through the filler opening to the filler neck.

RECOMMENDED ANTIFREEZE: TH model: Honda PRE-MIX Coolant KO, U model: High quality ethylene glycol antifreeze containing silicatefree corrosion inhibitors

- Start the engine and let it idle for 2 3 minutes.
- Snap the throttle three or four times to bleed air from the system.
- Stop the engine and add coolant up to the filler neck.
- Reinstall the radiator cap.
- Radiator reserve tank cap.

6

If the coolant level is below or near the lower level, add the recommended coolant to the upper level line.



#### **RADIATOR/COOLING FAN**



Radiator cover →3-8









# **RADIATOR RESERVE TANK**







## WATER PUMP/THERMOSTAT/WATER PIPE









Coolant →2-17

Thermostat inspection

# FUEL & ENGINE







Coolant →2-17



#### CYLINDER HEAD VALVE CLEARANCE

INSPECTION



- Inspect while the engine is cold (below 35°C).
- After the valve clearance inspection, check the engine idle speed.
- Cylinder head cover →2-24
- Timing hole cap/O-ring, crankshaft hole cap/O-ring Timing cap wrench: 07709-0010001

• Rotate the crankshaft counterclockwise and align the "T" mark on the flywheel with the index notch on the left crank-case cover.

- The index lines on the cam sprockets must be flush with the cylinder head surface.
- Make sure the piston is at TDC (Top Dead Center) on the compression stroke.

Valve clearance (Insert a feeler gauge between the rocker arm and shim). IN: 0.16 ± 0.03 mm, EX: 0.27 ± 0.03 mm

**FUEL & ENGINE** 

#### ADJUSTMENT



- Rotate the camshafts by rotating the crankshaft counterclockwise several times.
- Recheck the valve clearance  $\rightarrow$  2-22





- Remove the radiator mounting bolt, shift the radiator forward. →2-12
- Battery box →4-53
- Radiator reserve tank →2-19
  - 1 Apply sealant (Three bond 5211C or 1207B or 1215 or Shin-Etsu Silicone KE45 or equivalent) to the cylinder head cover gasket semicircular corner.

#### **CAMSHAFT/ROCKER ARM**



- Cylinder head cover →2-24
- Set the piston to the TDC (Top Dead Center) on the compression stroke →2-22
- Install the special tool into the tensioner body and turn the tool clockwise until it stops. Hold the tensioner lifter by pushing the tool while aligning the tabs of the tool with the grooves of the tensioner lifter.

Cam chain tensioner lifter stopper: 070MG-0010100







Basic

1 Install each camshaft, rocker arm, camshaft holder and cam chain guide B to the correct position with the identification mark.

Camshaft inspection Camshaft oil clearance inspection





- Engine →2-40
  Camshaft →2-24
  - 1 Loosen the cylinder head nuts in a crisscross pattern in two or three steps.

• 1 Install the cam chain guide while aligning its pins with the grooves on the cylinder head and its end with the groove on the left crankcase.









#### **CAM CHAIN TENSIONER**



• Install the special tool into the tensioner body and turn the tool clockwise until it stops. Hold the tensioner lifter by pushing the tool while aligning the tabs of the tool with the grooves of the tensioner lifter.

Cam chain tensioner lifter stopper: 070MG-0010100

- Check the cam chain tensioner lifter operation:
- The tensioner shaft should not go into the body when it is pushed.
- When it is turned clockwise with the tensioner stopper, the tensioner shaft should be pulled into the body. The shaft should protrude from the body as soon as the tensioner stopper is released.



### **CYLINDER/PISTON**



- Piston and piston rings inspection
- Basic Cylinder inspection •



### **CLUTCH/GEARSHIFT LINKAGE**





- Gearshift pedal →3-10
- Water pipe →2-20
- Under cowl  $\rightarrow$  3-7
- 1 Loosen the clutch center lock nut.
- Clutch center holder: 07724-0050002
  Phold the flywheel and loosen the primary drive gear lock nut. Gear holder, M1.5: 07724-0010200



• 1 The mainshaft and clutch outer guide has ID color paint mark. When the clutch outer assembly is replaced, be sure to selecting same color codes of the mainshaft and clutch outer guide.





CLUTCH LIFTER ARM NEEDLE BEARING:
 [A] Pilot collar, 16 mm: 07PAF-0010620
 [B] Bearing remover head, 10 mm: 07746-0050200







# **ALTERNATOR/STARTER CLUTCH**

• This service can be serviced with the engine installed in the frame.



- 2 Flywheel
  - Flywheel puller: 07733-0020001



• 1 Clean any oil and grease from crankshaft and flywheel contact area.







# **CRANKCASE/CRANKSHAFT/BALANCER**





- Engine →2-40
- Cylinder/piston →2-29
- Clutch/gearshift linkage →2-30 •
- Alternator/starter clutch  $\rightarrow$  2-33 Oil pump  $\rightarrow$  2-16 VS sensor  $\rightarrow$  4-59

- Neutral switch →4-33 • Starter motor →4-32
- Remove the crankcase bolts in a crisscross pattern in 2 3 steps.
- Place the crankcase with the right crankcase facing down and separate.





- 1 Install the balancer driven sub gear with its "OUT" mark facing out.
  2 Align the holes of the balancer driven and sub gear.



2

Basic

### **CRANKSHAFT RUNOUT INSPECTION**



Set the crankshaft on V-blocks and measure the runout using a dial indicator. Limit: (L) 0.02 mm/(R) 0.03 mm

### MAIN JOURNAL BEARING SELECTION



- Record the bearing support I.D. code letter [1].
  Letters A, B or C on each crankcase is the code for the crankcase main journal bearing support I.D.

BEARING SUPPORT		MAIN JOURNAL O.D.	
I.D. CODE (Crankcase replaced)	BEARING SUPPORT I.D.	33.985 – 34.000 mm (Crankshaft replaced)	33.975 – 33.985 mm
A	38.000 – 38.006 mm	C (Brown) 1.996 – 1.999 mm	B (Black) 1.999 – 2.002 mm
В	38.006 – 38.012 mm	B (Black) 1.999 – 2.002 mm	A (Blue) 2.002 – 2.005 mm
С	38.012 – 38.018 mm	A (Blue) 2.002 – 2.005 mm	O.S. G (Pink) 2.005 – 2.008 mm
-	38.018 – 38.024 mm	O.S. G (Pink) 2.005 – 2.008 mm	O.S. F (Yellow) 2.008 – 2.011 mm
_	38.024 – 38.030 mm	O.S. F (Yellow) 2.008 – 2.011 mm	O.S. E (Green) 2.011 – 2.014 mm
_	38.030 – 38.036 mm	O.S. E (Green) 2.011 – 2.014 mm	O.S. D (Red) 2.014 – 2.017 mm



# BEARING THICKNESS:

O.S. D (Red):	Thick	
O.S. E (Green):	1	
O.S. G (Pink):	ı Middle	
A (Blue):	1	
B (Black):	$\checkmark$	
C (Brown):	Thin	
<ul> <li>After selecting new hearings recher</li> </ul>		

After selecting new bearings, recheck the clearance. Incorrect clearance can cause severe engine damage.



- 1 Install an O.D. 3 mm pin [A] into the hole of the balancer driven gear assembly.
- 2 Insert the gear holder between the balancer drive gear and balancer driven gear assembly. Gear holder, M2.5: 07724-0010100



- 1 Set the bearings and special tools assembly on inside of the crankcase, fitting the bearing edge in the crankcase main journal. Align the mating line of the bearings with the index mark on the crankcase as shown. Metal installer set: 070MF-KYJ0100
- 2 Apply sealant (Three bond 1207B, 1215 or equivalent) to the left crankcase mating surface except the oil passage area.
- 3 Install an O.D. 3 mm pin [A] into the hole of the balancer driven gear assembly. Install the balancer drive gear with its "OUT" mark [B] facing out. Align the punch marks [C] of the balancer drive gear and balancer driven gear.
- 4 Each shift fork has an identification mark.
- Crankshaft inspection
- Connecting rod inspection
  - Shift fork/shift drum/drum journal inspection



# TRANSMISSION

#### MAINSHAFT





#### COUNTERSHAFT








- Coolant →2-17
  Throttle body →2-8
  Exhaust pipe/muffler →3-15
- Drive sprocket cover →3-10
- 1 Loosely install all the engine fastener of [1] to [4], then tighten them with the specified torque in order of [1] to [4].

## **3. FRAME & CHASSIS**

BODY PANELS ······	3-2
SIDESTAND ······3	-14
EXHAUST PIPE/MUFFLER·······3	-15
FRONT WHEEL ······3	-16
FORK3	-18
HANDLEBAR ·······3	-21

STEERING STEM ·······3-2	23
REAR WHEEL ······3-2	25
REAR SUSPENSION ······3-2	27
FRONT BRAKE······3-2	28
REAR BRAKE ······3-3	31





### **BODY PANELS**



# **6** &

### FRONT FENDER





Front wheel →3-16

### **REARVIEW MIRROR**





### SINGLE SEAT



### **PILLION SEAT**





# 6

### **REAR FENDER A**





Pillion seat → 3-4





### **PILLION STEP**





• Exhaust pipe/muffler →3-15

### **BRAKE PEDAL**



٢

## UNDER COWL







### RADIATOR COVER



٢

### FUEL TANK COVER









### DRIVE SPROCKET COVER



Fuel tank cover →3-9

### **GEARSHIFT PEDAL**



٢

### DRIVE CHAIN CASE







Rear fender A → 3-5
 Rear cowl → 3-13

3-12

## **REAR COWL**



### SEAT LOCK















Under cowl →3-7
Drive sprocket cover →3-10







- Drive in a new right bearing [A] squarely with its marked side facing outside until it is fully seated.
- Drive in a new right bearing
   Install the distance collar.
  - Drive in a new left bearing [B] squarely with its marked side facing outside until it is fully seated on the distance collar.

Attachment, 42 x 47 mm: 07746-0010300 Pilot 15 mm: 07746-0040300 Driver: 07749-0010000 Wheel disassembly and inspection

Basic





- Front fender →3-3
  Front brake caliper →3-29
  - 1 Install the front fork so that the end of the outer pipe is aligned with the top bridge upper surface.



#### **RIGHT SIDE:**







#### • Fork cap: Fork cap

- Fork cap wrench: 070MA-MGP0100
- 1 Drive in the oil seal into the outer tube using the special tool. Fork seal driver, 43.2 mm: 07YMD-MCF0100
- 2 Pour the specified amount of recommended fork fluid into the fork pipe. **RECOMMENDED FORK FLUID: Honda Ultra Cushion Oil 10W or equivalent FORK FLUID CAPACITY: 425 ± 2.5 cm<sup>3</sup>**
- Compress the fork leg fully and measure the fluid level from the top of the outer tube. FORK FLUID LEVEL: 111 mm
- 3 Install the fork spring with its tightly wound coil side facing down.
- 4 Attach the special tool to the spring collar holes. Compress the spring collar with the spring collar holder. Damper rod holder: 070MF-MBZC120 Spring collar holder: 070MF-MBZC110
- Insert the special tool between the lock nut and spring collar.
   Stopper plate: 070MF-MBZC130
- Hold the fully seated fork rod nut [A] and tighten the fork cap [B]. Fork cap wrench: 070MA-MGP0100
- Fork disassembly and inspection

Basic





Front brake master cylinder →3-28

Install the holder with the "UP" mark facing up. Align the edge of the lever bracket with the punch mark.
2 Align the upper surface of the lower handlebar holder with the punch mark on the handlebar. Tighten the forward bolts first, then the rear bolts.



## HANDLEBAR WEIGHT





### **STEERING STEM**

TOP BRIDGE



FRAME & CHASSIS

#### **BOTTOM BRIDGE**



- 2 Turn the steering stem lock-to-lock five times to seat the bearing. Completely loosen the adjusting nut, and then tighten the adjusting nut to the specified torque.
   TORQUE: 29 N·m
- 3 Install the top thread until it is seated to the lock washer tabs lightly. Further tighten the top thread within 90° enough to align its grooves with the lock washer tabs. Bend the lock washer tabs up into the lock nut grooves. Then, make sure the steering stem is smooth movement by turning the steering stem again.
- Steering disassembly/assembly and inspection

# **T**

### **REAR WHEEL**





Wheel inspection





#### **REAR WHEEL**



 Install the bearing remover head into the bearing. From the opposite side, install the bearing remover shaft and drive out the bearing from the wheel hub.
 Remover head, 17 mm: 07746-0050500



 Drive in a new right bearing [A] squarely with its marked side facing outside until it is fully seated. Attachment, 42 x 47 mm: 07746-0010300 Pilot 17 mm: 07746-0040400 Driver: 07749-0010000

- Install the distance collar.
- Drive in a new left bearing [B] squarely with its marked side facing outside until it is fully seated on the distance collar.

Attachment, 37 x 40 mm: 07746-0010200 Pilot 17 mm: 07746-0040400 Driver: 07749-0010000 Wheel disassembly and inspection

Bearing remover shaft: 07746-0050100



ic





Drive in a new bearing [C] squarely.
 Attachment, 42 x 47 mm: 07746-0010300
 Pilot 20 mm: 07746-0040500
 Driver: 07749-0010000

### **REAR SUSPENSION**



<sup>• 3</sup> Place the vehicle on the ground. Compressing the rear end several times, then tighten the shock absorber nuts to the specified torque.



### FRONT BRAKE BRAKE FLUID REPLACEMENT



• Add the reservoir with brake fluid from a sealed container to the set line. RECOMMENDED BRAKE FLUID: DOT 3 or 4 brake fluid

### **BRAKE MASTER CYLINDER**



• Rearview mirror →3-3

• 1 Install the holder with the "UP" mark facing up. Align the edge of the master cylinder with the punch mark.







Master cylinder inspection

### **BRAKE CALIPER**

Basic

#### BRAKE PAD REPLACEMENT





•

1 Install the pad spring with the arrow mark facing up. 2 Make sure that the collars are installed into the caliper bracket properly.







## REAR BRAKE BRAKE MASTER CYLINDER





3-31



### BRAKE CALIPER

BRAKE PAD REPLACEMENT





• Rear wheel → 3-25





Brake caliper inspection

• <a>[1] Apply Honda Bond A or equivalent to the retainer seating surface.</a>

MEMO

# **4. ELECTRICAL SYSTEM**

PGM-FI SYSTEM ······ 4-2
IGNITION SYSTEM ······4-27
ELECTRICAL STARTER ······4-30
ABS4-34

BATTERY/CHARGING SYSTEM ······· 4-51
LIGHTING SYSTEM ······ 4-54
COMBINATION METER 4-57
ELECTRICAL COMPONENT ·······4-61




### **PGM-FI SYSTEM**



- Refer to "Basic Shop manual" for the following information.
   PGM-FI technical feature and each sensor function.

  - Symptom troubleshooting for the PGM-FI system.
     MCS (Motorcycle Communication System) information.

### **DTC CODE INDEX**

1.1       MAP sensor malfunction       • Engine operates normally       \$44-5\$         1.2       MAP sensor malfunction       • Engine operates normally       \$44-6\$         7.1       ECT sensor malfunction       • Hard start at a low temperature       \$44-7\$         7.2       ECT sensor malfunction       • Hard start at a low temperature       \$44-8\$         8.1       TP sensor malfunction       • Poor engine acceleration       \$44-9\$         8.2.       TP sensor low voltage       • Poor engine acceleration       \$44-9\$         8.2.       TP sensor low voltage       • Engine operates normally       \$44-10\$         9.1       IAT sensor malfunction       • Poor engine acceleration       \$44-9\$         9.2       IAT sensor malfunction       • Engine operates normally       \$44-10\$         9.1       IAT sensor malfunction       • Engine operates normally       \$44-11\$         9.2       IAT sensor malfunction       • Engine operates normally       \$44-12\$         11-1       VS sensor malfunction       • Engine operates normally       \$44-14\$         11-2       Injector malfunction       • Engine operates normally       \$44-14\$         21-1       Os sensor malfunction       • Engine operates normally       \$44-14\$         21-1       Os sensor malfun	DTC	Function Failure	Symptom/Fail-safe function	Page	
11       • MAP sensor low voltage       • Engine operates normally       • 44-6         1-2       • MAP sensor malfunction       • Engine operates normally       • 44-6         7-1       • ECT sensor indifunction       • Hard start at a low temperature       • 44-7         7-2       • ECT sensor indifunction       • Hard start at a low temperature       • 44-7         7-2       • ECT sensor indifunction       • Hard start at a low temperature       • 44-8         8-1       TP sensor malfunction       • Poor engine acceleration       • 44-9         8-2       TP sensor malfunction       • Poor engine acceleration       • 44-9         9-1       • IAT sensor malfunction       • Engine operates normally       • 44-10         9-2       • IAT sensor malfunction       • Engine operates normally       • 44-11         9-2       • IAT sensor malfunction       • Engine operates normally       • 44-12         11-1       VS sensor malfunction       • Engine operates normally       • 44-13         12-1       Injector malfunction       • Engine operates normally       • 44-14         11-1       VS sensor malfunction       • Engine operates normally       • 44-14         12-1       Ioc sensor malfunction       • Engine operates normally       • 4-15         21-2	1 1	MAP sensor malfunction	<ul> <li>Engine operates normally</li> </ul>	<b>→</b> 1 5	
1.2       MAP sensor malfunction       • Engine operates normally       \$4.6         7.1       ECT sensor malfunction       • Hard start at a low temperature       \$4.7         7.2       ECT sensor malfunction       • Hard start at a low temperature       \$4.8         8.1       TP sensor malfunction       • Hard start at a low temperature       \$4.9         8.2       TP sensor malfunction       • Poor engine acceleration       \$4.9         9.1       IAT sensor malfunction       • Engine operates normally       \$4.10         9.2       IAT sensor malfunction       • Engine operates normally       \$4.11         9.2       IAT sensor malfunction       • Engine operates normally       \$4.12         11.1       VS sensor malfunction       • Engine operates normally       \$4.12         11.1       VS sensor malfunction       • Engine operates normally       \$4.13         12.1       Injector malfunction       • Engine operates normally       \$4.14         21.1       VS sensor malfunction       • Engine operates normally       \$4.13         21.1       Oz sensor induction       • Engine operates normally       \$4.14         21.1       Oz sensor high voltage       • Engine operates normally       \$4.15         21.2       Oz sensor inalfunction <td< td=""><td>1-1</td><td><ul> <li>MAP sensor low voltage</li> </ul></td><td></td><td>74-3</td></td<>	1-1	<ul> <li>MAP sensor low voltage</li> </ul>		74-3	
112       • MAP sensor high voltage       • Hard start at a low temperature       • 44.7         7.1       • ECT sensor malfunction       • Hard start at a low temperature       • 44.7         7.2       • ECT sensor high voltage       • Hard start at a low temperature       • 44.8         8.1       • TP sensor malfunction       • Hard start at a low temperature       • 44.8         8.1       • TP sensor malfunction       • Poor engine acceleration       • 44.9         8.2       TP sensor malfunction       • Poor engine acceleration       • 44.9         9.1       AT sensor malfunction       • Engine operates normally       • 44.10         9.1       IAT sensor malfunction       • Engine operates normally       • 44.12         11.1       VS sensor malfunction       • Engine operates normally       • 44.12         11.1       VS sensor malfunction       • Engine operates normally       • 44.14         11.1       VS sensor malfunction       • Engine operates normally       • 44.14         11.1       VS sensor indip voltage       • Engine operates normally       • 44.14         11.1       VS sensor indip voltage       • Engine operates normally       • 44.14         11.1       VS sensor indip voltage       • Engine operates normally       • 44.14         12.2<	1-2	MAP sensor malfunction	<ul> <li>Engine operates normally</li> </ul>	→1-6	
7.1       ECT sensor malfunction       • Hard start at a low temperature       \$4.7         7.2       ECT sensor malfunction       • Hard start at a low temperature       \$4.8         8.1       TP sensor malfunction       • Poor engine acceleration       \$4.9         8.1       TP sensor malfunction       • Poor engine acceleration       \$4.9         8.2       TP sensor malfunction       • Poor engine acceleration       \$4.10         9.1       IAT sensor malfunction       • Engine operates normally       \$4.11         9.2       IAT sensor malfunction       • Engine operates normally       \$4.12         11-1       VS sensor malfunction       • Engine operates normally       \$4.12         11-1       VS sensor malfunction       • Engine operates normally       \$4.12         11-1       VS sensor malfunction       • Engine operates normally       \$4.12         11-1       VS sensor malfunction       • Engine operates normally       \$4.13         12-1       Injector malfunction       • Engine operates normally       \$4.14         21-1       O: sensor malfunction       • Engine operates normally       \$4.13         21-2       O: sensor ligh voltage       • Engine operates normally       \$4.16         23-1       O: sensor inghy voltage       • E		<ul> <li>MAP sensor high voltage</li> </ul>		<b>7</b> <del>-</del> -0	
1       • ECT sensor naffunction       • Hard start at a low temperature       \$4.8         7-2       • ECT sensor malfunction       • Poor engine acceleration       \$4.9         8.1       • TP sensor malfunction       • Poor engine acceleration       \$4.9         8.2       TP sensor malfunction       • Poor engine acceleration       \$4.10         9.1       IAT sensor malfunction       • Poor engine acceleration       \$4.10         9.1       IAT sensor malfunction       • Engine operates normally       \$4.11         9.2       • IAT sensor malfunction       • Engine operates normally       \$4.12         11-1       VS sensor malfunction       • Engine operates normally       \$4.12         11-1       VS sensor malfunction       • Engine operates normally       \$4.12         11-1       VS sensor malfunction       • Engine operates normally       \$4.13         12-1       Injector fuel pump and ignition coil shut down       \$4.14         21-1       O2 sensor malfunction       • Engine operates normally       \$4.14         21-2       O2 sensor high voltage       • Engine operates normally       \$4.15         21-2       O2 sensor high voltage       • Engine operates normally       \$4.16         23-1       O2 sensor malfunction       • Engine operates n	7_1	ECT sensor malfunction	<ul> <li>Hard start at a low temperature</li> </ul>	→4-7	
7-2       ECT sensor malfunction       • Hard start at a low temperature       >4-8         8-1       TP sensor migh voltage       • Poor engine acceleration       >4-9         8-1       TP sensor malfunction       • Poor engine acceleration       >4-9         8-2       TP sensor malfunction       • Poor engine acceleration       >4-10         9-1       IAT sensor malfunction       • Engine operates normally       >4-11         9-2       IAT sensor malfunction       • Engine operates normally       >4-12         11-1       VS sensor malfunction       • Engine operates normally       >4-13         12-1       Injector malfunction       • Engine operates normally       >4-14         21-1       O2 sensor malfunction       • Engine operates normally       >4-14         21-1       O2 sensor low voltage       • Engine operates normally       >4-14         21-1       O2 sensor low voltage       • Engine operates normally       >4-14         21-2       O2 sensor low voltage       • Engine operates normally       >4-15         21-2       O2 sensor high voltage       • Engine operates normally       >4-16         23-2       O2 sensor high voltage       • Engine operates normally       >4-17         33-2       D2 sensor malfunction       • Engine		ECT sensor low voltage			
1       • ECT sensor high voltage       • Poor engine acceleration       • 4.9         8-1       • TP sensor malfunction       • Poor engine acceleration       • 4.9         8-2       • TP sensor malfunction       • Poor engine acceleration       • 4.10         9-1       IAT sensor malfunction       • Engine operates normally       • 4-11         9-2       IAT sensor high voltage       • Engine operates normally       • 4-12         11-1       VS sensor malfunction       • Engine operates normally       • 4-13         9-2       IAT sensor high voltage       • Engine operates normally       • 4-12         11-1       VS sensor malfunction       • Engine operates normally       • 4-13         12-1       Injector malfunction       • Engine operates normally       • 4-14         21-1       O <sub>2</sub> sensor malfunction       • Engine operates normally       • 4-14         21-1       O <sub>2</sub> sensor high voltage       • Engine operates normally       • 4-15         21-2       O <sub>2</sub> sensor high voltage       • Engine operates normally       • 4-16         23-1       O <sub>2</sub> sensor high voltage       • Engine operates normally       • 4-17         29-1       IACV malfunction       • Engine stalls, hard to start, rough idling       • 4-17         29-1       Bank angl	7-2	ECT sensor malfunction	<ul> <li>Hard start at a low temperature</li> </ul>	→4-8	
8-1       TP sensor malfunction • TP sensor moltunction • TP sensor malfunction • TP sensor malfunction • TP sensor malfunction • TP sensor malfunction • TAT sensor malfunction • IAT sensor malfunction • Injector malfunction • D2 sensor malfunction • O2 sensor neater malfunction • O2 sensor neater malfunction • D2 sensor malfunction • D3 sensor malfunction • D3 sensor malfunction • Engine operates normally • 4-16       • 4-14         21-1       O2 sensor malfunction • O2 sensor malfunction • O2 sensor malfunction • D3 sensor malfunction • Engine operates normally • 4-16       • 4-19         33-2       O2 sensor malfunction • Bank angle sensor malfunction • Engine operates normally • A-21       • 4-20         54-1       Bank angle sensor malfunction • Bank angle sensor malfunction • Bank angle sensor high voltage • Engine operates normally • Loose or poor contact of the EVAP purge control solenoid valve connector • EVAP purge control solenoid valve or its cir- cuit malfunction • Engine operates normally • Engine operates normally • Engine operat		ECT sensor high voltage		210	
* 1P sensor low voltage       * Poor engine acceleration       * 4-10         8-2       TP sensor malfunction       * Engine operates normally       * 4-11         9-1       IAT sensor malfunction       * Engine operates normally       * 4-12         9-2       IAT sensor malfunction       * Engine operates normally       * 4-12         11-1       VS sensor malfunction       * Engine operates normally       * 4-13         12-1       Injector malfunction       * Engine operates normally       * 4-14         21-1       VS sensor malfunction       * Engine operates normally       * 4-13         12-1       Injector malfunction       * Engine operates normally       * 4-14         21-1       O2 sensor malfunction       * Engine operates normally       * 4-15         21-2       O2 sensor malfunction       * Engine operates normally       * 4-16         21-2       O2 sensor heater malfunction       * Engine operates normally       * 4-17         29-1       IACV malfunction       * Engine operates normally       * 4-18         21-2       O2 sensor heater malfunction       * Engine operates normally       * 4-19         33-2       Does not hold the self diagnosis data       * 00es not hold the self diagnosis data       * 4-19         54-1       Bank angle sensor	8-1	TP sensor malfunction	<ul> <li>Poor engine acceleration</li> </ul>	<b>→</b> 4-9	
8-2       TP sensor malfunction       • Poor engine acceleration       \$4-10         9-1       IAT sensor malfunction       • Engine operates normally       \$4-11         9-2       IAT sensor malfunction       • Engine operates normally       \$4-12         11-1       VS sensor malfunction       • Engine operates normally       \$4-13         12-1       Injector malfunction       • Engine operates normally       \$4-14         21-1       O2 sensor malfunction       • Engine operates normally       \$4-14         21-1       O2 sensor malfunction       • Engine operates normally       \$4-14         21-1       O2 sensor malfunction       • Engine operates normally       \$4-15         21-2       O2 sensor low voltage       • Engine operates normally       \$4-16         23-1       O2 sensor high voltage       • Engine operates normally       \$4-16         23-1       O2 sensor high voltage       • Engine operates normally       \$4-16         23-1       O2 sensor high voltage       • Engine operates normally       \$4-16         33-2       D2 sensor malfunction       • Engine operates normally       \$4-18         33-2       ECM EEPROM malfunction       • Engine operates normally       \$4-19         54-1       Bank angle sensor malfunction       •	• •	TP sensor low voltage			
9-1       IAT sensor malfunction       • Engine operates normally       ≠4-11         9-2       IAT sensor malfunction       • Engine operates normally       ≠4-12         11-1       VS sensor malfunction       • Engine operates normally       ≠4-13         12-1       Injector malfunction       • Engine operates normally       ≠4-14         21-1       VS sensor malfunction       • Engine operates normally       ≠4-13         12-1       Injector malfunction       • Engine operates normally       ≠4-14         21-1       VS sensor malfunction       • Engine operates normally       ≠4-14         21-1       O <sub>2</sub> sensor malfunction       • Engine operates normally       ≠4-15         21-2       O <sub>2</sub> sensor low voltage       • Engine operates normally       ≠4-16         23-1       O <sub>2</sub> sensor high voltage       • Engine operates normally       ≠4-16         23-1       O <sub>2</sub> sensor high voltage       • Engine operates normally       ≠4-16         23-1       O <sub>2</sub> sensor high voltage       • Engine operates normally       ≠4-16         23-1       O <sub>2</sub> sensor high voltage       • Engine operates normally       ≠4-17         33-2       IACV malfunction       • Engine operates normally       ≠4-18         54-1       Bank angle sensor malfunction	8-2	TP sensor malfunction	<ul> <li>Poor engine acceleration</li> </ul>	<b>→</b> 4-10	
9-1IAT sensor malfunction • IAT sensor low voltage• Engine operates normally>4-119-2IAT sensor malfunction • IAT sensor high voltage• Engine operates normally>4-1211-1VS sensor malfunction • Igetor malfunction• Engine operates normally • Engine does not start • Injector, fuel pump and ignition coil shut down • A-14>4-1312-1Injector malfunction • O2 sensor malfunction • O2 sensor low voltage• Engine operates normally • Engine operates normally>4-1421-2O2 sensor malfunction • O2 sensor high voltage• Engine operates normally • Engine operates normally>4-1621-2O2 sensor high voltage • O2 sensor high voltage• Engine operates normally • Engine operates normally>4-1623-1O2 sensor heater malfunction • Engine operates normally • O2 sensor heater malfunction • Engine stalls, hard to start, rough idling • Does not hold the self diagnosis data • Does not erase the self diagnosis data • Does not erase the self diagnosis data with SCS connector>4-1933-2• Bank angle sensor malfunction • Bank angle sensor high voltage • Bank angle sensor high voltage • Engine operates normally • A-20>4-2054-1Bank angle sensor high voltage • Bank angle sensor high voltage • Bank angle sensor high voltage • Engine operates normally • Loose or poor contact of the EVAP purge control solenoid valve or its cir- cuit malfunction • EvAP purge control solenoid valve or its cir- cuit malfunction • Engine operates normally+4-23 </td <td></td> <td>IP sensor high voltage</td> <td></td> <td></td>		IP sensor high voltage			
9-2       IAT sensor ion woitage       +4-12         9-2       IAT sensor malfunction       + Engine operates normally       +4-12         11-1       VS sensor malfunction       + Engine operates normally       +4-13         12-1       Injector malfunction       + Engine operates normally       +4-14         21-1       O2 sensor malfunction       + Engine operates normally       +4-15         21-2       O2 sensor malfunction       + Engine operates normally       +4-16         21-2       O2 sensor malfunction       + Engine operates normally       +4-16         23-1       O2 sensor malfunction       + Engine operates normally       +4-16         23-1       O2 sensor high voltage       + Engine operates normally       +4-16         23-1       O2 sensor high voltage       + Engine operates normally       +4-17         29-1       IACV malfunction       + Engine operates normally       +4-18         3-2       D2 sensor malfunction       + Engine operates normally       +4-19         33-2       Bank angle sensor malfunction       + Engine operates normally       +4-20         54-1       Bank angle sensor malfunction       + Engine operates normally       +4-20         54-2       Bank angle sensor malfunction       + Engine operates normally	9-1	IAT sensor malfunction	<ul> <li>Engine operates normally</li> </ul>	→4-11	
9-2       IAT sensor malfunction       • Engine operates normally       →4-12         11-1       VS sensor malfunction       • Engine operates normally       →4-13         12-1       Injector malfunction       • Engine operates normally       →4-14         21-1       O2 sensor malfunction       • Engine operates normally       →4-14         21-1       O2 sensor malfunction       • Engine operates normally       →4-14         21-1       O2 sensor low voltage       • Engine operates normally       →4-14         21-2       O2 sensor low voltage       • Engine operates normally       →4-16         23-1       O2 sensor heater malfunction       • Engine operates normally       →4-16         23-1       O2 sensor heater malfunction       • Engine operates normally       →4-16         33-2       IACV malfunction       • Engine stalls, hard to start, rough idling       →4-18         33-2       ECM EEPROM malfunction       • Engine operates normally       →4-19         54-1       Bank angle sensor malfunction       • Engine operates normally       →4-19         54-2       Bank angle sensor malfunction       • Engine operates normally       • Engine operates normally       →4-20         54-1       Bank angle sensor malfunction       • Engine operates normally       • Engine operate	· ·	IAI sensor low voltage			
11-1       VS sensor malfunction       • Engine operates normally       →4-13         12-1       Injector malfunction       • Engine does not start       • Injector, fuel pump and ignition coil shut down         21-1       Oz sensor malfunction       • Engine operates normally       →4-14         21-1       Oz sensor malfunction       • Engine operates normally       →4-15         21-2       Oz sensor low voltage       • Engine operates normally       →4-16         23-1       Oz sensor heater malfunction       • Engine operates normally       →4-16         23-1       Oz sensor heater malfunction       • Engine operates normally       →4-16         33-2       IACV malfunction       • Engine stalls, hard to start, rough idling       →4-18         8-1       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-19         33-2       • Does not hold the self diagnosis data       →4-19         54-1       Bank angle sensor malfunction       • Engine operates normally       →4-20         54-2       Bank angle sensor high voltage       • Engine operates normally       →4-21         54-2       Bank angle sensor high voltage       • Engine operates normally       • Engine operates normally       • 4-21         6       • Dose or poor contact of the EVAP purge control solenoid val	9-2	IA I sensor malfunction	<ul> <li>Engine operates normally</li> </ul>	→4-12	
11-1       VS sensor malfunction       • Engine operates normally       \$4-13         12-1       Injector malfunction       • Engine does not start       • Injector, fuel pump and ignition coil shut down       \$4-14         21-1       02 sensor malfunction       • Engine operates normally       \$4-15         21-2       02 sensor malfunction       • Engine operates normally       \$4-16         23-1       02 sensor malfunction       • Engine operates normally       \$4-16         23-1       02 sensor heater malfunction       • Engine operates normally       \$4-16         23-1       02 sensor heater malfunction       • Engine operates normally       \$4-16         23-1       02 sensor heater malfunction       • Engine operates normally       \$4-16         33-2       IACV malfunction       • Engine stalls, hard to start, rough idling       \$4-18         33-2       • Engine operates normally       \$4-19         54-1       Bank angle sensor malfunction       • Engine operates normally       \$4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       \$4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       \$4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       \$4-20 <td></td> <td>IAI sensor high voltage</td> <td></td> <td>- · · -</td>		IAI sensor high voltage		- · · -	
12-1Injector malfunction• Engine does not start • Injector, fuel pump and ignition coil shut down→4-1421-1O2 sensor malfunction • O2 sensor low voltage• Engine operates normally→4-1521-2O2 sensor malfunction • O2 sensor high voltage• Engine operates normally→4-1623-1O2 sensor heater malfunction • O2 sensor heater malfunction• Engine operates normally • Engine stalls, hard to start, rough idling • Does not hold the self diagnosis data • Does not hold the self diagnosis data • Does not erase the self diagnosis data • Does not erase the self diagnosis data with • SCS connector→4-1954-1Bank angle sensor malfunction • Bank angle sensor low voltage• Engine operates normally • Engine operates nor	11-1	VS sensor malfunction	Engine operates normally	<b>→</b> 4-13	
21-1       O₂ sensor malfunction • O₂ sensor low voltage       • Engine operates normally       →4-15         21-2       O₂ sensor high voltage       • Engine operates normally       →4-16         23-1       O₂ sensor heater malfunction • O₂ sensor heater malfunction       • Engine operates normally       →4-16         23-1       O₂ sensor heater malfunction       • Engine operates normally       →4-16         23-1       O₂ sensor heater malfunction       • Engine operates normally       →4-17         29-1       IACV malfunction       • Engine stalls, hard to start, rough idling       →4-18         arrows       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-19         33-2       Bank angle sensor malfunction       • Engine operates normally       →4-20         54-1       Bank angle sensor low voltage       • Engine operates normally       →4-20         54-2       Bank angle sensor high voltage       • Engine operates normally       • 4-21         54-3       • Loose or poor contact of the EVAP purge control solenoid valve connector       • Engine operates normally       • 4-22         88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector       • Engine operates normally       • 4-22         89-1       PAIR control solenoid valve malfunction       • Engine operates normally	12-1	Injector malfunction	Engine does not start	→4-14	
21-1       O₂ sensor malfunction       • Engine operates normally       →4-15         21-2       O₂ sensor low voltage       • Engine operates normally       →4-16         21-2       O₂ sensor heater malfunction       • Engine operates normally       →4-16         23-1       O₂ sensor heater malfunction       • Engine operates normally       →4-16         23-1       O₂ sensor heater malfunction       • Engine operates normally       →4-17         29-1       IACV malfunction       • Engine stalls, hard to start, rough idling       →4-18         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-19         33-2       Sensor malfunction       • Engine operates normally       →4-19         54-1       Bank angle sensor malfunction       • Engine operates normally       →4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       • Engine operates normally         54-2       Bank angle sensor high voltage       • Engine operates normally       • 4-20         54-2       Bank angle sensor high voltage       • Engine operates normally       • 4-21         88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector       • Engine operates normally       • 4-22         88-1       • Loose or poor contact of			Injector, fuel pump and ignition coll shut down		
• O2 sensor low Voltage       • Engine operates normally       →4-16         21-2       • O2 sensor high voltage       • Engine operates normally       →4-16         23-1       O2 sensor heater malfunction       • Engine operates normally       →4-17         29-1       IACV malfunction       • Engine operates normally       →4-18         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-19         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-19         33-2       Bank angle sensor malfunction       • Engine operates normally       →4-19         54-1       Bank angle sensor malfunction       • Engine operates normally       →4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       • 4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       • 4-21         54-3       Bank angle sensor high voltage       • Engine operates normally       • 4-21         54-1       Bank angle sensor high voltage       • Engine operates normally       • 4-21         54-2       Bank angle sensor high voltage       • Engine operates normally       • 4-21         88-1       • Loose or poor contact of the EVAP purge control solenoid valve malfunction       • Engi	21-1	O <sub>2</sub> sensor malfunction	<ul> <li>Engine operates normally</li> </ul>	→4-15	
21-2       O2 sensor mainunction          • Engine operates normally           • 4-16          23-1       O2 sensor high voltage          • Engine operates normally           • 4-17          23-1       O2 sensor heater malfunction          • Engine operates normally           • 4-17          23-1       IACV malfunction            • Engine stalls, hard to start, rough idling           • 4-18          33-2            ECM EEPROM malfunction           • Engine operates normally           • 4-18          33-2              ECM EEPROM malfunction           • Engine operates normally            33-2              Eagine stalls, hard to start, rough idling            33-2            Eagine stalls, hard to start, rough idling           Does not hold the self diagnosis data            54-1              Bank angle sensor malfunction              54-2            Bank angle sensor high voltage             Engine operates normally           4-21          88-1		O <sub>2</sub> sensor low voltage		-	
23-1       O2 sensor heater malfunction       • Engine operates normally       →4-17         29-1       IACV malfunction       • Engine stalls, hard to start, rough idling       →4-18         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-18         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-18         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-19         54-1       Bank angle sensor malfunction       • Engine operates normally       →4-20         54-1       Bank angle sensor malfunction       • Engine operates normally       →4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       →4-21         54-2       Bank angle sensor high voltage       • Engine stop function does not operate       →4-21         54-1       • Bank angle sensor high voltage       • Engine operates normally       • Engine operates normally         54-2       Bank angle sensor the EVAP purge control solenoid valve malfunction       • Engine operates normally       • 4-21         88-1       • Loose or poor contact of the EVAP purge control solenoid valve or its circuit malfunction       • Engine operates normally       • 4-22         89-1       PAIR control solenoid valve malfunction <td< td=""><td>21-2</td><td>O<sub>2</sub> sensor malfunction</td><td>Engine operates normally</td><td>→4-16</td></td<>	21-2	O <sub>2</sub> sensor malfunction	Engine operates normally	→4-16	
23-1       O2 sensor neater mainunction       • Engine operates normally       \$\nothermath{\neq}4-17\$         29-1       IACV malfunction       • Engine stalls, hard to start, rough idling       \$\nothermath{\Rightarrow}4-18\$         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       \$\nothermath{\Rightarrow}4-18\$         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       \$\nothermath{\Rightarrow}4-19\$         54-1       Bank angle sensor malfunction       • Engine operates normally       \$\nothermath{\Rightarrow}4-20\$         54-1       Bank angle sensor low voltage       • Engine operates normally       \$\nothermath{\$\nothermath{\$<}4-20\$	00.4	O2 sensor high voltage		2447	
29-1       IACV mainunction       • Engine stalls, nard to start, rough idling       →4-18         33-2       ECM EEPROM malfunction       • Engine stalls, hard to start, rough idling       →4-19         33-2       Does not hold the self diagnosis data       • Does not hold the self diagnosis data       • 4-19         54-1       Bank angle sensor malfunction       • Engine operates normally       • 4-20         54-2       Bank angle sensor malfunction       • Engine stop function does not operate       • 4-21         54-2       Bank angle sensor malfunction       • Engine operates normally       • 4-21         54-1       • Bank angle sensor malfunction       • Engine operates normally       • 4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       • 4-21         88-1       • Loose or poor contact of the EVAP purge control solenoid valve malfunction       • Engine operates normally       • 4-22         88-1       • Loose or poor contact of the EVAP purge control solenoid valve or its circuit malfunction       • Engine operates normally       • 4-23         89-1       PAIR control solenoid valve malfunction       • Engine operates normally       • 4-23         91-1       Ignition coil primary circuit malfunction       • Engine does not start       • 4-24 <td>23-1</td> <td>O<sub>2</sub> sensor neater malfunction</td> <td>Engine operates normally</td> <td>→4-17</td>	23-1	O <sub>2</sub> sensor neater malfunction	Engine operates normally	→4-17	
33-2       ECM EEPROM malfunction          • Engine stalls, hard to start, rougn idling         • Does not hold the self diagnosis data         • Does not hold the self diagnosis data with         SCS connector          54-1       Bank angle sensor malfunction         • Bank angle sensor low voltage           • Engine operates normally         • Loose or poor contact of the EVAP purge         control solenoid valve connector         • EvAP purge control solenoid valve or its circuit malfunction         • Engine operates normally         • A-22         • Engine operates normally         • A-23         • A-23         • Engine operates normally         • A-24         • A-24         • Engine does not start         • Injector and ignition coil shut down         • A-24	29-1		Engine stalls, nard to start, rough idling	→4-18	
33-2       • Does not hold the set diagnosis data • Does not hold the set diagnosis data • Does not erase the self diagnosis data • Does not erase the self diagnosis data • Does not rease the self diagnosis data • Does not nold the set diagnosis data • Does not hold the set diagnosis data • Does not erase the self diagnosis data • Engine operates normally • A-21         88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector • EVAP purge control solenoid valve or its cir- cuit malfunction       • Engine operates normally • Engine operates normally       →4-22         89-1       PAIR control solenoid valve malfunction • Ignition coil primary circuit malfunction • Ignition coil primary circuit malfunction • Ignition coil or its circuit malf		ECM EEPROM malfunction	Engine stalls, hard to start, rough idling		
54-1       Bank angle sensor malfunction       • Engine operates normally       • 4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       • 4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       • 4-21         54-2       Bank angle sensor malfunction       • Engine operates normally       • 4-21         54-2       Bank angle sensor high voltage       • Engine operates normally       • 4-21         88-1       EVAP purge control solenoid valve malfunction       • Engine operates normally       • 4-22         88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector       • Engine operates normally       • 4-22         88-1       • Loose or poor contact of the EVAP purge control solenoid valve or its circuit malfunction       • Engine operates normally       • 4-22         89-1       PAIR control solenoid valve malfunction       • Engine operates normally       • 4-23         91-1       Ignition coil primary circuit malfunction       • Engine does not start       • 4-24	33-2		<ul> <li>Does not noid the self diagnosis data</li> <li>Does not areas the self diagnosis data with</li> </ul>	<b>→</b> 4-19	
54-1       Bank angle sensor malfunction       • Engine operates normally       • 4-20         54-2       Bank angle sensor low voltage       • Engine operates normally       • 4-20         54-2       Bank angle sensor malfunction       • Engine operates normally       • 4-21         54-2       Bank angle sensor high voltage       • Engine operates normally       • 4-21         54-2       Bank angle sensor high voltage       • Engine operates normally       • 4-21         88-1       EVAP purge control solenoid valve malfunction       • Engine operates normally       • 4-22         88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector       • Engine operates normally       • 4-22         88-1       • Loose or poor contact of the EVAP purge control solenoid valve or its circuit malfunction       • Engine operates normally       • 4-22         89-1       PAIR control solenoid valve malfunction       • Engine operates normally       • 4-23         91-1       Ignition coil primary circuit malfunction       • Engine does not start       • 4-24			• Does not erase the sell diagnosis data with	I	
54-1       Bank angle sensor manufaction          • Engine operates normally         • Engine stop function does not operate           • 4-20          54-2       Bank angle sensor malfunction         • Bank angle sensor high voltage           • Engine operates normally           • 4-21          54-2       Bank angle sensor high voltage           • Engine operates normally           • 4-21          54-2       Bank angle sensor high voltage           • Engine operates normally           • 4-21          88-1          • Loose or poor contact of the EVAP purge control solenoid valve connector           • Engine operates normally           • 4-22          88-1          • Loose or poor contact of the EVAP purge control solenoid valve or its circuit malfunction           • Engine operates normally           • 4-22          88-1          • Loose or poor contact of the EVAP purge control solenoid valve or its circuit malfunction           • Engine operates normally           • 4-22          88-1          • Loose or poor contact of the EVAP purge control solenoid valve or its circuit malfunction           • Engine operates normally           • 4-22          89-1          PAIR control solenoid valve malfunction           • Engine does not start           • 4-23		Dept. engle concer molfunction			
54-2       Bank angle sensor malfunction • Bank angle sensor malfunction • Bank angle sensor high voltage       • Engine stop function does not operate         54-2       Bank angle sensor malfunction • Bank angle sensor high voltage       • Engine operates normally • Engine stop function does not operate         88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector • EVAP purge control solenoid valve or its cir- cuit malfunction       • Engine operates normally • Engine operates normally         89-1       PAIR control solenoid valve malfunction • Ignition coil primary circuit malfunction • Ignition coil or its circuit malfunction       • Engine does not start • Injector and ignition coil shut down	54-1	Bank angle sensor manunction	<ul> <li>Engine operates normally</li> <li>Engine step function does not operate</li> </ul>	→4-20	
54-2       Bank angle sensor high voltage <ul> <li>Engine operates normally</li> <li>Engine stop function does not operate</li> <li>EVAP purge control solenoid valve malfunction</li> <li>Loose or poor contact of the EVAP purge control solenoid valve connector</li> <li>EVAP purge control solenoid valve connector</li> <li>EVAP purge control solenoid valve or its circuit malfunction</li> <li>EVAP purge control solenoid valve or its circuit malfunction</li> <li>ENgine operates normally</li> <li>→4-21</li> <li>→4-21</li> <li>Engine operates normally</li> <li>→4-22</li> <li>→4-22</li> <li>→4-23</li> <li>91-1</li> <li>Ignition coil primary circuit malfunction</li> <li>Ignition coil or its circuit malfunction</li> <li>Injector and ignition coil shut down</li> <li>→4-24</li> <li>Injector and ignition coil shut down</li> <li>Injector and ignition coil shut down</li> <li>→4-24</li> <li>Injector and ignition coil shut down</li> <li>→4-24</li> <li>Injector and ignition coil shut down</li> <li>→4-24</li> <li>Injector and ignition coil shut down</li> <li>Injector and ignition coil shut down</li> <li>→4-24</li> <li>Injector and ignition coil shut down</li> <li>Injector and ignition coil shut down</li> <li>→4-24</li> <li>Injector and ignition coil shut d</li></ul>		Dank angle sensor molfunction	Engine stop function does not operate		
88-1       EVAP purge control solenoid valve malfunctor       • Engine stop function does not operate         88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector       • Engine operates normally         • EVAP purge control solenoid valve connector       • Engine operates normally         • EVAP purge control solenoid valve or its circuit malfunction       • Engine operates normally         • Borno operates normally       • 4-22         • Ignition coil primary circuit malfunction       • Engine operates normally         • Ignition coil primary circuit malfunction       • Engine does not start         • Ignition coil or its circuit malfunction       • Engine does not start         • Ignition coil or its circuit malfunction       • Engine does not start	54-2	Bank angle sensor high voltage	<ul> <li>Engine operates normally</li> <li>Engine stop function does not operate</li> </ul>	→4-21	
88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector       • EvAP purge control solenoid valve connector         88-1       • EVAP purge control solenoid valve or its circuit malfunction       • Engine operates normally         91-1       Ignition coil primary circuit malfunction       • Engine does not start         • Ignition coil or its circuit malfunction       • Engine does not start       • A-23		Balik angle sensor night voltage     EVAD purge control colonoid volve molfune	Engine stop function does not operate     Engine operates permelly		
88-1       • Loose or poor contact of the EVAP purge control solenoid valve connector		tion		I	
88-1       A Loose of pool contact of the LVAL purge control solenoid valve connector control solenoid valve connector       →4-22         • EVAP purge control solenoid valve or its circuit malfunction       • Engine operates normally       →4-23         91-1       Ignition coil primary circuit malfunction       • Engine does not start       • Injector and ignition coil shut down		• Loose or poor contact of the EVAP purge			
• EVAP purge control solenoid valve or its circuit malfunction       • Engine operates normally       →4-23         89-1       PAIR control solenoid valve malfunction       • Engine does not start       • Engine does not start         91-1       • Ignition coil or its circuit malfunction       • Engine does not start       • A-24	88-1	control solenoid valve connector		→4-22	
89-1       PAIR control solenoid valve malfunction       • Engine operates normally       →4-23         91-1       • Ignition coil primary circuit malfunction       • Engine does not start       • Injector and ignition coil shut down		FVAP purge control solenoid valve or its cir-		I	
89-1       PAIR control solenoid valve malfunction       • Engine operates normally       →4-23         91-1       Ignition coil primary circuit malfunction       • Engine does not start       • Injector and ignition coil shut down       →4-24		cuit malfunction			
91-1 Ignition coil or its circuit malfunction • Ignition coil or its circuit malfunction • Injector and ignition coil shut down • Injector and ignition coil shut down	89-1	PAIR control solenoid valve malfunction	Engine operates normally	→4-23	
91-1 • Ignition coil or its circuit malfunction • Injector and ignition coil shut down • $-4-24$	00 1	Ignition coil primary circuit malfunction	Engine does not start	→4-24	
	91-1	Ignition coil or its circuit malfunction	<ul> <li>Injector and ignition coil shut down</li> </ul>		

### **PGM-FI SYSTEM LOCATION**





### PGM-FI SYSTEM DIAGRAM



4-4

### DTC TROUBLESHOOTING

DTC 1-1 (MAP SENSOR LOW VOLTAGE)



Fuel tank lifting →4-52

#### MAP Sensor Diagram



Yes ▼

#### 3. MAP Sensor Output Voltage Inspection



- Check a short circuit in Lg/Y wire.
- If there is no short circuit, replace the ECM with a new one →4-25, and recheck.



#### DTC 1-2 (MAP SENSOR HIGH VOLTAGE)



Fuel tank lifting →4-52

#### **MAP Sensor Diagram**



No

#### 1. MAP Sensor System Inspection

- · Check the MAP sensor voltage with MCS. • Is the voltage about 5 V indicated?

Intermittent failure • Loose or poor contact at the connector

Yes ▼

#### 2. MAP Sensor Inspection



- · Install a jumper wire between the terminals. Connection: Lg/Y – G/W
- Check the MAP sensor voltage with MCS.
- Is the voltage about 0 V indicated?

#### No ▼

#### 3. MAP Sensor Output Line Inspection

- Check an open circuit in Lg/Y and G/W wire. · If there is no open circuit, replace the ECM with a new one  $\rightarrow$ 4-25, and recheck.
- Yes · Replace the sensor unit (MAP sensor) with a new one  $\rightarrow$  2-8, and recheck.



#### DTC 7-1 (ECT SENSOR LOW VOLTAGE)



Fuel tank lifting →4-52

#### **ECT Sensor Diagram**



#### 1. ECT Sensor System Inspection

<ul> <li>Check the ECT sensor voltage with MCS.</li> <li>Is the voltage about 0 V indicated?</li> </ul>	<ul><li>Intermittent failure</li><li>Loose or poor contact at the connector</li></ul>
---	---

Yes ▼

2. ECT Sensor Inspection



- Check a short circuit in Y/Bu wire.
- · If there is no short circuit, replace the ECM with a new one  $\rightarrow$ 4-25, and recheck.



#### DTC 7-2 (ECT SENSOR HIGH VOLTAGE)



Fuel tank lifting →4-52

#### **ECT Sensor Diagram**



No

Yes

•

#### **1. ECT Sensor System Inspection**

- Check the ECT sensor voltage with MCS.
- Is the voltage about 5 V indicated?

Yes ▼

#### 2. ECT Sensor Inspection



- Install a jumper wire between the terminals. Connection: Y/Bu – G/W
- Check the ECT sensor voltage with MCS.
- Is the voltage about 0 V indicated?

#### No ▼

#### 3. ECT Sensor Output Line Inspection

- Check an open circuit in Y/Bu and G/W wire.
- If there is no open circuit, replace the ECM with a new one →4-25, and recheck.

\_\_\_\_\_

Loose or poor contact at the connector

Intermittent failure

• Replace the ECT sensor with a new one →4-25, and recheck.

#### DTC 8-1 (TP SENSOR LOW VOLTAGE)



Fuel tank lifting →4-52

#### **TP Sensor Diagram**





#### DTC 8-2 (TP SENSOR HIGH VOLTAGE)



Fuel tank lifting →4-52

#### **TP Sensor Diagram**



#### 1. TP Sensor System Inspection

- Check the TP sensor voltage with MCS when the throttle fully closed.
- Is the voltage about 5 V indicated?
- <sup>e</sup> No ►

Yes

- Check the TP sensor voltage with MCS.
- Operate the throttle from fully closed to fully opened.
- If the voltage is not increase continuously, replace the sensor unit (TP sensor) with a new one →2-8, and recheck.

Yes ▼

#### 2. TP Sensor Ground Line Inspection

- Check a open circuit in G/W wire.
- Is there open circuit?

No ▼

#### 3. TP Sensor Inspection

- Replace the sensor unit (TP sensor) with a new one →2-8
- Erase the DTC.
- Check the TP sensor with MCS.
- If DTC 8-2 is indicated, replace the ECM with a new one →4-25, and recheck.

Faulty G/W wire



#### DTC 9-1 (IAT SENSOR LOW VOLTAGE)



Fuel tank lifting →4-52

#### **IAT Sensor Diagram**



No

#### 1. IAT Sensor System Inspection

- · Check the IAT sensor voltage with MCS.
- Is the voltage about 0 V indicated?

Yes **V** 

- Intermittent failure
- · Loose or poor contact at the connector

#### 2. IAT Sensor Inspection



- Check a short circuit in Gr/Bu wire. ٠
- If there is no short circuit, replace the ECM with a ٠ new one  $\rightarrow$ 4-25, and recheck.
- Replace the sensor unit (IAT sensor) with a new



#### DTC 9-2 (IAT SENSOR HIGH VOLTAGE)



Fuel tank lifting →4-52

#### **IAT Sensor Diagram**



No

►

#### **1. IAT Sensor System Inspection**

· Check the IAT sensor voltage with MCS.

Is the voltage about 5 V indicated?

- Intermittent failure •
- Loose or poor contact at the connector

Yes ▼

#### 2. IAT sensor Inspection



- · Install a jumper wire between the terminals. Connection: Gr/Bu - G/W
- · Check the IAT sensor voltage with MCS.
- Is the voltage about 0 V indicated?

#### No ▼

#### 3. IAT Sensor Voltage Input Line Inspection

- · Check an open circuit in Gr/Bu and G/W wire. • If there is no open circuit, replace the ECM with a new one  $\rightarrow$ 4-25, and recheck.
- Replace the sensor unit (IAT sensor) with a new Yes one  $\rightarrow$  2-8, and recheck.

#### DTC 11-1 (VS SENSOR)



Meter cover →4-54
Fuel tank lifting →4-52

#### VS Sensor Diagram





#### DTC 12-1 (INJECTOR)



Fuel tank lifting →4-52

#### **Injector Diagram**



#### DTC 21-1 (O<sub>2</sub> SENSOR LOW VOLTAGE)



Fuel tank lifting →4-52

#### O2 Sensor Diagram

MCS.

If DTC 21-1 is indicated, replace the ECM with a

new one  $\rightarrow$  4-25, and recheck.





#### DTC 21-2 (O2 SENSOR HIGH VOLTAGE)



Fuel tank lifting →4-52

#### O<sub>2</sub> Sensor Diagram



#### 1. O<sub>2</sub> Sensor System Inspection

• Test-ride the vehicle and check the O<sub>2</sub> sensor with MCS.

Yes ▼

· Is the DTC 21-2 indicated?

No 

Yes

· Intermittent failure

· Faulty BI/O or G/W wire.

· Loose or poor contact at the connector

#### 2. O<sub>2</sub> Sensor Circuit Inspection

- · Check the open circuit in BI/O and G/W wires.
- · Are there open circuit?

No ▼

#### 3. O<sub>2</sub> Sensor Inspection

- Replace the  $O_2$  sensor with a new one.  $\rightarrow$  4-26
- · Erase the DTC's.
- Test-ride the vehicle and check the O<sub>2</sub> sensor with MCS.
- · If DTC 21-2 is indicated, replace the ECM with a new one  $\rightarrow$ 4-25, and recheck.



#### DTC 23-1 (O2 SENSOR HEATER)



Fuel tank lifting →4-52

#### O2 Sensor Heater Diagram



#### 1. O<sub>2</sub> Sensor Heater System Inspection

- Erase the DTC's, and check the O<sub>2</sub> sensor heater with MCS.
- Is the DTC 23-1 indicated?

Yes ▼

#### 2. O<sub>2</sub> Sensor Heater Input Voltage Inspection



No

►

Intermittent failure

· Loose or poor contact at the connector

#### 3. O<sub>2</sub> Sensor Heater Signal Line Inspection

	-	
<ul><li>Check a open or short circuit in Bu/Y wire.</li><li>Is there open or short circuit?</li></ul>	Yes ►	Faulty Bu/Y wire

No ▼

3. O<sub>2</sub> Sensor Heater Resistance Inspection





#### DTC 29-1 (IACV)



Fuel tank lifting →4-52

#### **IACV** Diagram



#### DTC 33-2 (EEPROM)

#### 1. EEPROM System Inspection

- Check the EEPROM with MCS.
- Is the DTC 33-2 is indicated?

#### Yes ▼

- Replace the ECM with a new one →4-25, and recheck.
- No Intermittent failure

►

• Loose or poor contact at the connector



#### DTC 54-1 (BANK ANGLE SENSOR LOW VOLTAGE)



Battery box →4-53

#### **Bank Angle Sensor Diagram**



►

#### 1. Bank Angle Sensor System Inspection

- · Check the bank angle sensor voltage with MCS.
- Is the voltage about 0 V indicated?

# Yes ▼



#### 2. Bank Angle Sensor Power Input Voltage Inspection



Yes ▼

#### 3. Bank Angle Sensor Output Line Inspection

- Check a open or short circuit in Bu/R wire.
- Is there open or short circuit?

No ▼

#### 4. Bank Angle Sensor Inspection

- Replace the bank angle sensor with a new one. →4-26
- · Erase the DTC's.
- · Check the bank angle sensor with MCS.
- If DTC 54-1 is indicated, replace the ECM with a new one  $\rightarrow$ 4-25, and recheck.

Yes · Faulty Bu/R wire

#### DTC 54-2 (BANK ANGLE SENSOR HIGH VOLTAGE)



Bank angle sensor (Connector is connected.) →4-26

#### Bank Angle Sensor Diagram



Yes

►

#### • Check the bank angle sensor voltage with MCS.

- Incline the bank angle sensor.
- Is the voltage decrease?

#### No ▼

- Replace the bank angle sensor with a new one  $\rightarrow$  4-26, and recheck.
- Replace the ECM with a new one →4-25, and recheck.



#### DTC 88-1 (EVAP PURGE CONTROL SOLENOID VALVE)



Fuel tank lifting →4-52

#### **EVAP Purge Control Solenoid Valve Diagram**



#### 1. EVAP Purge Control Solenoid Valve System Inspection

- Check the EVAP purge control solenoid valve with MCS.
  Is the DTC 88-1 indicated?
- Intermittent failure
- Loose or poor contact at the connector

Yes ▼

#### 2. EVAP Purge Control Solenoid Valve Input Voltage Inspection



Yes

►

No

#### 3. EVAP Purge Control Solenoid Valve Signal Line Inspection

· Check an open or short circuit in Y/R wire.

Is there open or short circuit?

No ▼

Faulty Y/R wire

#### 4. EVAP Purge Control Solenoid Valve Resistance inspection





#### DTC 89-1 (PAIR CONTROL SOLENOID VALVE)



Fuel tank lifting →4-52

#### PAIR Control Solenoid Valve Diagram



#### 1. PAIR Control Solenoid Valve System Inspection

• Check the PAIR Control Solenoid Valve with MCS.

• Is the DTC 89-1 indicated?

Intermittent failure
Loose or poor contact at the connector

Yes ▼



No

No ▼

4. PAIR Control Solenoid Valve Resistance Inspection



Faulty PAIR Control Solenoid Valve



#### DTC 91-1 (IGNITION COIL PRIMARY CIRCUIT)



Battery box →4-53

#### Ignition Coil Primary Circuit Diagram



#### 1. Ignition Coil Primary Circuit System Inspection

- · Check the Ignition coil with MCS.
- Is the DTC 91-1 indicated?

# Intermittent failure Loose or poor contact at the connector

Yes **V** 

#### 2. Ignition Coil Primary Circuit Input Voltage Inspection



Yes

No

Yes ▼

#### 3. Ignition Coil Primary Circuit Signal Line Inspection



Is there open or short circuit?

No ▼

#### 4. Ignition Coil Inspection

- Replace the ignition coil with a new one  $\rightarrow$ 4-53
- · Erase the DTC's.
- Test-ride the vehicle and check the ignition coil with MCS.
- If DTC 91-1 is indicated, replace the ECM with a new one →4-25, and recheck.

Faulty P/Bu wire

٠



### ECM



- Fuel tank lifting →4-52

• ECM power circuit and ground circuit inspection

## ECT SENSOR







### O<sub>2</sub> SENSOR





Drive sprocket cover →3-10
1 Remove the O<sub>2</sub> sensor.
Flare nut socket: FRXM17 (Snap on) or equivalent

### **BANK ANGLE SENSOR**



Bank angle sensor inspection

Basic



**IGNITION SYSTEM DIAGRAM** 





### SPARK PLUG REPLACEMENT





• Battery box →4-53



Spark plug inspection

### **INSPECTION**

#### **IGNITION COIL PRIMARY PEAK VOLTAGE**





#### **IGNITION TIMING**

- Refer to "Basic Shop Manual" for the detail information of ignition coil primary peak voltage inspection.
- Battery box →4-53
- Temporarily install the wire harness by connecting battery and each connector.
- Connect a known-good spark plug to the spark plug cap and ground it to the cylinder head bolt as done in a spark test.
- With the ignition coil primary wires connected, connect the peak voltage adaptor probes to the ignition coil primary terminal and ground.
   CONNECTION: P/Bu (+) – Ground (–)
- Check the initial voltage at this time.
   STANDARD VOLTAGE: Battery voltage
- Shift the transmission into neutral.
- Crank the engine with the starter and measure the ignition coil primary peak voltage.
   PEAK VOLTAGE: 100 V minimum
- Warm up the engine normal operating temperature.
- Timing hole cap →2-22
- Connect the timing light to the spark plug wire.
- Start the engine and let it idle IDLE SPEED: 1,400 ± 100 rpm
- The ignition timing is correct if the "F" mark on the flywheel aligns with the index notch on the left crankcase cover.



## ELECTRICAL STARTER ELECTRICAL STARTER SYSTEM LOCATION



### **ELECTRICAL STARTER SYSTEM DIAGRAM**



### ELECTRICAL STARTER TROUBLESHOOTING

#### STARTER MOTOR DOES NOT TURN



Fuel tank lifting →4-52

Loose or poor contacts of related terminal/connector
Battery condition
Burned fuse

#### **Connector Diagram**



#### 1. Starter Relay Coil Input Circuit Inspection





### **STARTER MOTOR**





Engine →2-40
Cam chain tensioner →2-28





### **NEUTRAL SWITCH**





Engine oil →2-15
Drive sprocket cover →3-10



### ABS

Basic

- Refer to "Basic Shop manual" for the following information.
   ABS technical feature and each
- function.
- Troubleshooting for the ABS.
   MCS (Motorcycle Communication System) information.

### **DTC CODE INDEX**

DTC	Eurotion Failure	Detection		Symptom/Eail safe function	Dago
DIC	Function Failure	*A	*B	Symptom/Fail-Sale function	Faye
	ABS indicator malfunction <ul> <li>ABS modulator voltage input line</li> </ul>			<ul> <li>ABS indicator never come ON at all</li> </ul>	<b>→</b> 4-38
_	<ul> <li>Indicator related wires</li> </ul>			<ul> <li>ABS indicator stays ON</li> </ul>	
	Combination meter				<b>→</b> 4-38
	ABS modulator     ABS ECLI fuse (7.5A)				
-	Front wheel speed sensor circuit inspection			Stops ABS operation	
1-1	<ul> <li>Wheel speed sensor or related wires</li> </ul>	0	0		<b>→</b> 4-40
	Front wheel speed sensor malfunction			<ul> <li>Stops ABS operation</li> </ul>	
1_2	Wheel speed sensor, pulser ring or related		0		→1_10
1-2	wires		0		74-40
	Electromagnetic interference				
1-3	Rear wheel speed sensor circuit malfunction	0	0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 4-41
	Wheel speed sensor of felded wiles	-	-	Stops ABS operation	
	Wheel speed sensor, pulser ring or related				
1-4	wires		0		→4-41
	Electromagnetic interference				
2.1	Front pulser ring		0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 1 10
2-1	<ul> <li>Pulser ring or related wires</li> </ul>		0		74-40
2-3	Rear pulser ring		0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 4-41
	Pulser ring or related wires		•		
3-1	Solenoid valve maifunction (ABS modulator)			<ul> <li>Stops ABS operation</li> </ul>	
33	-	0	0		<b>→</b> 4-42
3-4	-				
	Front wheel lock			Stops ABS operation	
4-1	Riding condition		0		<b>N</b> 4 40
12	Front wheel lock (Wheelie)		0		₩4-40
4-2	Riding condition		0		
4-3	Rear wheel lock		0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 4-41
	Riding condition		-	· Stope ABS operation	
	Pump motor (ABS modulator) or related			<ul> <li>Stops ABS operation</li> </ul>	
5-1	wires	0	0		<b>→</b> 4-43
	ABS MOTOR fuse (30A)				
	Pump motor stuck off			<ul> <li>Stops ABS operation</li> </ul>	
5-2	Pump motor (ABS modulator) or related	$\circ$	$\circ$		→4-43
0-2	wires	0	0		<b>2</b> + − + 0
-	ABS MOTOR fuse (30A)				
	Pump motor Stuck on     Pump motor (ABS modulator) or related			<ul> <li>Stops ABS operation</li> </ul>	
5-3	wires	0	0		<b>→</b> 4-43
	ABS MOTOR fuse (30A)				
	Power supply relay malfunction			Stops ABS operation	
5_1	Power supply relay (ABS modulator) or re-	$\circ$	0		$\rightarrow 4 - 11$
J-4	lated wires	0	0		74-44
	ABS SOL fuse (20A)				



DTC	Function Failure	Detection		Symptom/Eail acts function	Dama
		*A	*B	- Symptom/Fail-Safe function	rage
6-1	Power circuit under voltage <ul> <li>Input footage (too low)</li> <li>ABS ECU fuse (7.5A)</li> </ul>	0	0	Stops ABS operation	<b>→</b> 4-45
6-2	<ul><li>Power circuit over voltage</li><li>Input voltage (too high)</li></ul>	0	0	Stops ABS operation	<b>→</b> 4-45
7-1	<ul> <li>Tire malfunction</li> <li>Tire size</li> <li>Incorrect sprocket gear ratio (Sprockets not recommended for the vehicle are installed.)</li> </ul>		0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 4-46
8-1	<ul> <li>ABS control unit</li> <li>ABS control unit malfunction (ABS modula- tor)</li> </ul>	0	0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 4-46
8-3	<ul><li>IMU acceleration malfunction</li><li>IMU or related wires</li><li>ABS ECU fuse (7.5 A)</li></ul>	0	0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 4-47
8-4	<ul><li>IMU angle rate malfunction</li><li>IMU or related wires</li><li>ABS ECU fuse (7.5 A)</li></ul>	0	0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 4-47
8-5	<ul><li>IMU circuit malfunction</li><li>IMU or related wires</li><li>ABS ECU fuse (7.5 A)</li></ul>	0	0	<ul> <li>Stops ABS operation</li> </ul>	<b>→</b> 4-47

\*A: Pre-start self-diagnosis

\*B: Ordinary self-diagnosis: diagnoses while the vehicle is running (after pre-start self-diagnosis)



#### How To Erase the DTC Without MCS



• Connect the DLC.

• Squeeze the brake lever.

- The ABS indicator should come on 2 seconds and go off.
- After the ABS indicator is off, release the brake lever immediately.
- After the ABS indicator is on, squeeze the brake lever immediately.
- After the ABS indicator is off, release the brake lever immediately.
  - When code erasure is complete, the ABS indicator blinks 2 times and stay on.
  - If the ABS indicator does not blink, the data has not been erased, so try again.

### **ABS LOCATION**



### **ABS DIAGRAM**




### DTC TROUBLESHOOTING

- Before starting this troubleshooting, check the burned fuse and initial function of the meter.
- Use a fully charged battery. Do not diagnose with a charger connected to the battery.
- Perform inspection with the ignition switch OFF, unless otherwise specified.
- All connector diagrams in the troubleshooting are viewed from the terminal side.
- When the ABS modulator assembly is detected to be faulty, recheck the wire harness and connector connections closely before replacing it.
- After diagnostic troubleshooting, erase the DTC and test-ride the vehicle to check that the ABS indicator operates normally during pre-start self-diagnosis.

#### **ABS indicator malfunction**

Meter cover →4-54

#### ABS indicator does not come ON (When the ignition switch ON)



### 1. ABS Indicator Inspection









### DTC 1-1, 1-2, 2-1, 4-1, 4-2

#### (Front wheel speed sensor circuit / Front wheel speed sensor / Front pulser ring / Front wheel lock)



### DTC 1-3, 1-4, 2-3, 4-3

#### (Rear wheel speed sensor circuit / Rear wheel speed sensor / Rear pulser ring/ Rear wheel lock)





### DTC 3-1, 3-2, 3-3, 3-4

(Solenoid Valve malfunction)



Faulty ABS modulator

### DTC 5-1, 5-2, 5-3

(Pump Motor Lock / Pump motor stuck off / Pump motor stuck on)



### 1. ABS Modulator Power Line Inspection 1

· Faulty ABS modulator



### **DTC 5-4**

### (Power Supply Relay malfunction)





· Is there short circuit?

No ▼

### 3. Failure Reproduction

- Erase the DTC and test-ride the vehicle above 30 No km/h, then recheck the DTC. ►
- · Is the DTC 5-4 indicated?

Yes ▼

· Faulty ABS modulator

- · Faulty R/G wire
- Intermittent failure

### DTC 6-1, 6-2 (Power Circuit)







### DTC 7-1

### (Tire Size)



- Check the following and correct the faulty part.
- Incorrect tire pressure
  - Tires not recommended for the vehicle were installed (incorrect tire size).
  - Sprockets not recommended for the vehicle were installed (incorrect sprocket gear ratio).
  - Deformation of the wheel or tire.

### 1. Failure Reproduction

• Erase the DTC and test-ride the vehicle above 30

Yes ▼

- km/h, then recheck the DTC.
- Is the DTC 7-1 indicated?

No ►

Intermittent failure

· Faulty ABS modulator

### DTC 8-1

### (ABS Control Unit)

### 1. Failure Reproduction

- Erase the DTC and test-ride the vehicle above 30 km/h, then recheck the DTC.
- · Is the DTC 8-1 indicated?

- No ►
- Intermittent failure

### Yes ▼

· Faulty ABS modulator



#### DTC 8-3, 8-4, 8-5



(IMU)







### WHEEL SPEED SENSOR



- Rear wheel →3-25
- Basic

Wheel speed sensor inspection

### IMU











Engine →2-40
Pull up the lock lever and disconnect the ABS modulator 18P connector.

# BATTERY/CHARGING SYSTEM BATTERY/CHARGING SYSTEM LOCATION



**BATTERY/CHARGING SYSTEM DIAGRAM** 





Battery/charging system information, troubleshooting and inspection



# BATTERY



Fuel tank cover →3-9
Cover the handlebar holders with a protective cloth to prevent the battery terminals from scratching them.

# **BATTERY BOX**





Battery →4-52
Fuel tank →2-6
Left radiator cover →3-8



# LIGHTING SYSTEM







• Pillion seat →3-4

# HEADLIGHT AIM





### TURN SIGNAL LIGHT TROUBLESHOOTING



• When all turn signal lights blink faster than usual, replace the turn signal light relay with a known good one, and recheck.

### ALL TURN SIGNAL LIGHTS DO NOT LIGHT



- · Loose or poor contacts of related terminal/connector
- Battery condition
  - Burned fuse



### 1. Turn Signal Light Relay Input Voltage Inspection



# **COMBINATION METER**





### CLOCK ADJUST



- Push and hold both the SEL button and SET button for more than 2 seconds.
  The clock will be set in the adjust mode with the hour dis-
  - The clock will be set in the adjust mode with the hour display flashing.

- The time is advanced by one hour, each time the button is pushed.
- The time advances fast when the button is pushed and held.

- Push the SET button.
- The minute display will start flashing.

- The time advances by one minute, each time the button is pushed.
- The time advances fast when the button is pushed and held.
- To end the adjustment, push the SET button or turn the ignition switch to OFF.
- The display will stop flashing automatically and the adjustment will be cancelled if the button is not pushed for about 30 seconds.

## **VS SENSOR**



# FUEL LEVEL SENSOR





Fuel pump unit →2-4

•  $\fbox$  Route the fuel level sensor wires to the guide and terminals properly.



## FUEL METER TROUBLESHOOTING

### FUEL GAUGE FAILURE INDICATION



Fuel pump unit →2-4

· Loose or poor contacts of related terminal/connector





# ELECTRICAL COMPONENT IGNITION SWITCH





Top bridge →3-23

### **IGNITION SWITCH INSPECTION**



Headlight →4-54





Check for continuity the ignition switch 4P connector of the ignition switch side.

#### Connection: Black/white (+) – Pink (–) Black/white (–) – Pink (+)

It is normal if there is continuity in one direction.

• It is faulty of the ignition switch if there is continuity in both directions.



# SIDESTAND SWITCH (EXCEPT TH MODEL)





• Drive sprocket cover →3-10

# HORN



# INDEX

A Few Words About Safety1-2
ABS
AIR CLEANER ·······2-7
ALTERNATOR/STARTER CLUTCH 2-33
BATTERY/CHARGING SYSTEM 4-51
BODY PANELS ····································
BRAKE FLUID REPLACEMENT 3-28
CABLE & HARNESS ROUTING1-19
CLUTCH/GEARSHIFT LINKAGE 2-30
COMBINATION METER ······4-57
COOLANT REPLACEMENT ·······2-17
COOLING SYSTEM 2-17
CRANKCASE/CRANKSHAFT/BALANCER2-35
CYLINDER HEAD ······2-22
CYLINDER/PISTON ······2-29
ELECTRICAL COMPONENT ···································
ELECTRICAL STARTER ······4-30
ENGINE OIL CHANGE ····································
ENGINE OIL LEVEL CHECK ····································
ENGINE OIL STRAINER SCREEN/OIL PUMP2-16
ENGINE UNIT ······2-40
EVAP SYSTEM ······2-13
EXHAUST PIPE/MUFFLER ····································
FORK
FRONT BRAKE ····································
FRONT WHEEL ···································
FUEL LEVEL SENSOR ······4-59
FUEL LINE 2-2
FUEL PUMP UNIT

FUEL TANK ······	2-6
HANDLEBAR ······	······ 3-21
HORN	4-62
How To Use This Manual	1-3
IGNITION SYSTEM	4-27
	2-11
	4-54
	2-10
REAR SUSPENSION	
REAR WHEEL	3-25
SECONDARY AIR SUPPLY SYSTEM	····· 2-12
SIDESTAND	3-14
SPARK PLUG REPLACEMENT	4-28
SPECIAL TOOL LIST	1-18
SPECIFICATIONS	1-6
STEERING STEM ······	3-23
TECHNICAL FEATURES	····· 1-28
THROTTLE BODY ·····	2-8
TORQUE VALUE	······ 1-12
TP SENSOR RESET PROCEDURE	2-10
	2-39
WATER PUMP/THERMOSTAT	2-20





© Honda Motor Co.,Ltd. 2017 Published by Honda Motor Co.,Ltd. Printed in Japan