



YAMAHA

2007

YZ85W1

YZ85(W)

YZ85LW(W)

SERVICE MANUAL

5PA-28197-E0

EAS00000

**YZ85W1/YZ85 (W)/YZ85LW (W)
SERVICE MANUAL
©2006 by Yamaha Motor Co., Ltd.
First edition, April 2006
All rights reserved.
Any reproduction or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.**

NOTICE

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles.

Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

Designs and specifications are subject to change without notice.

IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the vehicle operator, a bystander or a person checking or repairing the vehicle.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the vehicle.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- ① The manual is divided into chapters. An abbreviation and symbol in the upper right corner of each page indicate the current chapter. Refer to "SYMBOLS".
- ② Each chapter is divided into sections. The current section title is shown at the top of each page, except in Chapter 3 ("PERIODIC CHECKS AND ADJUSTMENTS"), where the sub-section title(s) appears.
- ③ Sub-section titles appear in smaller print than the section title.
- ④ To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.
- ⑤ Numbers are given in the order of the jobs in the exploded diagram. A circled number indicates a disassembly step.
- ⑥ Symbols indicate parts to be lubricated or replaced. Refer to "SYMBOLS".
- ⑦ A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
- ⑧ Jobs requiring more information (such as special tools and technical data) are described sequentially.

②
①

CLUTCH

ENG

CLUTCH

Order	Job/Part	Q'ty	Remarks
	Removing the clutch		
	Transmission oil		Drain Refer to "CHANGING THE TRANSMISSION OIL" in chapter 3. Disconnect
1	Clutch cable	1	
2	Clutch cover	1	
3	Clutch cover gasket	1	
4	Dowel pin	2	
5	Compression spring	5	
6	Pressure plate	1	
7	Push rod 1	1	
8	Ball	1	
9	Push rod 2	1	
10	Friction plate 1	1	
11	Clutch plate 1	6	
12	Friction plate 3	5	

CLUTCH

ENG

CLUTCH

REMOVING THE CLUTCH

1. Remove:

- clutch cover ①
- gasket

NOTE:
Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.

2. Remove:

- compression spring bolts ①
- compression springs
- pressure plate ②

3. Remove:

- push rod 1
- ball
- push rod 2

4. Remove:

- friction plate ①
- clutch plate ②
- friction plate ③
- friction plate ④

5. Remove:

- clutch boss nut ①
- washer ②
- clutch boss ③

NOTE:
While holding the clutch boss with the universal clutch holder ③, loosen the clutch boss nut.

Universal clutch holder
90890-04086, YM-91042

6. Remove:

- washer
- primary drive gear
- spacer

SYMBOLS

The following symbols are not relevant to every vehicle.

Symbols ① to ⑩ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Chassis
- ⑤ Engine
- ⑥ Cooling system
- ⑦ Carburetor(s)
- ⑧ Electrical system
- ⑨ Tuning
- ⑩ Troubleshooting

Symbols ⑪ to ⑱ indicate the following.

- ⑪ Serviceable with engine mounted
- ⑫ Filling fluid
- ⑬ Lubricant
- ⑭ Special tool
- ⑮ Tightening torque
- ⑯ Wear limit, clearance
- ⑰ Engine speed
- ⑱ Electrical data

Symbols ⑲ to ⑳ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑲ Engine oil
- ⑳ Gear oil
- ㉑ Molybdenum-disulfide oil
- ㉒ Wheel-bearing grease
- ㉓ Lithium-soap-based grease
- ㉔ Molybdenum-disulfide grease

Symbols ㉕ to ㉖ in the exploded diagrams indicate the following.

- ㉕ Apply locking agent (LOCTITE®)
- ㉖ Replace the part with a new one.





TABLE OF CONTENTS

GENERAL INFORMATION	
	GEN INFO 1
SPECIFICATIONS	
	SPEC 2
PERIODIC CHECKS AND ADJUSTMENTS	
	CHK ADJ 3
CHASSIS	
	CHAS 4
ENGINE	
	ENG 5
COOLING SYSTEM	
	COOL 6
CARBURETOR	
	CARB 7
ELECTRICAL SYSTEM	
	ELEC 8
TUNING	
	TUN 9
TROUBLESHOOTING	
	TRBL SHTG 10

CHAPTER 1
GENERAL INFORMATION

VEHICLE IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER	1-1
MODEL LABEL	1-1
IMPORTANT INFORMATION	1-2
PREPARATION FOR REMOVAL AND DISASSEMBLY	1-2
REPLACEMENT PARTS	1-2
GASKETS, OIL SEALS AND O-RINGS	1-2
LOCK WASHERS/PLATES AND COTTER PINS	1-3
BEARINGS AND OIL SEALS	1-3
CIRCLIPS	1-3
FUEL AND ENGINE MIXING OIL	1-4
CHECKING THE CONNECTIONS	1-5
SPECIAL TOOLS	1-6




EAS00014

GENERAL INFORMATION
VEHICLE IDENTIFICATION

EAS00017

VEHICLE IDENTIFICATION NUMBER





The vehicle identification number ① is stamped into the right side of the steering head pipe.



EAS00018

MODEL LABEL

The model label ① is affixed to the frame. This information will be needed to order spare parts.



EAS00020

**IMPORTANT INFORMATION
PREPARATION FOR REMOVAL AND
DISASSEMBLY**

1. Before removal and disassembly, remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.
Refer to the "SPECIAL TOOLS".
3. When disassembling, always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

EAS00021


REPLACEMENT PARTS

Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EAS00022

GASKETS, OIL SEALS AND O-RINGS


1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly, properly oil all mating parts and bearings and lubricate the oil seal lips with grease.



EAS00023

LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EAS00024


BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.


① Oil seal

CAUTION:

Do not spin the bearing with compressed air because this will damage the bearing surfaces.



① Bearing



EAS00025

CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

④ Shaft

FUEL AND ENGINE MIXING OIL


Mix oil with the gas at the ratio specified below. Always use fresh, name-brand gasoline, and mix the oil and gas the day of the race. Do not use premix that is more than a few hours old.

	<p>Recommended fuel Premium unleaded gasoline only with a research octane number of 95 or higher.</p>
---	--

NOTE: _____
 If knocking or pinging occurs, use a different brand of gasoline or higher octane grade.

CAUTION: _____

Never mix two types of oil in the same batch; clotting of the oil could result. If you wish to change oil types, be sure to drain the fuel tank and the carburetor float bowl of old premix prior to filling with the new type.





	<p>Fuel tank capacity 5.0 L (1.10 Imp gal, 1.32 US gal)</p>
---	--

	<p>Mixing oil Recommended oil Yamalube "2-R" (Yamalube racing 2-cycle oil) Mixing ratio: 30 : 1 If unavailable, use an equivalent type of oil.</p>
---	---

CHECKING THE CONNECTIONS

GEN
INFO



EAS00026

CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:

- lead
- coupler
- connector

2. Check:

- lead
- coupler
- connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.

3. Check:

- all connections

Loose connection → Connect properly.

NOTE: _____

If the pin ① on the terminal is flattened, bend it up.

4. Connect:



- lead
- coupler
- connector

NOTE: _____

Make sure all connections are tight.

5. Check:

- continuity
(with the pocket tester)



Pocket tester

90890-03112, YU-3112-C

NOTE: _____

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.

EAS00027








SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools as this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools, part numbers or both may differ depending on the country.

When placing an order, refer to the list provided below to avoid any mistakes.






NOTE:

- For U.S.A. and Canada, use part number starting with “YM-”, “YU-”, or “ACC-”.
- For others, use part number starting with “90890-”.


Tool No.	Tool name/Function	Illustration
90890-01135 YU-1135-A	Crankcase separating tool This tool is used to split the crankcase as well as remove the crankshaft from either case.	
90890-01189 YM-1189	Flywheel puller This tool is used to remove the flywheel magneto.	
90890-01235 YU-1235	Rotor holding tool This tool is used when loosening or tightening the flywheel magneto securing nut.	
Dial gauge set 90890-01252 Dial gauge and stand YU-3097 YU-1256	Dial gauge and stand Stand These tools are used to check each part for runout or bent.	
90890-01268	Ringnut wrench This tool is used to loosen and tighten the exhaust and steering ringnut.	
Crankshaft installing tool For EUR, OCE 90890-01274 90890-01275 90890-01277 For U.S.A, CAN YU-90050 YM-1277	Crankshaft installing tool Crankshaft installing pot Crankshaft installing bolt Adapter (M10) These tools are used to install the crankshaft.	
90890-01304 YU-1304	Piston pin puller set This tool is used to remove the piston pin.	

SPECIAL TOOLS



Tool No.	Tool name/Function	Illustration
Radiator cap tester 90890-01325 YU-24460-01 Radiator cap tester adapter 90890-01352 YU-33984	Radiator cap tester Radiator cap tester adapter These tools are used for checking the cooling system.	
90890-01403 YU-33975	Steering nut wrench This tool is used when tighten the steering ring nut to specification.	
90890-01434 YM-01434	Rod holder This tool is used to hold the fork spring.	
Rod puller 90890-01437 YM-01437 Rod puller attachment 90890-01436 YM-01436	Rod puller Rod puller attachment (M10) These tools are used to pull up the fork damper rod.	
90890-01442 YM-01442	Fork seal diver This tool is used when install the fork oil seal.	
90890-01454 YM-01454	Damper rod holder Use this tool to remove and install the damper rod.	
90890-01495 YM-01495	Drive gear holder This tool is used when removing or tightening the primary drive gear securing nut.	
90890-03112 YU-3112-C	Pocket tester Use this tool to inspect the coil resistance, output voltage and amperage.	
90890-04086 YM-91042	Universal clutch holder This tool is used to hold the clutch when removing or installing the clutch boss securing nut.	

SPECIAL TOOLS

Tool No.	Tool name/Function	Illustration
90890-06754 YM-34487	Dynamic spark tester Ignition checker This instrument is necessary for checking the ignition system components.	 A line drawing of a dynamic spark tester, which is a U-shaped metal tool with a central component that can be inserted into a spark plug gap.
90890-85505	Yamaha bond No.1215 (Three Bond No.1215 [®]) This sealant (Bond) is used for crankcase mating surface, etc.	 A line drawing of a tube of sealant, showing the nozzle and the body of the tube.

**CHAPTER 2
SPECIFICATIONS**

GENERAL SPECIFICATIONS 2-1

ENGINE SPECIFICATIONS 2-2

CHASSIS SPECIFICATIONS 2-7

ELECTRICAL SPECIFICATIONS..... 2-11

CONVERSION TABLE 2-12

GENERAL TIGHTENING TORQUE SPECIFICATIONS 2-12

TIGHTENING TORQUES 2-13

 ENGINE TIGHTENING TORQUES 2-13

 CHASSIS TIGHTENING TORQUES 2-14

LUBRICATION POINTS AND LUBRICANT TYPES 2-16

 ENGINE 2-16

 CHASSIS 2-16

CABLE ROUTING..... 2-17



SPECIFICATIONS

GENERAL SPECIFICATIONS

Item	Standard	Limit
Model code	YZ85 5PAG (EUR, CAN), 5PAH (AUS,NZL) YZ85LW 5SHG (EUR), 5SHH (AUS,NZL)
Dimensions		
Overall length	1,818 mm (71.6 in) (YZ85) 1,903 mm (74.9 in) (YZ85LW)
Overall width	758 mm (29.8 in)	...
Overall height	1,161mm (45.7 in) (YZ85) 1,205 mm (47.4 in) (YZ85LW)
Seat height	864 mm (34.0 in) (YZ85) 904 mm (35.6 in) (YZ85LW)
Wheelbase	1,255 mm (49.4 in) (YZ85) 1,286 mm (50.6 in) (YZ85LW)
Minimum ground clearance	351 mm (13.8 in) (YZ85) 393 mm (15.5 in) (YZ85LW)
Dry weight		
Without oil and fuel	66 kg (145.5 lb) (YZ85) 69 kg (152.2 lb) (YZ85LW)





ENGINE SPECIFICATIONS

Item	Standard	Limit
Engine		
Engine type	Liquid cooled 2-stroke, gasoline	•••
Displacement	84.7 cm ³ (5.17 cu.in)	•••
Cylinder arrangement	Single cylinder, forward inclined	•••
Bore × stroke	47.5 × 47.8 mm (1.870 × 1.882 in)	•••
Compression ratio	8.2 : 1	•••
Fuel		
Recommended fuel	Premium unleaded gasoline only	•••
Fuel tank capacity Total	5.0L (1.09 Imp gal, 1.30 US gal)	•••
Lubrication system	Premix (30 : 1) (Yamalube 2-R)	•••
Transmission oil		
Recommended oil	Yamalube 4 (10W-30) or SAE 10W-30 API service SG type or higher JASO standard MA	•••
Periodic oil change	0.50 L (0.44 Imp qt, 0.53 US qt)	•••
Total amount	0.55 L (0.48 Imp qt, 0.58 US qt)	•••
Cooling system		
Coolant capacity (including all routes)	0.54 L (0.48 Imp qt, 0.57 US qt)	•••
Radiator capacity	0.32 L (0.28 Imp qt, 0.34 US qt)	•••
Radiator cap opening pressure	93 ~ 123 kPa (0.93 ~ 1.23 kg/cm ² , 13.2 ~ 17.5 psi)	•••
Radiator core		
Width	117.8 mm (4.64 in)	•••
Height	240.0 mm (9.45 in)	•••
Depth	32.0 mm (1.26 in)	•••
Water pump		
Water pump type	Single suction centrifugal pump	•••
Reduction ratio	25/18 (1.388)	•••
Starting system	Kickstarter	•••
Spark plug		
Model (manufacturer) × quantity	BR10EG (NGK) × 1	•••
Spark plug gap	0.5 ~ 0.6 mm (0.0197 ~ 0.0236 in)	•••
Cylinder head		
Volume	7.14 cm ³ (0.44 cu.in)	•••
Max. warpage	•••	0.03 mm (0.0012 in)

ENGINE SPECIFICATIONS

SPEC



Item	Standard	Limit
Cylinder		
Bore	47.500 ~ 47.514 mm (1.8701 ~ 1.8706 in)	47.6 mm (1.874 in)
Max. taper limit	•••	0.05 mm (0.0020 in)
Max. out-of-round	•••	0.01 mm (0.0004 in)
Piston		
Piston-to-cylinder clearance	0.040 ~ 0.045 mm (0.0016 ~ 0.0018 in)	0.1 mm (0.004 in)
Diameter D	47.457 ~ 47.472 mm (1.8684 ~ 1.8690 in)	0.1 mm (0.004 in)
		
Height H	20.0 mm (0.79 in)	•••
Piston pin bore (in the piston) Diameter	14.004 ~ 14.015 mm (0.5513 ~ 0.5518 in)	14.040 mm (0.5528 in)
Offset	1.0 mm (0.039 in)	•••
Offset direction	Exhaust side	•••
Piston pin Outside diameter	13.996 ~ 14.000 mm (0.5510 ~ 0.5512 in)	13.975 mm (0.5502 in)
Piston ring		
		
Ring type	Plain	•••
Dimensions (B × T)	0.8 × 2.0 mm (0.032 × 0.079 in)	•••
End gap (installed)	0.30 ~ 0.45 mm (0.012 ~ 0.018 in)	0.8 mm (0.032 in)
Ring side clearance	0.030 ~ 0.065 mm (0.001 ~ 0.003 in)	0.1 mm (0.004 in)

ENGINE SPECIFICATIONS

SPEC



Item	Standard	Limit
<p>Crankshaft</p> <div style="text-align: center;"> </div> <p>Crank width "A" Runout limit "C"</p> <p>Big end side clearance "D" Small end free play "F"</p>		
	<p>44.90 ~ 44.95 mm (1.768 ~ 1.770 in)</p> <p>0.03 mm (0.0012 in)</p>	<p>•••</p> <p>0.05 mm (0.002 in) (YZ85)</p> <p>0.08 mm (0.003 in) (YZ85LW)</p>
	<p>0.20 ~ 0.70 mm (0.008 ~ 0.028 in)</p> <p>0.5 ~ 1.2 mm (0.020 ~ 0.047 in)</p>	<p>•••</p> <p>2.0 mm (0.08 in)</p>
<p>Clutch</p> <p>Clutch type Clutch release method Clutch cable free play (at the end of the clutch lever) Friction plates Thickness Plate quantity Clutch plates Thickness Plate quantity Max. warpage Clutch springs Free length Spring quantity Clutch housing thrust clearance Clutch housing radial clearance</p>		
	<p>Wet, multiple disc Inner push, cam push 10.0 ~ 15.0 mm (0.39 ~ 0.59 in)</p> <p>2.9 ~ 3.1 mm (0.114 ~ 0.122 in)</p> <p>7</p> <p>1.8 ~ 2.2 mm (0.071 ~ 0.087 in)</p> <p>6</p> <p>•••</p> <p>33.0 mm (1.30 in)</p> <p>5</p> <p>0.10 ~ 0.35 mm (0.0039 ~ 0.0138 in)</p> <p>0.022 ~ 0.051 mm (0.0009 ~ 0.0020 in)</p>	<p>•••</p> <p>•••</p> <p>•••</p> <p>•••</p> <p>2.7 mm (0.106 in)</p> <p>•••</p> <p>•••</p> <p>•••</p> <p>0.1 mm (0.004 in)</p> <p>31.0 mm (1.22 in)</p> <p>•••</p> <p>•••</p> <p>•••</p>

ENGINE SPECIFICATIONS


SPEC


Item	Standard	Limit
Transmission		
Transmission type	Constant mesh, 6-speed	•••
Primary reduction system	Spur gear	•••
Primary reduction ratio	65/18 (3.611)	•••
Secondary reduction system	Chain drive	•••
Secondary reduction ratio	47/14 (3.357) (YZ85 for EUR, CAN)	•••
	48/14 (3.428) (YZ85 for AUS, NZL)	•••
	52/14 (3.714) (YZ85LW)	•••
Operation	Left-foot operation	•••
Gear ratios		
1st gear	27/11 (2.454)	•••
2nd gear	32/17 (1.882)	•••
3rd gear	26/17 (1.529)	•••
4th gear	22/17 (1.294)	•••
5th gear	26/23 (1.130)	•••
6th gear	25/25 (1.000)	•••
Max. main axle runout		0.01 mm (0.004 in)
Max. drive axle runout		0.01 mm (0.004 in)
Shifting mechanism		
Shift mechanism type	Cam drum/Guide bar	•••
Guide bar bending limit	•••	0.05 mm (0.002 in)
Air filter type		
Air filter oil glade	Wet element	•••
	Form air filter oil or 2-stroke motor oil	•••
Carburetors		
Model (manufacturer)	PWK28 (KEIHIN)	•••
Throttle cable free play (at the flange of the throttle grip)	3.0 ~ 5.0 mm (0.118 ~ 0.197 in)	•••
ID mark	5PA1 00	•••
Main jet	#138	•••
Main air jet	#60	•••
Jet needle-clip position	NBKF-2	•••
Needle jet	ø2.6	•••
Cutaway	3.0	•••
Pilot jet	#45	•••
Bypass	ø0.8	•••
Pilot outlet	ø0.4	•••
Pilot screw turns out	2	•••
Valve seat size	ø2.6	•••
Starter jet	#62	•••
Float height	18 ~ 20 mm (0.71 ~ 0.79 in)	•••

ENGINE SPECIFICATIONS

SPEC



Item	Standard	Limit
<p>Reed valve</p>  <p>Thickness "T" Valve stopper height Valve bending limit</p>	<p>0.42 mm (0.017 in) 7.4 ~ 7.8 mm (0.291 ~ 0.307 in)</p>	<p>••• ••• 0.2 mm (0.008 in)</p>

CHASSIS SPECIFICATIONS

SPEC



CHASSIS SPECIFICATIONS

Item	Standard	Limit
Frame		
Frame type	Semi double cradle	•••
Material	Steel	•••
Caster angle	26.3° (YZ85)	•••
	26.9° (YZ85LW)	•••
Trail	88.0 mm (3.46 in) (YZ85)	•••
	105.5 mm (4.15 in) (YZ85LW)	•••
Front wheel		
Wheel type	Spoke wheel	•••
Rim		
Size	17 × 1.40 (YZ85)	•••
	19 × 1.40 (YZ85LW)	•••
Material	Aluminum	•••
Wheel travel	275 mm (10.83 in)	•••
Wheel runout		
Radial wheel runout limit	•••	2.0 mm (0.08 in)
Lateral wheel runout limit	•••	2.0 mm (0.08 in)
Rear wheel		
Wheel type	Spoke wheel	•••
Rim		
Size	14 × 1.60 (YZ85)	•••
	16 × 1.85 (YZ85LW)	•••
Material	Aluminum	•••
Wheel travel	282 mm (11.10 in) (YZ85)	•••
	287 mm (11.30 in) (YZ85LW)	•••
Wheel runout		
Radial wheel runout limit	•••	2.0 mm (0.08 in)
Lateral wheel runout limit	•••	2.0 mm (0.08 in)

CHASSIS SPECIFICATIONS

SPEC



Item	Standard	Limit
Front tire		
Tire type	Tube	•••
Size	70/100-17 40M (YZ85) 70/100-19 42M (YZ85LW)	••• •••
Model (manufacturer)	D739FA (DUNLOP) (YZ85 for EUR, CAN) D756F (DUNLOP) (YZ85 for AUS, NZL) D756F (DUNLOP) (YZ85LW)	••• ••• •••
Tire pressure (cold)	100 kPa (1.0 kgf/cm ² , 1.0 bar, 14.2 psi)	•••
Rear tire		
Tire type	Tube	•••
Size	90/100-14 49M (YZ85) 90/100-16 52M (YZ85LW)	••• •••
Model (manufacturer)	D756 (DUNLOP)	•••
Tire pressure (cold)	100 kPa (1.0 kgf/cm ² , 1.0 bar, 14.2 psi)	•••
Front brakes		
Brake type	Single disc brake	•••
Operation	Right hand operation	•••
Recommended fluid	DOT 4	•••
Brake lever free play	0 mm (0.00 in)	•••
Brake discs		
Diameter × thickness	220 × 3 mm (8.66 × 0.12 in)	•••
Thickness limit	•••	2.5 mm (0.10 in)
Deflection limit	•••	0.15 mm (0.006 in)
Brake pad lining thickness	4.0 mm (0.16 in)	0.8 mm (0.03 in)
Master cylinder inside diameter	11.0 mm (0.433 in)	•••
Caliper cylinder inside diameter	22.2 mm (0.874 in) × 2	•••
Rear brake		
Brake type	Single disc brake	•••
Operation	Right foot operation	•••
Brake pedal position (vertical height above footrest top)	4.0 ~ 10.0 mm (0.16 ~ 0.39 in)	•••
Recommended fluid	DOT 4	•••
Brake pedal freeplay	0 mm (0.00 in)	•••
Brake discs		
Diameter × thickness	190 × 3 mm (7.48 × 0.12 in)	•••
Thickness limit	•••	2.5 mm (0.10 in)
Deflection limit	•••	0.15 mm (0.006 in)
Brake pad lining thickness	3.7 mm (0.15 in)	1.0 mm (0.04 in)
Master cylinder inside diameter	12.7 mm (0.500 in)	•••
Caliper cylinder inside diameter	27.0 mm (1.063 in)	•••

CHASSIS SPECIFICATIONS

SPEC



Item	Standard	Limit
Steering		
Steering bearing type	Taper roller bearing	•••
Lock to lock angle (left)	45°	•••
Lock to lock angle (right)	45°	•••
Front suspension		
Suspension type	Telescopic fork	•••
Front fork type	Coil spring/oil damper	•••
Front fork travel	275 mm (10.83 in)	•••
Spring		
Free length	430 mm (16.93 in)	425 mm (16.73 in)
Installed length	430 mm (16.93 in)	•••
Spring rate, STD (K1)	2.84 N/mm (0.29 kg/mm, 16.2 lb/in) (YZ85)	•••
	2.94 N/mm (0.30 kg/mm, 16.8 lb/in) (YZ85LW)	•••
Spring stroke (K1)	0 ~ 275 mm (0 ~ 10.82 in)	•••
Inner tube outer diameter	36 mm (1.42 in)	•••
Inner tube bending limit	•••	0.2 mm (0.008 in)
Optional spring available	Yes	•••
Fork oil		
Recommended oil	Suspension oil "01"	•••
Quantity (each front fork leg)	318 cm ³ (11.2 Imp oz, 10.8 US oz)	•••
Level (from the top of the outer tube, with the outer tube fully compressed, and without the fork spring)	90 mm (3.54 in)	•••
Rebound damping adjusting positions		
Minimum*	20	•••
Standard*	7	•••
Maximum*	1	•••
Compression damping adjusting positions		
Minimum*	20	•••
Standard*	10 (YZ85) 9 (YZ85LW)	•••
Maximum*	1	•••
*from the fully turned-in position		

CHASSIS SPECIFICATIONS

SPEC



Item	Standard	Limit
Rear suspension		
Suspension type	Swingarm (link type monocross suspension)	•••
Rear shock absorber assembly type	Coil spring/gas, oil damper	•••
Rear shock absorber assembly travel	102 mm (4.02 in)	•••
Spring		
Free length	220 mm (8.66 in)	•••
Installed length	215 mm (8.46 in) (YZ85)	•••
	212 mm (8.35 in) (YZ85LW for EUR)	•••
Spring rate, STD (K1)	207 mm (8.15 in) (YZ85LW for AUS, NZL)	•••
	49.0 N/mm (5.00 kg/mm, 280.0 lb/in) (YZ85)	•••
	47.0 N/mm (4.80 kg/mm, 268.2 lb/in) (YZ85LW for EUR)	•••
Spring stroke, STD (K1)	51.0 N/mm (5.20 kg/mm, 291.1 lb/in) (YZ85LW for AUS, NZL)	•••
	102 mm (4.02 in)	•••
Optional spring available	Yes	•••
Standard spring preload gas/air pressure	1,000 kPa (10.0 kg/cm ² , 142 psi)	•••
Rebound damping adjusting positions		
Minimum*	20	•••
Standard*	6 (YZ85)	•••
	12 (YZ85LW for EUR)	•••
	7 (YZ85LW for AUS, NZL)	•••
Maximum*	1	•••
Compression damping adjusting positions		
Minimum*	20	•••
Standard*	9 (YZ85)	•••
	12 (YZ85LW for EUR)	•••
	7 (YZ85LW for AUS, NZL)	•••
Maximum*	1	•••
*from the fully turned-in position		
Swingarm		
Free play (at the end of the swingarm)		
Radial	•••	1.0 mm (0.04 in)
Drive chain		
Model (manufacturer)	DID428DS (DAIDO)	•••
Link quantity	117 links + joint (YZ85)	•••
	123 links + joint (YZ85LW)	•••
Drive chain slack	35.0 ~ 45.0 mm (1.38 ~ 1.77 in)	•••
Maximum 15-link section	•••	194.3 mm (7.65 in)

ELECTRICAL SPECIFICATIONS

SPEC



ELECTRICAL SPECIFICATIONS

Item	Standard	Limit
Ignition system		
Ignition system type	CDI	•••
Ignition timing (B.T.D.C.)	0.9 mm (0.035 in)	•••
Advancer type	Digital	•••
C.D.I.		
Magneto model (manufacturer)	5PA-01 (YAMAHA)	•••
Pickup coil resistance (color)	248 ~ 372 Ω at 20 °C (68 °F) (W/L-W/R)	•••
Charging coil 1 resistance (color)	720 ~ 1,080 Ω at 20 °C (68 °F) (G/W-B/R)	•••
Charging coil 2 resistance (color)	44 ~ 66 Ω at 20 °C (68 °F) (B-G/L)	•••
C.D.I. unit model (manufacturer)	5PA-01 (YAMAHA)	•••
Ignition coils		
Model (manufacturer)	2JN (YAMAHA)	•••
Minimum ignition spark gap	6 mm (0.24 in)	•••
Primary coil resistance	0.18 ~ 0.28 Ω at 20 °C (68 °F)	•••
Secondary coil resistance	6.3 ~ 9.5 k Ω at 20 °C (68 °F)	•••
Spark plug cap		
Material	Resin	•••
Resistance	5 k Ω	•••

CONVERSION TABLE/ GENERAL TIGHTENING TORQUE SPECIFICATIONS



EAS00028

CONVERSION TABLE

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

METRIC		MULTIPLIER	=	IMPERIAL
** mm	×	0.03937	=	** in
2 mm	×	0.03937	=	0.08 in


CONVERSION TABLE

METRIC TO IMPERIAL			
	Metric unit	Multiplier	Imperial unit
Tightening torque	m•kg	7.233	ft•lb
	m•kg	86.794	in•lb
	cm•kg	0.0723	ft•lb
	cm•kg	0.8679	in•lb
Weight	kg	2.205	lb
	g	0.03527	oz
Speed	km/hr	0.6214	mph
Distance	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume/ Capacity	cc (cm ³)	0.03527	oz (IMP liq.)
	cc (cm ³)	0.06102	cu•in
	lt (liter)	0.8799	qt (IMP liq.)
	lt (liter)	0.2199	gal (IMP liq.)
Misc.	kg/mm	55.997	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade (°C)	9/5 + 32	Fahrenheit (°F)

EAS00030

GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



A: Distance between flats

B: Outside thread diameter

A (nut)	B (bolt)	General tightening torques		
		Nm	m•kg	ft•lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94

TIGHTENING TORQUES

SPEC



TIGHTENING TORQUES ENGINE TIGHTENING TORQUES

Item	Fastener	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m•kg	ft•lb	
Spark plug	—	M14	1	20	2.0	14	
Cylinder head	Nut	M8	4	30	3.0	22	
	Stud bolt	M8	4	13	1.3	9.4	
Cylinder	Nut	M8	4	28	2.8	20	
	Studbolt	M8	4	13	1.3	9.4	
Water pump impeller	—	M8	1	14	1.4	10	
Coolant drain bolt	Bolt	M6	1	10	1.0	7.2	
Water pump housing	Bolt	M6	2	10	1.0	7.2	
Radiator hose clamp	Clamp	M6	4	1	0.1	0.7	
Air filter element	Bolt	M6	1	2	0.2	1.4	
Carburetor joint	Bolt	M6	4	8	0.8	5.8	
Reed valve	Screw	M3	4	1	0.1	0.7	
Exhaust pipe	Bolt	M6	2	12	1.2	8.7	
Exhaust pipe stay	Bolt	M6	1	12	1.2	8.7	
Silencer	Bolt	M6	1	12	1.2	8.7	
Fiber (silencer)	Bolt	M6	2	12	1.2	8.7	
Crankcase	Screw	M6	11	8	0.8	5.8	
Left crankcase cover	Screw	M6	4	5	0.5	3.6	
Right crankcase cover	Bolt	M6	4	10	1.0	7.2	
Right crankcase cover	Bolt	M6	1	10	1.0	7.2	
Clutch cover	Bolt	M6	6	10	1.0	7.2	
Transmission oil drain bolt	Bolt	M8	1	10	1.0	7.2	
Kickstarter crank	Bolt	M6	1	10	1.0	7.2	
Primary drive gear	Nut	M12	1	79	7.9	57	
Clutch boss	Nut	M12	1	70	7.0	51	
Clutch spring	Bolt	M5	5	6	0.6	4.3	
Drive sprocket	Nut	M16	1	60	6.0	43	
Crankcase bearing stopper	Screw	M6	2	8	0.8	5.8	
Crankcase oil seal holder	Bolt	M8	1	20	2.0	14	
Shift pedal	Bolt	M6	1	10	1.0	7.2	
Stator assembly	Screw	M6	2	8	0.8	5.8	
Rotor	Nut	M10	1	33	3.3	24	

TIGHTENING TORQUES

SPEC



CHASSIS TIGHTENING TORQUES

Item	Fastener	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m•kg	ft•lb	
Upper bracket and outer tube	Bolt	M8	2	22	2.2	16	
Lower bracket and outer tube	Bolt	M8	4	20	2.0	14	
Upper bracket and steering stem	Nut	M22	1	125	12.5	90	
Handlebar holder and upper bracket	Bolt	M8	4	27	2.7	20	
Steering stem and steering ring nut	Nut	M25	1	See NOTE.			
Front fork and cap bolt	Bolt	M40	2	28	2.8	20	
Front fork and base valve	—	M22	2	55	5.5	40	
Cap bolt and damper rod	Nut	M10	2	15	1.5	11	
Front fork bleed screw and cap bolt	Bolt	M5	2	1	0.1	0.7	
Front fork and front fork protector	Bolt	M6	6	7	0.7	5.1	
Front fork and brake hose guide	Screw	M5	1	4	0.4	2.9	
Front fork and brake hose holder	Bolt	M6	1	10	1.0	7.2	
Throttle grip cap	Screw	M5	2	4	0.4	2.9	
Throttle cable cap	Screw	M4	2	1	0.1	0.7	
Front brake master cylinder	Bolt	M6	2	9	0.9	6.5	
Brake lever mounting bolt	Bolt	M6	1	6	0.6	4.3	
Brake lever mounting nut	Nut	M6	1	6	0.6	4.3	
Brake lever position locknut	Nut	M6	1	5	0.5	3.6	
Clutch lever holder	Bolt	M5	2	4	0.4	2.9	
Front brake master cylinder cap	Screw	M4	2	2	0.2	1.4	
Front brake hose union bolt	Bolt	M10	2	26	2.6	19	
Front fork and brake caliper bracket	Bolt	M8	2	30	3.0	22	
Brake caliper support bolt	Bolt	M8	1	23	2.3	17	
Front brake caliper and bleed screw	Bolt	M7	1	6	0.6	4.3	
Rear brake caliper and brake caliper bracket	Bolt	M8	2	23	2.3	17	
Rear brake caliper and pad pin	Bolt	M10	2	18	1.8	13	
Rear brake caliper and bleed screw	Screw	M8	1	6	0.6	4.3	
Front wheel axle and axle nut	Nut	M12	1	70	7.0	51	
Front brake disc	Bolt	M6	3	12	1.2	8.7	
Rear brake disc	Bolt	M6	4	12	1.2	8.7	
Rear brake master cylinder	Bolt	M6	2	10	1.0	7.2	
Rear brake reservoir tank	Bolt	M6	1	10	1.0	7.2	
Rear brake hose union bolt	Bolt	M10	2	26	2.6	19	
Rear wheel axle and axle nut	Nut	M14	1	90	9.0	65	
Nipple (spoke)	—	—	64	3	0.3	2.2	
Rear wheel sprocket	Nut	M8	4	42	4.2	30	
Rear brake caliper protector	Bolt	M6	1	10	1.0	7.2	
Drive chain puller adjust locknut	Nut	M8	2	16	1.6	12	
Engine and frame (front)	Nut	M10	1	69	6.9	50	
Engine and frame (lower)	Nut	M10	1	69	6.9	50	
Pivot shaft and nut	Nut	M12	1	63	6.3	46	
Relay arm and frame	Nut	M10	1	54	5.4	39	

TIGHTENING TORQUES

SPEC



Item	Fastener	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m•kg	ft•lb	
Relay arm and connecting rod	Nut	M12	1	53	5.3	38	
Connecting rod and swingarm	Nut	M12	1	53	5.3	38	
Rear shock absorber and frame	Nut	M10	1	36	3.6	26	
Rear shock absorber and relay arm	Bolt	M10	1	36	3.6	26	
Rear frame (upper)	Bolt	M8	1	26	2.6	19	
Rear frame (lower)	Bolt	M8	2	16	1.6	12	
Swingarm and brake hose holder	Screw	M5	4	1	0.1	0.7	
Drive chain support	Nut	M8	2	16	1.6	12	
Drive chain support cover	Nut	M6	1	7	0.7	5.1	
Drive chain guide and swingarm	Bolt	M6	2	10	1.0	7.2	
Fuel tank	Bolt	M6	2	7	0.7	5.1	
Fuel cock	Screw	M6	2	4	0.4	2.9	
Fuel tank bracket and fuel tank	Bolt	M6	4	7	0.7	5.1	
Seat set bracket and fuel tank	Screw	M6	1	7	0.7	5.1	
Air scoop	Bolt	M6	3	4	0.4	2.9	
Front fender	Bolt	M6	4	7	0.7	5.1	
Rear fender	Bolt	M6	4	7	0.7	5.1	
Flap guard	Bolt	M6	2	7	0.7	5.1	
Side cover	Bolt	M6	2	7	0.7	5.1	
Seat	Bolt	M6	2	7	0.7	5.1	
Number plate	Bolt	M6	1	7	0.7	5.1	
Ignition coil	Bolt	M6	2	7	0.7	5.1	

NOTE:

1. First, tighten the steering nut approximately 38 Nm (3.8 m•kg, 27 ft•lb) by using the steering nut wrench, then loosen the steering nut one turn.
2. Retighten the steering nut 4 Nm (0.4 m•kg, 2.9 ft•lb).

LUBRICATION POINTS AND LUBRICANT TYPES

SPEC



EAS00031

LUBRICATION POINTS AND LUBRICANT TYPES

ENGINE

Lubrication point	Lubricant
Oil seal lips	
O-rings	
Bearings	
Crankshaft pins	
Piston surfaces	
Piston pins	
Water pump impeller shaft	
Kick shaft	
Kick shaft stopper	
Kick idle gear inner surface	
Primary driven gear	
Push rod and push lever (upper)	
Push lever (lower)	
Transmission wheel gears inner surface	
Transmission pinion gears	
Shift forks and shift fork guide bers	
Shift shaft	
Shift dram	
Crankcase mating surface	Yamaha bond No.1215

EAS00032

CHASSIS


Lubrication point	Lubricant
Steeling bearings and bearing race (upper and lower)	
Brake lever pivoting point and metal-to-metal moving parts	
Clutch lever pivoting point and metal-to-metal moving parts	
Throttle tube guide inner surface	
Rear brake pedal	
Swing arm bearing and bushing inner surface	
Swingarm oil seal , dust seal and bushing	
Pivot shaft	
Reray arm oil seal, bearing, bushing, collar and bolt surface	
Connecting rod oil seal, bearing, bushing and bolt surface	
Front wheel oil seal (left and right)	
Front wheel axle shaft	
Front wheel collar	
Rear wheel oil seal (left and right)	
Rear wheel axle shaft	
Rear wheel collar	



EAS00035

CABLE ROUTING

- ① Cable guide
- ② Brake hose
- ③ Throttle cable
- ④ Fuel tank breather hose
- ⑤ Engine stop switch lead
- ⑥ Ground lead
- ⑦ Ignition coil
- ⑧ Primary coil lead (orange color)
- ⑨ Damper
- ⑩ Clamp
- ⑪ Air vent hoses
- ⑫ CDI magneto lead
- ⑬ Carburetor overflow hose
- ⑭ Transmission oil breather hose
- ⑮ Radiator breather hose
- ⑯ Clutch cable
- ⑰ Spark plug lead
- ⑱ Radiator hose
- ⑲ Brake hose holder




CABLE ROUTING

SPEC



- A** Pass the fuel tank breather hose between the handlebar and tension bar, then insert its end into the hole of the steering stem.
- B** Fasten the ground lead together with the ignition coil.
- C** Insert the primary coil lead (orange color) in the ignition coil.
- D** Pass the transmission oil breather hose through the wire holder located at the right side of the vehicle. Route the air vent hose and carburetor overflow hose from the left side of the vehicle.
- E** Do not flatten out the radiator breather hose.
- F** Securely install the spark plug cap to the spark plug. Route the spark plug lead by the inner side of the vehicle than the radiator hose and throttle cable.
- G** Clamp the brake hose with the brake hose holder.
- H** Fit the brake hose into the guides of the protector.
- I** 40 mm (1.57 in)




CABLE ROUTING

SPEC




- ① Sub-wire harness
- ② CDI unit
- ③ Ignition coil
- ④ Clutch cable
- ⑤ Cable guide
- ⑥ Transmission oil breather hose
- ⑦ CDI unit band
- ⑧ Clamp
- ⑨ Brake hose
- ⑩ Brake hose holder
- ⑪ Brake fluid reservoir hose
- ⑫ Reservoir tank
- ⑬ Brake master cylinder

- A** Route the clutch cable in front of the throttle cable.
- B** Pass the transmission oil breather hose through the hose guide.
- C** Clamp it between these parts.
- D** Clamp it using the white PVC tape as a guide.
- E** Pass the sub-wire harness on the left side of the CDI unit.
- F** Cut the tip of the clamp near the position of chain double-dashed line.
- G** Tighten the sub-wire harness to the CDI unit. Position the lock section under the CDI unit.
- H** Route the reservoir tank hose by the outer side of the vehicle than the brake hose.
- I** Pass the brake fluid reservoir hose through the cable guides.





- J** Install the clip pointing the clamp section to the rear side.
- K** Touch the brake pipe to the stopper.
- L** When installing the brake hose, install it so that the bend section of the brake hose attachment is pointed in the direction as shown in the illustration.




CABLE ROUTING

SPEC



- ① Master cylinder
- ② Throttle cable
- ③ Clutch cable
- ④ Clamp
- ⑤ Engine stop switch lead
- ⑥ Brake hose
- ⑦ Cable guide

- A** This is the number plate attaching section. The clutch cable and throttle cable shall be routed crossways above the number plate attaching section. At this time, make sure to route the clutch cable to the front side of the throttle cable.
- B** Route the clutch cable in front of the throttle cable.
- C** Fasten the engine stop switch lead to the handlebar with the plastic band.
- D** Pass the brake hose in front of the number plate.
- E** Vertical direction
- F** $40^\circ \pm 10^\circ$



CHAPTER 3

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION	3-1
PERIODIC MAINTENANCE AND LUBRICATION INTERVALS	3-1
SEAT, SIDE COVERS AND FUEL TANK	3-3
ENGINE	3-5
ADJUSTING THE PILOT AIR SCREW	3-5
ADJUSTING THE ENGINE IDLING SPEED	3-5
ADJUSTING THE THROTTLE CABLE FREE PLAY	3-6
CHECKING THE SPARK PLUG	3-7
CHECKING THE IGNITION TIMING	3-8
CHANGING THE TRANSMISSION OIL	3-9
ADJUSTING THE CLUTCH CABLE FREE PLAY	3-10
CLEANING THE AIR FILTER ELEMENT	3-10
CHECKING THE CARBURETOR JOINT	3-12
CHECKING THE HOSES	3-12
CHECKING THE CRANKCASE BREATHER HOSE	3-13
CHECKING THE EXHAUST SYSTEM	3-13
CHECKING THE COOLANT LEVEL	3-14
CHECKING THE COOLING SYSTEM	3-15
CHANGING THE COOLANT	3-15
CHASSIS	3-17
ADJUSTING THE FRONT BRAKE	3-17
ADJUSTING THE REAR BRAKE	3-18
CHECKING THE BRAKE FLUID LEVEL	3-19
CHECKING THE FRONT AND REAR BRAKE PADS	3-20
CHECKING THE FRONT AND REAR BRAKE HOSES	3-20
BLEEDING THE HYDRAULIC BRAKE SYSTEM	3-21
ADJUSTING THE SHIFT PEDAL	3-22
ADJUSTING THE DRIVE CHAIN SLACK	3-22
LUBRICATING THE DRIVE CHAIN	3-24
CHECKING AND ADJUSTING THE STEERING HEAD	3-24
CHECKING THE FRONT FORK	3-25
ADJUSTING THE FRONT FORK LEGS	3-26
ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY	3-28
CHECKING THE TIRES	3-30
CHECKING AND TIGHTENING THE SPOKES	3-32
LUBRICATING THE LEVERS AND PEDALS	3-32
LUBRICATING THE REAR SUSPENSION	3-32

INTRODUCTION/PERIODIC MAINTENANCE AND LUBRICATION INTERVALS



EAS00036

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. If followed, these preventive maintenance procedures will ensure more reliable vehicle operation, a longer service life and reduce the need for costly overhaul work. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

EAS00037

PERIODIC MAINTENANCE AND LUBRICATION INTERVALS

NOTE:

- From the seventh race, repeat the maintenance intervals starting from “Every race”.
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

NO.	ITEM	ROUTINE	After break-in	Every race	Every third race	Every fifth race	As required
1	* Piston	• Check piston for carbon deposits and cracks or damage. • Clean.	√	√			
		• Replace.				√	√
2	* Piston rings	• Check piston ring end gap and rings for damage.	√	√			
		• Replace.			√		√
3	* Piston pin and small end bearing	• Check piston pin and small end bearing for damage.		√			
		• Replace.					√
4	* Cylinder head	• Check cylinder head for carbon deposits. • Clean.	√	√			
		• Check cylinder head gasket for damage. • Tighten cylinder head bolts if necessary.	√	√			
		• Replace cylinder head gasket.					√
5	* Cylinder	• Check cylinder for score marks or wear. • Clean.	√	√			
		• Replace.					√
6	* Clutch	• Check clutch housing, friction plates, clutch plates and clutch springs for wear or damage. • Adjust.	√	√			
		• Replace.					√
7	* Transmission	• Change the transmission oil.	√			√	
		• Check transmission for damage.					√
		• Replace bearings.					√
8	* Shift forks, guide bars, shift cam	• Check all parts for wear and damage. • Replace if necessary.					√
9	* Rotor nut (flywheel magneto)	• Tighten.	√			√	
10	* Kickstarter system	• Check idle gear for damage. • Replace if necessary.					√
11	* Exhaust system	• Check exhaust pipe and muffler for carbon deposits.	√	√			
		• Clean.				√	
12	* Crankshaft	• Check crankshaft for carbon deposits and damage.				√	√
		• Clean.				√	√
13	* Carburetor	• Check carburetor settings and for obstructions.	√	√			
		• Adjust and clean.	√	√			
14	Spark plug	• Check condition.	√	√			
		• Clean and regap.					
		• Replace.					√
15	Drive chain	• Check chain slack, alignment and condition. • Adjust and thoroughly lubricate chain with Yamaha chain and cable lube or equivalent.	√	√			
		• Replace.					√

PERIODIC MAINTENANCE AND LUBRICATION INTERVALS




NO.	ITEM	ROUTINE	After break-in	Every race	Every third race	Every fifth race	As required
16	* Cooling system	• Check coolant level and for leakage.	√	√			
		• Check hoses for cracks or damage.		√			
		• Check radiator cap spring operation.					√
		• Change coolant.	Every 2 years				
17	* Chassis fasteners	• Check all chassis fitting and fasteners. • Correct or tighten if necessary.	√	√			
18	* Air filter element	• Clean.	√	√			
		• Replace.					√
19	* Frame	• Clean and check for damage.	√	√			
20	* Fuel line	• Clean and check for leakage.	√		√		
21	* Brakes	• Adjust lever position and pedal height. • Lubricate pivot points. • Check brake disk surface. • Check fluid level and for leakage. • Tighten brake disk bolts, caliper bolts, master cylinder bolts and union bolts.	√	√			
		• Replace brake pads.					√
		• Replace brake fluid.	Every year				
22	* Front fork	• Check operation and for oil leakage. • Adjust if necessary. • Clean dust seal and lubricate with lithium-soap-based grease.	√	√			
		• Replace fork oil.	√			√	
		• Replace oil seals.					√
23	* Shock absorber assembly	• Check operation and adjust. • Tighten if necessary.	√	√			
		• Lubricate with molybdenum disulfide grease.			√		√ (After washing the vehicle or riding in the rain)
24	* Drive chain roller and support guide	• Check for wear or damage. • Replace if necessary.					√
25	* Rear suspension	• Check operation and tighten if necessary.	√	√			
		• Lubricate with molybdenum disulfide grease.	√	√			
26	* Steering head	• Check operation, free play, and tighten if necessary.	√	√			
		• Clean and lubricate with lithium-soap-based grease.				√	
		• Replace bearings.					√
27	* Tires and wheels	• Check tire air pressure, wheel runout, spokes for looseness, and tires for wear.	√	√			
		• Tighten sprocket bolts if necessary.	√	√			
		• Check wheel bearings for looseness.			√		
		• Lubricate wheel bearings with lithium-soap-based grease.			√		
		• Replace wheel bearings.					√
28	* Moving parts and cables	• Lubricate.	√	√			
29	* Throttle grip housing and cable	• Check operation and free play. • Adjust the throttle cable free play if necessary. • Lubricate the throttle grip housing and cable.	√	√			

NOTE: _____

- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level.
 - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.


EAS00042

SEAT, SIDE COVERS AND FUEL TANK



Order	Job/Part	Q'ty	Remarks
	Removing the seat, side covers and fuel tank		Remove the parts in the order listed.
1	Seat	1	
2	Side covers (left and right)	2	
3	Air scoop	1	
4	Fuel pipe	1	Disconnect.
5	Fuel cock	1	
6	O-ring	1	
7	Grommet	2	
8	Collar	2	
9	Hose	1	Disconnect.
10	Joint pipe	1	
11	Hose	1	Disconnect.
12	Fuel tank cap	1	
13	Fuel tank	1	

SEAT, SIDE COVERS AND FUEL TANK



Order	Job/Part	Q'ty	Remarks
14	Number plate	1	For installation, reverse the removal procedure.

EAS00058


ADJUSTING THE THROTTLE CABLE FREE PLAY

NOTE:


Prior to adjusting the throttle cable free play, the engine idling speed should be adjusted.

1. Check:

- throttle cable free play (a)
Out of specification → Adjust.



**Throttle cable free play
(at the flange of the throttle grip)**
3.0 ~ 5.0 mm (0.12 ~ 0.20 in)



2. Adjust:

- throttle cable free play



Handlebar side

- Loosen the locknut (1).
- Turn the adjusting nut (2) in direction (a) or (b) until the specified throttle cable free play is obtained.

Direction (a)	Throttle cable free play is increased.
Direction (b)	Throttle cable free play is decreased.

- Tighten the locknut.

WARNING

After adjusting the throttle cable free play, start the engine and turn the handlebar to the right or left to ensure that this does not cause the engine idling speed to change.



EAS00060

CHECKING THE SPARK PLUG

1. Disconnect:
 - spark plug cap
2. Remove:
 - spark plug

CAUTION:

Before removing the spark plug, blow away any dirt accumulated in the spark plug well with compressed air to prevent it from falling into the cylinder.

3. Check:
 - spark plug type
Incorrect → Change.



Spark plug type (manufacturer)
BR10EG (NGK)

4. Check:
 - electrode ①
Damage/wear → Replace the spark plug.
 - insulator ②
Abnormal color → Replace the spark plug.
Normal color is medium-to-light tan.
5. Clean:
 - spark plug
(with a spark plug cleaner or wire brush)
6. Measure:
 - spark plug gap ③
(with a wire thickness gauge)
Out of specification → Regap.



Spark plug gap
0.5 ~ 0.6 mm (0.0197 ~ 0.0236 in)

7. Install:
 - spark plug




Spark plug
20 Nm (2.0 m•kg, 14 ft•lb)


NOTE:

Before installing the spark plug, clean the spark plug and gasket surface.

8. Connect:
 - spark plug cap



CHECKING THE IGNITION TIMING/ CHANGING THE TRANSMISSION OIL



Screw (stator)
8 Nm (0.8 m•kg, 5.8 ft•lb)

6. Check:
- ignition timing
- Re-check the ignition timing.

EAS00074

CHANGING THE TRANSMISSION OIL

1. Start the engine, warm it up for several minutes, and then turn it off.
2. Place the vehicle on a level place and hold it on upright position by placing the suitable stand under the engine.
3. Place a container under the transmission oil drain bolt.
4. Remove:
 - transmission oil filler cap ①
 - transmission drain bolt ②
5. Drain:
 - transmission oil (completely from the crankcase)
6. Install:
 - transmission oil drain bolt gasket **New**
 - transmission oil drain bolt (along with the new gasket)


 **10 Nm (1.0 m•kg, 7.2 ft•lb)**

7. Fill:
 - transmission oil (with the specified amount of the recommended transmission oil)




Quantity
Total amount
0.5 L (0.44 Imp qt, 0.53 US qt)

8. Install:
 - transmission oil filler cap
9. Start the engine, warm it up for several minutes, and then turn it off.
10. Check:
 - oil leakage



ADJUSTING THE CLUTCH CABLE FREE PLAY/ CLEANING THE AIR FILTER ELEMENT




EAS00081

ADJUSTING THE CLUTCH CABLE FREE PLAY

1. Check:
 - clutch cable free play (a)
 Out of specification → Adjust.



**Clutch cable free play
(at the end of the clutch lever)**
10.0 ~ 15.0 mm (0.39 ~ 0.59 in)




2. Adjust:
 - clutch cable free play



- a. Loosen the locknut (1).
- b. Turn the adjusting nut (2) in direction (a) or (b) until the specified clutch cable free play is obtained.

Direction (a)	Clutch cable free play is increased.
Direction (b)	Clutch cable free play is decreased.

- c. Tighten the locknut.




EAS00090

CLEANING THE AIR FILTER ELEMENT

1. Remove:
 - seat
 - side covers (left and right)
 Refer to "SEAT, SIDE COVERS AND FUEL TANK".
2. Remove:
 - air filter case cover (1)





- a. Set the air filter case cover as shown, and install it to the seat rail of the rear frame while rotating air filter case cover in the direction of the arrow.
- b. Using a conventional screwdriver, hold up the front of the air filter case cover. Then engage the groove (a) in the cover over the air filter case edge (b).



CLEANING THE AIR FILTER ELEMENT

CHK
ADJ



- fitting bolt ②
- washer ③
- air filter guide ④
- air filter element ⑤

CAUTION:

Never operate the engine without the air filter element installed. Unfiltered air will cause rapid wear of engine parts and may damage the engine. Operating the engine without the air filter element will also affect the carburetor tuning, leading to poor engine performance and possible overheating.

3. Clean:

- air filter element
(with solvent)

NOTE:

After cleaning, remove the remaining solvent by squeezing the element.

CAUTION:

- Do not twist the element when squeezing the element.
- Leaving too much of solvent in the element may result in poor starting.

4. Check:


- air filter element
Damage → Replace.

5. Apply:

- foam-air-filter oil or equivalent oil
To the element.

NOTE:

Squeeze out the excess oil. Element should be wet but not dripping.




6. Install:


- air filter guide ①
- air filter element ②

CLEANING THE AIR FILTER ELEMENT/CHECKING THE CARBURETOR JOINT/CHECKING THE HOSES

CHK
ADJ



7. Apply:
- lithium-soap-base grease
- On the matching surface (a) on air filter element.




8. Install:
- air filter element (1)
 - washer
 - fitting bolt

2 Nm (0.2 m•kg, 1.4 ft•lb)

NOTE:

- Install the air filter element with its projection (a) facing upward.
- Make sure the air filter element is properly installed in the air filter case.



EAS00094


CHECKING THE CARBURETOR JOINT

1. Remove:
 - carburetor

Refer to "CARBURETOR" in chapter 7.
2. Check:
 - carburetor joint (1)

Cracks/damage → Replace.

Refer to "CARBURETOR" in chapter 7.
3. Install:
 - carburetor joint
 - carburetor



EAS00096

CHECKING THE HOSES


The following procedure applies to all of the fuel and vacuum hoses.

1. Check:
 - fuel hose
 - carburetor breather hose (1)
 - over flow hose (2)

Cracks/damage → Replace.

Loose connection → Connect properly.

CHECKING THE CRANKCASE BREATHER HOSE/ CHECKING THE EXHAUST SYSTEM




EAS00098

CHECKING THE CRANKCASE BREATHER HOSE

1. Check:
 - crankcase breather hose ①
 - Cracks/damage → Replace.
 - Loose connection → Connect properly.

CAUTION:

Make sure the crankcase breather hose is routed correctly.



EAS00100

CHECKING THE EXHAUST SYSTEM

The following procedure applies to all of the exhaust pipes, mufflers and gaskets.

1. Remove:
 - seat
 - side cover (right)

Refer to “SEAT, SIDE COVERS AND FUEL TANK”.
2. Remove:
 - silencer ①
 - exhaust joint ②
 - exhaust pipe ③
 - gasket ④
3. Check:
 - silencer ①
 - exhaust joint ②
 - exhaust pipe ③


Cracks/damage → Replace.
4. Install:
 - gasket ④ **New**
 - exhaust pipe ③
 - exhaust joint ②
 - silencer ①



Exhaust pipe bolt ⑤
12 Nm (1.2 m•kg, 8.7 ft•lb)
Silencer bolt ⑥
12 Nm (1.2 m•kg, 8.7 ft•lb)

CHECKING THE COOLANT LEVEL

CHK
ADJ



EAS00102

CHECKING THE COOLANT LEVEL

1. Stand the vehicle on a level surface.

NOTE:

- Place the vehicle on a suitable stand.
- Make sure the vehicle is upright.


2. Remove:

- radiator cap ①

CAUTION:

A hot radiator is under pressure. Therefore, do not remove the radiator cap when the engine is hot. Scalding hot fluid and steam may be blown out, which could cause serious injury. When the engine has cooled, open the radiator cap as follows:

Place a thick rag or a towel over the radiator cap and slowly turn the radiator cap counterclockwise toward the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the radiator cap and turn it counterclockwise to remove.



3. Check:

- coolant level
Coolant level ② low → Add coolant.

CAUTION:

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.

4. Start the engine, warm it up for several minutes, and then turn it off.

5. Check:

- coolant level

NOTE:


Before checking the coolant level, wait a few minutes until it settles.

6. Install:

- radiator cap

CHECKING THE COOLING SYSTEM/ CHANGING THE COOLANT


CHK
ADJ



EAS00104

CHECKING THE COOLING SYSTEM

1. Remove:
 - air scoop
Refer to “SEAT, SIDE COVERS AND FUEL TANK”.
2. Check:
 - radiator ①
 - radiator hose joint ②
 - radiator hose ③
Cracks/damage → Replace.
Refer to “COOLING SYSTEM” in chapter 6.
3. Install:
 - air scoop



EAS00105

CHANGING THE COOLANT

1. Remove:
 - coolant drain bolt ①
2. Remove:
 - radiator cap

⚠ WARNING

A hot radiator is under pressure. Therefore, do not remove the radiator cap when the engine is hot. Scalding hot fluid and steam may be blown out, which could cause serious injury. When the engine has cooled, open the radiator cap as follows:

Place a thick rag or a towel over the radiator cap and slowly turn the radiator cap counterclockwise toward the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the radiator cap and turn it counterclockwise to remove.


3. Drain:
 - coolant
4. Install:
 - copper washer **New**
 - coolant drain bolt



Coolant drain bolt
10 Nm (1.0 m•Kg, 7.2 ft•lb)

CHANGING THE COOLANT

CHK
ADJ



5. Fill:
 - coolant
(with the specified amount of the recommended coolant)



Recommended antifreeze
High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines
Mixing ratio
1:1 (antifreeze:water)
Quantity
Total amount
0.54 L (0.48 Imp qt, 0.57 US qt)

Handling notes for coolant

Coolant is potentially harmful and should be handled with special care.

⚠ WARNING

- If coolant splashes in your eyes, thoroughly wash them with water and consult a doctor.
- If coolant splashes on your clothes, quickly wash it away with water and then with soap and water.
- If coolant is swallowed, induce vomiting and get immediate medical attention.

CAUTION:

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.
- If coolant comes into contact with painted surfaces, immediately wash them with water.
- Do not mix different types of antifreeze.

6. Install:
 - radiator cap
7. Start the engine, warm it up for several minutes, and then stop it.

CHECKING THE BRAKE FLUID LEVEL



EAS00115

CHECKING THE BRAKE FLUID LEVEL

1. Stand the vehicle on a level surface.


NOTE:

- Place the vehicle on a suitable stand.
- Make sure the vehicle is upright.

2. Check:

- brake fluid level

Below the minimum level mark (a) → Add the recommended brake fluid to the proper level.



- A Front brake
- B Rear brake

WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.




CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

NOTE:

In order to ensure a correct reading of the brake fluid level, make sure the top of the brake fluid reservoir is horizontal.

CHECKING THE FRONT AND REAR BRAKE PADS/ CHECKING THE FRONT AND REAR BRAKE HOSES



EAS00118

CHECKING THE FRONT AND REAR BRAKE PADS

The following procedure applies to all of the brake pads.

1. Check:

- front brake pad
- rear brake pad

Wear indicators (a) or (b) almost touch the brake disc → Replace the brake pads as a set.

Refer to “REPLACING THE FRONT BRAKE PADS” and “REPLACING THE REAR BRAKE PADS” in chapter 4.



Brake pad wear limit

- (a) 0.8 mm (0.032 in)
- (b) 1.0 mm (0.039 in)

- [A] Front brake
- [B] Rear brake

EAS00131

CHECKING THE FRONT AND REAR BRAKE HOSES

The following procedure applies to all of the brake hoses and brake hose clamps.

1. Check:

- brake hose
Cracks/damage/wear → Replace.

2. Check:

- brake hose holder (1)
Loose → Tighten the holder bolt (2).

NOTE:

- Align the brake hose holder with the projection (a) on the front fork and clamp the brake hose.
- Pass the brake hose behind the rib (b) on the front fork.

3. Hold the vehicle upright and apply the brake several times.

4. Check:

- brake hose
Brake fluid leakage → Replace the damaged hose.
Refer to “FRONT AND REAR BRAKES” in chapter 4.

BLEEDING THE HYDRAULIC BRAKE SYSTEM/ADJUSTING THE SHIFT PEDAL/ADJUSTING THE DRIVE CHAIN SLACK




- i. Repeat steps (e) to (h) until all of the air bubbles have disappeared from the brake fluid in the plastic hose.
- j. Tighten the bleed screw to specification.

	<p>Bleed screw 6 Nm (0.6 m•kg, 4.3 ft•lb)</p>
---	--

- k. Fill the brake fluid reservoir to the proper level with the recommended brake fluid. Refer to “CHECKING THE BRAKE FLUID LEVEL”.

⚠ WARNING

After bleeding the hydraulic brake system, check the brake operation.



EAS00137

ADJUSTING THE SHIFT PEDAL

- 1. Adjust:
 - shift pedal ①



- a. Install the shift pedal with the bottom of the pedal outer diameter (a) as close to the center of the engine mounting bolt ② as possible.



EAS00138

ADJUSTING THE DRIVE CHAIN SLACK

NOTE:

The drive chain slack must be checked at the tightest point on the chain.



CAUTION:

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive chain slack within the specified limits.






EAS00143

LUBRICATING THE DRIVE CHAIN

The drive chain consists of many interacting parts. If the drive chain is not maintained properly, it will wear out quickly. Therefore, the drive chain should be serviced, especially when the vehicle is used in dusty areas.

Use only kerosene to clean the drive chain. Wipe the drive chain dry and thoroughly lubricate it with engine oil or chain lubricant that is suitable for non-O-ring chains.



EAS00147

CHECKING AND ADJUSTING THE STEERING HEAD

1. Stand the vehicle on a level surface.

⚠ WARNING



Securely support the vehicle so that there is no danger of it falling over.

NOTE:

Place the vehicle on a suitable stand so that the front wheel is elevated.

2. Check:
 - steering head
Grasp the bottom of the front fork legs and gently rock the front fork.
Binding/looseness → Adjust the steering head.
3. Remove:
 - handlebar
 - upper bracket
Refer to “HANDLEBAR” and “STEERING HEAD” in chapter 4.
4. Adjust:
 - steering head

CHECKING THE FRONT FORK/ ADJUSTING THE FRONT FORK LEGS



2. Check:
 - inner tube ①
Damage/scratches → Replace.
 - oil seal ②
Oil leakage → Replace.
3. Hold the vehicle upright and apply the front brake.
4. Check:
 - front fork operation
Push down hard on the handlebar several times and check if the front fork rebounds smoothly.
Rough movement → Repair.
Refer to “FRONT FORK” in chapter 4.

EAS00155

ADJUSTING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

⚠ WARNING

- **Always adjust both front fork legs evenly. Uneven adjustment can result in poor handling and loss of stability.**
- **Securely support the vehicle so that there is no danger of it falling over.**

Front fork internal pressure bleeding

NOTE:

If the front fork initial movement feels stiff during a run, bleed the front fork internal pressure.


1. Elevate the front wheel by placing a suitable stand under the engine.
2. Remove the air bleed screw ① and release the internal pressure from the front fork.
3. Install:

- air bleed screw  **1 Nm (0.1 m•kg, 0.7 ft•lb)**

Rebound damping


CAUTION:

Never go beyond the maximum or minimum adjustment positions.



ADJUSTING THE REAR SHOCK ABSORBER ASSEMBLY/ CHECKING THE TIRES

CHK
ADJ



NOTE:

This is the position which is back by the specific number of clicks from the fully turned-in position. (Which align the punch mark ③ on the adjuster with the punch mark ④ on the bracket.)

Adjusting positions

Minimum: 20 clicks in direction ⑥*

Standard (YZ85): 9 clicks in direction ⑥*

Standard (YZ85LW): 12 clicks in direction ⑥* (for EUR)

Standard (YZ85LW): 7 clicks in direction ⑥* (for AUS, NZL)

Maximum: 1 clicks in direction ⑥*

* with the adjusting knob fully turned-in direction ①



EAS00164

CHECKING THE TIRES

The following procedure applies to both of the tires.


1. Check:

- tire pressure

Out of specification → Regulate.

⚠ WARNING

- The tire pressure should only be checked and regulated when the tire temperature equals the ambient air temperature.
- The tire pressure and the suspension must be adjusted according to the total weight (including rider) and the anticipated riding speed.



Standard tire pressure:
100 kpa (1.0 kgf/cm², 15 psi)

⚠ WARNING

It is dangerous to ride with a worn-out tire. When the tire tread reaches the wear limit, replace the tire immediately.



2. Check:
- tire surfaces
Damage/wear → Replace the tire.

⚠ WARNING

- Do not use a tubeless tire on a wheel designed only for tube tires to avoid tire failure and personal injury from sudden deflation.
- When using tube tires, be sure to install the correct tube.
- Always replace a new tube tire and a new tube as a set.
- To avoid pinching the tube, make sure the wheel rim band and tube are centered in the wheel groove.
- Patching a punctured tube is not recommended. If it is absolutely necessary to do so, use great care and replace the tube as soon as possible with a good quality replacement.
- After extensive tests, the tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. The front and rear tires should always be by the same manufacturer and of the same design. No guarantee concerning handling characteristics can be given if a tire combination other than one approved by Yamaha is used on this vehicle.

Front tire

YZ85:

Manufacturer	Size	Model
DUNLOP	70/100-17 40M	D739FA (EUR, CAN) D756F (AUS, NZL)

YZ85LW:

Manufacturer	Size	Model
DUNLOP	70/100-19 42M	D756F



Rear tire

YZ85:

Manufacturer	Size	Model
DUNLOP	90/100-14 49M	D756

YZ85LW:

Manufacturer	Size	Model
DUNLOP	90/100-16 52M	D756



⚠ WARNING

New tires have a relatively low grip on the road surface until they have been slightly worn.

NOTE:

Align the mark ① with the valve installation point.

EAS00169

CHECKING AND TIGHTENING THE SPOKES

The following procedure applies to all of the spokes.

1. Check:

- spoke ①
Bends/damage → Replace.
Loose → Tighten.
Tap the spokes with a screwdriver.

NOTE:

A tight spoke will emit a clear, ringing tone; a loose spoke will sound flat.

2. Tighten:

- spoke (with a spoke wrench ②)

 **3 Nm (0.3 m•kg, 2.2 ft•lb)**

NOTE:

Be sure to tighten the spokes before and after break-in. After a practice or a race check spokes for looseness.

EAS00171

LUBRICATING THE LEVERS AND PEDALS

Lubricate the pivoting point and metal-to-metal moving parts of the levers and pedals.

	Recommended lubricant Lithium-soap-based grease
---	--

EAS00174

LUBRICATING THE REAR SUSPENSION

Lubricate the pivoting point and metal-to-metal moving parts of the rear suspension.

	Recommended lubricant Molybdenum disulfide grease
---	--

CHAPTER 4 CHASSIS


FRONT WHEEL AND BRAKE DISC	4-1
REMOVING THE FRONT WHEEL	4-3
CHECKING THE FRONT WHEEL.....	4-3
CHECKING THE BRAKE DISCS.....	4-6
INSTALLING THE FRONT WHEEL.....	4-7
REAR WHEEL AND BRAKE DISC	4-8
REAR WHEEL	4-8
REAR BRAKE DISC AND REAR WHEEL SPROCKET	4-10
REMOVING THE REAR WHEEL	4-12
CHECKING THE REAR WHEEL.....	4-13
CHECKING AND REPLACING THE REAR WHEEL SPROCKET ..	4-13
INSTALLING THE REAR WHEEL.....	4-14
FRONT AND REAR BRAKES	4-15
FRONT BRAKE PADS.....	4-15
REAR BRAKE PADS.....	4-16
REPLACING THE FRONT BRAKE PADS.....	4-17
REPLACING THE REAR BRAKE PADS.....	4-19
FRONT BRAKE MASTER CYLINDER	4-21
REAR BRAKE MASTER CYLINDER.....	4-23
DISASSEMBLING THE FRONT BRAKE MASTER CYLINDER	4-25
DISASSEMBLING THE REAR BRAKE MASTER CYLINDER	4-25
CHECKING THE FRONT AND REAR BRAKE MASTER CYLINDERS	4-26
ASSEMBLING AND INSTALLING THE FRONT BRAKE MASTER CYLINDER.....	4-27
ASSEMBLING THE REAR BRAKE MASTER CYLINDER	4-29
FRONT BRAKE CALIPER.....	4-31
REAR BRAKE CALIPER	4-33
DISASSEMBLING THE FRONT BRAKE CALIPER	4-35
DISASSEMBLING THE REAR BRAKE CALIPER.....	4-35
CHECKING THE FRONT AND REAR BRAKE CALIPERS.....	4-36
ASSEMBLING AND INSTALLING THE FRONT BRAKE CALIPER .	4-37
ASSEMBLING AND INSTALLING THE REAR BRAKE CALIPER ..	4-39
FRONT FORK	4-42
FRONT FORK LEGS.....	4-42
REMOVING THE FRONT FORK LEGS	4-45
DISASSEMBLING THE FRONT FORK LEGS	4-46
CHECKING THE FRONT FORK LEGS.....	4-47
ASSEMBLING THE FRONT FORK LEGS	4-48
INSTALLING THE FRONT FORK LEGS.....	4-54

HANDLEBAR	4-55
REMOVING THE HANDLEBAR	4-57
CHECKING THE HANDLEBAR.....	4-57
INSTALLING THE HANDLEBAR.....	4-57
STEERING HEAD	4-61
UNDER BRACKET	4-61
REMOVING THE LOWER BRACKET.....	4-62
CHECKING THE STEERING HEAD	4-62
INSTALLING THE STEERING HEAD	4-63
REAR SHOCK ABSORBER ASSEMBLY	4-65
HANDLING THE REAR SHOCK ABSORBER AND GAS CYLINDER.....	4-66
DISPOSING OF A REAR SHOCK ABSORBER AND GAS CYLINDER.....	4-66
REMOVING THE REAR SHOCK ABSORBER ASSEMBLY	4-67
CHECKING THE REAR SHOCK ABSORBER ASSEMBLY AND GAS CYLINDER	4-68
INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY	4-68
SWINGARM AND DRIVE CHAIN	4-70
REMOVING THE SWINGARM	4-72
REMOVING THE DRIVE CHAIN.....	4-73
CHECKING THE SWINGARM.....	4-73
CHECKING THE DRIVE CHAIN	4-74
CHECKING THE DRIVE CHAIN SUPPORT	4-76
INSTALLING THE SWINGARM.....	4-76
INSTALLING THE DRIVE CHAIN	4-78


EAS00512

CHASSIS


FRONT WHEEL AND BRAKE DISC



Order	Job/Part	Q'ty	Remarks
	Removing the front wheel and brake disc		Remove the parts in the order listed. NOTE: _____ Place the vehicle on a suitable stand so that the front wheel is elevated.
1	Front wheel axle	1	
2	Front wheel	1	
3	Collar	2	
4	Front brake disc	1	
			For installation, reverse the removal procedure.



Order	Job/Part	Q'ty	Remarks
	Disassembling the front wheel		
①	Oil seal	2	Disassemble the parts in the order listed. For assembly, reverse the disassembly procedure.
②	Wheel bearing	2	
③	Collar	1	



EAS00519

REMOVING THE FRONT WHEEL

1. Stand the vehicle on a level surface.

⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.

NOTE:

Place the vehicle on a suitable stand so that the front wheel is elevated.

2. Remove:

- front brake caliper

NOTE:

Do not apply the brake lever when removing the brake caliper.

3. Elevate:


- front wheel

NOTE:

Place the vehicle on a suitable stand so that the front wheel is elevated.

4. Remove:

- front wheel axle nut
- front wheel axle
- front wheel
- collar



EAS00526

CHECKING THE FRONT WHEEL

1. Check:

- wheel axle

Roll the wheel axle on a flat surface.

Bends → Replace.



Wheel axle bending limit
0.5 mm (0.020 in)



NOTE:

The bending value is shown by one half of the dial gauge reading.

⚠ WARNING

Do not attempt to straighten a bent wheel axle.


FRONT WHEEL AND BRAKE DISC



- c. Remove the wheel bearings (3) with a general bearing puller (4).
- d. Install the new wheel bearings and oil seals in the reverse order of disassembly.

CAUTION: _____

Do not contact the wheel bearing inner race (5) or balls (6). Contact should be made only with the outer race (7).



NOTE: _____

Use a socket (8) that matches the diameter of the wheel bearing outer race and oil seal.





Brake disc bolt
12 Nm (1.2 m•kg, 8.7 ft•lb)
LOCTITE®


- d. Measure the brake disc deflection.
- e. If out of specification, repeat the adjustment steps until the brake disc deflection is within specification.
- f. If the brake disc deflection cannot be brought within specification, replace the brake disc.




EAS00546

INSTALLING THE FRONT WHEEL

- 1. Lubricate:
 - front wheel axle
 - oil seal lips



Recommended lubricant
Lithium-soap-based grease



- 2. Install:
 - collar ①
 - front wheel ②
 - front wheel axle ③


NOTE: _____
 Install the brake disc between the brake pads correctly.

- 3. Tighten:
 - front wheel axle  **70 Nm (7.0 m•kg, 51 ft•lb)**

AS00551


REAR WHEEL AND BRAKE DISC

REAR WHEEL



Order	Job/Part	Q'ty	Remarks
	Removing the rear wheel		Remove the parts in the order listed. NOTE: _____ Place the vehicle on a suitable stand so that the rear wheel is elevated. _____
	Rear brake caliper		Remove Refer to "REMOVING THE REAR BRAK PADS".
1	Rear wheel axle nut	1	
2	Locknut	2	Loosen.
3	Adjusting bolt	2	Loosen.
4	Rear wheel axle	1	
5	Washer	2	
6	Drive chain puller	2	
7	Rear wheel	1	


REAR WHEEL AND BRAKE DISC




Order	Job/Part	Q'ty	Remarks
8	Collar	2	For installation, reverse the removal procedure.

EAS00560

REAR BRAKE DISC AND REAR WHEEL SPROCKET



Order	Job/Part	Q'ty	Remarks
	Removing the rear brake disc and rear wheel sprocket		Remove the parts in the order listed.
1	Rear brake disc	1	
2	Rear wheel sprocket	1	
3	Rear wheel	1	
			For installation, reverse the disassembly procedure.



Order	Job/Part	Q'ty	Remarks
	Disassembling the rear wheel		Disassemble the parts in the order listed.
①	Oil seal	2	
②	Circlip	1	
③	Bearing	2	
④	Collar	1	
			For assembly, reverse the disassembly procedure.

EAS00561

REMOVING THE REAR WHEEL


1. Stand the vehicle on a level surface.

⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.

NOTE:

Place the vehicle on a suitable stand so that the rear wheel is elevated.




2. Remove:

- protector ①
- brake caliper ②


NOTE:

Do not depress the brake pedal when removing the brake caliper.



3. Loosen:

- locknut ①
- adjusting bolt ②




4. Remove:

- wheel axle nut ①
- wheel axle
- rear wheel

NOTE:

Push the rear wheel forward and remove the drive chain from the rear wheel sprocket.



5. Remove:

- left collar ①
- right collar

EAS00566

CHECKING THE REAR WHEEL


1. Check:
 - rear wheel axle
 - rear wheel
 - wheel bearings
 - oil seals

Refer to “CHECKING THE FRONT WHEEL”.
2. Check:
 - tire
 - rear wheel

Damage/wear → Replace.
Refer to “CHECKING THE TIRES” and “CHECKING THE WHEELS” in chapter 3.
3. Check:
 - spokes

Refer to “CHECKING THE FRONT WHEEL”.
4. Measure:
 - radial wheel runout
 - lateral wheel runout

Refer to “CHECKING THE FRONT WHEEL”.



EAS00568

CHECKING AND REPLACING THE REAR WHEEL SPROCKET


1. Check:
 - rear wheel sprocket

More than 1/4 tooth (a) wear → Replace the rear wheel sprocket and drive chain as set.
Bent teeth → Replace the rear wheel sprocket and drive chain as a set.
- (b) Correct
(1) Drive chain roller
(2) Rear wheel sprocket

EAS00577

FRONT AND REAR BRAKES


FRONT BRAKE PADS



Order	Job/Part	Q'ty	Remarks
	Removing the front brake pads		Remove the parts in the order listed.
1	Brake caliper	1	
2	Brake pad	2	
3	Brake pad support	2	
4	Bleed screw	1	
			For installation, reverse the removal procedure.

EAS00578

REAR BRAKE PADS



Order	Job/Part	Q'ty	Remarks
	Removing the rear brake pads		Remove the parts in the order listed.
1	Protector	1	
2	Spacer	1	
3	Brake pad pin	2	
4	Rear brake caliper	1	
5	Brake pad	2	
6	Brake pad shim	1	
7	Brake pad spring	1	
8	Bleed screw	1	
			For installation, reverse the removal procedure.



EAS00579



CAUTION:

Disc brake components rarely require disassembly.

Therefore, always follow these preventive measures:

⚠ WARNING

- Never disassemble brake components unless absolutely necessary.
- If any connection on the hydraulic brake system is disconnected, the entire brake system must be disassembled, drained, cleaned, properly filled, and bled after reassembly.
- Never use solvents on internal brake components.
- Use only clean or new brake fluid for cleaning brake components.
- Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.
- Avoid brake fluid coming into contact with the eyes as it can cause serious injury.
- **FIRST AID FOR BRAKE FLUID ENTERING THE EYES:**
- Flush with water for 15 minutes and get immediate medical attention.



EAS00581




REPLACING THE FRONT BRAKE PADS**NOTE:**

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

1. Remove:
 - brake caliper ①

2. Remove:
 - brake pads ①

8. Check:
 - brake lever operation
 - Soft or spongy feeling → Bleed the brake system.
 - Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.



EAS00583

REPLACING THE REAR BRAKE PADS

NOTE: _____

When replacing the brake pads, it is not necessary to disconnect the brake hose or disassemble the brake caliper.

1. Loosen:
 - brake pad pins ①
2. Remove:
 - brake caliper ②
3. Remove:
 - brake pad pins ③
 - brake pads ④
 - (along with the brake pad shims)
 - brake pad spring
4. Measure:
 - brake pad wear limit ①
 - Out of specification → Replace the brake pads as a set.



Brake pad wear limit
1.0 mm (0.04 in)


5. Install:
 - brake pad spring
 - brake pad shims
 - (onto the brake pads)
 - brake pads
 - brake pad pins
 - brake caliper

NOTE: _____

Always install new brake pads, brake pad shims, and a brake pad spring as a set.


EAS00584

FRONT BRAKE MASTER CYLINDER



Order	Job/Part	Q'ty	Remarks
	Removing the front brake master cylinder		Remove the parts in the order listed.
	Brake fluid		Drain. Refer to "CHANGING THE BRAKE FLUID" in chapter 3.
1	Union bolt	1	
2	Copper washer	2	
3	Front brake hose	1	
4	Brake lever cover	1	
5	Brake lever	1	
6	Brake master cylinder holder	1	
7	Brake master cylinder	1	
			For installation, reverse the removal procedure.


EAS00585



Order	Job/Part	Q'ty	Remarks
	Disassembling the rear brake master cylinder		Remove the parts in the order listed.
①	Brake master cylinder cap	1	
②	Brake master cylinder reservoir diaphragm	1	
③	Brake master cylinder reservoir float	1	
④	Brake master cylinder boot	1	
⑤	Circlip	1	
⑥	Washer	1	
⑦	Brake master cylinder kit	1	
			For assembly, reverse the disassembly procedure.


EAS00586

REAR BRAKE MASTER CYLINDER




Order	Job/Part	Q'ty	Remarks
	Removing the rear brake master cylinder		Remove the parts in the order listed.
	Brake fluid		Drain. Refer to "CHANGING THE BRAKE FLUID" in chapter 3.
1	Brake fluid reservoir cap	1	
2	Brake fluid reservoir diaphragm holder	1	
3	Brake fluid reservoir diaphragm	1	
4	Brake fluid reservoir tank	1	
5	Brake fluid reservoir hose	1	
6	Hose holder	1	
7	Union bolt	1	
8	Copper washer	2	
9	Brake hose	1	
10	Brake master cylinder	1	
			For installation, reverse the removal procedure.

EAS00587



Order	Job/Part	Q'ty	Remarks
	Removing the rear brake master cylinder		Remove the parts in the order listed.
①	Brake master cylinder kit	1	
②	Circlip	1	
③	Brake master cylinder joint	1	
④	O-ring	1	
			For assembly, reverse the disassembly procedure.



EAS00588

DISASSEMBLING THE FRONT BRAKE MASTER CYLINDER

NOTE:


Before disassembling the front brake master cylinder, drain the brake fluid from the entire brake system.

1. Remove:
 - union bolt ①
 - copper washers ②
 - brake hose ③

NOTE:

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.

2. Remove:
 - brake master cylinder bracket
 - brake master cylinder
3. Remove:
 - brake master cylinder boot
 - circlip



EAS00589

DISASSEMBLING THE REAR BRAKE MASTER CYLINDER





NOTE:

Before disassembling the rear brake master cylinder, drain the brake fluid from the entire brake system.

NOTE:

To collect any remaining brake fluid, place a container under the master cylinder and the end of the brake hose.

1. Remove:
 - union bolt ①
 - copper washers ②
 - brake hose ③
2. Remove:
 - brake master cylinder
3. Remove:
 - circlip
 - brake master cylinder joint



EAS00592

CHECKING THE FRONT AND REAR BRAKE MASTER CYLINDERS

The following procedure applies to the both of the brake master cylinders.

1. Check:

- brake master cylinder ①
Damage/scratches/wear → Replace.
- brake fluid delivery passages (brake master cylinder body)
Obstruction → Blow out with compressed air.

A Front

B Rear

2. Check:

- brake master cylinder kit ①
Damage/scratches/wear → Replace.

C Front

D Rear

3. Check:

- rear brake fluid reservoir ①
Cracks/damage → Replace.
- rear brake fluid reservoir diaphragm ②
Cracks/damage → Replace.

4. Check:

- front brake master cylinder reservoir ①
Cracks/damage → Replace.
- front brake master cylinder reservoir diaphragm ②
Damage/wear → Replace.

5. Check:


- brake hoses
Cracks/damage/wear → Replace.
Refer to “CHECKING THE FRONT AND REAR BRAKE HOSES” in chapter 3.

EAS00598

ASSEMBLING AND INSTALLING THE FRONT BRAKE MASTER CYLINDER

⚠ WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components.



**Recommended brake fluid
DOT 4**


1. Install:

- brake master cylinder ①

 **9 Nm (0.9 m•kg, 6.5 ft•lb)**

NOTE:

- Install the brake master cylinder holder ② with the “UP” mark facing up.
- First, tighten the upper bolt, then the lower bolt.



2. Install:

- copper washers ① **New**

- brake hose ②

- union bolt ③


 **26 Nm (2.6 m•kg, 19 ft•lb)**

⚠ WARNING

Proper brake hose routing is essential to insure safe vehicle operation. Refer to “CABLE ROUTING” in chapter 2.

CAUTION:

Install the brake hose so that its pipe portion ① directs as shown and lightly touches the projection ② on the brake master cylinder.



**NOTE:**

- While holding the brake hose, tighten the union bolt as shown.
- Turn the handlebar to the left and right to make sure the brake hose does not touch other parts (e.g., wire harness, cables, leads). Correct if necessary.

3. Fill:

- brake master cylinder reservoir
(with the specified amount of the recommended brake fluid)



Recommended brake fluid
DOT 4

⚠ WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:


Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

4. Bleed:

- brake system
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.

5. Check:

- brake fluid level
Below the minimum level mark (a) → Add the recommended brake fluid to the proper level.
Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.





6. Check:
 - brake lever operation
 - Soft or spongy feeling → Bleed the brake system.
 - Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.

EAS00608

ASSEMBLING THE REAR BRAKE MASTER CYLINDER

1. Install:
 - O-ring **New**
 - brake master cylinder joint
 - circlip **New**
 - brake master cylinder kit
2. Install:
 - copper washers **New**
 - brake hoses
 - union bolt  **26 Nm (2.6 m•kg, 19 ft•lb)**



⚠ WARNING

Proper brake hose routing is essential to insure safe vehicle operation. Refer to “CABLE ROUTING” in chapter 2.

CAUTION:

When installing the brake hose onto the brake master cylinder, make sure the brake pipe touches the projection (a) as shown.

3. Fill:
 - brake fluid reservoir (to the maximum level mark (b))

	Recommended brake fluid DOT 4
---	--

⚠ WARNING



- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.



- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilled brake fluid immediately.



4. Bleed:
 - brake system
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.
5. Check:
 - brake fluid level
Below the minimum level mark (a) → Add the recommended brake fluid to the proper level.
Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.
6. Check:
 - brake pedal operation

⚠ WARNING

A soft or spongy feeling in the brake pedal can indicate the presence of air in the brake system. Before the vehicle is operated, the air must be removed by bleeding the brake system. Air in the brake system will considerably reduce braking performance and could result in loss of control and possibly an accident. Therefore, check and, if necessary, bleed the brake system.


7. Adjust:
 - brake pedal position (b)
Refer to “ADJUSTING THE REAR BRAKE” in chapter 3.



Brake pedal position (above the top of the rider footrest)
4.0 ~ 10.0 mm (0.16 ~ 0.39 in)


EAS00613

FRONT BRAKE CALIPER



Order	Job/Part	Q'ty	Remarks
	Removing the front brake caliper		Remove the parts in the order listed.
	Brake fluid		Drain.
			Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.
1	Protector	1	
2	Brake hose holder	1	
3	Union bolt	1	
4	Copper washer	2	
5	Brake hose	1	
6	Brake caliper	1	
			For installation, reverse the removal procedure.


EAS00614



Order	Job/Part	Q'ty	Remarks
	Disassembling the front brake caliper		Remove the parts in the order listed.
①	Brake pad	2	
②	Brake caliper bracket	1	
③	Brake pad support	2	
④	Sleeve boot	1	
⑤	Brake caliper piston	2	
⑥	Brake caliper piston seal	4	
⑦	Pin boot	1	
⑧	Bleed screw	1	
			For assembly, reverse the disassembly procedure.


EAS00616

REAR BRAKE CALIPER






Order	Job/Part	Q'ty	Remarks
	Removing the rear brake caliper		
	Brake fluid		Remove the parts in the order listed. Drain. Refer to "BLEEDING THE HYDRAULIC BRAKE SYSTEM" in chapter 3.
1	Union bolt	1	
2	Copper washer	2	
3	Brake hose	1	
4	Brake pad pin	2	Loosen.
5	Protector	1	
6	Brake caliper	1	
			For installation, reverse the removal procedure.

EAS00617



Order	Job/Part	Q'ty	Remarks
	Disassembling the rear brake caliper		Remove the parts in the order listed.
①	Brake pad pin	2	
②	Brake pad	2	
③	Brake pad shim	1	
④	Brake caliper seal	2	
⑤	Brake caliper piston	1	
⑥	Brake pad spring	1	
⑦	Bleed screw	1	
			For assembly, reverse the disassembly procedure.



1. Check:
 - brake caliper pistons ①
Rust/scratches/wear → Replace the brake caliper pistons.
 - brake caliper cylinders ②
Scratches/wear → Replace the brake caliper assembly.
 - brake caliper body ③
Cracks/damage → Replace the brake caliper assembly.
 - brake fluid delivery passages (brake caliper body)
Obstruction → Blow out with compressed air.

⚠ WARNING

Whenever a brake caliper is disassembled, replace the brake caliper piston seals.

- A** Front
- B** Rear

2. Check:
 - front brake caliper bracket ①
Cracks/damage → Replace.
 - guide pin ②
Rust/damage → Replace.
 - sleeve boot ③
Crack/damage → Replace.
 - pin boot ④
Wear/damage → Replace.

EAS00634



ASSEMBLING AND INSTALLING THE FRONT BRAKE CALIPER

⚠ WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston seals.



Recommended brake fluid
DOT 4



1. Install:

- brake caliper bracket

 30 Nm (3.0 m•kg, 22 ft•lb)

- brake pads
- brake caliper ①

 23 Nm (2.3 m•kg, 17 ft•lb)

- copper washers **New**

- brake hose ②

 26 Nm (2.6 m•kg, 19 ft•lb)

- union bolt ③

⚠ WARNING

Proper brake hose routing is essential to insure safe vehicle operation. Refer to “CABLE ROUTING” in chapter 2.

CAUTION:

When installing the brake hose onto the brake caliper ①, make sure the brake pipe ① touches the projection ② on the brake caliper.

2. Fill:

- brake master cylinder reservoir (with the specified amount of the recommended brake fluid)


	Recommended brake fluid DOT 4
---	--

⚠ WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.




3. Bleed:
 - brake system
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.
4. Check:
 - brake fluid level
Below the minimum level mark (a) → Add the recommended brake fluid to the proper level.
Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.
5. Check:
 - brake lever operation
Soft or spongy feeling → Bleed the brake system.
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.

EAS00642

ASSEMBLING AND INSTALLING THE REAR BRAKE CALIPER

⚠ WARNING

- Before installation, all internal brake components should be cleaned and lubricated with clean or new brake fluid.
- Never use solvents on internal brake components as they will cause the piston seals to swell and distort.
- Whenever a brake caliper is disassembled, replace the brake caliper piston seals.




	Recommended brake fluid DOT 4
---	--

1. Install:
 - brake pad spring
 - brake pad shim
 - brake pad pins
2. Install:
 - brake caliper ① (front)

	23 Nm (2.3 m•kg, 17 ft•lb)
	(rear)
	23 Nm (2.3 m•kg, 17 ft•lb)
 - protector ②

	10 Nm (1.0 m•kg, 7.2 ft•lb)
---	------------------------------------
 - copper washers **New**
 - brake hose ③
 - union bolt ④

	26 Nm (2.6 m•kg, 19 ft•lb)
---	-----------------------------------

**⚠ WARNING**

Proper brake hose routing is essential to insure safe vehicle operation. Refer to “CABLE ROUTING” in chapter 2.

CAUTION:

When installing the brake hose onto the brake caliper ①, make sure the brake pipe ② touches the projection ③ on the brake caliper.

3. Fill:

- brake master cylinder reservoir (with the specified amount of the recommended brake fluid)



Recommended brake fluid
DOT 4

⚠ WARNING


- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake master cylinder reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

4. Bleed:


- brake system
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.



5. Check:
 - brake fluid level
Below the minimum level mark (a) → Add the recommended brake fluid to the proper level.
Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.
6. Check:
 - brake lever operation
Soft or spongy feeling → Bleed the brake system.
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.


EAS00646

FRONT FORK
FRONT FORK LEGS




Order	Job/Part	Q'ty	Remarks
	Removing the front fork legs		
	Front wheel		Remove the parts in the order listed. Refer to "FRONT WHEEL AND BRAKE DISC".
	Protector		Refer to "FRONT AND REAR BRAKES".
	Front brake caliper		
	Number plate		Refer to "SEAT, SIDE COVERS AND FUEL TANK" in chapter 3.
1	Cap bolt	1	Loosen.
2	Upper bracket pinch bolt	1	Loosen.
3	Lower bracket pinch bolt	2	Loosen.
4	Front fork	1	For installation, reverse the removal procedure.

EAS00648



Order	Job/Part	Q'ty	Remarks
	Disassembling the front fork legs		Remove the parts in the order listed.
①	Guide protector	1	
②	Cap bolt	1	
③	O-ring	1	
④	Damper adjusting rod	1	
⑤	Nut	1	
⑥	Washer	1	
⑦	Fork spring	1	
⑧	Spring guide	1	
⑨	Dust seal	1	
⑩	Oil seal clip	1	
⑪	Inner tube	1	
⑫	Outer tube	1	
⑬	Piston metal	1	
⑭	Slide metal	1	
⑮	Oil seal washer	1	



Order	Job/Part	Q'ty	Remarks
①⑥	Oil seal	1	For assembly, reverse the disassembly procedure.
①⑦	Plug	1	
①⑧	Base valve	1	
①⑨	Gasket	1	
②①	O-ring	2	
②①	Damper rod	1	
②②	O-ring	1	
②③	Air bleed screw	1	



EAS00650

REMOVING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.

1. Stand the vehicle on a level surface.


⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.


NOTE:

Place the vehicle on a suitable stand so that the front wheel is elevated.

2. Remove
 - front wheel
 - protector
 - front brake caliper
 - number plate



3. Loosen:
 - cap bolt ①




4. Loosen:
 - upper bracket pinch bolt ①
 - lower bracket pinch bolts ②

⚠ WARNING

Before loosening the upper and lower bracket pinch bolts, support the front fork leg.

5. Remove:
 - front fork leg

6. Remove:
- slide metal
 - oil seal washer
 - oil seal
 - piston metal
 - oil seal clip
 - dust seal



7. Remove:
- base valve ①
 - damper rod ②

NOTE:

While holding the inner tube with the damper rod holder ③, loosen the base valve.




Damper rod holder
90890-01454, YM-01454

EAS00656

CHECKING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.


1. Check:
- inner tube ①
 - outer tube ②
- Bends/damage/scratches → Replace.



⚠ WARNING


Do not attempt to straighten a bent inner tube as this may dangerously weaken it.

2. Measure:
- spring free length ①
- Out of specification → Replace.




Spring free length
430 mm (16.9 in)
<Limit>: 425 mm (16.7 in)

3. Check:
- damper rod ①
- Bend/damage → Replace.
Obstruction → Blow out all of the oil passages with compressed air.
- damper rod adjusting rod
- Bend/damage → Replace.




**CAUTION:**

- The front fork leg has a built-in damper adjusting rod and a very sophisticated internal construction, which are particularly sensitive to foreign material.
- When disassembling and assembling the front fork leg, do not allow any foreign material to enter the front fork.



4. Check:

- base valve assembly ①
Damage/wear → Replace.



5. Check:

- cap bolt ①
Damage/wear → Replace.
- air bleed screw ②
Damage/wear → Replace.

EAS00661

ASSEMBLING THE FRONT FORK LEGS

The following procedure applies to both of the front fork legs.


⚠ WARNING

- Make sure the oil levels in both front fork legs are equal.
- Uneven oil levels can result in poor handling and a loss of stability.

NOTE:

When assembling the front fork leg, be sure to replace the following parts:


- outer tube and inner tube bushing
- oil seal
- dust seal
- Before assembling the front fork leg, make sure all of the components are clean.




1. Install:
 - damper rod assembly ①
 - inner tube ②

CAUTION:

Allow the damper rod assembly to slide slowly down the inner tube until it protrudes from the bottom of the inner tube. Be careful not to damage the inner tube.



2. Install:
 - gasket ① **New**
 - base valve ②



3. Tighten:
 - base valve ①  **55 Nm (5.5 m•kg, 40 ft•lb)**
LOCTITE®

NOTE:

While holding the damper rod ③ with the damper rod holder ②, tighten the base valve.




Damper rod holder
90890-01454, YM-01454

4. Lubricate:
 - inner tube's outer surface




Recommended lubricant
Suspension oil "01"



5. Install:
 - spring guide ①
 - nut ②

NOTE:


Install the spring guide with its cut (a) facing downward.



6. Install:
- dust seal ①
 - oil seal clip ②
 - oil seal ③ **New**
 - oil seal washer ④
 - slide metal ⑤ **New**


CAUTION: _____

Make sure the numbered side of the oil seal faces up.



NOTE: _____


- Before installing the oil seal, lubricate its lips with lithium-soap-based grease.
- Lubricate the outer surface of the inner tube with fork oil.
- Before installing the oil seal, cover the top of the front fork leg with a plastic bag to protect the oil seal during installation.




7. Install:
- piston metal ① **New**

NOTE: _____

Install the piston metal on to the slot on inner tube.




8. Install:
- outer tube ①



9. Install:
- slide metal ① **New**
 - oil seal washer ②
(with the fork seal driver ③)


	<p>Fork seal driver 90890-01442, YM-01442</p>
---	--



10. Install:
- oil seal ① **New**
(with the fork seal driver ②)




Fork seal driver
90890-01442, YM-01442



11. Install:
- oil seal clip ①

NOTE:

Adjust the oil seal clip so that it fits into the outer tube's groove.



12. Install:
- dust seal ①
13. Fill:


- front fork leg
(with the specified amount of the recommended fork oil)



Quantity (each front fork leg)
0.32 L (0.28 Imp qt, 0.34 US qt)
Recommended oil
Suspension oil "01"



Front fork leg oil level ② (from the top of the outer tube, with the outer tube fully compressed and without the fork spring)
Standard: 90 mm (3.54 in)
Extent of adjustment:
80 ~ 120 mm (3.15 ~ 4.72 in)



NOTE:

- While filling the front fork leg, keep it upright.
- After filling, slowly pump the front fork leg up and down to distribute the fork oil.



EAS00662

INSTALLING THE FRONT FORK LEGS


The following procedure applies to both of the front fork legs.

1. Install:
 - front fork leg

Temporarily tighten the upper and lower bracket pinch bolts.

NOTE:

Make sure the inner fork tube is flush with the top of the handlebar holder.




2. Tighten:
 - cap bolt ①  28 Nm (2.8 m•kg, 20 ft•lb)
3. Adjust:
 - front fork top end ②

**Front fork top end (standard)**

YZ85: 24 mm (0.94 in)

YZ85LW: 0 mm (0.00 in)



4. Tighten:
 - upper bracket pinch bolt ①  22 Nm (2.2 m•kg, 16 ft•lb)
 - lower bracket pinch bolt ②  20 Nm (2.0 m•kg, 14 ft•lb)

⚠ WARNING


Make sure the brake hoses are routed properly.

5. Install:
 - protector  7 Nm (0.7 m•kg, 5.1 ft•lb)
6. Adjust:
 - spring preload
 - rebound damping
 - compression damping


Refer to “ADJUSTING THE FRONT FORK LEGS” in chapter 3.

EAS00664

HANDLEBAR



Order	Job/Part	Q'ty	Remarks
	Removing the handlebar		
	Number plate		Remove the parts in the order listed. Refer to "SEAT, SIDE COVERS AND FUEL TANK" in chapter 3.
1	Clutch cable	1	
2	Clutch lever holder	1	
3	Clutch lever	1	
4	Engine stop switch	1	
5	Brake master cylinder cap	1	
6	Brake master cylinder	1	
7	Throttle cable cap	1	
8	Grip cap (lower)	1	
9	Grip cap (upper)	1	
10	Throttle cable	1	
11	Right grip	1	
12	Tube guide	1	
13	Collar	1	



Order	Job/Part	Q'ty	Remarks
14	Left grip	1	For installation, reverse the removal procedure.
15	Handlebar upper holder	2	
16	Handlebar	1	




EAS00666

REMOVING THE HANDLEBAR

1. Stand the vehicle on a level surface.

⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.




2. Remove:

- grip ①

NOTE:

Blow compressed air between the handlebar and the handlebar grip, and gradually push the grip off the handlebar.



EAS00668

CHECKING THE HANDLEBAR

1. Check:

- handlebar ①
Bends/cracks/damage → Replace.

⚠ WARNING

Do not attempt to straighten a bent handlebar as this may dangerously weaken it.

EAS00670

INSTALLING THE HANDLEBAR

1. Stand the vehicle on a level surface.


⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.

2. Install:






- handlebar ①
- handlebar upper holder ②

27 Nm (2.7 m•kg, 19 ft•lb)



CAUTION:

- First, tighten the bolts on the front side of the handlebar holder, and then on the rear side.
- Turn the handlebar all the way to the left and right. If there is any contact with the fuel tank, adjust the handlebar position.

**NOTE:**

- The upper handlebar holders should be installed with the punched mark (a) forward.
- First tighten the bolts on the front side of the handlebar upper holder, and then tighten the bolts on the rear side.

3. Install:

- left grip (1)
- apply the adhesive to the handlebar (2).

NOTE:

- Before applying the adhesive, wipe off grease or oil on the handlebar surface (a) with a lacquer thinner.
- Install the left grip to the handlebar so that the arrow mark (L) faces straight upward.

4. Install:

- right grip (1)
- apply the adhesive on the tube guide (2).

NOTE:


- Before applying the adhesive, wipe off grease or oil on the tube guide surface (a) with a lacquer thinner.
- Locate the mating mark (b) on the grip as shown.

5. Install:

- collar (1)
- tube guide (2)
- grip cap (upper) (3)
- throttle cable (4)

NOTE:

Apply the lithium soap base grease on the throttle cable end and tube guide cable winding portion.




6. Install:
- throttle cable cap ①
 - grip cap (lower) ②

 **1 Nm (0.1 m•kg, 0.7 ft•lb)**

 **4 Nm (0.4 m•kg, 2.9 ft•lb)**


7. Adjust:
- cover (grip cap) ③
- Refer to “ADJUSTING THE THROTTLE CABLE FREE PLAY” in chapter 3.



8. Install:
- brake master cylinder ①
 - brake master cylinder bracket ②

 **9 Nm (0.9 m•kg, 6.5 ft•lb)**


NOTE: _____
Install the bracket so that the arrow mark (a) face upward.



9. Install:
- engine stop switch ①
 - clutch lever holder ②


 **4 Nm (0.4 m•kg, 2.9 ft•lb)**


NOTE: _____
The engine stop switch and clutch lever holder should be installed according to the dimensions shown.



10. Install:
- clutch cable ①

NOTE: _____
Apply the lithium soap base grease on the clutch cable end.






11. Adjust:
 - clutch lever free play
Refer to “ADJUSTING THE CLUTCH CABLE FREE PRAY” in chapter 3.
12. Clamp the clamp portion (a) of the number plate to the handlebar.
13. Insert the end of the fuel tank breather hose (1) into the hole of the steering stem.



EAS00675

STEERING HEAD

UNDER BRACKET



Order	Job/Part	Q'ty	Remarks
	Removing the lower bracket		
	Number plate		Remove the parts in the order listed. Refer to "SEAT, SIDE COVERS AND FUEL TANK" in chapter 3.
	Handlebar		Refer to "HANDLEBAR".
	Front fender		
1	Steering stem nut	1	
2	Washer	1	
3	Upper bracket	1	
4	Steering ring nut	1	
5	Lower bracket	1	
6	Bearing race cover	1	
7	Washer	1	
8	Upper bearing	1	
9	Lower bearing	1	
10	Bearing race	2	
			For installation, reverse the removal procedure.

EAS00677

REMOVING THE LOWER BRACKET


1. Stand the vehicle on a level surface.

⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.

2. Remove:

- steering stem nut
- washer
- upper bracket
- steering ring nut ①
(with the ring nut wrench ②)



Steering nut wrench
90890-01403, YU-33975

⚠ WARNING

Securely support the lower bracket so that there is no danger of it falling.

EAS00682


CHECKING THE STEERING HEAD

1. Wash:

- bearings
- bearing races



Recommended cleaning solvent
Kerosene




2. Check:

- bearings ①
 - bearing races
- Damage/pitting → Replace.

EAS00685

REAR SHOCK ABSORBER ASSEMBLY



Order	Job/Part	Q'ty	Remarks
	Removing the rear shock absorber assembly		Remove the parts in the order listed.
	Seat		Refer to "SEAT, SIDE COVERS AND FUEL TANK" in chapter 3.
	Right side cover		
	Silencer		Refer to "EXHAUST PIPE" in chapter 5.
1	Clamp	1	Loosen
2	Rear frame	1	
3	Washer/bolt	1/1	
4	Self-locking nut/washer/bolt	1/1/1	
5	Rear shock absorber	1	
6	Spring guide	1	
7	Spring	1	
8	Adjuster	1	
9	Locknut	1	
			For installation, reverse the removal procedure.




EAS00687

HANDLING THE REAR SHOCK ABSORBER AND GAS CYLINDER

⚠ WARNING

This rear shock absorber and gas cylinder contain highly compressed nitrogen gas. Before handling the rear shock absorber or gas cylinder, read and make sure you understand the following information. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling of the rear shock absorber and gas cylinder.

- Do not tamper or attempt to open the rear shock absorber or gas cylinder.
- Do not subject the rear shock absorber or gas cylinder to an open flame or any other source of high heat. High heat can cause an explosion due to excessive gas pressure.
- Do not deform or damage the rear shock absorber or gas cylinder in any way. If the rear shock absorber, gas cylinder or both are damaged, damping performance will suffer.



EAS00689

DISPOSING OF A REAR SHOCK ABSORBER AND GAS CYLINDER

1. Gas pressure must be released before disposing of a rear shock absorber and gas cylinder. Before disposing the rear shock absorber, be sure to extract the nitrogen gas from valve ①.

⚠ WARNING

Wear eye protection to prevent eye damage from released gas or metal chips.

EAS00694

REMOVING THE REAR SHOCK ABSORBER ASSEMBLY

1. Stand the vehicle on a level surface.

⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.

NOTE:

Place the vehicle on a suitable stand so that the rear wheel is elevated.

2. Remove:


- seat and right side cover
Refer to “SEAT, SIDE COVERS AND FUEL TANK” in chapter 3.
- silencer
Refer to “EXHAUST PIPE” in chapter 5.

3. Loosen:

- air filter clamp


4. Remove:

- rear frame ①




5. Remove:

- rear shock absorber lower bolt ①
- washer ②




6. Remove:

- rear shock absorber upper bolt ①
- washer ②
- self-locking nut ③
- rear shock absorber ④



REAR SHOCK ABSORBER ASSEMBLY

CHAS



EAS00696

CHECKING THE REAR SHOCK ABSORBER ASSEMBLY AND GAS CYLINDER

- Check:
 - rear shock absorber rod ①
Bends/damage → Replace the rear shock absorber assembly.
 - rear shock absorber ②
Gas leaks/oil leaks → Replace the rear shock absorber assembly.
 - spring ③
Damage/wear → Replace the rear shock absorber assembly.
 - spring guide ④
Damage/wear → Replace.
 - gas cylinder
Damage/gas leaks → Replace.
 - bushings
Damage/wear → Replace.
 - dust seals
Damage/wear → Replace.
 - bolts
Bends/damage/wear → Replace.



EAS00698

INSTALLING THE REAR SHOCK ABSORBER ASSEMBLY

- Lubricate:
 - spacers
 - bolts



Recommended lubricant
Molybdenum disulfide grease




- Install:
 - rear shock absorber ①

NOTE:

- When installing the rear shock absorber assembly, lift up the swingarm.
- Install the connecting arm front bolt from the right.


- Tighten:
 - rear shock absorber upper nut ②
36 Nm (3.6 m•kg, 26 ft•lb)
 - rear shock absorber lower bolt ③
36 Nm (3.6 m•kg, 26 ft•lb)
- Install:
 - rear frame (upper)
26 Nm (2.6 m•kg, 19 ft•lb)
 - rear frame (lower)
16 Nm (1.6 m•kg, 12 ft•lb)
 - clamp



5. Install:
 - silencer
Refer to “EXHAUST PIPE” in chapter 5.
 - seat and right side cover
Refer to “SEAT, SIDE COVERS AND FUEL TANK” in chapter 3.
6. Adjust
 - spring preload
 - rebound damping
 - compression damping
Refer to “ADJUSTING THE REAR SHOCK ABSORBER” in chapter 3.



EAS00700

SWINGARM AND DRIVE CHAIN



Order	Job/Part	Q'ty	Remarks
	Removing the swingarm and drive chain		Remove the parts in the order listed.
	Rear wheel		Refer to "REAR WHEEL, AND BRAKE DISC".
	Brake hose holder		Refer to "FRONT AND REAR BRAKES".
	Rear brake caliper		
	Left crankcase cover		Refer to "CDI MAGNETO" in chapter 5.
1	Drive chain	1	
2	Drive chain support	1	
3	Drive chain support cover	1	
4	Pivot shaft	1	
5	Swingarm	1	
			For installation, reverse the removal procedure.

SWINGARM AND DRIVE CHAIN



Order	Job/Part	Q'ty	Remarks
	Disassembling the swingarm		Disassemble the parts in the order listed.
①	Relay arm	1	
②	Connecting rod	1	
③	Cover	2	
④	Dust seal	2	
⑤	Collar	5	
⑥	Bushing	5	
⑦	Oil seal	8	
⑧	Bearing	9	
⑨	Bushing	2	
⑩	Drive chain guide	1	
			For assembly, reverse the disassembly procedure.

EAS00706

REMOVING THE DRIVE CHAIN


1. Stand the vehicle on a level surface.

⚠ WARNING

Securely support the vehicle so that there is no danger of it falling over.


NOTE:

Place the vehicle on a suitable stand so that the rear wheel is elevated.



2. Remove:

- master link clip
- master link ①
- master link plate ②
- drive chain ③



EAS00707

CHECKING THE SWINGARM

1. Check:


- swingarm
Bends/cracks/damage → Replace.

2. Check:

- pivot shaft
Roll the pivot shaft on a flat surface.
Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent pivot shaft.




3. Wash:

- pivot shaft
- collar
- bearings


	Recommended cleaning solvent Kerosene
---	---

SWINGARM AND DRIVE CHAIN



CHAS



4. Check:
- collars ①
 - oil seals ②
Damage/wear → Replace.
 - bearings ③
Damage/pitting → Replace.
 - bushings ④
Damage/wear → Replace.



5. Check:
- connecting rod ①
 - relay arm ②
Damage/wear → Replace.
6. Check:
- bearings ③
 - oil seals ④
Damage/wear → Replace.
 - dust seals ⑤
Damage/pitting → Replace.
7. Check:
- bushings ⑥
Damage/wear → Replace.
 - spacers ⑦
Damage/scratches → Replace.




EAS00710

CHECKING THE DRIVE CHAIN


1. Measure:
- Measure the dimension between 15-links on the inner side (a) and outer side (b) of the roller and calculate the dimension between pin centers.
 - Dimension (c) between pin centers = (Inner dimension (a) + Outer dimension (b))/2
 - 15-link section (c) of the drive chain
Out of specification → Replace the drive chain, front drive sprocket and rear drive sprocket as a set.



**15-link drive chain section limit
(maximum)
194.3 mm (6.75 in)**




6. Check:
- drive sprocket
 - rear wheel sprocket
- More than 1/4 tooth (a) wear → Replace the drive chain sprockets as a set.
 Bent teeth → Replace the drive chain sprockets as a set.
- (b) Correct
 (1) Drive chain roller
 (2) Drive chain sprocket



CHECKING THE DRIVE CHAIN SUPPORT

1. Check:
- drive chain support
- Limit reaches indicator (a) → Replace.




EAS00711

INSTALLING THE SWINGARM

1. Install:
- bearing (1)
 - bushing (swingarm) (2)
 - oil seal (3)
(with the swingarm)

NOTE:

- Apply the molybdenum disulfide grease on the bearing and bushing when installing.
- Install the bearing by pressing it on the side having the manufacture's marks or numbers.
- First install the bushing and then the bearing to a specified depth from inside.






Installed depth of bearings and bushings
 Bearing (a): 4.5 mm (0.18 in)
 Bushing (b): 4.5 mm (0.18 in)

SWINGARM AND DRIVE CHAIN


CHAS




2. Install:
- bearing ①
 - oil seal ②
(with the relay arm)

NOTE:

- Apply the molybdenum disulfide grease on the bearing when installing.
- Install the bearing by pressing it on the side having the manufacturer's marks or numbers.



Installed depth of bearings
 Depth ①: 4.5 mm (0.18 in)
 Depth ②: 0.5 mm (0.02 in)
 Depth ③: 4.0 mm (0.16 in)




3. Install:
- bearing ①
 - oil seal ②
(with the connecting rod)

NOTE:

- Apply the molybdenum disulfide grease on the bearing when installing.
- Install the bearing by pressing it on the side having the manufacturer's marks or numbers.



Installed depth of bearings ①
 6.5 mm (0.26 in)




4. Install:
- connecting rod ①

53 Nm (5.3 m•kg, 38 ft•lb)

SWINGARM AND DRIVE CHAIN


CHAS



5. Install:

- relay arm ①

54 Nm (5.4 m•kg, 39 ft•lb)



6. Install:

- swingarm ①
- pivot shaft ②
- pivot shaft nut ③

63 Nm (6.3 m•kg, 46 ft•lb)

7. Install:

- rear shock absorber
- rear wheel

Refer to “REAR WHEEL AND BRAKE DISC”.

8. Adjust:

- drive chain slack

Refer to “ADJUSTING THE DRIVE CHAIN SLACK” in chapter 3.



Drive chain slack

35 ~ 45 mm (1.38 ~ 1.77 in)

EAS00714

INSTALLING THE DRIVE CHAIN


1. Lubricate:

- drive chain
- master link




Recommended lubricant

Engine oil or chain lubricant
suitable for non-O-ring chains



2. Install:

- master link ①
- master link plate ②



3. Install:

- master link clip ③ **New**

CAUTION: _____

- The closed end of the master link clip must face in the direction of drive chain rotation.
- Never install a new drive chain onto worn drive chain sprockets; this will dramatically shorten the drive chain's life.

4. Adjust:

- drive chain slack

Refer to "ADJUSTING THE DRIVE CHAIN SLACK" in chapter 3.



Drive chain slack

35 ~ 45 mm (1.38 ~ 1.77 in)

CAUTION: _____

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive chain slack within the specified limits.



CHAPTER 5 ENGINE


ENGINE	5-1
DRIVE SPROCKET	5-1
EXHAUST PIPE	5-2
SILENCER FIBER REPLACEMENT	5-3
ENGINE	5-4
INSTALLING THE ENGINE	5-6
CYLINDER HEAD, CYLINDER AND PISTON	5-7
CYLINDER HEAD	5-7
REMOVING THE CYLINDER HEAD	5-8
CHECKING THE CYLINDER HEAD	5-8
INSTALLING THE CYLINDER HEAD	5-9
CYLINDER AND PISTON	5-10
REMOVING THE CYLINDER AND PISTON	5-11
CHECKING THE CYLINDER AND PISTON	5-11
COMBINATION OF PISTON AND CYLINDER	5-13
CHECKING THE PISTON RING	5-14
CHECKING THE PISTON PIN	5-14
CHECKING THE SMALL END BEARING	5-15
INSTALLING THE PISTON AND CYLINDER	5-16
CLUTCH	5-18
CLUTCH	5-18
REMOVING THE CLUTCH	5-20
CHECKING THE FRICTION PLATES	5-21
CHECKING THE CLUTCH PLATES	5-21
CHECKING THE CLUTCH SPRINGS	5-22
CHECKING THE CLUTCH HOUSING	5-22
CHECKING THE CLUTCH BOSS	5-22
CHECKING THE PRESSURE PLATE	5-22
CHECKING THE PUSH LEVER SHAFT	5-23
CHECKING THE CLUTCH PUSH RODS	5-23
INSTALLING THE CLUTCH	5-23



KICK STARTER AND SHIFT SHAFT	5-26
PRIMARY DRIVE GEAR	5-26
KICK STARTER AND SHIFT SHAFT	5-28
REMOVING THE PRIMARY DRIVE GEAR	5-30
REMOVING THE KICK SHAFT ASSEMBLY	5-30
CHECKING THE KICK STARTER	5-30
CHECKING THE SHIFT SHAFT	5-31
CHECKING THE STOPPER LEVER	5-31
CHECKING THE PRIMARY DRIVE GEAR AND PRIMARY DRIVEN GEAR	5-31
INSTALLING THE SHIFT SHAFT	5-31
INSTALLING THE KICK STARTER SHAFT ASSEMBLY	5-33
INSTALLING THE KICK IDLE GEAR	5-33
INSTALLING THE PRIMARY DRIVE GEAR	5-34
CDI MAGNETO	5-36
REMOVING THE ROTOR	5-37
CHECKING THE CDI MAGNETO	5-37
CHECKING THE WOODRUFF KEY	5-37
INSTALLING THE CDI MAGNETO	5-38
CRANKCASE AND CRANKSHAFT	5-40
CRANKCASE AND CRANKSHAFT	5-40
DISSASSEMBLING THE CRANKCASE	5-41
REMOVING THE CRANKSHAFT ASSEMBLY	5-41
REMOVING THE CRANKSHAFT BEARING	5-42
CHECKING THE CRANKSHAFT AND CONNECTING ROD	5-42
CHECKING THE CRANKCASE	5-43
CHECKING THE BEARINGS AND OIL SEALS	5-43
INSTALLING THE CRANKSHAFT	5-44
ASSEMBLING THE CRANKCASE	5-44
TRANSMISSION	5-46
REMOVING THE TRANSMISSION	5-49
CHECKING THE SHIFT FORKS	5-49
CHECKING THE SHIFT DRUM ASSEMBLY	5-50
CHECKING THE TRANSMISSION	5-50
INSTALLING THE TRANSMISSION	5-51

ENGINE


ENGINE DRIVE SPROCKET




Order	Job/Part	Q'ty	Remarks
	Removing the drive sprocket		
	Drive chain		Remove the parts in the order listed. Loosen. Refer to "ADJUSTING THE DRIVE CHAIN SLACK" in chapter 3.
1	Left crank case cover	1	
2	Nut	1	
3	Lock washer	1	
4	Drive sprocket	1	
			For installation, reverse the removal procedure.



EXHAUST PIPE




Order	Job/Part	Q'ty	Remarks
	Removing the exhaust pipe		
	Seat		Remove the parts in the order listed. Refer to "SEAT, SIDE COVERS AND FUEL TANK" in chapter 3.
	Right side cover		
1	Silencer	1	
2	Exhaust pipe joint	1	
3	Exhaust pipe spring	2	
4	Exhaust pipe	1	
5	Exhaust pipe gasket	2	
			For installation, reverse the removal procedure.



SILENCER FIBER REPLACEMENT

1. Remove:
 - seat
 - right side cover
 - bolt (silencer) ①
 - silencer ②
 - bolt (fiber) ③
 - washer




2. Remove:
 - inner pipe ①
3. Replace:
 - fiber ②
4. Install:
 - inner pipe

NOTE:

Fully apply Yamaha bond No. 1215 (Three bond No. 1215[®]) or equivalent as shown.



**Yamaha bond No.1215
(Three Bond No.1215[®])
90890-85505**



5. Install:
 - washer
 - bolt (fiber) ①
 - silencer ②
 - bolt (silencer) ③


	12 Nm (1.2 m•kg, 8.7 ft•lb)
	LOCTITE[®]

	12 Nm (1.2 m•kg, 8.7 ft•lb)
	7 Nm (0.7 m•kg, 5.1 ft•lb)
	7 Nm (0.7 m•kg, 5.1 ft•lb)


- right side cover
- seat

EAS00191


ENGINE



Order	Job/Part	Q'ty	Remarks
	<p>Removing the engine</p> <p>Coolant</p> <p>Seat</p> <p>Fuel tank</p> <p>Carburetor</p> <p>Exhaust pipe</p> <p>Silencer</p> <p>Clutch cable</p> <p>Radiator hose</p> <p>CDI magneto lead</p>		<p>Remove the parts in the order listed.</p> <p>NOTE: _____</p> <p>Place a suitable stand under the frame and engine.</p> <hr/> <p>Drain</p> <p>Refer to "CHANGING THE COOLANT" in chapter 3.</p> <p>Refer to "SEAT, SIDECOVERS AND FUEL TANK" in chapter 3.</p> <p>Refer to "CARBURETOR" in chapter 7.</p> <p>Refer to "EXHAUST PIPE".</p> <p>Refer to "HANDLEBAR" in chapter 4.</p> <p>Refer to "RADIATOR" in chapter 6.</p> <p>Disconnect.</p> <p>Loosen.</p>



Order	Job/Part	Q'ty	Remarks
	CDI magneto lead		Disconnect.
	Drive chain		Loosen. Refer to "ADJUSTING THE DRIVE CHAIN SLACK" in chapter 3.
1	Engine mount nut	2	
2	Engine mount bolt	2	
3	Pivot shaft nut	1	
4	Pivot shaft	1	
5	Engine	1	
			For installation, reverse the removal procedure.



EAS00192

INSTALLING THE ENGINE

1. Install:

- engine ①
- pivot shaft ②
- engine mount bolt (front) ③
- engine mount bolt (lower) ④

NOTE:

Do not fully tighten the bolts.

2. Tighten:

- pivot shaft nut  **63 Nm (6.3 m•kg, 46 ft•lb)**
- engine mount nut (front)  **69 Nm (6.9 m•kg, 50 ft•lb)**
- engine mount nut (lower)  **69 Nm (6.9 m•kg, 50 ft•lb)**


CYLINDER HEAD, CYLINDER AND PISTON



EAS00221

CYLINDER HEAD, CYLINDER AND PISTON

CYLINDER HEAD





Order	Job/Part	Q'ty	Remarks
	Removing the cylinder head		Remove the parts in the order listed.
	Coolant		Drain Refer to "CHANGING THE COOLANT" in chapter 3.
	Seat		Refer to "SEAT, SIDECOVERS AND FUEL TANK" in chapter 3.
	Fuel tank		
	Radiator hose		Refer to "RADIATOR" in chapter 6.
1	Spark plug	1	
2	Cylinder head nut	4	
3	Copper washer	4	
4	Cylinder head	1	
5	O-ring	2	
			For installation, reverse the removal procedure.



- d. Place a 400 ~ 600 grit wet sandpaper on the surface plate and resurface the cylinder head using a figure-eight sanding pattern.

NOTE:

To ensure an even surface, rotate the cylinder head several times.



EAS00233

INSTALLING THE CYLINDER HEAD

1. Lubricate:
 - O-rings

	Recommended lubricant Lithium-soap-based grease
--	--

2. Install:
 - O-rings ① **New**

3. Install:
 - cylinder head ①
 - copper washer ②
 - cylinder head nuts ③

30 Nm (3.0 m•kg, 22 ft•lb)

NOTE:

Tighten the cylinder head nuts in stage, using a crisscross pattern.

4. Install:
 - spark plug
 - spark plug cap
 - radiator hoses.


CYLINDER HEAD, CYLINDER AND PISTON

ENG




EAS00251

CYLINDER AND PISTON



Order	Job/Part	Q'ty	Remarks
	Removing the cylinder and piston		Remove the parts in the order listed. Refer to "CYLINDER HEAD".
1	Cylinder head	4	
2	Cylinder nut	1	
3	Cylinder	1	
3	Dowel pin	4	
4	Cylinder gasket	1	
5	Piston pin clip	2	
6	Piston pin	1	
7	Piston	1	
8	Small end bearing	1	
9	Piston ring	1	
			For installation, reverse the removal procedure.




EAS00253

REMOVING THE CYLINDER AND PISTON

1. Remove:
 - piston pin clip ①

NOTE: _____

Before removing the piston pin clip, cover the crankcase opening with a clean rag to prevent the piston pin clip from falling into the crankcase.



2. Remove:
 - piston pin ①
 - piston ②
 - small end bearing ③

CAUTION: _____


Do not use a hammer to drive the piston pin out.

NOTE: _____

Before removing the piston pin, deburr the piston pin clip's groove and the piston's pin bore area. If both areas are deburred and the piston pin is still difficult to remove, remove it with the piston pin puller set ④.



Piston pin puller set
90890-01304, YU-1304



3. Remove:
 - piston ring ①

NOTE: _____

When removing a piston ring, open the end gap with your fingers and lift the other side of the ring over the piston crown.

EAS00257


CHECKING THE CYLINDER AND PISTON

1. Check:
 - piston wall
 - cylinder wall

Vertical scratches → Replace the cylinder, and the piston and piston rings as a set.

CYLINDER HEAD, CYLINDER AND PISTON

ENG



2. Measure:

- piston-to-cylinder clearance




- a. Measure cylinder bore “C” with the cylinder bore gauge.

NOTE:

Measure cylinder bore “C” by taking side-to-side and front-to-back measurements of the cylinder. Then, find the average of the measurements.

Standard	47.500 ~ 47.514 mm (1.8701 ~ 1.8706 in)
Wear limit	47.6 mm (1.8740 in)
Taper limit “T”	0.05 mm (0.0020 in)
Out of round “R”	0.05 mm (0.0020 in)

“C” = maximum of D₁ ~ D₆
“T” = maximum of D₁ or D₂ – maximum of D₅ or D₆
“R” = maximum of D₁ D₃ or D₅ – minimum of D₂ D₄ or D₆



- b. If out of specification, replace the cylinder, and the piston and piston rings as a set.
c. Measure piston skirt diameter “P” with the micrometer.

- Ⓐ 20.0 mm (0.79 in) from the bottom edge of the piston

Piston size “P”
Standard
47.457 ~ 47.472 mm (1.8684 ~ 1.8690 in)

- d. If out of specification, replace the piston and piston rings as a set.
e. Calculate the piston-to-cylinder clearance with the following formula.

Piston-to-cylinder clearance = Cylinder bore “C” – Piston skirt diameter “P”




Piston-to-cylinder clearance 0.040 ~ 0.045 mm (0.0016 ~ 0.0018 in) <Limit>: 0.10 mm (0.0039 in)
--

- f. If out of specification, replace the cylinder, and the piston and piston rings as a set.



CYLINDER HEAD, CYLINDER AND PISTON

ENG



COMBINATION OF PISTON AND CYLINDER

1. Check:

- cylinder mark (a)

Cylinder mark (a)	Cylinder size
A	47.500 ~ 47.502 mm (1.8701 ~ 1.8702 in)
B	47.504 ~ 47.506 mm (1.8702 ~ 1.8703 in)
C	47.508 ~ 47.510 mm (1.8704 ~ 1.8705 in)
D	47.512 ~ 47.514 mm (1.87055 ~ 1.87063 in)

2. Check:

- piston mark (b)

Piston mark (b) (color)	Piston size
A (red)	47.457 ~ 47.460 mm (1.8684 ~ 1.8685 in)
B (orange)	47.461 ~ 47.464 mm (1.8685 ~ 1.8687 in)
C (green)	47.465 ~ 47.468 mm (1.8687 ~ 1.8688 in)
D (purple)	47.469 ~ 47.472 mm (1.8689 ~ 1.8690 in)


3. Combination:



- combine the piston and cylinder by the following chart.

Cylinder mark	Piston mark (color)
A	A (red)
B	B (orange)
C	C (green)
D	D (purple)

NOTE:

When you purchase a cylinder, you cannot designate its size. Choose the piston that matches the above chart.





EAS00263

CHECKING THE PISTON RING

1. Measure:

- piston ring side clearance
Out of specification → Replace the piston and piston ring as a set.

NOTE:

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston ring.



Piston ring side clearance

Piston ring

0.030 ~ 0.065 mm

(0.001 ~ 0.003 in)

<Limit>: 0.1 mm (0.004 in)

2. Install:

- piston ring
(into the cylinder)

NOTE:

Level the piston ring into the cylinder with the piston crown.

3. Measure:

- piston ring end gap
Out of specification → Replace the piston ring.




Piston ring end gap

Top ring

0.30 ~ 0.45 mm

(0.012 ~ 0.018 in)

<Limit>: 0.80 mm (0.032 in)



CHECKING THE PISTON PIN

1. Check:

- piston pin
Blue discoloration/grooves → Replace the piston pin and then check the fuel and engine mixing oil.

2. Measure:


- piston pin outside diameter (a)
Out of specification → Replace the piston pin.



Piston pin outside diameter
 13.996 ~ 14.000 mm
 (0.5510 ~ 0.5512 in)
 <Limit>: 13.975 mm (0.5502 in)

3. Measure:

- piston pin bore inside diameter (b)
 Out of specification → Replace the piston.




Piston pin bore inside diameter
 14.004 ~ 14.015 mm
 (0.5513 ~ 0.5518 in)
 <Limit>: 14.040 mm (0.5528 in)

4. Calculate:

- piston-pin-to-piston clearance
 Out of specification → Replace the piston pin and piston as a set.



Piston-pin-to-piston clearance =
Piston pin bore size –
Piston pin outside diameter
Piston-pin-to-piston clearance
 0.008 ~ 0.015 mm
 (0.0003 ~ 0.0006 in)
 <Limit>: 0.065 mm (0.0026 in)



CHECKING THE SMALL END BEARING

1. Check:

- small end bearing
 Signs of heat discoloration → Replace.



EAS00267


INSTALLING THE PISTON AND CYLINDER

1. Install:

- piston ring ①

NOTE: _____


- Take care not to scratch the piston or damage the piston ring.
- Align the piston ring gap with the pin ②.
- After installing the piston ring, check the smooth movement of it.



2. Install:

- gasket (cylinder) ① **New**
- small end bearing ②
(with the recommended lubricant)
- dowel pin ③

	Recommended lubricant Engine oil
---	---





3. Install:

- piston ①
- piston pin ②
- piston pin clip ③ **New**


NOTE: _____

- Apply engine oil the piston pin.
- Make sure the arrow mark (a) on the piston points towards the exhaust side of the cylinder.
- Before installing the piston pin clip, cover the crankcase opening with a clean rag to prevent the clip from falling into the crankcase.
- Do not allow the clip open ends to meet the piston pin slat (b).



CYLINDER HEAD, CYLINDER AND PISTON

ENG



4. Lubricate:

- piston
- piston ring
- cylinder
(with the recommended lubricant)



Recommended lubricant
Engine oil

5. Install:

- cylinder ①
- cylinder nut ②  **28 Nm (2.8 m•kg, 20 ft•lb)**


NOTE:

- While compressing the piston ring with one hand, install the cylinder with the other hand.
- Tighten the nuts in stage, using a crisscross pattern.




EAS00274


CLUTCH
CLUTCH



Order	Job/Part	Q'ty	Remarks
	Removing the clutch		
	Transmission oil		Drain Refer to "CHANGING THE TRANSMISSION OIL" in chapter 3.
	Clutch cable		Disconnect
1	Clutch cover	1	
2	Clutch cover gasket	1	
3	Dowel pin	2	
4	Compression spring	5	
5	Pressure plate	1	
6	Push rod 1	1	
7	Ball	1	
8	Push rod 2	1	
9	Friction plate 1	2	
10	Clutch plate 1	6	
11	Friction plate 2	5	
12	Clutch boss nut	1	



Order	Job/Part	Q'ty	Remarks
13	Conical washer	1	
14	Clutch boss	1	
15	Washer	1	
16	Primary drive gear	1	
17	Spacer	1	
18	Washer	1	
19	Push lever shaft	1	
20	Spring	1	
21	Oil seal	1	
22	Bearing	1	
			For installation, reverse the removal procedure.




EAS00276

REMOVING THE CLUTCH


1. Remove:
 - clutch cover ①
 - gasket

NOTE:


Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.



2. Remove:
 - compression spring bolts ①
 - compression springs
 - pressure plate ②
3. Remove:
 - push rod 1
 - ball
 - push rod 2



4. Remove:
 - friction plate 1 ①
 - clutch plate ②
 - friction plate 2 ③



5. Remove:
 - clutch boss nut ①
 - washer ②
 - clutch boss ③

NOTE:

While holding the clutch boss with the universal clutch holder ④, loosen the clutch boss nut.



Universal clutch holder
90890-04086, YM-91042

6. Remove:
 - washer
 - primary driven gear
 - spacer



EAS00280


CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

1. Check:
 - friction plate
Damage/wear → Replace the friction plates as a set.
2. Measure:
 - friction plate thickness
Out of specification → Replace the friction plates as a set.

NOTE:

Measure the friction plate at four places.



1411101

**Friction plate thickness**

2.9 ~ 3.1 mm (0.114 ~ 0.112 in)


<Limit>: 2.7 mm (0.106 in)

EAS00281

CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.

1. Check:
 - clutch plate
Damage → Replace the clutch plates as a set.
2. Measure:
 - clutch plate warpage
(with a surface plate and thickness gauge
①)
Out of specification → Replace the clutch plates as a set.



1411901

**Clutch plate warpage limit**

0.1 mm (0.004 in)



EAS00282


CHECKING THE CLUTCH SPRINGS

The following procedure applies to all of the clutch springs.

1. Check:

- clutch spring

Damage → Replace the clutch springs as a set.



11412901

2. Measure:

- clutch spring free length (a)

Out of specification → Replace the clutch springs as a set.



Clutch spring free length

33.0 mm (1.30 in)

<Limit>: 31.0 mm (1.22 in)

EAS00284

CHECKING THE CLUTCH HOUSING


1. Check:

- clutch housing dogs

Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

NOTE: _____

Pitting on the clutch housing dogs will cause erratic clutch operation.



EAS00285

CHECKING THE CLUTCH BOSS


1. Check:

- clutch boss splines

Damage/pitting/wear → Replace the clutch boss.

NOTE: _____

Pitting on the clutch boss splines will cause erratic clutch operation.




EAS00286


CHECKING THE PRESSURE PLATE

1. Check:

- pressure plate


Cracks/damage → Replace.





CHECKING THE PUSH LEVER SHAFT


1. Check:
 - push lever shaft
Wear/damage → Replace.



EAS00288

CHECKING THE CLUTCH PUSH RODS

1. Check:
 - push rod 1 ①
 - ball ②
 - push rod 2 ③
Wear/damage/bend → Replace.




EAS00298

INSTALLING THE CLUTCH


1. Install:
 - washer ①
 - spacer ②
 - primary driven gear ③
(with the recommended lubricant)



Recommended lubricant
Transmission oil




2. Install:
 - washer ①
 - clutch boss ②



3. Install:
 - washer ①

NOTE:

Install the conical washer to the main axle ② as shown in the illustration.



4. Install:

- clutch boss nut ①

 70 Nm (7.0 m•kg, 51 ft•lb)

NOTE:

While holding the clutch boss with the universal clutch holder ②, tighten the clutch boss nut.






Universal clutch holder
90890-04086, YM-91042

5. Lubricate:

- friction plates
- clutch plates
(with the recommended lubricant)



Recommended lubricant
Transmission oil



6. Install:

- friction plate 1 ①
- clutch plate ②
- friction plate 2 ③

NOTE:


- Install the clutch plates and friction plates alternately on the clutch boss, starting with a friction plate and ending with a friction plate.
- Use the friction plate for the first and final while paying attention to the difference in surface pattern.

7. Install:

- push rod 2 ①
- ball ②
- push rod 1 ③
(with the recommended lubricant)




Recommended lubricant
Transmission oil



8. Install:
- pressure plate 1 (1)

NOTE:

Align the punch mark (a) on the pressure plate with the punch mark (b) on the clutch boss.




9. Install:
- clutch spring (1)
 - clutch spring bolt (2)

 6 Nm (0.6 m•kg, 4.3 ft•lb)

NOTE:

Tighten the clutch spring bolts in stages and in a crisscross pattern.



10. Install
- dowel pin
 - clutch cover gasket **New**
 - clutch cover (1)  10 Nm (1.0 m•kg, 7.2 ft•lb)


NOTE:

Tighten the bolts in stage, using a crisscross pattern.



EAS00327


KICK STARTER AND SHIFT SHAFT PRIMARY DRIVE GEAR



Order	Job/Part	Q'ty	Remarks
	Removing the primary drive gear		Remove the parts in the order listed.
	Transmission oil		Drain.
			Refer to "CHANGING THE TRANSMISSION OIL" in chapter 3.
	Coolant		Drain.
			Refer to "CHANGING THE COOLANT" in chapter 3.
	Water pump housing		Refer to "WATER PUMP" in chapter 6.
	Radiator hose 2		Refer to "RADIATOR" in chapter 6.
	Brake pedal		
	Clutch		Refer to "CLUTCH".
1	Kick starter crank	1	
2	Right crankcase cover	1	
3	Gasket	1	
4	Dowel pin	2	
5	Primary drive gear nut	1	
6	Washer	1	

KICK STARTER AND SHIFT SHAFT


ENG



Order	Job/Part	Q'ty	Remarks
7	Primary drive gear	1	For installation, reverse the removal procedure.




KICK STARTER AND SHIFT SHAFT




Order	Job/Part	Q'ty	Remarks
	Removing the kick starter shaft and shift		Remove the parts in the order listed.
	shaft		
1	Circlip	1	
2	Washer	2	
3	Kick idle gear	1	
4	Spring guide	1	
5	Torsion spring	1	
6	Washer	1	
7	Kick starter gear clip	1	
8	Kick starter gear	1	
9	Kick starter shaft	1	
10	Shift pedal	1	
11	Shift shaft	1	
12	Stopper lever spring	1	
13	Circlip	1	

KICK STARTER AND SHIFT SHAFT

ENG



Order	Job/Part	Q'ty	Remarks
14	Washer	1	For installation, reverse the removal procedure.
15	Stopper lever	1	
16	Collar	1	
17	Shift shaft spring	1	
18	Oil seal	1	
19	Oil seal	1	



REMOVING THE PRIMARY DRIVE GEAR


1. Remove:
 - nut (primary drive gear) ①

NOTE:

Hold the drive gear holder ② onto the crankcase using the M6 bolts ③.



Drive gear holder
90890-01495, YM-01495




REMOVING THE KICK SHAFT ASSEMBLY

1. Remove:
 - kick shaft assembly ①


NOTE:

Unhook the torsion spring ② from the hole ① in the crankcase.




CHECKING THE KICK STARTER

1. Check:
 - kick starter gear smooth movement
Unsmooth movement → Replace.
 - kick starter shaft ①
Wear/damage → Replace.




2. Check:
 - kick starter gear ①
Wear/damage → Replace.
 - kick idle gear ②
Wear/damage → Replace.
 - gear teeth ①
Wear/damage → Replace.



3. Measure:
 - kick starter gear clip friction force
Out of specification → Replace.
(with the spring gauge ①)




Kick starter gear clip force
0.6 ~ 1.5 kg (1.3 ~ 3.3 lb)



EAS00328

CHECKING THE SHIFT SHAFT


1. Check:
 - shift shaft ①
Bends/damage/wear → Replace.
 - spring ②
Damage/wear → Replace.



EAS00330


CHECKING THE STOPPER LEVER

1. Check:
 - stopper lever ①
Bends/damage → Replace.
 - torsion spring ②
Damage/wear → Replace.



CHECKING THE PRIMARY DRIVE GEAR AND PRIMARY DRIVEN GEAR

1. Check:
 - primary drive gear ①
Damage/wear → Replace.
 - primary driven gear ②
Damage/wear → Replace.
2. Check:
 - primary driven gear circumferencial play
Free play exists → Replace.



EAS00331

INSTALLING THE SHIFT SHAFT


1. Install:
 - stopper lever ①
 - washer ②
 - circlip ③ **New**
 - torsion spring ④
(with thw collar ⑤)

NOTE:

Install the torsion spring with its shorter end (a) aligning with the stopper (b).

KICK STARTER AND SHIFT SHAFT


ENG



2. Install:
- stopper lever assembly ①
(with the shift shaft ②)

NOTE:



Apply the transmission oil on the stopper lever assembly.




3. Install:
- stopper lever
 - shift shaft ①

NOTE:

- Apply transmission oil on the shift shaft.
- When installing the shift shaft, align the stopper lever roller with the slot on segment.
- When installing the shift shaft, make sure that the torsion spring ② is in the position as shown.



4. Check:
- shift lever ① position
- Gaps ① and ② are not equal except in neutral → Replace the shift shaft.




INSTALLING THE KICK STARTER SHAFT ASSEMBLY

1. Install:
 - kick starter gear ①
 - washer ②
 - torsion spring ③

NOTE: _____


Make sure the stopper (a) of the torsion spring fits into the hole (c) in the other side of the stopper (b) of the kick starter shaft (4).



2. Install:
 - spring guide ①

NOTE: _____


Slide the spring guide into the kick starter shaft, make sure the groove (a) in the spring guide fits on the stopper of the torsion spring.



3. Install:
 - kick starter shaft assembly ①

NOTE: _____


- Apply the transmission oil on the kick shaft.
- Apply the lithium soap base grease on the kick shaft stopper.
- Slide the kick starter shaft assembly into the crankcase, make sure the clip (2) and kick starter shaft stopper (a) fit into their home positions (b), (c).



4. Install:
 - torsion spring ①

NOTE: _____

Turn the torsion spring clockwise and hook into the proper hole (a) in the crankcase.




INSTALLING THE KICK IDLE GEAR

1. Install:
 - washer ①
 - kick idle gear ②
 - circlip ③ **New**


NOTE: _____

- Apply the transmission oil on the kick idle gear inner circumference.
- Install the kick idle gear with its groove (a) facing the engine.



INSTALLING THE PRIMARY DRIVE GEAR


1. Install:
 - straight key ①



2. Install:
 - primary drive gear ①
 - washer ②
 - primary drive gear nut ③

NOTE:

Install the conical washer to the crankshaft ④ as shown in the illustration.



3. Tighten:
 - primary drive gear nut ①


79 Nm (7.9 m•kg, 57 ft•lb)




Drive gear holder
90890-01495, YM-01495

NOTE:

Hold the drive gear holder ② onto the crankcase using the M6 bolts ③.



4. Install:
 - primary driven gear
Refer to "CLUTCH".
5. Install:
 - dowel pin ①
 - gasket (right crankcase cover) ② **New**




6. Install:
 - right crankcase cover ①

NOTE:

Mesh the impeller shaft gear ② with primary drive gear ③.

KICK STARTER AND SHIFT SHAFT

ENG



7. Install:

- bolt (right crankcase cover) ①

10 Nm (1.0 m•kg, 7.2 ft•lb)

- copper washer (oil drain bolt) ② **New**

- oil drain bolt ③

10 Nm (1.0 m•kg, 7.2 ft•lb)


- copper washer (coolant drain bolt) ④ **New**

- coolant drain bolt ⑤

10 Nm (1.0 m•kg, 7.2 ft•lb)

NOTE:

Tighten the bolts in stage, using a crisscross pattern.




8. Install:

- kick starter crank ①

10 Nm (1.0 m•kg, 7.2 ft•lb)

NOTE:

Install the kick starter crank closest to but not contacting the pillar tube ② and exhaust pipe ③.



9. Install:

- shift pedal ①

10 Nm (1.0 m•kg, 7.2 ft•lb)


NOTE:

Install the shift pedal with the bottom of the pedal outer diameter (a) as close to the center of the engine mounting bolt ② as possible.





EAS00343

CDI MAGNETO



Order	Job/Part	Q'ty	Remarks
	Removing the CDI magneto		Remove the parts in the order listed.
	Seat		
	Fuel tank		
1	CDI magneto lead	1	Disconnect.
2	Left crankcase cover	1	
3	Left crankcase cover gasket	1	
4	Rotor	1	
5	Stator	1	
6	Woodruff key	1	
			For installation, reverse the removal procedure.



EAS00346

REMOVING THE ROTOR

1. Remove:
 - nut ①
 - washer ②

NOTE: _____
 While holding the rotor with the rotor holding tool ③, loosen the rotor nut.




Rotor holding tool
 90890-01235, YU-1325

2. Remove:
 - rotor ①
 (with the flywheel puller ②)
 - woodruff key




Flywheel puller
 90890-01189, YM-1189

NOTE: _____
 When installing the flywheel puller, turn it counterclockwise.




CHECKING THE CDI MAGNETO

1. Check:
 - rotor inner surface (a)
 - stator outer surface (b)
 Damage → Inspect the crankshaft runout and crankshaft bearing.
 If necessary, replace CDI magneto and/or stator.



CHECKING THE WOODRUFF KEY


1. Check:
 - woodruff key ①
 Damage → Replace.



INSTALLING THE CDI MAGNETO

1. Install:
- stator ①
 - screw ②


NOTE: _____
Temporarily tighten the screw at this point.



2. Install:
- woodruff key ①
 - rotor ②

NOTE: _____

- Clean the tapered portions of the crankshaft and rotor.
- When installing the woodruff key, make sure that its flat surface ① is in parallel with the crankshaft center line ②.
- When installing the rotor, align the keyway ③ of the rotor with the woodruff key.




3. Install:
- washer ①
 - nut ②
- 33 Nm (3.3 m•kg, 24 ft•lb)**
(with the rotor holding tool ③)

	Rotor holding tool 90890-01235, YU-1325
---	---

4. Adjust:
- ignition timing

	Ignition timing (B.T.D.C.) 0.9 mm (0.035 in)
---	--


Refer to “CHECKING THE IGNITION TIMING” in chapter 3.




5. Tighten:
- screw (stator) ①

 8 Nm (0.8 m•kg, 5.8 ft•lb)

6. Check:
- ignition timing
- Re-check the ignition timing.



7. Connect:
- CDI magneto lead ①
- Refer to “CABLE ROUTING” in chapter 2.



8. Install:
- gasket (left crankcase cover) **New**
 - left crankcase cover ①


 5 Nm (0.5 m•kg, 3.6 ft•lb)

NOTE: _____
Tighten the screws in stage, using a crisscross pattern.


EAS00381

CRANKCASE AND CRANKSHAFT

CRANKCASE AND CRANKSHAFT



Order	Job/Part	Q'ty	Remarks
	Removing the crankcase and crankshaft		Remove the parts in the order listed.
	Engine		Refer to "ENGINE".
	Piston		Refer to "CYLINDER AND PISTON".
	Primary drive gear		Refer to "CLUTCH".
	Kick idle gear		Refer to "KICK STARTER AND SHIFT SHAFT".
	Stopper lever		Refer to "KICK STARTER AND SHIFT SHAFT".
	Rotor and stator		Refer to "CDI MAGNETO".
1	Crank case oil seal holder	1	
2	Right crankcase	1	
3	Left crankcase	1	
4	Dowel pin	2	
5	Crankshaft	1	
6	Oil seal	2	
7	Bearing	2	
			For installation, reverse the removal procedure.



EAS00385

DISSASSEMBLING THE CRANKCASE

1. Remove:

- right crankcase ①
(with the crankcase separating tool ②)





Crankcase separating tool
90890-01135, YU-1135-A

NOTE:

- Fully tighten the tool holding bolts, but make sure the tool body is parallel with the case. If necessary, one screw may be backed out slightly to level tool body.
- As pressure is applied, alternately tap on the front engine mounting boss and transmission shafts.

CAUTION:

- Turn the segment ③ to the position shown in the figure so that it does not contact the crankcase.
- Use soft hammer to tap on the case half. Tap only on reinforced portions of case. Do not tap on gasket mating surface. Work slowly and carefully. Make sure the case halves separate evenly. If one end “hangs up”, take pressure off the push screw, realign, and start over. If the cases do not separate, check for a remaining case screw or fitting. Do not force.



EAS00388

REMOVING THE CRANKSHAFT ASSEMBLY

1. Remove:

- crankshaft ①
(with the crankcase separating tool ②)






Crankcase separating tool
90890-01135, YU-1135-A

NOTE:

Make appropriate bolts ③ as shown available by yourself and attach the tool with them.

CAUTION:

Do not use a hammer to drive out the crankshaft.



REMOVING THE CRANKSHAFT BEARING

1. Remove:
 - bearing ①

NOTE: _____

- Remove the bearing from the crankcase by pressing its inner race as shown in [A].
- If the bearing is removed together with the crankshaft, remove the bearing using a general bearing puller ② as shown in [B].

CAUTION: _____

Do not use the removed bearing.

EAS00394

CHECKING THE CRANKSHAFT AND CONNECTING ROD

1. Measure:
 - crankshaft runout ①
 Out of specification → Replace the crankshaft, bearing or both.

NOTE: _____

Turn the crankshaft slowly.




Maximum crankshaft runout
0.08 mm (0.003 in)

2. Measure:
 - small end free play ②
 Out of specification → Replace the small end bearing or piston pin.



Maximum small end free play
2.0 mm (0.08 in)



3. Measure:

- big end side clearance (c)

Out of specification → Replace the big end bearing, crankshaft pin, or connecting rod.



Big end side clearance

0.20 ~ 0.70 mm (0.008 ~ 0.028 in)

4. Measure:

- crankshaft width (d)


Out of specification → Replace the crankshaft.



Crankshaft width

44.90 ~ 44.95 mm

(1.768 ~ 1.770 in)




EAS00399

CHECKING THE CRANKCASE

1. Check:

- contacting surface (a)
Scratches → Replace.
- engine mounting boss (b), crankcase
Cracks/damage → Replace.




EAS00401

CHECKING THE BEARINGS AND OIL SEALS


1. Check:

- bearings (1)
Clean and lubricate the bearings, then rotate the inner race with your finger.
Rough movement → Replace.



2. Check:

- oil seals (1)
Damage/wear → Replace.



EAS00408

INSTALLING THE CRANKSHAFT

1. Install:

- crankshaft assembly ①

NOTE:

- Install the crankshaft assembly with the crankshaft installer pot ②, crankshaft installer bolt ③, adapter (M10) ④.




Crankshaft installer pot
90890-01274, YU-90050
Crankshaft installer bolt
90890-01275, YU-90050
Adapter (M10)
90890-01277, YM-1277

CAUTION:

To avoid scratching the crankshaft and to ease the installation procedure, lubricate the oil seal lips with lithium-soap-based grease and each bearing with engine oil.

NOTE:

Hold the connecting rod at top dead center with one hand while turning the nut of the crankshaft installer bolt with the other. Turn the crankshaft installer bolt until the crankshaft assembly bottoms against the bearing.



EAS00416

ASSEMBLING THE CRANKCASE

1. Apply:

- sealant
(onto the crankcase mating surfaces)




Yamaha bond No. 1215
(Three Bond No. 1215®)
90890-85505

NOTE:

Do not allow any sealant to come into contact with the oil gallery.

CRANKCASE AND CRANKSHAFT



ENG



2. Install:
 - dowel pin ①
 - right crankcase ②
(onto the left crankcase ③)

NOTE:

- Turn the shift cam ④ to the position shown in the figure so that it does not contact the crankcase when installing the crankcase.
- Fit the right crankcase onto the left crankcase. Tap lightly on the case with soft hammer.
- When installing the crankcase, the connecting rod should be positioned at TDC.




3. Install:
 - clamp ①
 - screw ②

 8 Nm (0.8 m•kg, 5.8 ft•lb)

NOTE:

Tighten the crankcase tightening screws in stage, using a crisscross pattern.



4. Install:
 - crankcase oil seal holder ①
 - bolt ②

 20 Nm (2.0 m•kg, 14 ft•lb)


LOCTITE®

5. Remove:
 - sealant
 - forced out on the cylinder mating surface.
6. Apply:
 - Transmission oil
To the crank pin, bearing, oil delivery hole and connecting rod end washer.
7. Check:
 - crankshaft and transmission operation
Unsmooth operation → Repair.




EAS00419


TRANSMISSION




Order	Job/Part	Q'ty	Remarks
	Removing the transmission		Remove the parts in the order listed.
	Engine		Refer to "ENGINE".
	Crankcase		Separate. Refer to "CRANKCASE AND CRANKSHAFT".
1	Shift fork guide bar	2	
2	Shift drum	1	
3	Shift fork-R	1	
4	Shift fork-L	1	
5	Shift fork-C	1	
6	Bearing	1	
7	Circlip	1	
8	2ND pinion gear	1	
9	6TH pinion gear	1	
10	Washer	1	
11	Circlip	1	



Order	Job/Part	Q'ty	Remarks
12	3RD pinion gear	1	
13	Circlip	1	
14	Washer	1	
15	5TH pinion gear	1	
16	Main axle	1	
17	Bearing	1	
18	Circlip	1	
19	Washer	1	
20	1ST wheel gear	1	
21	5TH wheel gear	1	
22	Circlip	1	
23	Washer	1	
24	4TH wheel gear	1	
25	3RD wheel gear	1	
26	6TH wheel gear	1	
27	Drive axle	1	



Order	Job/Part	Q'ty	Remarks
28	2ND wheel gear	1	For installation, reverse the removal procedure.
29	Washer	1	
30	Bearing	1	
31	Oil seal	1	
32	Bearing	2	




EAS00420

REMOVING THE TRANSMISSION

1. Remove:
 - right crankcase
Refer to "CRANKCASE AND CRANK-SHAFT".
2. Remove:
 - main axle ①
 - drive axle ②

NOTE:

- Remove assembly carefully. Note the position of each part. Pay particular attention to the location and direction of shift forks.
- Remove the main axle and drive axle by tapping lightly on the transmission drive axle with a soft hammer.




AS00421

CHECKING THE SHIFT FORKS

The following procedure applies to all of the shift forks.


1. Check:
 - shift fork pin ①
 - shift fork cam follower ②
Bends/damage/scoring/wear → Replace the shift fork.




2. Check:
 - shift fork guide bar
Roll the shift fork guide bar on a flat surface.
Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent shift fork guide bar.



3. Check:
 - shift fork movement
(along the shift fork guide bar)
Rough movement → Replace the shift forks and shift fork guide bar as a set.




EAS00422

CHECKING THE SHIFT DRUM ASSEMBLY

1. Check:

- shift drum grooves
Damage/scratches/wear → Replace the shift drum assembly.
- shift drum segment ①
Damage/wear → Replace the shift drum assembly.
- shift drum bearing ②
Damage/pitting → Replace the shift drum assembly.



EAS00423


CHECKING THE TRANSMISSION

1. Measure:

- main axle runout
(with a centering device and dial gauge ①)
Out of specification → Replace the main axle.



Main axle runout limit
0.01 mm (0.0004 in)




2. Measure:

- drive axle runout
(with a centering device and dial gauge ①)
Out of specification → Replace the drive axle.




Drive axle runout limit
0.01 mm (0.0004 in)




3. Check:

- transmission gears ①
Blue discoloration/pitting/wear → Replace the defective gear(s).
- transmission gear dogs ②
Cracks/damage/rounded edges → Replace the defective gear(s).
- transmission shift fork groove ③
Wear/damage → Replace.



4. Check:
 - transmission gear engagement
(each pinion gear to its respective wheel gear)
Incorrect → Reassemble the transmission axle assemblies.
5. Check:
 - transmission gear movement
Rough movement → Replace the defective part(s).
6. Check:
 - circlips
Bends/damage/looseness → Replace.




INSTALLING THE TRANSMISSION


1. Install:
 - 5TH pinion gear ①
 - 3RD/4TH pinion gear ②
 - 6TH pinion gear ③
 - 2ND pinion gear ④
 - (onto the main axle ⑤)

- NOTE:**
- Apply the molybdenum disulfide oil on the 5TH and 6TH pinion gears inner circumference and on the end surface.
 - Apply the transmission oil on the 3RD/4TH and 2ND pinion gears inner circumference.

2. Install:
 - 2ND wheel gear ①
 - 6TH wheel gear ②
 - 3RD wheel gear ③
 - 4TH wheel gear ④
 - 5TH wheel gear ⑤
 - 1ST wheel gear ⑥
 - (onto the drive axle ⑦)

- NOTE:**
- Apply the molybdenum disulfide oil on the 1ST, 2ND, 3RD and 4TH wheel gears inner circumference and on the end surface.
 - Apply the transmission oil on the 5TH and 6TH wheel gears inner circumference.







3. Install:
- washer ①
 - circlip ② **New**

NOTE:


- Be sure the circlip sharp-edged corner (a) is positioned opposite side to the washer and gear (b).
- Be sure the circlip end (c) is positioned at axle spline groove (d).




4. Install:
- collar ①

NOTE:


- Apply the lithium soap base grease on the oil seal lip.
- When installing the collar into the crankcase, pay careful attention to the crankcase oil seal lip.



5. Install:
- main axle ①
 - drive axle ②




6. Install:
- shift fork-L ①
 - shift fork-C ②
 - shift fork-R ③
 - shift fork pin ④



NOTE:

- Mesh the shift fork-L ① with the 6th wheel gear ⑤ and shift fork-R ③ with the 5TH wheel gear ⑦ on the drive axle.
- Mesh the shift fork-C ② with the 3RD/4TH pinion gear ⑥ on the main axle.




7. Install:

- shift cam ①

NOTE:

Apply the transmission oil on the shift cam.




8. Install:

- shift fork guide bar ①


NOTE:

- Apply the transmission oil on the guide bars.
- Be sure the long bar is inserted into the shift fork-L and shift fork-R and the short one into shift fork-C.



9. Check:

- shifter operation
- transmission operation



CHAPTER 6 COOLING SYSTEM


RADIATOR	6-1
CHECKING THE RADIATOR	6-2
INSTALLING THE RADIATOR	6-2
WATER PUMP	6-4
CHECKING THE WATER PUMP	6-5
INSTALLING THE WATER PUMP	6-5



EAS00454

COOLING SYSTEM


RADIATOR



Order	Job/Part	Q'ty	Remarks
	Removing the radiator		Remove the parts in the order listed.
	Air scoop		Refer to "SEAT, SIDECOVERS AND FUEL TANK" in chapter 3.
	Coolant		Drain. Refer to "CHANGING THE COOLANT" in chapter 3.
1	Radiator guard	1	
2	Radiator inlet hose	1	
3	Radiator outlet hose	1	
4	Radiator breather hose	1	
5	Radiator	1	
6	Radiator cap	1	
			For installation, reverse the removal procedure.

RADIATOR

COOL



2. Check:

- cooling system

Leaks → Repair or replace any faulty part.



- Attach the radiator cap tester ① to the radiator.



Radiator cap tester

90890-01325, YU-24460-01

Radiator cap tester adapter

90890-01352, YU-33984

- Apply 100 kPa (1.0 kg/cm², 14.22 psi) of pressure.


- Measure the indicated pressure with the gauge.






EAS00468

WATER PUMP



Order	Job/Part	Q'ty	Remarks
	Removing the water pump		Remove the parts in the order listed. NOTE: _____ It is not necessary to remove the water pump unless the coolant level is extremely low or the coolant contains engine oil. _____
	Right crankcase cover		Refer to "PRIMARY DRIVE GEAR" in chapter 5.
1	Water pump housing	1	
2	Gasket	1	
3	Impeller	1	
4	Water pump impeller shaft	1	
5	Bearing	1	
6	Oil seal	2	
			For installation, reverse the removal procedure.




EAS00472

CHECKING THE WATER PUMP


1. Check:

- oil seal ①
Damage/wear → Replace.




2. Check:

- bearing ①
Rough movement → Replace.




3. Check:

- impeller ①
Cracks/damage/wear → Replace.



4. Check:

- water pump impeller shaft ①
Damage/wear → Replace.
- water pump drive gear ②
Damage/wear → Replace.



EAS00479

INSTALLING THE WATER PUMP

1. Install:


- oil seal ① **New**

NOTE:

Lubricate the oil seal with a thin coat of lithium-soap-based grease.

WATER PUMP


COOL



2. Install:
- bearing ①

NOTE: _____

Install the bearing by pressing its outer race parallel.





3. Install:
- water pump impeller shaft ①
 - washer ②
 - impeller ③

14 Nm (1.4 m•kg, 10 ft•lb)

NOTE: _____

- Take care so that the oil seal lip is not damaged or the spring does not slip off its position.
 - When installing the water pump impeller shaft, apply the lithium-soap-base grease on the oil seal lip and water pump impeller shaft. And install the shaft while turning it.
 - Hold the impeller shaft on its width across the flats (a) with spanners, etc. and install the impeller.
- _____



4. Install:
- gasket **New**
 - water pump housing ①

10 Nm (1.0 m•kg, 7.2 ft•lb)

- copper washer ② **New**

5. Fill:

- cooling system
(with the specified amount of the recommended coolant)
Refer to “CHANGING THE COOLANT” in chapter 3.

6. Check:

- cooling system
Refer to “CHECKING THE COOLING SYSTEM” in chapter 3.

**CHAPTER 7
CARBURETOR**


CARBURETOR AND REED VALVE 7-1
 CHECKING THE CARBURETOR 7-4
 CHECKING THE REED VALVE 7-5
 ASSEMBLY THE REED VALVE 7-6
 ASSEMBLING THE CARBURETOR 7-6
 INSTALLING THE REED VALVE 7-8
 INSTALLING THE CARBURETOR 7-8
 MEASURING AND ADJUSTING THE FUEL LEVEL 7-9
 CHECKING THE FUEL COCK 7-9



EAS00480


CARBURETOR

CARBURETOR AND REED VALVE




Order	Job/Part	Q'ty	Remarks
	Removing the carburetor and reed valve		Remove the parts in the order listed.
1	Clamp	2	Loosen.
2	Carburetor assembly	1	
3	Carburetor joint	1	
4	Reed valve assembly	1	
5	Reed valve stopper	2	
6	Reed valve	2	
			For installation, reverse the removal procedure.

CARBURETOR AND REED VALVE



Order	Job/Part	Q'ty	Remarks
	Disassembling the carburetor		Remove the parts in the order listed
①	Mixing chamber top	1	
②	Throttle valve	1	
③	Jet needle	1	
④	Ring	1	
⑤	Throttle valve spring	1	
⑥	Gascket (mixing chamber top)	1	
⑦	Float chamber	1	
⑧	Gascket (float chamber)	1	
⑨	Float pin	1	
⑩	Float	1	
⑪	Needle valve	1	
⑫	Main jet	1	
⑬	Main nozzle holder	1	
⑭	Main nozzle	1	
⑮	Pilot jet	1	


CARBURETOR AND REED VALVE



Order	Job/Part	Q'ty	Remarks
①⑥	Starter plunger	1	For assembly, reverse the disassembly procedure.
①⑦	Throttle stop screw	1	
①⑧	Pilot air screw	1	

CARBURETOR AND REED VALVE

CARB




7. Check:

- jet needle ①
- main nozzle ③
- main jet ②
- main nozzle holder ④
- pilot jet ⑤
- starter plunger ⑥

Bends/damage/wear → Replace.

Obstruction → Clean.

Blow out the jets with compressed air.



8. Check:

- piston valve movement

Insert the piston valve ① into the carburetor body and move it up and down.

Tightness → Replace the piston valve.

9. Check:

- hose joints

Cracks/damage → Replace.

10. Check:


- carburetor breather hoses

- fuel hoses

Cracks/damage/wear → Replace.

Obstruction → Clean.

Blow out the hoses with compressed air.



CHECKING THE REED VALVE


1. Measure:

- reed valve bending (a)

Out of limit → Replace.



Reed valve bending limit
0.2 mm (0.008 in)



- valve stopper height (b)


Out of specification → Replace.



Valve stopper height
7.4 ~ 7.8 mm (0.291 ~ 0.307 in)

CARBURETOR AND REED VALVE

CARB



ASSEMBLY THE REED VALVE


1. Install:

- reed valve ①
- reed valve stopper ②
- screw (reed valve) ③

 **1 Nm (0.1 m•kg, 0.7 ft•lb)**
LOCTITE®

NOTE:

- Install the reed valve with the reed valve bending as shown.
- Note the cut (a) in the lower corner of the reed valve and stopper.
- Tighten each screw gradually to avoid warping.



EAS00487

ASSEMBLING THE CARBURETOR

CAUTION:

- **Before assembling the carburetor, wash all of the parts in a petroleum-based solvent.**
- **Always use a new gasket.**

1. Install:

- pilot air screw ①
- throttle stop screw ②

NOTE:


- Turn in the pilot air screw until it is lightly seated.
- Turn out the pilot air screw by the number of turns recorded before removing.




Pilot air screw setting
2 turns out

CARBURETOR AND REED VALVE

CARB




2. Install:
- starter plunger ①



3. Install:
- pilot jet ①
 - main nozzle ②
 - main jet holder ③
 - main jet ④

NOTE:

Install the main nozzle with its chamfered side (a) facing the carburetor.




4. Install:
- needle valve ①
 - float ②
 - float pin ③

NOTE:

- After installing the needle valve to the float, install them to the carburetor.
- Check the float for smooth movement.

5. Install:
- float chamber
 - gasket (float chamber) **New**
 - hose holder (carburetor breather hose)


6. Install:
- carburetor breather hose
 - overflow hose



7. Install:
- jet needle ①
 - throttle valve ②

CARBURETOR AND REED VALVE

CARB




8. Install:

- throttle cable ①
- mixing chamber top ②
- gasgasket (mixing chamber top) ③ **New**
- spring (throttle valve) ④
- ring ⑤
- throttle valve ⑥

NOTE: _____

• While compressing the spring, connect the throttle cable.

• Align the cut (a) in the ring with the throttle cable.




INSTALLING THE REED VALVE

1. Install:

- reed valve assembly ①

NOTE: _____

Install the reed valve assembly with its projection (a) facing upward.



2. Install:

- carburetor joint ①

8 Nm (0.8 m•kg, 5.8 ft•lb)

EAS00492

INSTALLING THE CARBURETOR

1. Adjust:

- engine idle speed

Refer to "ADJUSTING THE ENGINE IDLING SPEED" in chapter 3.

CHAPTER 8
ELECTRICAL SYSTEM

ELECTRICAL COMPONENTS..... 8-1

CHECKING SWITCH CONTINUITY..... 8-2

IGNITION SYSTEM..... 8-3


TROUBLESHOOTING..... 8-3



EAS00729

ELECTRICAL SYSTEM

ELECTRICAL COMPONENTS

- ① Ignition coil
- ② Engine stop switch
- ③ CDI unit
- ④ CDI magneto





CEAS00730

CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

CAUTION:


Never insert the tester probes into the coupler terminal slots. Always insert the probes from the opposite end of the coupler ① taking care not to loosen or damage the leads.



Pocket tester
90890-03112, YU-3112

NOTE:

- Before checking for continuity, set the pocket tester to "0" and to the "Ω x 1" range.
- When checking for continuity, switch back and forth between the switch positions a few times.



EAS00736

IGNITION SYSTEM TROUBLESHOOTING

The ignition system fails to operate (no spark or intermittent spark).

Check:

1. Spark plug
2. Ignition spark gap
3. Spark plug cap resistance
4. Ignition coil resistance
5. Engine stop switch
6. Pickup coil resistance
7. Charging coil resistance
8. Wiring connections (of the entire ignition system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. air scoop
 3. fuel tank
- Troubleshoot with the following special tool(s).



Dynamic spark tester
YM-34487
Ignition checker
90890-06754
Pocket tester
90890-03112, YU-3112-C

EAS00740

1. Spark plug

- Check the condition of the spark plug.
- Check the spark plug type.
- Measure the spark plug gap.
Refer to "CHECKING THE SPARK PLUG" in chapter 3.



Standard spark plug
BR10EG (NGK)

Spark plug gap

0.5 ~ 0.6 mm (0.0197 ~ 0.0236 in)

- Is the spark plug in good condition, is it of the correct type, and is its gap within specification?



YES




NO

Re-gap or replace the spark plug.

EAS00742

2. Ignition spark gap

- Disconnect the spark plug cap from the spark plug.
- Connect the ignition checker/dynamic spark tester ① as shown.
- ② Spark plug cap
- Kick the kickstarter crank.
- Measure the ignition spark gap (a).
- Crank the engine, and gradually increase the spark gap until a misfire occurs.



Minimum ignition spark gap
6.0 mm (0.24 in)

- Is there a spark and is the spark gap within specification?




NO



YES

The ignition system is OK.




EAS00744

3. Spark plug cap resistance

- Remove the spark plug cap from the spark plug lead.
- Connect the pocket tester (“ $\Omega \times 1k$ ” range) to the spark plug cap as shown.
- Measure the spark plug cap resistance.

Positive tester probe → spark plug lead terminal ①
Negative tester probe → spark plug terminal ②



Spark plug cap resistance
 4 ~ 6 k Ω at 20 °C (68 °F)

- Is the spark plug cap OK?

↓ YES

↓ NO


Replace the spark plug cap.

EAS00746

4. Ignition coil resistance

- Disconnect the ignition coil connectors from the ignition coil terminals.
- Connect the pocket tester ($\Omega \times 1$) to the ignition coil as shown.

Positive tester probe → orange ①
Negative tester probe → black ②




- Measure the primary coil resistance.



Primary coil resistance
 0.18 ~ 0.28 Ω at 20 °C (68 °F)

- Connect the pocket tester ($\Omega \times 1k$) to the ignition coil as shown.

Positive tester probe → spark plug lead ①
Negative tester probe → orange ②



- Measure the secondary coil resistance.




Secondary coil resistance
 6.3 ~ 9.5 k Ω at 20 °C (68 °F)

- Is the ignition coil OK?

↓ YES

↓ NO

Replace the ignition coil.




EAS00750

5. Engine stop switch

- Check the engine stop switch for continuity.
- Connect the pocket tester ($\Omega \times 1$) to the engine stop switch as shown.

Positive tester probe → black/white ①
Negative tester probe → black ②



Engine stop switch continuity
PUSH → continuity
FREE → no continuity

- Is the engine stop switch OK?

↓ YES

↓ NO


Replace the engine stop switch.

EAS00748

6. Pickup coil resistance

- Disconnect the pickup coil coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 100$) to the pickup coil terminal as shown.

Positive tester probe → white/red ①
Negative tester probe → white/blue ②



- Measure the pickup coil resistance.




Pickup coil resistance
248 ~ 372 Ω at 20 °C (68 °F)
(between white/red and white/blue)

- Is the pickup coil OK?

↓ YES

↓ NO

Replace the pickup coil.




EAS00775

7. Charging coil resistance

- Disconnect the charging coil coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 100$) to the charging coil terminal as shown.

Positive tester probe → black/red ①
Negative tester probe → green/white ②




- Measure the charging coil resistance.



Charging coil resistance
 720 ~ 1,080 Ω at 20 °C (68 °F)

- Connect the pocket tester ($\Omega \times 10$) to the charging coil

Positive tester probe → green/blue ①
Negative tester probe → black ②



- Measure the charging coil resistance.



Charging coil resistance
 44 ~ 66 Ω at 20 °C (68 °F)

- Is the charging coil OK?

↓ YES

↓ NO

Replace the charging coil.

EAS00754

8. Wiring

- Check the entire ignition system's wiring. Refer to "WIRING DIAGRAM".
- Is the ignition system's wiring properly connected and without defects?

↓ YES

↓ NO

Replace the CDI unit.

Properly connect or repair the ignition system's wiring.



CHAPTER 9 TUNING

ENGINE	9-1
CARBURETOR SETTING	9-1
ATMOSPHERIC CONDITIONS AND CARBURETOR SETTINGS ..	9-1
TEST RUN	9-2
EFFECTS OF THE SETTING PARTS ON THE THROTTLE VALVE OPENING	9-2
MAIN JET ADJUSTMENT	9-3
PILOT AIR SCREW ADJUSTMENT	9-3
PILOT JET ADJUSTMENT	9-3
JET NEEDLE ADJUSTMENT	9-3
JET NEEDLE GROOVE POSITION ADJUSTMENT	9-4
CARBURETOR SETTING PARTS	9-4
ROAD CONDITION AND EXAMPLES OF CARBURETOR SETTING	9-5
EXAMPLES OF CARBURETOR SETTING DEPENDING ON SYMPTOM	9-5
CHANGE OF THE HEAT RANGE OF SPARK PLUGS	9-6
CHASSIS	9-7
SELECTION OF THE SECONDARY REDUCTION RATIO (SPROCKET)	9-7
DRIVE AND DRIVEN SPROCKETS SETTING PARTS	9-8
TIRE PRESSURE	9-9
FRONT FORK SETTING	9-9
CHANGE IN LEVEL AND CHARACTERISTICS OF FORK OIL ...	9-10
SETTING OF SPRING AFTER REPLACEMENT	9-10
FRONT FORK SETTING PARTS	9-11
REAR SUSPENSION SETTING	9-12
CHOOSING SET LENGTH	9-12
SETTING OF SPRING AFTER REPLACEMENT	9-13
REAR SHOCK ABSORBER SETTING PARTS	9-14
SUSPENSION SETTING	9-15



TUNING ENGINE

CARBURETOR SETTING

- The role of fuel is to cool the engine, and in the case of a 2-stroke engine, to lubricate the engine in addition to power generation. Accordingly, if a mixture of air and fuel is too lean, abnormal combustion will occur, and engine seizure may result. If the mixture is too rich, spark plugs will get wet with oil, thus making it impossible to bring the engine into full play or if the worst comes to the worst, the engine may stall.
- The richness of the air-fuel mixture required for the engine will vary with atmospheric conditions of the day and therefore, the settings of the carburetor must be properly suited to the atmospheric conditions (air pressure, humidity and temperature).
- Finally, the rider himself must make a test run and check his vehicle for conditions (pick-up of engine speed, road surface conditions) and for the discoloration of the spark plug(s).

After taking these into consideration, he must select the best possible carburetor settings.

- * It is advisable to make a note of settings, atmospheric conditions, road surface condition, lap-time, etc. so that the memorandum can be used as a reference useful for future.


ATMOSPHERIC CONDITIONS AND CARBURETOR SETTINGS

Air temp.	Humidity	Air pressure (altitude)	Mixture	Setting
High	High	Low (high)	Richer	Leaner
Low	Low	High (low)	Leaner	Richer

The air density (i.e., concentration of oxygen in the air) determines the richness or leanness of the air/fuel mixture. Therefore, refer to the above table for mixture settings.

That is:

- Higher temperature expands the air with its resultant reduced density.
- Higher humidity reduces the amount of oxygen in the air by so much of the water vapor in the same air.
- Lower atmospheric pressure (at a high altitude) reduces the density of the air.



TEST RUN

After warming up the engine equipped with the standard type carburetor(s) and spark plug(s), run two or three laps of the circuit and check the smooth operation of the engine and discoloration of spark plug(s).


Discoloration	Condition of spark plug
Normal	Insulator is dry and burnt brown.
Over burned (too lean)	Insulator is whitish.
Oil fouled (too rich)	Insulator is sooty and wet.

- A Normal
- B Over burned (too lean)
- C Oil fouled (too rich)

EFFECTS OF THE SETTING PARTS ON THE THROTTLE VALVE OPENING

Setting part	Throttle valve opening				
	Full-closed	1/4	1/2	3/4	Full-open
Pilot jet Pilot air screw					
Jet needle	Diameter of straight portion				
Main jet	Clip position				

- ① Throttle valve opening
- ② Full-open
- ③ Full-closed




MAIN JET ADJUSTMENT

The richness of air-fuel mixture with 3/4 ~ 4/4 throttle can be set by changing the main jet ①.

Standard main jet	#138
--------------------------	-------------

1. Spark plug is too hot.
Select a main jet having higher calibrating No. than standard. (To be enriched)
2. Spark plug is wet.
Select a main jet having lower calibrating No. than standard. (To be leaned out)




PILOT AIR SCREW ADJUSTMENT

The richness of the air-fuel mixture with the throttle fully closed to 1/4 open can be set by turning the pilot air screw ①.

Turning in the pilot air screw will make the mixture enrich at low speeds, and turning it out will lean it.

Standard pilot air screw position	2 turns out
--	--------------------




PILOT JET ADJUSTMENT

The richness of air-fuel mixture with the throttle fully closed to 1/2 open can be set by turning the pilot jet ①. It is changed when adjustment cannot be made by the pilot air screw alone.

A larger size jet results in a richer mixture at low speeds, and a smaller size in a leaner mixture.

Standard pilot jet	#45
---------------------------	------------




JET NEEDLE ADJUSTMENT

The richness of air-fuel mixture with 1/4 ~ 3/4 throttle can be set by changing the jet needle ①.

A smaller diameter jet needle results in a richer mixture at middle speeds, and a larger diameter in a leaner mixture.

Standard jet needle	NBKF
----------------------------	-------------




JET NEEDLE GROOVE POSITION ADJUSTMENT

Should the engine be hard to run smoothly at intermediate speeds, the jet needle ① must be adjusted. If the mixture is too rich or too lean at intermediate speed operation, irregular engine operation and poor acceleration will result. Whether or not the richness of the mixture is proper is hard to be determined by means of the spark plug and therefore, it should be judged from your feeling of actual engine operation.

Standard clip position	No.2 groove
-------------------------------	--------------------

1. Too rich at intermediate speeds
 Rough engine operation is felt and the engine will not pick up speed smoothly. In this case, step up the jet needle clip by one groove and move down the needle to lean out the mixture.
2. Too lean at intermediate speeds
 The engine breathes hard and will not pick up speed quickly. In this case, step down the jet needle clip by one groove and move up the needle to enrich the mixture.



CARBURETOR SETTING PARTS

Part name	Size	Part number
Main jet ① (STD)	Rich	#148 4MX-14943-87
	↑	#145 4MX-14943-36
		#142 4MX-14943-86
	↓	#140 4MX-14943-35
		#138 4MX-14943-85
	Lean	#135 4MX-14943-34
	#132 4MX-14943-84	
Pilot jet ② (STD)	Rich	#48 4MX-14948-06
	↕	#45 4MX-14948-05
		Lean
Jet needle ③ Refer to the following table about the change in the air-fuel mixture ratio due to a different jet needle.	NBLE	5PA-14916-LE
	NBLF	5PA-14916-LF
	NBLG	5PA-14916-LG
	NBKE	5PA-14916-KE
	NBKF	5PA-14916-KF
	NBKG	5PA-14916-KG



Clip position		Diameter of straight portion		
		Rich ←		→ Lean
		φ 2.405 mm (0.0947 in)	φ 2.415 mm (0.0951 in)	φ 2.425 mm (0.0955 in)
Rich ↑ ↓ Lean	1 richer	NBKE-3rd groove	NBKF-3rd groove	NBKG-3rd groove
	0.5 richer	NBLE-2nd groove	NBLF-2nd groove	NBLG-2nd groove
	STD	NBKE-2nd groove	NBKF-2nd groove (STD)	NBKG-2nd groove
	0.5 leaner	NBLE-1st groove	NBLF-1st groove	NBLG-1st groove
	1 leaner	NBKE-1st groove	NBKF-1st groove	NBKG-1st groove

ROAD CONDITION AND EXAMPLES OF CARBURETOR SETTING

Conditions	General condition			Sandy condition		
	Under 10 °C (50 °F) (Winter)	15 ~ 25 °C (59 ~ 77 °F) (Spring, Autumn)	Over 30 °C (86 °F) (Summer)	Under 10 °C (50 °F) (Winter)	15 ~ 25 °C (59 ~ 77 °F) (Spring, Autumn)	Over 30 °C (86 °F) (Summer)
Main jet	#140	#138	#135 ~ #138	#142	#142	#142
Jet needle	NBKF-2	NBKF-2	NBKF-2	NBKF-2	NBKF-2	NBKF-2
Pilot jet	#45	#45	#45	#48	#48	#48
Pilot air screw	Zero	Zero	+1/4	-1/2	-1/2	Zero ~ +1/2

NOTE:

Optimum pilot air screw setting can be obtained by adding the ex-factory number of the same screw back-out turns to any required value provided in the chart.

For example, if the ex-factory number is “2”, add “2” to the value chosen in the chart.

EXAMPLES OF CARBURETOR SETTING DEPENDING ON SYMPTOM


Symptom	Setting	Checking
At full throttle Stall at high speeds *Hard breathing Shearing noise Whitish spark plug ↓ Lean mixture	Increase main jet calibration no. (Gradually)	Discoloration of spark plug → If tan color, it is in good condition. If cannot be corrected: Clogged float valve seat Clogged fuel hose Clogged fuel cock
At full throttle Speed pick-up stops Slow speed pick-up Slow response Sooty spark plug ↓ Rich mixture	Decrease main jet calibration no. (Gradually) *In case of racing slight enrichment of mixture reduces engine trouble.	Discoloration of spark plug → If tan color, it is in good condition. If cannot be corrected: Clogged air filter Fuel overflow from carburetor
Lean mixture	Use jet needle with a smaller diameter, or NBLF. Lower jet needle clip position.	
Rich mixture	Use jet needle with a larger diameter, or NBKG. Raise jet needle clip position.	
1/4 ~ 3/4 throttle *Hard breathing Lack of speed	Use jet needle with a smaller diameter, or NBLF. Lower jet needle clip position.	
1/4 ~ 1/2 throttle Slow speed pick-up White smoke Poor acceleration	Use jet needle with a larger diameter, or NBKG. Raise jet needle clip position.	The clip position is the jet needle groove on which the clip is installed. The positions are numbered from the top.
Closed to 1/4 throttle *Hard breathing Speed down	Use jet needle with a smaller diameter. Turn out pilot air screw.	



Symptom	Setting	Checking
Closed to 1/4 throttle Poor acceleration White smoke	Use jet needle with a larger diameter. Turn in pilot air screw.	
Unstable at low speeds Pinking noise	Lower jet needle clip position. (1 groove down) Turn in pilot air screw.	
Poor response at extremely low speed	Reduce pilot jet calibration No. Turn out pilot air screw. If not effect, reverse the above procedures.	Dragging brake Overflow from carburetor
Poor response in the low to intermediate speeds	Raise jet needle clip position. If this has no effect, lower the jet needle clip position.	
Poor response when throttle is opened quickly	Check overall settings. Use main jet with a lower calibration no. Raise jet needle clip position. Use jet needle with a larger diameter. If these have no effect, use a main jet with a higher calibration no. and lower the jet needle clip position.	Check air filter for fouling.
Poor engine operation	Turn in pilot air screw. Adjust the throttle stop screw.	Check throttle valve operation.

* marked: In case of hard breathing, check the carburetor breather hoses for clogging.

This should be taken simply for an example. It is necessary to set the carburetor while checking the operating conditions of the engine and discoloration of spark plugs. Normally, carburetor setting is made by means of the main jet, jet needle clip position, pilot jet and pilot air screw.



CHANGE OF THE HEAT RANGE OF SPARK PLUGS

Judging from the discoloration of spark plugs, if they are found improper, it can be corrected by the following two methods; changing carburetor settings and changing the heat range of spark plug.

Standard spark plug	BR10EG/NGK (resistance type)
----------------------------	---

- In principle, it is advisable to first use spark plugs of standard heat range, and judging from the discoloration of spark plugs, adjust carburetor settings.
- If the calibration No. of the main jet must be changed by ± 30 , it is advisable to change the heat range of spark plugs and newly select the proper main jet.



NOTE: _____

- When checking the discoloration of spark plugs, be sure to stop the engine immediately after a run and check.
- Avoid racing.
- When changing the heat range of spark plugs, never attempt to change it more than ±1 rank.
- When using a spark plug other than standard, check its heat range against the standard and check that it is a resistance type.
- Note that even if the discoloration seems proper, it may slightly vary with the spark plug maker and oil in use.

CHASSIS

SELECTION OF THE SECONDARY REDUCTION RATIO (SPROCKET)

$$\text{Secondary reduction ratio} = \frac{\text{Number of rear wheel sprocketteeth}}{\text{Number of drive sprocket teeth}}$$

Standard secondary reduction ratio	YZ85: 47/14 (3.357) (for EUR, CAN) 48/14 (3.429) (for AUS, NZL) YZ85LW: 52/14 (3.714)
---	--

<Requirement for selection of secondary gear reduction ratio>


- It is generally said that the secondary gear ratio should be reduced for a longer straight portion of a speed course and should be increased for a course with many corners. Actually, however, as the speed depends on the ground condition of the day of the race, be sure to run through the circuit to set the vehicle suitable for the entire course.



- In actuality, it is very difficult to achieve settings suitable for the entire course and some settings may be sacrificed. Thus, the settings should be matched to the portion of the course that has the greatest effect on the race result. In such a case, run through the entire course while making notes of lap times to find the best balance; then, determine the secondary reduction ratio.
- If a course has a long straight portion where a vehicle can run at maximum speed, the vehicle is generally set such that it can develop its maximum revolutions toward the end of the straight line, with care taken to avoid the engine over-revving.

NOTE:

Riding technique varies from rider to rider and the performance of a vehicle also vary from vehicle to vehicle. Therefore, do not imitate other rider's settings from the beginning but choose your own setting according to the level of your riding technique.



DRIVE AND DRIVEN SPROCKETS SETTING PARTS

YZ85:

Part name	Size	Part number
Drive Sprocket ① (STD)	14T	9382A-14227
	15T	9382A-15228
Real wheel sprocket ②	46T	5PA-25446-00
	*(STD) 47T	4ES-25447-10
	** (STD) 48T	5PA-25448-00
	49T	5PA-25449-00

*For EUR, CAN

**For AUS, NZL

YZ85LW:

Part name	Size	Part number
Drive Sprocket ① (STD)	14T	9382A-14227
	15T	9382A-15228
Real wheel sprocket ② (STD)	51T	5PA-25451-00
	52T	5PA-25452-00
	53T	5PA-25453-00



TIRE PRESSURE

Tire pressure should be adjusted to suit the road surface condition of the circuit.



Standard tire pressure
100 kPa (1.0 kgf/cm², 15 psi)

- Under a rainy, muddy, sandy, or slippery condition, the tire pressure should be lower for a larger area of contact with the road surface.



Extent of adjustment
60 ~ 80 kPa
(0.6 ~ 0.8 kgf/cm², 9.0 ~ 12 psi)

- Under a stony or hard road condition, the tire pressure should be higher to prevent a flat tire.



Extent of adjustment
100 ~ 120 kPa
(1.0 ~ 1.2 kgf/cm², 15 ~ 18 psi)


FRONT FORK SETTING

The front fork setting should be made depending on the rider's feeling of an actual run and the circuit conditions.

The front fork setting includes the following three factors:

1. Setting of air spring characteristics
 - Change the fork oil level.
2. Setting of spring preload
 - Change the spring.
3. Setting of damping force
 - Change the compression damping.
 - Change the rebound damping.

The spring acts on the load and the damping force acts on the cushion travel speed.



CHANGE IN LEVEL AND CHARACTERISTICS OF FORK OIL

Damping characteristic near the final stroke can be changed by changing the fork oil amount.

CAUTION:

Adjust the oil level in 5 mm (0.2 in) increments or decrements. Too low oil level causes the front fork to produce a noise at full rebound or the rider to feel some pressure on his hands or body. Alternatively, too high oil level will develop unexpectedly early oil lock with the consequent shorter front fork travel and deteriorated performance characteristics. Therefore, adjust the front fork within the specified range.



Front fork leg oil level
(from the top of the outer tube,
with the outer tube fully
compressed and without the fork
spring)

Standard: 90 mm (3.54 in)

Extent of adjustment:

80 ~ 120 mm (3.15 ~ 4.72 in)

A Air spring characteristics in relation to oil level change

B Load

C Stroke

① Max. oil level

② Standard oil level

③ Min. oil level

SETTING OF SPRING AFTER REPLACEMENT

As the front fork setting can be easily affected by rear suspension, take care so that the vehicle front and rear are balanced (in position, etc.) when setting the front fork.

1. Use of soft spring

Generally a soft spring gives a soft riding feeling. Rebound damping tends to become stronger and the front fork may sink deeply over a series of gaps.

To set a soft spring:

- Change the rebound damping.
Turn out one or two clicks.
- Change the compression damping.
Turn in one or two clicks.




2. Use of stiff spring

Generally a stiff spring gives a stiff riding feeling. Rebound damping tends to become weaker, resulting in lack of a sense of contact with the road surface or in a vibrating handlebar.

To set a stiff spring:

- Change the rebound damping.
Turn in one or two clicks.
- Change the compression damping.
Turn out one or two clicks.



FRONT FORK SETTING PARTS

- Front fork spring ①

YZ85:

TYPE	SPRING RATE	SPRING PART NUMBER	I.D. MARK (slits)
SOFT	0.280	4ES-23141-50	I
STD	0.290	4ES-23141-40	—
STIFF	0.300	4ES-23141-60	II

YZ85LW:

TYPE	SPRING RATE	SPRING PART NUMBER	I.D. MARK (slits)
SOFT	0.290	4ES-23141-40	—
STD	0.300	4LB-23141-10	—
STIFF	0.310	4ES-23141-70	III

NOTE:

The I.D. mark (slits) ① is proved on the end of the spring.






REAR SUSPENSION SETTING

The rear suspension setting should be made depending on the rider's feeling of an actual run and the circuit conditions.

The rear suspension setting includes the following two factors:

1. Setting of spring preload
 - Change the set length of the spring.
 - Change the spring.
2. Setting of damping force
 - Change the rebound damping.
 - Change the compression damping.



CHOOSING SET LENGTH

1. Place a stand or block under the engine to put the rear wheel above the floor, and measure the length (a) between the rear wheel axle center and the rear fender holding bolt.
2. Remove the stand or block from the engine and with a rider astride the seat, measure the sunken length (b) between the rear wheel axle center and the rear fender holding bolt.
3. Loosen the locknut (1) and make adjustment by turning the spring adjuster (2) to achieve the standard figure from the subtraction of the length (b) from the length (a).



Standard figure
75 ~ 85 mm (3.0 ~ 3.3 in)

NOTE:


- If the vehicle is new and after it is broken in, the same set length of the spring may change because of the initial fatigue, etc. of the spring. Therefore, be sure to make reevaluation.
- If the standard figure cannot be achieved by adjusting the spring adjuster and changing the spring set length, replace the spring with an optional one and make re-adjustment.



SETTING OF SPRING AFTER REPLACEMENT

After replacement, be sure to adjust the spring to the set length [sunken length 75 ~ 85 mm (3.0 ~ 3.3 in)] and set it.

1. Use of soft spring
 - Set the soft spring for less rebound damping to compensate for its less spring load. Run with the rebound damping adjuster one or two clicks on the softer side and readjust it to suit your preference.
 2. Use of stiff spring
 - Set the soft spring for more rebound damping to compensate for its greater spring load. Run with the rebound damping adjuster one or two clicks on the stiffer side and readjust it to suit your preference.
- * Adjusting the rebound damping will be followed more or less by a change in the compression damping. For correction, turn the compression damping adjuster on the softer side.




CAUTION:

When using a rear shock absorber other than currently installed, use the one whose overall length (a) does not exceed the standard as it may result in faulty performance. Never use one whose overall length is greater than standard.



Length (a) of standard shock
403.5 mm (15.89 in)



REAR SHOCK ABSORBER SETTING PARTS

- Rear shock spring ①

YZ85:

For EUR

TYPE	SPRING RATE	SPRING PART NUMBER	I.D. COLOR
SOFT	4.4	4ES-22212-M0	Brown
STD	4.6	4ES-22212-K0	Green
STIFF	4.8	4ES-22212-G0	Red

For CAN, AUS, NZL

TYPE	SPRING RATE	SPRING PART NUMBER	I.D. COLOR
SOFT	4.8	4ES-22212-G0	Red
STD	5.0	4ES-22212-F0	–
STIFF	5.2	4ES-22212-H0	Blue

YZ85LW:

For EUR

TYPE	SPRING RATE	SPRING PART NUMBER	I.D. COLOR
SOFT	4.6	4ES-22212-K0	Green
STD	4.8	4ES-22212-G0	Red
STIFF	5.0	4ES-22212-F0	–

For AUS, NZL

TYPE	SPRING RATE	SPRING PART NUMBER	I.D. COLOR
SOFT	5.0	4ES-22212-F0	–
STD	5.2	4ES-22212-H0	Blue
STIFF	5.4	4ES-22212-J0	Black

NOTE:

The I.D. color ① is marked at the end of the spring.



SUSPENSION SETTING

- Front fork

NOTE:

- If any of the following symptoms is experienced with the standard position as the base, make resetting by reference to the adjustment procedure given in the same chart.
- Before any change, set the rear shock absorber sunken length to the standard figure 75 ~ 85 mm (3.0 ~ 3.3 in).

Symptom	Section				Check	Adjust
	Jump	Large gap	Medium gap	Small gap		
Stiff over entire range	○	○	○		Compression damping Oil level (oil amount) Spring	Turn adjuster counterclockwise (about 2 clicks) to decrease damping. Decrease oil level by about 5 ~ 10 mm (0.2 ~ 0.4 in). Replace with soft spring.
Unsmooth movement over entire range	○	○	○	○	Outer tube Inner tube Under bracket tightening torque	Check for any bends, dents, and other noticeable scars, etc. If any, replace affected parts. Retighten to specified torque.
Poor initial movement				○	Rebound damping Oil seal	Turn adjuster counterclockwise (about 2 clicks) to decrease damping. Apply grease in oil seal wall.
Soft over entire range, bottoming out	○	○			Compression damping Oil level (oil amount) Spring	Turn adjuster clockwise (about 2 clicks) to increase damping. Increase oil level by about 5 ~ 10 mm (0.2 ~ 0.4 in). Replace with stiff spring.
Stiff toward stroke end	○				Oil level (oil amount)	Decrease oil level by about 5 mm (0.2 in).
Soft toward stroke end, bottoming out	○				Oil level (oil amount)	Increase oil level by about 5 mm (0.2 in).
Stiff initial movement	○	○	○	○	Compression damping	Turn adjuster counterclockwise (about 2 clicks) to decrease damping.
Low front, tending to lower front posture			○	○	Compression damping Rebound damping Balance with rear end Oil level (oil amount)	Turn adjuster clockwise (about 2 clicks) to increase damping. Turn adjuster counterclockwise (about 2 clicks) to decrease damping. Set sunken length for 80 ~ 85 mm (3.1 ~ 3.3 in) when one passenger is astride seat (lower rear posture). Increase oil level by about 5 mm (0.2 in).
"Obtrusive" front, tending to upper front posture			○	○	Compression damping Balance with rear end Spring Oil level (oil amount)	Turn adjuster counterclockwise (about 2 clicks) to decrease damping. Set sunken length for 75 ~ 80 mm (3.0 ~ 3.1 in) when one passenger is astride seat (upper rear posture). Replace with soft spring. Decrease oil level by about 5 ~ 10 mm (0.2 ~ 0.4 in).



- Rear shock absorber

NOTE:

- If any of the following symptoms is experienced with the standard position as the base, make resetting by reference to the adjustment procedure given in the same chart.
- Adjust the damping in 2-click increments or decrements.

Symptom	Section				Check	Adjust
	Jump	Large gap	Medium gap	Small gap		
Stiff, tending to sink			○	○	Rebound damping Spring set length	Turn adjuster counterclockwise (about 2 clicks) to decrease damping. Set sunken length for 75 ~ 80 mm (3.0 ~ 3.1 in) when one passenger is astride seat.
Spongy and unstable			○	○	Rebound damping Spring	Turn adjuster clockwise (about 2 clicks) to increase damping. Replace with stiff spring.
Heavy and dragging			○	○	Rebound damping Spring	Turn adjuster counterclockwise (about 2 clicks) to decrease damping. Replace with soft spring.
Poor road gripping				○	Rebound damping Compression damping Spring set length Spring	Turn adjuster counterclockwise (about 2 clicks) to decrease damping. Turn adjuster clockwise (about 2 clicks) to increase damping. Set sunken length for 75 ~ 80 mm (3.0 ~ 3.1 in) when one passenger is astride seat. Replace with soft spring.
Bottoming out	○	○			Compression damping Spring set length Spring	Turn adjuster clockwise (about 2 clicks) to increase damping. Set sunken length for 75 ~ 80 mm (3.0 ~ 3.1 in) when one passenger in astride seat. Replace with stiff spring.
Bouncing	○	○			Rebound damping Spring	Turn adjuster clockwise (about 2 clicks) to increase damping. Replace with soft spring.
Stiff travel	○	○			Compression damping Spring set length Spring	Turn adjuster counterclockwise (about 2 clicks) to decrease damping. Set sunken length for 80 ~ 85 mm (3.1 ~ 3.3 in) when one passenger is astride seat. Replace with soft spring.

CHAPTER 10 TROUBLESHOOTING

STARTING FAILURES	10-1
ENGINE	10-1
FUEL SYSTEM	10-1
ELECTRICAL SYSTEMS.....	10-1
 INCORRECT ENGINE IDLING SPEED	 10-2
ENGINE	10-2
FUEL SYSTEM	10-2
ELECTRICAL SYSTEMS.....	10-2
 POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE	 10-2
ENGINE	10-2
FUEL SYSTEM	10-2
 FAULTY GEAR SHIFTING	 10-2
SHIFTING IS DIFFICULT	10-2
SHIFT PEDAL DOES NOT MOVE	10-2
JUMPS OUT OF GEAR.....	10-2
 FAULTY CLUTCH	 10-3
CLUTCH SLIPS	10-3
CLUTCH DRAGS.....	10-3
 OVERHEATING	 10-3
ENGINE	10-3
COOLING SYSTEM.....	10-3
FUEL SYSTEM	10-3
CHASSIS	10-3
ELECTRICAL SYSTEMS.....	10-3
 POOR BRAKING PERFORMANCE	 10-4
 FAULTY FRONT FORK LEGS	 10-4
LEAKING OIL.....	10-4
MALFUNCTION.....	10-4
 UNSTABLE HANDLING	 10-4



EAS00844

TROUBLESHOOTING

NOTE:

The following guide for troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to basic troubleshooting. Refer to the relative procedure in this manual for checks, adjustments, and replacement of parts.

STARTING FAILURES

ENGINE

Cylinder(s) and cylinder head(s)

- Loose spark plug
- Loose cylinder head or cylinder
- Damaged cylinder gasket
- Worn or damaged cylinder

Piston(s) and piston ring(s)

- Improperly installed piston ring
- Damaged, worn or fatigued piston ring
- Seized piston ring
- Seized or damaged piston

Air filter

- Improperly installed air filter
- Clogged air filter element

Crankcase and crankshaft

- Improperly assembled crankcase
- Seized crankshaft

Reed valve

- Deformed reed valve stopper
- Improperly sealed reed valve stopper
- Incorrect tightened manifold
- Damaged gasket
- Damaged reed valve

ELECTRICAL SYSTEMS

Spark plug(s)

- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- Faulty spark plug cap

Ignition coil(s)

- Cracked or broken ignition coil body
- Broken or shorted primary or secondary coils
- Faulty spark plug lead

FUEL SYSTEM

Fuel tank

- Empty fuel tank
- Clogged fuel strainer
- Clogged fuel tank drain hose
- Clogged rollover valve
- Clogged rollover valve hose
- Deteriorated or contaminated fuel

Fuel cock

- Clogged or damaged fuel hose

Carburetor(s)

- Deteriorated or contaminated fuel
- Clogged pilot jet
- Clogged pilot air passage
- Sucked-in air
- Damaged float
- Worn needle valve
- Improperly installed needle valve seat
- Incorrect fuel level
- Improperly installed pilot jet
- Clogged starter jet
- Faulty starter plunger
- Improperly adjusted starter cable

Ignition system

- Faulty CDI unit
- Faulty pickup coil
- Broken generator rotor woodruff key

Switches and wiring

- Faulty engine stop switch
- Broken or shorted wiring
- Improperly grounded circuit
- Loose connections

INCORRECT ENGINE IDLING SPEED/POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE/FAULTY GEAR SHIFTING



EAS00846

INCORRECT ENGINE IDLING SPEED ENGINE

Air filter

- Clogged air filter element

FUEL SYSTEM

Carburetor(s)

- Faulty starter plunger
- Loose or clogged pilot jet
- Loose or clogged pilot air jet
- Damaged or loose carburetor joint
- Improperly synchronized carburetors
- Improperly adjusted engine idling speed (throttle stop screw)
- Improper throttle cable free play
- Flooded carburetor
- Faulty air induction system

ELECTRICAL SYSTEMS

Spark plug(s)

- Incorrect spark plug gap
- Incorrect spark plug heat range
- Fouled spark plug
- Worn or damaged electrode
- Worn or damaged insulator
- Faulty spark plug cap

Ignition coil(s)

- Broken or shorted primary or secondary coils
- Faulty spark plug lead
- Cracked or broken ignition coil

Ignition system

- Faulty CDI unit
- Faulty pickup coil
- Broken generator rotor woodruff key

EAS00848

POOR MEDIUM-AND-HIGH-SPEED PERFORMANCE

Refer to "STARTING FAILURES".

ENGINE

Air filter

- Clogged air filter element

FUEL SYSTEM

Carburetor(s)

- Faulty diaphragm
- Incorrect fuel level
- Loose or clogged main jet

EAS00850

FAULTY GEAR SHIFTING SHIFTING IS DIFFICULT

Refer to "CLUTCH DRAGS".

SHIFT PEDAL DOES NOT MOVE

Shift shaft

- Improperly adjusted shift rod
- Bent shift shaft.

Shift drum and shift forks

- Foreign object in a shift drum groove
- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear
- Foreign object between transmission gears
- Improperly assembled transmission

JUMPS OUT OF GEAR

Shift shaft

- Incorrect shift pedal position
- Improperly returned stopper lever

Shift forks

- Worn shift fork

Shift drum

- Incorrect axial play
- Worn shift drum groove

Transmission

- Worn gear dog



EAS00851

FAULTY CLUTCH

CLUTCH SLIPS

Clutch

- Improperly assembled clutch
- Improperly adjusted clutch cable
- Loose or fatigued clutch spring
- Worn friction plate
- Worn clutch plate

Transmission oil

- Incorrect oil level
- Incorrect oil viscosity (low)
- Deteriorated oil

CLUTCH DRAGS

Clutch

- Unevenly tensioned clutch springs
- Warped pressure plate
- Bent clutch plate
- Swollen friction plate
- Bent clutch push rod
- Broken clutch boss
- Burnt primary driven gear bushing
- Match marks not aligned

Transmission oil

- Incorrect oil level
- Incorrect oil viscosity (high)
- Deteriorated oil

EAS00855

OVERHEATING

ENGINE

Clogged coolant passages

- Cylinder head(s) and piston(s)
- Heavy carbon buildup

Transmission oil

- Incorrect oil level
- Incorrect oil viscosity
- Inferior oil quality

COOLING SYSTEM

Coolant

- Low coolant level

Radiator

- Damaged or leaking radiator
- Faulty radiator cap
- Bent or damaged radiator fin

Water pump

- Damaged or faulty water pump
- Hose(s) and pipe(s)
- Damaged hose
- Improperly connected hose
- Damaged pipe
- Improperly connected pipe

FUEL SYSTEM

Carburetor(s)

- Incorrect main jet setting
- Incorrect fuel level
- Damaged or loose carburetor joint

Air filter

- Clogged air filter element

CHASSIS

Brake(s)

- Dragging brake

ELECTRICAL SYSTEMS

Spark plug(s)

- Incorrect spark plug gap
- Incorrect spark plug heat range

Ignition system

- Faulty CDI unit

POOR BRAKING PERFORMANCE/ FAULTY FRONT FORK LEGS/UNSTABLE HANDLING

TRBL
SHTG



EAS00857

POOR BRAKING PERFORMANCE

- Worn brake pad
- Worn brake disc
- Air in hydraulic brake system
- Leaking brake fluid
- Faulty brake caliper kit
- Faulty brake caliper seal
- Loose union bolt
- Damaged brake hose
- Oil or grease on the brake disc
- Oil or grease on the brake pad
- Incorrect brake fluid level

EAS00861

FAULTY FRONT FORK LEGS LEAKING OIL

- Bent, damaged or rusty inner tube
- Cracked or damaged outer tube
- Improperly installed oil seal
- Damaged oil seal lip
- Incorrect oil level (high)
- Loose damper rod assembly bolt
- Damaged damper rod assembly bolt copper washer
- Cracked or damaged cap bolt O-ring

MALFUNCTION

- Bent or damaged inner tube
- Bent or damaged outer tube
- Damaged fork spring
- Worn or damaged outer tube bushing
- Bent or damaged damper rod
- Incorrect oil viscosity
- Incorrect oil level

EAS00864

UNSTABLE HANDLING

Handlebar

- Bent or improperly installed handlebar

Steering head components

- Improperly installed upper bracket
- Improperly installed lower bracket (improperly tightened ring nut)
- Bent steering stem
- Damaged ball bearing or bearing race

Front fork leg(s)

- Uneven oil levels (both front fork legs)
- Unevenly tensioned fork spring (both front fork legs)
- Broken fork spring
- Bent or damaged inner tube
- Bent or damaged outer tube

Swingarm

- Worn bearing or bushing
- Bent or damaged swingarm

Rear shock absorber assembly(-ies)

- Faulty rear shock absorber spring
- Leaking oil or gas

Tire(s)

- Uneven tire pressures (front and rear)
- Incorrect tire pressure
- Uneven tire wear

Wheel(s)

- Incorrect wheel balance
- Broken or loose spoke
- Damaged wheel bearing
- Bent or loose wheel axle
- Excessive wheel runout

Frame

- Bent frame
- Damaged steering head pipe
- Improperly installed bearing race




YAMAHA MOTOR CO., LTD.

2500 SHINGAI IWATA SHIZUOKA JAPAN

**YZ85W1/YZ85(W)/YZ85LW(W)
2007 WIRING DIAGRAM**

**YZ85W1/YZ85(W)/YZ85LW(W)
2007 SCHEMA DE CABLAGE**

**YZ85W1/YZ85(W)/YZ85LW(W)
SCHALTPLAN 2007**



COMPOSANTS ELECTRIQUES

- ① Coupe-circuit du moteur
- ② Bobine d'allumage
- ③ Bloc CDI
- ④ Volant magnétique CDI
- ⑤ Bougie

CODE DE COULEUR

- B Noir
- O Orange
- B/R Noir/Rouge
- B/W Noir/Blanc
- G/L Vert/Bleu
- G/W Vert/Blanc
- W/L Blanc/Bleu
- W/R Blanc/Rouge

ELECTRICAL COMPONENTS

- ① Engine stop switch
- ② Ignition coil
- ③ CDI unit
- ④ CDI magneto
- ⑤ Spark plug

COLOR CODE

- B Black
- O Orange
- B/R Black/Red
- B/W Black/White
- G/L Green/Blue
- G/W Green/White
- W/L White/Blue
- W/R White/Red

ELEKTRISCHEBAUTEILE

- ① Motorstoppschalter
- ② Zündspule
- ③ CDI-Magnetzünder
- ④ CDI-Magnet
- ⑤ Zündkerze


FARB-CODIERUNG

- B Schwarz
- O Orange
- B/R Schwarz/Rot
- B/W Schwarz/Weiß
- G/L Grün/Blau
- G/W Grün/Weiß
- W/L Weiß/Blau
- W/R Weiß/Rot

**YZ85W1/YZ85(W)/YZ85LW(W)
2007 WIRING DIAGRAM**

**YZ85W1/YZ85(W)/YZ85LW(W)
2007 SCHEMA DE CABLAGE**

**YZ85W1/YZ85(W)/YZ85LW(W)
SCHALTPLAN 2007**



COMPOSANTS ELECTRIQUES

- ① Coupe-circuit du moteur
- ② Bobine d'allumage
- ③ Bloc CDI
- ④ Volant magnétique CDI
- ⑤ Bougie

CODE DE COULEUR

- B Noir
- O Orange
- B/R Noir/Rouge
- B/W Noir/Blanc
- G/L Vert/Bleu
- G/W Vert/Blanc
- W/L Blanc/Bleu
- W/R Blanc/Rouge

ELECTRICAL COMPONENTS

- ① Engine stop switch
- ② Ignition coil
- ③ CDI unit
- ④ CDI magneto
- ⑤ Spark plug

COLOR CODE

- B Black
- O Orange
- B/R Black/Red
- B/W Black/White
- G/L Green/Blue
- G/W Green/White
- W/L White/Blue
- W/R White/Red

ELEKTRISCHEBAUTEILE

- ① Motorstoppschalter
- ② Zündspule
- ③ CDI-Magnetzünder
- ④ CDI-Magnet
- ⑤ Zündkerze

FARB-CODIERUNG

- B Schwarz
- O Orange
- B/R Schwarz/Rot
- B/W Schwarz/Weiß
- G/L Grün/Blau
- G/W Grün/Weiß
- W/L Weiß/Blau
- W/R Weiß/Rot