



Discover 125 ST



Mobil Super™
4T Ultra

www.auteco.com.co
Línea gratuita nacional: 018000 520090



IRC *LLANTAS* *TECNOLOGÍA JAPONESA*



**Los Expertos en motos
las usan y recomiendan:**

 **BAJAJ**
Distinctly Ahead

 **auteco**
www.auteco.com.co

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO CATALOGO	CÓDIGO SAP
PULSAR 200 NS, AS200	DELANTERA	100/80-17	IRC	NR73	PISTERA	41070-1017-NR73/18	10020077
		110/70-17		RX01	PISTERA	41070-1117-RX01/18	10020095
	TRASERA	130/70-17	IRC	RX01	PISTERA	41070-1317-RX01/18	10020115
PULSAR 220	DELANTERA	90/90X17	IRC	NF45	PISTERA TUBE LESS	41070-9017-NF45/18	10020217
				NF52TL	PISTERA TUBE LESS	90/90-17-NF52-TL	10029297
				NF42	PISTERA TUBE LESS	41070-9017-NF42/18	10020214
				NF46	PISTERA TUBE LESS	41070-9017-NF46/18	10020220
				RX01	PISTERA TUBE LESS	41070-1117-RX01/18	10020095
	TRASERA	130/70-17	IRC	RX01	PISTERA TUBE LESS	41070-1317-RX01/18	10020115
		120/80X17		NR57TL	PISTERA TUBE LESS	120/80-17-NR57-TL	10007401
AVENGER 220	DELANTERA	90/90X17	IRC	NF45	PISTERA	41070-9017-NF45/18	10020217
	TRASERA	130/90X15		NR66	SPORT	130/90-15-NR66-TT	10008722
PULSAR 200, 180 UG	DELANTERA	2.75X17	IRC	NF53	PISTERA	41070-2717-NR53/18	10020143
		90/80X17		NR73	PISTERA	90/80-17-NR73-TT	10029270
		90/90X17		NF53	PISTERA	41070-9017-NF53/18	10020223
		100/80-17		NR73	PISTERA	41070-1017-NR73/18	10020077
		110/70-17		RX01	PISTERA	41070-1117-RX01/18	10020095
	TRASERA	130/70-17	IRC	RX01	PISTERA	41070-1317-RX01/18	10020115

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO CATALOGO	CÓDIGO SAP
PULSAR 135	DELANTERA	2.75X17	IRC	NR53	PISTERA	41070-2717-NR53/18	10020143
		90/80-17		NR73TT	PISTERA	90/80-17-NR73-TT	10029270
	TRASERA	110/80-17	IRC	NR53	PISTERA	41070-1117-NR53/18	10020089
		100/80X17		NR64	PISTERA	41070-1117-NR64/18	10020092
PULSAR 180 (CLASSIC, DTS-i)	DELANTERA	2.75X18	IRC	NR73	PISTERA	41070-1017-NR73/18	10020077
				NR21	SPORT	41070-2718-NR21/18	10020146
	TRASERA	3.00X18	IRC	NR53	PISTERA	41070-2718-NR53/18	10020149
				GP1	TRIAL ROMBO	41070-3018-GP1/18	10020171
DISCOVER 125 ST DISCOVER 125 DISCOVER 100 DISCOVER 135 KS/ES DISCOVER DTSI PULSAR 180 DTS-i TEC,BLACK, PULSAR II	DELANTERA	2.75X17	IRC	NR53	PISTERA	41070-2717-NR53/18	10020143
		90/80-17		NR73TT	PISTERA	90/80-17-NR73-TT	10029270
	TRASERA	3.00X17	IRC	GP1	TRIAL ROMBO	41070-3017-GP1/18	10020163
		100/80-17		NR1	SPORT	41070-3017-NR1/18	10020166
		80/90-17		NR73	PISTERA	41070-1017-NR73/18	10020077
				NR78YL	PISTERA	80/90-17-NR78Y-TT	10027758
DISCOVER 100M, 110	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	90/80-17-NR73-TT	10029270
	TRASERA	100/80X17		NR73	PISTERA	100/80-17-NR73-TT	10020077
DISCOVER 150ST-F	DELANTERA	100/80-17	IRC	NR73S	PISTERA	100/80-17-NR73S-TL	10003158
	TRASERA	80/90-17		NR73	PISTERA	80/90-17-NR73S-TL	10027755

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO CATALOGO	CÓDIGO SAP
PLATINO 125 5S, PLATINO 125, PLATINO CT, 100 SPORT, PLATINO 110, XCD 125	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	90/80-17-NR73-TT	10029270
		2.75X17		NR53	PISTERA	41070-2717-NR53/18	10020143
				GP1	TRIAL ROMBO	41070-2717-GP1/18	10020137
	TRASERA	100/80-17	IRC	NR73	PISTERA	41070-1017-NR73/18	10020077
		3.00X17		GP1	TRIAL ROMBO	41070-3017-GP1/18	10020163
				NR1	SPORT	41070-3017-NR1/18	10020166
BOXER CON RIN 17" BM 150, CT 100, BM 100	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	41070-9017-NR73TT/18	10029270
		90/90-17		NR53	PISTERA	41070-2717-NR53/18	10020143
		2.75X17		NR53	PISTERA	41070-2717-NR53/18	10020143
				GP1	TRIAL ROMBO	41070-2717-GP1/18	10020137
	TRASERA	100/80-17	IRC	NR73	PISTERA	41070-1017-NR73/18	10020077
		3.00X17		GP1	TRIAL ROMBO	41070-3017-GP1/18	10020163
BOXER BM 100 CLASSIC ES	DELANTERA	2.75X17	IRC	NR53	PISTERA	41070-2717-NR53/18	10020143
	TRASERA	3.00X17		NR1	SPORT	41070-3017-NR1/18	10020166
BOXER CON RIN 18" 4T, UG, K-TEC	DELANTERA	2.50X18	IRC	NR53	PISTERA	41070-2518-NR53/18	10020134
	TRASERA	3.00X18	IRC	GP1	TRIAL ROMBO	41070-3018-GP1/18	10020171
				NR53	PISTERA	41070-3018-NR53/18	10020174
BOXER CON RIN 18" (S1D) CALIBER 115 WIND 125	DELANTERA	2.75X18	IRC	NR21	SPORT	41070-2718-NR21/18	10020146
				NR53	PISTERA	41070-2718-NR53/18	10020149
	TRASERA	3.00X18	IRC	GP1	TRIAL ROMBO	41070-3018-GP1/18	10020171
				NR53	PISTERA	41070-3018-NR53/18	10020174

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO CATALOGO	CÓDIGO SAP
AVANTI	DELANTERA	2.50X17	IRC	TR1	TRIAL ROMBO	41070-2517-TR1/18	10020132
	TRASERA	2.75X17	IRC	NR2	SPORT	41070-2717-NR2/18	10020140
				NR53	PISTERA	41070-2717-NR53/18	10020143
				GP1	TRIAL ROMBO	41070-2717-GP1/18	10020137
PLUS, CLASSIC, LEGEND	DELANTERA	3.50X10	IRC	MB-27	SPORT	41070-3510-27/18	10020183
	TRASERA						

Advierta lo que le dicen las llantas mientras conduce:

- Si su respuesta a la dirección es lenta o si en las curvas y en el frenado la respuesta es pesada, es muy probable que sus llantas estén desinfladas.
- Vibración o tambaleo durante la conducción, puede significar que la presión en las llantas es mayor a la recomendada, o que ha ocurrido un daño en la llanta y la falla es inminente.
- La llanta puede vibrar a ciertas velocidades debido al desbalanceo, en este caso su desgaste será muy acelerado.

**RECUERDE SIEMPRE REVISAR LA PRESIÓN DE AIRE EN SUS LLANTAS
ANTES DE COMENZAR A RODAR**

PREFACIO

Es nuestro placer presentarles a ustedes el Catálogo de Partes.

Este Catálogo ha sido especialmente diseñado para ayudarle en la selección de las partes correctas con el fin de mantener el vehículo en las mejores condiciones.

Los repuestos originales están sujetos a un exigente estándar de control de calidad, por lo tanto es necesario que usted sólo use repuestos originales.

En nuestro constante esfuerzo para mejorar la eficiencia y desempeño de su vehículo, las especificaciones, diagramas y número de partes pueden cambiar sin previo aviso. Consecuentemente las descripciones de los repuestos en este Catálogo pueden no ser las finales y definitivas.

Las alteraciones y modificaciones que ocurren en la impresión de este Catálogo, serán informadas a nuestra red, a través de circulares de Servicio o en nuestra página web: www.auteco.com.co accediendo al link repuestos. Es requisito que usted actualice su Catálogo y haga las correcciones necesarias, una vez reciba dichas circulares. Lo anterior le asegurará un rápido y adecuado despacho de sus partes, pues las órdenes están siendo diligenciadas con las referencias más actualizadas.

En caso de necesitar asistencia técnica, comunicarse con el Distribuidor Autorizado o llamar al Departamento de Servicios Auteco-Kawasaki.



DIRECTORIO TELEFÓNICO - UN REPUESTOS Y ACCESORIOS ÁREA COMERCIAL Y ASESORES DE VENTAS

NOMBRE	CARGO	ZONA	CELULAR	CORREO ELECTRÓNICO
Alvaro Enrique Carreño	ASESOR COMERCIAL	Magdalena Medio	314 701 17 85	acarreno@auteco.com.co
Andres Julian Giraldo	ASESOR COMERCIAL	Risaralda y Armenia	301 375 43 57	ajgiraldo@auteco.com.co
Bernardo De Jesus Muriel	ASESOR COMERCIAL	Cucuta	312 257 61 75	bmuriel@auteco.com.co
Carlos Humberto Tobon	ASESOR COMERCIAL	Nariño y Putumayo	310 447 36 11	ctobon@auteco.com.co
Carlos Mario Salazar	ASESOR COMERCIAL	Sucre	310 414 88 45	csalazar@auteco.com.co
Eliecer Zamora Vasquez	ASESOR COMERCIAL	Cali y Cauca	313 584 47 13	ezamora@auteco.com.co
Elkin Humberto Gallego	ASESOR COMERCIAL	Sur de Area Metropolitana de Medellín y Amazonas	310 436 25 98	egallego@auteco.com.co
Esmeralda Forero Acosta	ASESOR COMERCIAL	Zona Centro Bogota	313 585 22 07	eforero@auteco.com.co
Gustavo Adolfo Cantillo	ASESOR COMERCIAL	Atlántico	300 447 41 57	gcantillo@auteco.com.co
Hernan Alonso Pedraza	ASESOR COMERCIAL	Pueblos de Condinamarca	311 899 77 28	hpedraza@auteco.com.co
Ivano Alexy Villota Arteaga	ASESOR COMERCIAL	Sur de Huila y Caqueta	313 767 78 43	ivillota@auteco.com.co
Jaime Alfonso Villalba	ASESOR COMERCIAL	Bolivar	313 584 72 62	jvillalba@auteco.com.co
John Jairo Lopez	ASESOR COMERCIAL	Antioquia Norte	310 444 22 15	jlopez@auteco.com.co
Julio Mario Moterrosa	ASESOR COMERCIAL	Magdalena	313 585 60 28	jmonterrosa@auteco.com.co
Karen Lorena Candanoza	ASESOR COMERCIAL	Zona Sur Bogota	313 585 35 61	kcandanoza@auteco.com.co
Marlon Santiago Blandon	ASESOR COMERCIAL	Cordoba y Bajo Cauca	310 373 90 19	msblandon@auteco.com.co
Miguel Angel Guerrero	ASESOR COMERCIAL	Norte del Valle y Buenaventura	314 772 07 98	mguerreiro@auteco.com.co
Miguel Arturo Osorio Ruiz	ASESOR COMERCIAL	Cesar y Guajira	321 799 78 87	mosorio@auteco.com.co
Miller Fabian Acosta	ASESOR COMERCIAL	Zona Norte Bogota	313 585 98 37	macosta@auteco.com.co
Milton Cesar Olaya Carvajal	ASESOR COMERCIAL	Neiva y Norte Huila	310 436 27 42	molaya@auteco.com.co
Nestor Raul Adarve	ASESOR COMERCIAL	Antioquia Sur y Choco	310 436 26 89	nadarve@auteco.com.co
Oscar Alejandro Posada Villa	ASESOR COMERCIAL	Norte Area Metropolitana Medellin y San Andres	314 811 04 09	aposada@auteco.com.co
Rubén Dario Campo Cárdena	ASESOR COMERCIAL	Caldas y Norte de Risaralda	321 799 79 06	rcampo@auteco.com.co
Uberney Ortiz Velez	ASESOR COMERCIAL	Casanare, Vichada, Boyaca	313 672 73 37	uortiz@auteco.com.co
Willinton Franco Tobon	ASESOR COMERCIAL	Tolima	312 257 67 91	wfranco@auteco.com.co
William De Jesus Gutierrez	ASESOR COMERCIAL	Meta	310 407 40 72	wgutierrez@auteco.com.co
Wilson Sabogal	ASESOR COMERCIAL	Bucaramanga y Area Metropolitana	300 542 85 48	wsabogal@auteco.com.co
Herica Linares Riaño	ASESOR COMERCIAL BAJAJ	Bogota	301 247 71 10	hlinares@auteco.com.co
Jorge Mario Gil	ASESOR COMERCIAL BAJAJ	Medellin	313 672 73 53	jgil@auteco.com.co
Jorge Mario Maya Velez	ASESOR COMERCIAL BAJAJ	Medellin	312 258 93 84	jmaya@auteco.com.co
Meryce Alejandra Cortazar P.	ASESOR COMERCIAL BAJAJ	Cali	320 732 97 60	mcortazar@auteco.com.co
Pilar Katherine Garcia Tique	ASESOR COMERCIAL BAJAJ	Bogota	300 541 93 34	pgarcia@auteco.com.co
Raul De Jesus Foronda	ASESOR COMERCIAL BAJAJ	Santa Marta	312 850 45 74	rforonda@auteco.com.co
Richard Andres Muñoz	ASESOR COMERCIAL BAJAJ	Popayan	321 799 79 26	rmunoz@auteco.com.co
Yeesander Guzman Garcia	ASESOR COMERCIAL BAJAJ	Barranquilla	300 542 64 59	yguzman@auteco.com.co
Daniel Becerra Martinez	ASESOR COMERCIAL BOUTIQUE	Cali	300 542 43 98	dbecerra@auteco.com.co
German Alfredo Vivas	ASESOR COMERCIAL BOUTIQUE	Bogota	321 799 79 30	gvivas@auteco.com.co
Hilde Alexander Garcia Cano	ASESOR COMERCIAL BOUTIQUE	Medellin	321 641 50 63	hgarcia@auteco.com.co
Franz Caballero Castro	DESARROLLADOR UN RPTOS Y ACCS	BARRANQUILLA	301 375 25 32	fcaballero@auteco.com.co
Gonzalo Adolfo Saldarriaga	DESARROLLADOR UN RPTOS Y ACCS	MEDELLIN	310 406 88 74	gsaldarriaga@auteco.com.co
Gustavo Adolfo Corrales	DESARROLLADOR UN RPTOS Y ACCS	CALI	300 634 67 59	gcorrales@auteco.com.co
Gilberto Eduardo Ocampo	GERENTE REGIONAL ZONA SUR	GERENTE REGIONAL ZONA SUR	311 382 85 14	eocampo@auteco.com.co
Jhon Alexander Estrada Bello	GERENTE REGIONAL ZONA NORTE	GERENTE REGIONAL ZONA NORTE	311 737 37 48	jestrada@auteco.com.co
Jose Giovanni Suarez Martinez	GERENTE REGIONAL ZONA CENTRO	GERENTE REGIONAL ZONA CENTRO	320 766 49 45	jsuarez@auteco.com.co
Juan Guillermo Ospina	GERENTE COMERCIAL BAJAJ		313 767 78 36	jgospina@auteco.com.co
Laura Ocampo	COORDINADORA ALTA GAMA		320 682 09 64	locampo@auteco.com.co

SERVICIO AL CLIENTE

LÍNEA ÚNICA DE SERVICIO AL CLIENTE CANAL (4) 444 81 90 

UN DE REPUESTOS y ACCESORIOS • FAX OFICINAS: 373 03 75

ATENCIÓN EN:	NOMBRE	E-MAIL	TELÉFONO	FAX
SERVICIO A CONCESIONARIO Y MAYORISTAS	JHONATAN ZAPATA	servicioadistribuidoresymayoristas@auteco.com.co	(4) 444 81 90 OPCION (2)	
SERVICIO PAGO ANTICIPADO	DORIS CARMONA	serviciopagoanticipadorptos@auteco.com.co		(4) 373 83 94
COORDINADOR SERVICIO POSTVENTA	LUIS G. RODRIGUEZ	lrodriguez@auteco.com.co		
GARANTÍAS	ALEJANDRO FERNÁNDEZ	garantias2@auteco.com.co		
DEVOLUCIONES - RECLAMOS	LEONARDO AGUDELO	devolucionesrptos@auteco.com.co		
MOTO FUERA DE RUTA	JONI HOLGUIN	motofueraderuta@auteco.com.co	3004243097	
LÍNEA DE ATENCIÓN AL CLIENTE				
POSCONSUMO BATERIAS	YUDY DUQUE	yduque@auteco.com.co		(4) 277 5117
CARTERA		cartera@auteco.com.co		(4) 306 81 54
VENTA MOTOS		pedidosmotos@auteco.com.co		(4) 372 62 95

AUTOTECNICA COLOMBIANA S.A.S (AUTECO S.A.S) SEDE PRINCIPAL Cra. 42 N° 45-77 Itagüí Ant. - PBX: (4)306 81 81
Atención a clientes finales: LÍNEA GRATUITA NACIONAL - 01 8000 52 00 90

ÍNDICE

FIGURA Nº	DESCRIPCIÓN	PÁG. Nº	FIGURA Nº	DESCRIPCIÓN	PÁG. Nº
1	TAPA CULATA	1	26	REPOSAPIÉ DELANTERO	26
2	CULATA	2	27	REPOSAPIÉ TRASERO	27
3	VÁLVULAS	3	28	GUARDABARRO TRASERO Y DELANTERO	28
4	EJE DE LEVAS / TENSOR CADENILLA	4	29	GATO CENTRAL	29
5	CILINDRO / PISTÓN	5	30	LLANTAS / RINES / NEUMÁTICOS	30
6	CIGÜEÑAL	6	31	DISCO FRENO DELANTERO	31
7	TRANSMISIÓN	7	32	CILINDRO BOMBA FRENO	32
8	SELECTOR DE CAMBIOS	8	33	CALIPER DELANTERO	33
9	EJE DE CAMBIOS	9	34	PORTA BANDAS TRASERO	34 - 35
10	CARCASA DERECHA	10	35	PEDAL FRENO	36
11	CARCASA IZQUIERDA	11	36	MANUBRIO	37 - 38
12	BOMBA DE ACEITE	12	37	SUSPENSIÓN DELANTERA	39 - 40
13	PEDAL CRANK	13	38	TANQUE DE GASOLINA / GUARDABARRO / TAPAS LATERALES	41
14	CARCASA CLUTCH	14	39	GRIFO DE GASOLINA	42
15	CUBIERTA VOLANTE	15	40	ANTIVIBRANTES TANQUE Y TAPAS LATERALES	43
16	CLUTCH	16	41	VELOCÍMETRO	44
17	CARBURADOR	17	42	CABLES	45
18	FILTRO DE AIRE	18	43	GUARDACADENA	46
19	SILENCIADOR	19	44	FAROLA	47
20	MOTOR DE ARRANQUE	20	45	DIRECCIONALES	48
21	MAGNETO / C.D.I. / PLATO DE BOBINAS	21	46	STOP	49
22	SILLÍN	22	47	EQUIPO ELÉCTRICO	50
23	SOPORTES DE MOTOR	23	48	HERRAMIENTAS / ACCESORIOS	51
24	CHASIS	24	49	EDICIÓN ESPECIAL DISCOVER 125ST STYLE	52
25	BRAZO OSCILANTE / AMORTIGUADOR	25		LISTA DE KITS	53 - 54
				ACTUALIZACIONES	55 - 57
				INDICE DE REFERENCIAS	58 - 62

ÍNDICE DE GRÁFICOS




FIGURA N° 1: TAPA CULATA

PÁG. N°.
1




FIGURA N° 2: CULATA

PÁG. N°.
2




FIGURA N° 3: VÁLVULAS

PÁG. N°.
3




FIGURA N° 4: EJE DE LEVAS /
TENSOR CADENILLA

PÁG. N°.
4




FIGURA N° 5: CILINDRO / PISTÓN

PÁG. N°.
5




FIGURA N° 6: CIGÜEÑAL

PÁG. N°.
6

ÍNDICE DE GRÁFICOS




FIGURA N° 7: TRANSMISIÓN

PÁG. N°.
7




FIGURA N° 8: SELECTOR DE CAMBIOS

PÁG. N°.
8




FIGURA N° 9: EJE DE CAMBIOS

PÁG. N°.
9




FIGURA N° 10: CARCASA DERECHA

PÁG. N°.
10




FIGURA N° 11: CARCASA IZQUIERDA

PÁG. N°.
11




FIGURA N° 12: BOMBA DE ACEITE

PÁG. N°.
12

ÍNDICE DE GRÁFICOS




FIGURA N° 13: PEDAL CRANK

PÁG. N°.
13




FIGURA N° 14: CARCASA CLUTCH

PÁG. N°.
14




FIGURA N° 15: CUBIERTA VOLANTE

PÁG. N°.
15




FIGURA N° 16: CLUTCH

PÁG. N°.
16




FIGURA N° 17: CARBURADOR

PÁG. N°.
17










FIGURA N° 18: FILTRO DE AIRE

PÁG. N°.

18

ÍNDICE DE GRÁFICOS

	FIGURA N° 19: SILENCIADOR PÁG. N°. 19
	FIGURA N° 20: MOTOR DE ARRANQUE PÁG. N°. 20
	FIGURA N° 21: MAGNETO / C.D.I. / PLATO DE BOBINAS PÁG. N°. 21
	FIGURA N° 22: SILLÍN PÁG. N°. 22
	FIGURA N° 23: SOPORTES DE MOTOR PÁG. N°. 23
	FIGURA N° 24: CHASIS PÁG. N°. 24

ÍNDICE DE GRÁFICOS




FIGURA N° 25: BRAZO OSCILANTE / AMORTIGUADOR

PÁG. N°.
25




FIGURA N° 26: REPOSAPIÉ DELANTERO

PÁG. N°.
26




FIGURA N° 27: REPOSAPIÉ TRASERO

PÁG. N°.
27




FIGURA N° 28: GUARDABARRO TRASERO Y DELANTERO

PÁG. N°.
28




FIGURA N° 29: GATO CENTRAL

PÁG. N°.
29



ÍNDICE DE GRÁFICOS




FIGURA N° 31: DISCO FRENO DELANTERO

PÁG. N°.
31




FIGURA N° 32: CILINDRO BOMBA FRENO

PÁG. N°.
32




FIGURA N° 33: CALIPER DELANTERO

PÁG. N°.
33




FIGURA N° 34: PORTA BANDAS TRASERO

PÁG. N°.
34 - 35




FIGURA N° 35: PEDAL FRENO

PÁG. N°.
36




FIGURA N° 36: MANUBRIO

PÁG. N°.
37 - 38

ÍNDICE DE GRÁFICOS




FIGURA N° 37: SUSPENSIÓN DELANTERA

PÁG. N°.
39 - 40




FIGURA N° 38: TANQUE DE GASOLINA /
GUARDABARRO/ TAPAS LATERALES

PÁG. N°.
41




FIGURA N° 39: GRIFO DE GASOLINA

PÁG. N°.
42




FIGURA N° 40: ANTIVIBRANTES TANQUE Y
TAPAS LATERALES

PÁG. N°.
43




FIGURA N° 41: VELOCIMETRO

PÁG. N°.
44











FIGURA N° 42: CABLES

PÁG. N°.
45

ÍNDICE DE GRÁFICOS

					
FIGURA N° 43: GUARDACADENA	PÁG. N°. 46	FIGURA N° 44: FAROLA	PÁG. N°. 47	FIGURA N° 45: DIRECCIONALES	PÁG. N°. 48
					
FIGURA N° 46: STOP	PÁG. N°. 49	FIGURA N° 47: EQUIPO ELECTICO	PÁG. N°. 50	FIGURA N° 48: HERRAMIENTAS / ACCESORIOS	PÁG. N°. 51

ÍNDICE DE GRÁFICOS

					
FIGURA N° 49: EDICIÓN ESPECIAL DISCOVER 125ST STYLE		PÁG. N°. 52			

This exploded view diagram illustrates the assembly of a fuel pump. The components are numbered as follows:

- 1:** The upper fuel pump housing, which is a cast metal component with a central inlet/outlet port.
- 2:** A short hex-head bolt used to secure the upper housing to the lower housing.
- 3:** A rectangular gasket or O-ring that provides a seal between the upper and lower housings.
- 4:** The lower fuel pump housing, which contains the internal pump mechanism and has four mounting holes.
- 5:** A long hex-head bolt used to secure the lower housing to the engine block.
- 6:** A long hex-head bolt used to secure the fuel pump to the engine block, positioned on the opposite side from bolt 5.

The diagram shows the relative positions of these parts, with dashed lines indicating the assembly path and alignment points.

DISCOVER
125ST

This diagram illustrates the exploded view of a rear suspension assembly. The components are labeled with numbers 1 through 7:

- 1**: A long, threaded shock absorber body with a mounting flange at the bottom.
- 1/2**: A shorter threaded section, likely a spacer or a part of the shock absorber assembly.
- 2**: A circular mounting plate or flange that fits onto the top of the shock absorber body.
- 3**: A cylindrical component, possibly a bush or a part of the shock absorber's internal mechanism, positioned between the mounting plate and the shock absorber body.
- 4**: Two small, curved components, likely bushings or spacers, positioned at the top of the assembly.
- 5**: A complex metal bracket or arm, possibly a control arm or a part of the suspension linkage.
- 6**: A long, cylindrical component, likely a shock absorber or a strut, positioned horizontally to the right of the main assembly.
- 7**: A coiled metal spring, positioned vertically in the center of the assembly.

Dashed lines indicate the assembly path and alignment of the components. A bracket on the left side of the spring (7) indicates its position relative to the other components.

DISCOVER
125ST

This exploded view diagram illustrates the assembly of a motorcycle engine. The components are numbered as follows:

- 1**: Main crankshaft assembly.
- 2**: Crankshaft seal.
- 3**: Crankshaft nut.
- 3A**: Crankshaft lockwasher.
- 4**: Crankshaft cap nut.
- 5**: Crankshaft gear.
- 6**: Crankshaft pin.
- 7**: Crankshaft pin.
- 8**: Timing chain.
- 9A**: Timing chain guide (left).
- 9B**: Timing chain guide (right).
- 9**: Timing chain guides (collective label).
- 10**: Timing chain pin.
- 11**: Timing chain cover gasket.
- 12**: Timing chain cover.
- 13**: Timing chain cover pin.
- 14**: Timing chain cover nut.
- 15**: Timing chain cover cap nut.

 **Discover**
125 ST

This diagram illustrates the assembly of a piston and cylinder. The main components are shown in an exploded view, with a dashed box highlighting the piston assembly. The components are numbered as follows:

- 1**: Piston and cylinder assembly (indicated by a line pointing to the main assembly).
- 2**: Two small cylindrical pins or washers.
- 3**: A gasket or seal.
- 4**: A small bolt or screw.
- 5**: A set of four piston rings.
- 6**: Two small circular components, likely O-rings or seals.
- 7**: A small, curved component, possibly a clip or bracket.
- 8**: A small cylindrical component, possibly a pin or washer.

Discover 125 ST

An exploded view diagram of a mechanical assembly, labeled 1. The assembly consists of a central shaft with a large pulley or flywheel mounted on it. The pulley has a central hub and a large outer rim. A lever arm is attached to the top of the pulley. The shaft is supported by bearings (2, 3, 4, 5, 11) and a bush (6). A spring (9) is attached to the shaft. A pin (10) is used to secure the assembly. A rectangular plate (8) is also shown. The parts are numbered 1 through 11.

 **Discover**
125 ST

FIGURA N° 7: TRANSMISIÓN




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JZ551010	Eje Caja	1	
2	JZ551202	Piñón de 4a. (23T)	1	
3	JA551002	Arandela Caja	4	
4	39098717	Pin Eje Caja	5	
5	JE551209	Piñón de 3a. (18T)	1	
6	JZ551213	Piñón de 5a. (22T)	1	
7	JZ551200	Piñón de 2a. (17T)	1	
8	JA551004	Arandela Caja	1	
9	JZ551008	Eje de Salida	1	
10	JZ551206	Piñón de 2a. (31T)	1	
11	JZ551210	Buje Piñón de 2a	1	
12	JZ551211	Piñón de 5a. (20T)	1	
13	JE551210	Piñón Caja 3a. (24T)	1	
14	JZ551208	Piñón Caja 4a. (25T)	1	
15	JZ551205	Buje Piñón de 1a.	1	
16	JZ551204	Piñón de 1a. (34T)	1	
17	JA551008	Arandela Caja	1	
18	JA551009	Buje Eje Salida	1	
19	59210024	Anillo Retenedor	1	
20	JZ551004	Piñón Salida. (14T)	1	
21	DU101213	Arandela Piñón Salida	1	
22	39198104	Tornillo Arandela Piñón Salida	2	

This diagram illustrates the components of a rear suspension system, specifically a multi-link rear suspension. The parts are numbered as follows:

- 1:** Wheel hub assembly
- 2:** Upper ball joint
- 3:** Upper control arm
- 4:** Lower ball joint
- 5:** Rear axle housing
- 6:** Pin
- 7:** O-ring
- 8:** Lower ball joint
- 9:** Rear shock absorber
- 10:** O-ring
- 11:** Bolt
- 12:** Washer
- 13:** Tire
- 14:** Rear suspension assembly (indicated by a dashed box)
- 15:** Pin
- 16:** Lower control arm
- 17:** Rear suspension arm
- 18:** Spring
- 19:** Washer
- 20:** Nut

DISCOVER
125ST

This diagram shows an exploded view of a mechanical assembly. The main component is a cast housing (1A) with several internal features. The exploded parts are as follows:

- 1A**: The main cast housing.
- 2**: A circular gasket or seal ring.
- 3**: A small cylindrical cap or plug.
- 4**: A large circular flange or bearing housing.
- 5**: A small, irregularly shaped bracket or plug.
- 6**: A small screw or bolt.
- 7**: A long, threaded bolt or stud.
- 8**: A larger, irregularly shaped bracket or plug.
- 9**: Two small screws or bolts.
- 10**: A small cylindrical pin or plug.

Dashed lines indicate the assembly alignment for each part.

Discover 125 ST

This diagram illustrates the exploded view of a mechanical assembly, likely a pump or motor housing. The main component is a cast metal housing (1) with a central circular opening. Various parts are shown being assembled onto it, including:

- 5**: A circular flange or cap.
- 7**: A circular gasket or seal.
- 11**: A small cylindrical pin or plug.
- 4**: A cylindrical component with a flange.
- 2**: A circular flange with a central hole.
- 3**: A circular gasket or seal.
- 10**: A curved metal bracket or cover plate.
- 10A**: A small screw or fastener.
- 12**: A long screw or bolt.
- 13**: A long cylindrical component, possibly a shaft or armature.
- 14**: A small circular washer or spacer.
- 15**: A small cylindrical component.
- 16**: A small circular washer or spacer.
- 8**: A small cylindrical component.
- 9**: A small circular washer or spacer.
- 6**: A small cylindrical component.
- 11A**: A long screw or bolt.

 Dashed lines indicate the assembly path for each part.

Discover 125ST

This diagram shows an exploded view of a mechanical assembly. The components are numbered as follows:

- 1**: A long, black, cylindrical handle with a textured grip.
- 2**: A small, circular, black O-ring.
- 3**: Two small, black, circular O-rings.
- 4**: A small, black, cylindrical component.
- 5**: A small, black, cylindrical component with a flange.
- 6**: Two small, black, circular O-rings.
- 7**: A black, gear-like component with a central shaft.
- 8**: A small, black, circular O-ring.
- 9**: A large, black, coiled spring.
- 10**: A dashed rectangular box containing the following parts:
 - 11**: A small, black, cylindrical component with a flange.
 - 12**: A black, coiled spring.
 - 13**: A small, black, cylindrical component with a flange.
 - 14**: A small, black, cylindrical component with a flange.

Discover 125ST

This diagram illustrates the exploded view of a mechanical assembly, likely a pump or motor housing. The central component is a large, complex housing (1). Surrounding it are various sub-components and fasteners, each labeled with a number:

- 1**: Main housing or pump body.
- 2**: A long, thin metal rod or pin.
- 3**: A bracket or support arm.
- 4**: A small pin or screw.
- 5**: A small pin or screw.
- 6**: A circular cover or cap.
- 6A**: A circular gasket or seal.
- 7**: A circular component, possibly a filter or cap.
- 8**: A cylindrical component, possibly a filter or cap.
- 9**: A small cylindrical component.
- 10**: A small circular component.
- 11**: A small circular component.
- 12**: A small circular component.
- 13**: A small circular component.
- 14**: A small cylindrical component.
- 15**: A large, irregular gasket or seal.
- 16**: A small circular component.
- 17**: A small cylindrical component.
- 18**: A small cylindrical component.

Dashed lines indicate the assembly path and alignment of the parts.

Discover 125 ST

This exploded view diagram illustrates the components of a water pump assembly. The central component is the water pump housing (1). Key parts include:

- 1**: Water pump housing
- 2**: Impeller nut
- 3**: Impeller lock washer
- 4**: Bolt
- 5**: Bolt
- 6**: Bolt
- 7**: Bolt
- 8**: Gasket
- 9**: Water pump cover
- 10**: Bolt
- 11**: Water pump cover gasket
- 12**: Impeller
- 13**: Impeller
- 14**: Bolt

The diagram shows the assembly sequence, with dashed lines indicating the fit of each part. A warning symbol (11) is shown near the water pump cover gasket, indicating a specific handling or installation instruction.

DISCOVER
125ST

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or valve. The parts are numbered as follows:

- 1**: The main cylindrical body of the assembly.
- 2**: A small rectangular component, possibly a seal or plug.
- 3**: A large gear or impeller with multiple teeth.
- 3A**: A small circular washer or spacer.
- 4**: A circular flange or seal.
- 5**: A series of five circular rings or seals stacked together.
- 6**: A series of five circular rings or seals stacked together.
- 7**: A gear or impeller with teeth, similar to part 3.
- 8**: A hexagonal flange or mounting plate.
- 9**: A series of five circular rings or seals stacked together.
- 10**: Six screws or bolts used for mounting.
- 11**: A small circular washer or spacer.
- 12**: A small circular washer or spacer.
- 13**: A small circular washer or spacer.
- 14**: A small circular washer or spacer.
- 15**: A small circular washer or spacer.

The diagram shows the relative positions and assembly sequence of these components. Dashed lines indicate the alignment and fit of the parts. The main body (1) is shown with the gear (3) and the series of rings (5, 6, 9) attached. The hexagonal flange (8) is shown being mounted onto the main body. The screws (10) are shown being inserted into the flange. The gear (7) is shown being mounted onto the main body. The small components (2, 3A, 4, 11, 12, 13, 14, 15) are shown being inserted into the main body.

Discover 125 ST

This diagram illustrates the exploded view of a carburetor assembly, showing the main body and various sub-components. The parts are numbered as follows:

- 1**: Main carburetor body.
- 2**: Jet needle and needle valve assembly.
- 3**: Jet needle and needle valve assembly (alternative view).
- 4**: Jet needle and needle valve assembly (alternative view).
- 5**: Jet needle and needle valve assembly (alternative view).
- 6**: Jet needle and needle valve assembly (alternative view).
- 7**: Jet needle and needle valve assembly (alternative view).
- 8**: Jet needle and needle valve assembly (alternative view).
- 9**: Jet needle and needle valve assembly (alternative view).
- 10**: Jet needle and needle valve assembly (alternative view).
- 11**: Jet needle and needle valve assembly (alternative view).
- 12**: Jet needle and needle valve assembly (alternative view).
- 13**: Jet needle and needle valve assembly (alternative view).
- 14**: Jet needle and needle valve assembly (alternative view).
- 15**: Jet needle and needle valve assembly (alternative view).
- 16**: Jet needle and needle valve assembly (alternative view).
- 17**: Jet needle and needle valve assembly (alternative view).
- 18**: Jet needle and needle valve assembly (alternative view).
- 19**: Jet needle and needle valve assembly (alternative view).
- 20**: Jet needle and needle valve assembly (alternative view).

 **Discover**
125ST

DISCOVER
125 ST

This diagram shows an exploded view of a power tool handle assembly. The components are labeled with numbers 1 through 9:

- 1**: The main handle body, which is long and curved.
- 2**: A small black cap or plug.
- 3**: A circular O-ring or seal.
- 4**: A small circular component, possibly a button or indicator light, located on the side of the handle body.
- 5**: A small rectangular component, possibly a switch or trigger, located on the side of the handle body.
- 6**: A small rectangular component, possibly a switch or trigger, located on the side of the handle body.
- 7**: A small rectangular component, possibly a switch or trigger, located on the side of the handle body.
- 8**: A small rectangular component, possibly a switch or trigger, located on the side of the handle body.
- 9**: A small rectangular component, possibly a switch or trigger, located on the side of the handle body.



This exploded view diagram illustrates the assembly of a 4-cylinder engine. The components are numbered as follows:

- 1**: Flywheel
- 2**: Crankshaft
- 3**: Ignition coil
- 4**: Distributor
- 5**: Pin
- 6**: Plate
- 7**: Pin
- 8**: Camshaft
- 9**: Valve train assembly
- 10**: Hose
- 11**: Hose
- 12**: Cap
- 13**: Spark plug
- 14**: Spark plug
- 15**: Cap
- 16**: Pin
- 17**: Spark plug
- 18**: Pin
- 19**: Pin
- 20**: Pin

Discover 125ST

Diagram illustrating the assembly of the seat base. The main assembly shows the seat base (1) with a connector (5) and support legs (6). A detailed view shows the footrest (4) being attached to the base. Another detailed view shows the bracket (2) being secured with a screw (3) to the cable connector (7).

Discover 125 ST

This diagram illustrates the exploded view of a motorcycle chassis assembly. The components are labeled with numbers 1 through 10, indicating their assembly sequence or location. The main frame is shown in the center, with various mounting brackets and fasteners positioned around it. The callouts are as follows:

- 1**: A large, dark-colored mounting bracket or fender support.
- 1A** and **1B**: Two smaller, light-colored mounting brackets or fender supports.
- 2**: A small, dark-colored bolt or screw.
- 3**: A long, dark-colored bolt or screw.
- 4**: A small, light-colored bolt or screw.
- 5**: A small, light-colored bracket or plate.
- 6**: A small, dark-colored bolt or screw.
- 7**: A long, dark-colored bolt or screw.
- 8**: A small, dark-colored bolt or screw.
- 9**: A small, light-colored bracket or plate.
- 10**: A small, light-colored bolt or screw.

23

This diagram illustrates the components of a rear suspension system, likely for a vehicle. The parts are numbered as follows:

- 1**: Coil spring and shock absorber assembly.
- 2**: Two shock absorber mounting pins/bushings.
- 3**: Rear suspension cross member.
- 4**: A long cylindrical bush or sleeve.
- 5**: Two small bushings or spacers.
- 6**: Two small bushings or spacers.
- 7**: A small pin or bolt.
- 8**: A long cylindrical bush or sleeve.
- 9**: A small bushing or spacer.
- 10**: Two large circular bushings or spacers.
- 11**: A rear suspension control arm.
- 12**: A small pin or bolt.
- 13**: A small washer or spacer.
- 14**: A rectangular metal bracket or plate.
- 15**: Two metal brackets or plates.
- 16**: Two small metal brackets or plates.
- 17**: A small metal bracket or plate.

Dashed lines indicate the assembly sequence and the relative positions of the components.

Discover 125ST

This exploded view diagram illustrates the assembly of a mechanical component, likely a bracket or handle. The main assembly consists of a large bracket (9) and a mounting plate (11). The bracket (9) is secured with a screw (12) and a pin (14). A handle (10) is attached to the bracket (9) using a screw (13) and a pin (15). A mounting plate (11) is attached to the bracket (9) using a screw (16) and a pin (17). A dashed box highlights a sub-assembly of parts 1, 2, 3, 4, 5, 6, 7, 8, and 9. The sub-assembly includes a handle (10), a mounting plate (11), and various screws (12, 13, 14, 15, 16, 17, 18, 19) and a pin (2). The main assembly is shown in a perspective view, while the sub-assembly is shown in a top-down view within the dashed box.

Discover 125 ST

This exploded view diagram illustrates the assembly of a mechanical component, likely a bracket or housing. The parts are numbered as follows:

- 1**: Main housing or bracket.
- 2**: Small pin or screw.
- 3**: Small pin or screw.
- 4**: Small pin or screw.
- 5**: Small pin or screw.
- 6**: Small pin or screw.
- 7**: Flat plate or washer.
- 8**: Ball bearing or roller.
- 9**: Small rectangular component, possibly a sensor or actuator.
- 10**: Pin or screw.
- 10A**: Alternative design or position for part 10.
- 11**: Bracket or housing for the top assembly.
- 12**: Main housing or bracket.
- 13**: Pin or screw.
- 14**: Pin or screw.
- 15**: Long, thin component, possibly a sensor or actuator.
- 16**: Flat plate or washer.

The diagram shows the assembly sequence and relative positions of these components. Dashed lines indicate the alignment and assembly path for several parts, including the ball bearings (8) and the various pins/screws (2, 3, 4, 5, 6, 10, 13, 14).

[illegible]

Discover 125ST

This diagram illustrates the assembly of a wheel and tire. The components are labeled as follows:

- 1**: The wheel rim, featuring a multi-spoke design.
- 2**: The tire, shown in its assembled state on the rim.
- 3**: The tire, shown in its disassembled state, separate from the rim.
- 4**: The wheel rim, shown in its disassembled state, separate from the tire.
- 5**: The tire, shown in its assembled state on the rim.

Discover
125 ST

This exploded view diagram illustrates the assembly of a motorcycle wheel. The components are numbered as follows:

- 1**: Wheel rim
- 2**: Hub
- 3**: Tire
- 4**: Brake disc
- 5**: Brake pad
- 6**: Brake caliper
- 7**: Brake pin
- 8**: Axle
- 9**: Hub nut
- 10**: Axle nut
- 11**: Hub seal
- 12**: Hub seal
- 13**: Fender
- 14**: Fender bracket
- 15**: Fender pin
- 16**: Fender pin

Discover 125ST

This exploded view diagram illustrates the components of a car door lock assembly. The parts are numbered as follows:

- 1**: Door lock actuator arm.
- 2**: Pin/bush for the actuator arm.
- 3**: Lock cylinder pin.
- 4**: Lock cylinder pin bush.
- 5**: Screws for the lock body.
- 6**: Lock body housing.
- 7**: Lock body cover plate.
- 8**: Lock body mounting bracket.
- 8A**: Lock body mounting bracket (variant).
- 9**: Lock body mounting bracket (variant).
- 10**: O-rings for the cable.
- 11**: Cable end fittings.
- 12**: Lock cable.
- 13**: Lock cylinder pins.
- 14**: Lock cylinder housing.
- 15**: Lock cylinder housing (variant).
- 16**: Lock cable end fitting.

Discover 125 ST

Diagram illustrating the components of a brake master cylinder assembly, numbered 1 through 11.

Legend (8):

- 2: Tornillo de Sangrado (Bleed Screw)
- 3: Capuchón Tornillo de Sangrado (Bleed Screw Cap)
- 4: Guardapolvo (Dust Cap)
- 5: Resorte Pasta Freno (Brake Shoe Spring)

Main Assembly Components:

- 1: Master Cylinder Body
- 2: Bleed Screw
- 3: Bleed Screw Cap
- 4: Dust Cap
- 5: Brake Shoe Spring
- 6: Piston
- 7: Retenedor (Retainer)
- 8: Sello de Pistón (Piston Seal)
- 9: Guardapolvo (Dust Cap)
- 10: Aislante (Insulator)
- 11: Pistón (Piston)

DISCOVER
125ST

This diagram illustrates the components of a motorcycle wheel assembly, numbered 1 through 25. The central component is the wheel rim (1). Surrounding it are various parts including: a chain (2), a sprocket (3), a hub (4), a brake disc (5), a brake caliper (6), a brake master cylinder (7), a brake slave cylinder (8), a brake line (9), a brake hose (10), a brake lever (11), a brake pedal (12), a brake master cylinder (13), a brake slave cylinder (14), a brake line (15), a brake hose (16), a brake lever (17), a brake pedal (18), a brake master cylinder (19), a brake slave cylinder (20), a brake line (21), a brake hose (22), a brake lever (23), a brake pedal (24), a brake master cylinder (25), a brake slave cylinder (26), a brake line (27), a brake hose (28), a brake lever (29), and a brake pedal (30).

Discover 125ST

FIGURA N° 35: PEDAL FRENO




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JZ161009	Pedal Freno	1	
2	JZ161019	Caucho Pedal Freno	1	
3	39106301	Tornillo	1	
3A	39029215	Tuerca Tornillo Ajuste Pedal Freno	1	
4	JZ161011	Eje Leva Freno	1	
5	39153721	Anillo Retenedor	2	
6	JD161002	Resorte Pedal Freno	1	
7	JD161006	Buje Resorte Pedal Freno	1	
8	JZ131810	Varilla Freno	1	
9	JZ131875	Pin Varilla Freno	1	
10	39019811	Arandela	1	
11	39080808	Pin	1	
12	31201079	Swiche Freno Trasero	1	
13	JM191014	Resorte Swiche Freno Trasero	1	
14	JZ111072	Platina Soporte Swiche Freno Tras.	1	
15	DS151025	Varilla de Torque	1	
16	DH151029	Tornillo Varilla Freno	1	
17	39078912	Arandela Presión	2	
18	39154011	Arandela	1	
19	39069415	Tuerca 10 mm.	2	
20	39080708	Pin	2	
21	30151096	Tornillo Varilla Torque	1	
22	36DK0017	Kit Pines y Resorte Varilla Freno	1	

This exploded view diagram illustrates the components of a motorcycle handlebar assembly. The parts are numbered as follows:

- 1:** Right handlebar grip.
- 2:** Right handlebar.
- 3:** Pin for the right handlebar clamp.
- 4:** Right handlebar clamp.
- 5:** Left handlebar grip.
- 6:** Left handlebar.
- 7:** Left handlebar clamp.
- 8:** Pin for the left handlebar clamp.
- 9:** Left handlebar grip.
- 9A:** Left handlebar grip cap.
- 10:** Right handlebar grip cap.
- 11:** Pin for the right handlebar grip cap.
- 12:** Right handlebar clamp.
- 13:** Right handlebar clamp.
- 14:** Pin for the right handlebar clamp.
- 15:** Pin for the right handlebar clamp.
- 15A:** Right handlebar clamp.
- 16:** Right handlebar clamp.
- 17:** Right handlebar clamp.
- 18:** Right handlebar clamp.
- 19:** Right handlebar grip.
- 20:** Right handlebar grip.
- 21:** Right handlebar grip.
- 22:** Pin for the right handlebar grip.
- 23:** Left handlebar grip.
- 24:** Left handlebar grip.
- 26:** Right handlebar grip.
- 27:** Pin for the left handlebar clamp.
- 28:** Pin for the left handlebar clamp.
- 29:** Pin for the left handlebar clamp.
- 30:** Pin for the left handlebar clamp.

 **Discover**
125ST

This diagram illustrates the exploded view of a motorcycle engine assembly, showing various components and their assembly sequence. The parts are numbered as follows:

- 1: Air filter
- 2: Air duct
- 3: Bolt
- 4: Bolt
- 5: Air filter housing
- 6: Air filter housing cover
- 7: Bolt
- 8: Bolt
- 9: Air filter housing cover
- 10: Air filter housing cover
- 11: Bolt
- 12: Bolt
- 13: Bolt
- 14: Bolt
- 15: Bolt
- 15A: Air filter housing cover
- 16: Bolt
- 17: Bolt
- 18: Bolt
- 19: Bolt
- 20: Bolt
- 21: Air filter housing cover
- 22: Bolt
- 23: Air filter housing cover
- 24: Air filter housing cover
- 26: Air filter housing cover
- 27: Bolt
- 28: Bolt
- 29: Bolt
- 30: Bolt
- 3A: Air filter housing cover

The diagram shows the assembly of the air filter housing, including the air filter, air duct, and various bolts and covers. A dashed line indicates the assembly sequence for the air filter housing cover (15A) and the air filter housing cover (21).

DISCOVER
125ST

FIGURA N° 37: SUSPENSIÓN DELANTERA (1/2)




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JZ121027	Suspensión Delantera	1	
2	JZ121030	Camisa Tubo Telescópico Izq.	1	
3	JZ121031	Camisa Tubo Telescópico Der.	1	
4	30181025	Tornillo Camisa Telescópico	2	
5	30181026	Empaque	2	
6	DD181032	Guardapolvo Tubo Telescópico	1	
7	JK121007	Buje Guía	2	
8	JK121009	Arandela	2	
9	36JZ0107	Cilindro Tubo Telescópico	1	
10	JZ121040	Tubo Telescópico	2	
11	PA121017	Resorte Tubo Telescópico	2	
12	DS181012	Tornillo Tubo Telescópico	2	
12A	59040006	Tornillo Tubo Telescópico	2	
13	30181029	Anillo Retenedor	2	
14	PF121028	Antivibrante	1	
15	DD181090	Empaque Sup. Soporte Farola	2	
16	JZ151047	Soporte Farola	1	
17	DD181091	Empaque Soporte Farola Inferior	2	
18	30181045	Empaque Soporte Farola	2	
19	JZ121015	Espiga Central	1	
20	39078912	Arandela	2	
21	39118101	Tornillo	2	
22	DS181015	Tapón Horquilla	1	
23	DS181016	Arandela	1	

This diagram illustrates the exploded view of a mechanical assembly, with components labeled 1 through 26. The assembly is shown in a disassembled state to identify individual parts and their relative positions.

- Part 1:** The main vertical shaft or piston rod, shown in three segments.
- Part 2/3:** A long, dark cylindrical component, likely a piston or a guide sleeve, with a small side port.
- Part 4:** A small pin or clip at the bottom of the main shaft.
- Part 5:** A small circular washer or seal.
- Part 6:** A circular seal or O-ring.
- Part 7:** A small circular washer or seal.
- Part 8:** A small circular washer or seal.
- Part 9:** A small pin or clip located within a dashed box on the main shaft.
- Part 10:** A long, dark cylindrical component, similar to part 2/3, positioned below the main shaft.
- Part 11:** A coiled spring.
- Part 12:** A small circular washer or seal.
- Part 12A:** A small pin or clip.
- Part 13:** A small circular washer or seal.
- Part 14:** A small circular washer or seal.
- Part 15:** A small circular washer or seal.
- Part 16:** A bracket or support plate.
- Part 17:** A small circular washer or seal.
- Part 18:** A small circular washer or seal.
- Part 19:** A complex bracket or support plate at the bottom right.
- Part 20:** A small pin or clip at the bottom of the main shaft.
- Part 21:** A small pin or clip at the bottom of the main shaft.
- Part 22:** A small circular washer or seal.
- Part 23:** A small circular washer or seal.
- Part 24:** A small circular washer or seal.
- Part 25:** A small circular washer or seal.
- Part 26:** A small circular washer or seal.

DISCOVER
125ST

FIGURA N° 38: TANQUE DE GASOLINA / GUARDABARRO / TAPAS LATERALES




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	56JZ0123	Tanque de Gasolina	1	Sin pintar
2	JZ181238	Carenaje Farola	1	Sin pintar
3	JZ181414	Guardabarro Delantero	1	Sin pintar
4	JZ181233	Cubierta Sillín	1	Sin pintar
5	JZ181227	Tapa Lateral Izquierda	1	Sin pintar
6	JZ181231	Tapa Lateral Derecha	1	Sin pintar
7	JZ233178	Calcomanía "4 Valve"	2	
8	JZ233177	Calcomanía "BAJAJ"	1	
9	36JZ0089	Kit Calcomanía Carenaje	1	Negro-Azul
	36JZ0091		1	Negro-Rojo
	36JZ0093		1	Azul
	36JZ0095		1	Rojo
10	JZ233145	Kit Calcomanías Tanque Gasolina	1	Negro-Azul (1Parte)
	PA233094		1	Negro-Azul (2 Partes)
	JZ233153		1	Negro-Rojo (1 Parte)
	PA233101		1	Negro-Rojo (2 Partes)
	JZ233161		1	Azul (1 Parte)
	PA233109		1	Azul (2 Partes)
	JZ233169		1	Rojo (1Parte)
	PA233117		1	Rojo (2 Partes)
11	36JZ0090	Kit Calcomanías Cubierta Sillín	1	Negro-Azul
	36JZ0094		1	Azul
	36JZ0096		1	Rojo
	36JZ0092		1	Negro - Rojo

This diagram illustrates the exploded view of a vacuum cleaner motor unit. The components are numbered as follows:

- 1**: Main motor housing.
- 2, 3, 4**: Screws for the motor housing.
- 5**: O-ring seal.
- 6**: Small mounting pins or spacers.
- 7**: Motor base plate.
- 8**: Motor housing cover.
- 9**: Motor terminal block.
- 10**: Motor shaft assembly.
- 11**: Motor shaft extension.
- 12**: Motor shaft nut.
- 13**: Motor shaft pin.
- 14**: Motor shaft pin.
- 15**: Motor shaft pin.
- 16**: Motor shaft assembly (detailed view).
- 17**: Motor shaft pin.
- 18**: Motor shaft pin.
- 19**: Motor housing cover (detailed view).
- 20**: Motor housing cover (detailed view).

DISCOVER
125ST

 **Discover**
125 ST

FIGURA N° 41: VELOCÍMETRO




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	PA181226	Cubierta Velocímetro	1	
2	39155204	Tornillo	3	
3	39071111	Arandela	3	
4	JC141015	Antivibrante	3	
5	JC141016	Buje	3	
6	PA402422	Velocímetro Completo	1	
7	JG181238	Antivibrante	3	
8	PA402424	Velocímetro (Solo)	1	Minda
	YJZ08001		1	Pricol
9	PA402425	Medidor de Combustible	1	Minda
	YJZ08002		1	Pricol
10	PA402426	Cubierta Sup. Velocímetro	1	Minda
	YJZ08003		1	Pricol
11	PA402431	Ramal Velocímetro	1	Minda
	YJZ08004		1	Pricol
12	YJZ08008	Anillo Retenedor	1	
13	PA402428	Anillo Retenedor Cubierta Sup.	1	Minda
	YJZ08006		1	Pricol
14	YJZ08009	Cubierta Inf. Velocímetro	1	Minda
	YJZ08007		1	Pricol
15	CM201054	Bombillo 12V 2W	6	Minda-Pricol
16	PA402427	Cubierta Interna Velocímetro	1	Minda
	YJZ08011		1	Pricol
17	PA402429	Capuchón Perilla Velocímetro	1	Minda
	YJZ08010		1	Pricol
18	LDB00007	Arandela	3	
19	39029115	Tuerca	3	
20	PA402432	Bombillo LED 12V-2W/T5	6	Minda-Pricol

1

2

3

[illegible]

This diagram illustrates the exploded view of a bicycle seat assembly. The components are labeled with numbers 1 through 12:

- 1**: The main seat shell.
- 2**: Five screws used for mounting the seat to the rails.
- 3**: The seat post.
- 4**: The seat post clamp.
- 5**: The seat post insert.
- 6**: The seat post clamp nut.
- 7**: The seat post clamp bolt.
- 8**: A small washer or spacer.
- 9**: A small nut or washer.
- 10**: A small bolt or screw.
- 11**: A small washer or spacer.
- 12**: A small nut or washer.



This diagram shows an exploded view of a mechanical assembly. The components are numbered as follows:

- 1**: Small pin or bolt.
- 2**: Small pin or bolt.
- 3**: Large bracket or frame component.
- 4**: Main housing or body component.
- 5**: Small pin or bolt.
- 6**: Small pin or bolt.
- 7**: Small pin or bolt.
- 8**: Flap or cover component.
- 9**: Small pin or bolt.
- 10**: Small pin or bolt.
- 11**: Vertical support or guide component.
- 12**: Small pin or bolt.
- 13**: Small pin or bolt.
- 14**: Small pin or bolt.
- 15**: Small pin or bolt.
- 16**: Small pin or bolt.
- 17**: Small pin or bolt.
- 18**: Small pin or bolt.
- 19**: Small pin or bolt.
- 20**: Small pin or bolt.
- 21**: Small pin or bolt.
- 22**: Small pin or bolt.

Dashed lines indicate the assembly path and alignment for the various components.

47

This exploded view diagram illustrates the components of a motorcycle seat assembly. The main seat shell is shown at the top, with various mounting points and fasteners labeled. The lower part of the diagram shows the seat base and rear section, also with labeled components. The numbered callouts are as follows:

- 1: Left side fairing/cover.
- 2: Two sets of screws/bushings for mounting the seat to the frame.
- 3: A small pin or clip.
- 4: Right side fairing/cover.
- 5: Rear section of the seat base.
- 6: A small pin or clip.
- 7: Rear section of the seat shell.
- 8: A large circular fastener or cap.
- 9: A small pin or clip.

Discover 125ST

This exploded view diagram illustrates the components of a motorcycle headlight assembly. The main assembly is shown on the left, with various parts numbered 1 through 17. The components include:

- 1:** A small circular component, likely a lens or cap.
- 2:** The main headlight housing or bezel.
- 3:** A small bracket or mounting piece.
- 4:** A rectangular plate or cover.
- 5:** A small circular component, likely a lens or cap.
- 6:** A small circular component, likely a lens or cap.
- 7:** A small circular component, likely a lens or cap.
- 8:** A small circular component, likely a lens or cap.
- 9:** A small circular component, likely a lens or cap.
- 10:** A small circular component, likely a lens or cap.
- 11:** A small circular component, likely a lens or cap.
- 12:** A small rectangular plate or cover.
- 13:** A small rectangular plate or cover.
- 14:** A small rectangular plate or cover.
- 15:** A small circular component, likely a lens or cap.
- 16:** A small circular component, likely a lens or cap.
- 17:** A cable or wiring harness.

Discover 125 ST

Discover 125ST

 **Discover**
125 ST

1 — *Discover*

2 — *Discover*

3/4 —

5/6 — **125 ST**

8 —

7 —

9 —

Discover 125 ST

LISTA DE KITS

Item	Referencia	Descripción	Contenido del Kit		
			Referencia	Descripción	Cant.
1	36JE0001	Kit Resortes Válvula	39201719	Retén Válvula	1
			NA	Asiento Válvula	1
			JD511204	Resorte Válvula	1
			JD511205	Retén Válvula	1
			DG101029	Cuña Válvula	2
2	36JE0016	Kit Diafragma y Aguja Carburador	NA	Cortina Carburador	1
			NA	Diafragma Carburador	1
			NA	Resorte Cortina Carburador	1
3	36JE0017	Kit Tornillo Aire Carburador	NA	Tornillo Ajuste	1
			NA	Arandela	1
			NA	Resorte	1
4	36JE0018	Kit Boquereles Carburador	NA	Difusor	1
			NA	Aguja de La Cortina	1
			NA	Pulverizador	1
			NA	Boquerel de Alta	1
			NA	Boquerel de Baja	1
5	36JE0019	Kit Taza Carburador	NA	Taza Carburador	1
			DP121059	Anillo Retén Taza carburador	1
			JE581218	Tornillo Drenaje	1
			DP121067	Tornillo Taza Carburador	2
			DH121118	Anillo Retén Tornillo Drenaje	1
6	36JE0020	Kit Tapa Carburador	NA	Tapa Diafragma Carburador	1
			NA	Tornillo Tapa Carburador	2

LISTA DE KITS

Item	Referencia	Descripción	Contenido del Kit		
			Referencia	Descripción	Cant.
7	36JE0021	Kit Válvula de Choke	NA	Tornillo	1
			NA	Resorte	1
			NA	Válvula Choke	1
			NA	Anillo Retén	1
			NA	Guardapolvo	1
8	36JE0022	Kit Retenedores Carburador	DP121059	Anillo Retén Taza Carburador	1
			DH121118	Anillo Retén Tornillo Drenaje	1
			DH121088	Anillo Retén Auto Choke	1
			NA	Anillo Retén Tornillo Ralentí	1
9	36JZ0080	Kit Sprocket y Cadena	JZ551004	Piñón Delantero 14T	1
			NA	Cadena 428x 126L	1
			NA	Sprocket 45T	1
10	36JZ0081	Kit Guías Cadenilla	NA	Guía Cadenilla	1
			NA	Guía Cadenilla	1
11	36JZ0098	Kit Moñón Crank	NA	Moñón Crank	1
			NA	Resorte Pedal Crank	1
			30101236	Balín	1
			22150241	Aradela Crank	1
			30101235	Pin	1
			39085517	Arandela Crank	1

ACTUALIZACIONES

Fig. N°	Pág.	Ítem	Descripción	Referencia Actual	Referencia Nueva	Observación	Fecha
6	6	11	Rodamiento Bolas Cigüeñal		JE531001	Referencia Nueva	abr-13
9	9	4	Guardapolvo	JZ561405	JZ561407	Referencia y Descripción Errada en el Catálogo de Partes	abr-13
		8	Guardapolvo		JZ561405	Descripción Errada en el Catálogo de Partes	abr-13
15	15	1	Cubierta Volante Completa	36JB0020	JZ541209	Referencia Errada en el Catálogo de Partes	sep-13
		1A	Cubierta Volante Sola		36JZ0015	Referencia Nueva	sep-13
		12	Antivibrante Tapa Volante		JE541210	Referencia Nueva	sep-13
		13	Platina Antivibrante Tapa Volante		JA541221	Referencia Nueva	sep-13
		14	Tornillo Antivibrante Tapa Volante		LAD00018	Referencia Nueva	sep-13
18	18	13	Tornillo M6 X1X14L	39194904	39194304	Referencia Errada en el Catálogo de Partes	abr-13
19	19	5	Eje Crank	DH101315	DH101302	Referencia Errada en el Catálogo de Partes	abr-13
20	20	10	Arandela		39084914	Referencia Nueva	abr-13
21	21	18	Tornillo	39194904	39194304	Referencia Errada en el Catálogo de Partes	abr-13
23	23	1A	Soporte Delantero Motor Derecho		JZ113436	Cambio efectuado por el Proveedor desde Dic-14	dic-14
		1B	Soporte Delantero Motor Izquierdo		JZ113435		
27	27	7	Platina de Seguridad Izquierda		JZ113037	Descripción Errada en el Catálogo de Partes	abr-13
		16	Platina de Seguridad Derecha		JZ113038	Referencia Nueva	abr-13
28	28	2	Plato de Bobinas	59040019	39155604	Referencia Errada en el Catálogo de Partes	abr-13
29	29	4	Pasador Gato Central	JZ113207		Eje de 131.3 mm	abr-13
		4	Pasador Gato Central		JZ113214	Eje de 139.3 mm	abr-13
32	32	1	Leva Freno Delantero	DJ191006	DJ191059	Referencia Errada en el Catálogo de Partes	abr-13
34	34	15	Leva Freno Portabandas	DS151096	30151011	Referencia Errada en el Catálogo de Partes	abr-13
36	37	6	Kit Soporte Leva Clutch	PA401400	DJ191082	Referencia Errada en el Catálogo de Partes	abr-13
		7	Leva Clutch	DJ191055	DJ191083	Referencia Errada en el Catálogo de Partes	abr-13
		9A	Interruptor Clutch	PA401401	DJ201246	Referencia Errada en el Catálogo de Partes	abr-13

ACTUALIZACIONES

Fig. N°	Pág.	Item	Descripción	Referencia Actual	Referencia Nueva	Observación	Fecha
36	38	27	Tornillo Leva Clutch		DL191014	Referencia Nueva	sep-13
		28	Tuerca		39118415	Referencia Nueva	sep-13
		29	Kit Tornillos Ajuste Cable		36DK0019	Referencia Nueva	sep-13
37	39	6	Guardapolvo	36DF1801	DD181032	Referencia y Descripción Errada en el Catalogo de Partes	abr-13
		9	Cilindro Tubo Telescópico	36JZ0040	36JZ0107	Referencia Errada en el Catalogo de Partes	abr-13
		10	Tubo Telescópico	JA151013	JZ121040	Referencia Errada en el Catalogo de Partes	abr-13
	40	25	Pin Retén Tubo Telescópico		31181108	Referencia Nueva	abr-13
		26	Retén Tubo Telescópico		DL181080	Referencia Nueva	abr-13
		27	Guardapolvo		JZ151091	Referencia Nueva	abr-13
38	41	10	Kit Calcomanías Tanque Gasolina		PA233094	Negro-Azul (2 PARTES)	abr-13
					PA233101	Negro-Rojo (2 PARTES)	abr-13
					PA232309	Azul (2 PARTES)	abr-13
					PA233117	Rojo (2 PARTES)	abr-13
40	43	8	Arandela Nylon	39178911	39178924	Referencia Errada en el Catalogo de Partes	abr-13
		11	Tornillo	39214004	39194304	Referencia Errada en el Catalogo de Partes	abr-13
		16	Antivibrante		JZ181271	Referencia Nueva	abr-13
41	44	8	Velocímetro (Solo)		YJZ08001	Referencia Nueva Marca Pricol	jul-14
		9	Medidor de Combustible		YJZ08002	Referencia Nueva Marca Pricol	jul-14
		10	Cubierta Sup. Velocímetro		YJZ08003	Referencia Nueva Marca Pricol	jul-14
		11	Ramal Velocímetro		YJZ08004	Referencia Nueva Marca Pricol	jul-14
		12	Anillo Retenedor		YJZ08008	Referencia Nueva	jul-14
		13	Anillo Retenedor Cubierta Sup.		YJZ08006	Referencia Nueva Marca Pricol	jul-14

ACTUALIZACIONES

Fig. N°	Pág.	Item	Descripción	Referencia Actual	Referencia Nueva	Observación	Fecha
41	44	14	Cubierta Inf. Velocímetro		YJZ08009	Referencia Nueva Marca Minda	jul-14
					YJZ08007	Referencia Nueva Marca Pricol	
		16	Cubierta Interna Velocímetro		YJZ08011	Referencia Nueva Marca Pricol	jul-14
		17	Capuchón Perilla Velocímetro		YJZ08010	Referencia Nueva Marca Pricol	jul-14
44	47	15	Bombillo 12V 3W		DH191037	Referencia nueva	abr-13
		16	Tuerca M8		39096515	Referencia nueva	abr-13
		17	Tornillo		39171404	Referencia nueva	abr-13
		18	Arandela		39179211	Referencia nueva	abr-13
		19	Arandela		39176511	Referencia nueva	abr-13
		20	Tuerca		DJ161229	Referencia nueva	abr-13
		21	Tornillo		39194304	Referencia nueva	abr-13
		22	Kit Bujes y Tornillos		36JZ0101	Referencia nueva	abr-13
46	49	13	Porta Placa	JZ232810	DP161145	Referencia errada	nov-15
		15	Bombillo 12V 5W		DJ201072	Referencia nueva	abr-13
		16	Bombillo Stop		31201028	Referencia nueva	abr-13
		17	Soquete Stop		JZ401046	Referencia nueva	abr-13
47	50	18	Base Bateria	60111417	PA401805	Referencia y Descripción Errada en el Catálogo de Partes	abr-13
		19	Cable relay-Bateria		PA402226	Referencia nueva	abr-13
48	51	3	Defensa Delantera (Integración Nacional)	JZ231211	032034/00	Referencia nueva	abr-13
		7	Tornillo M8	39249804	4652/00	Para Defensa de Integración Nacional	abr-13
		12	Arandela		4653/00	Para Defensa de Integración Nacional	abr-13

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
01100905	12	9
020982/00	13	49
032034/00	3	51
10020353	3	30
20001580	12	51
22150241	11	54
22150241	14	13
30101096	5	16
30101142	18	14
30101195	3	15
30101235	11	54
30101236	8	27
30101236	11	54
30141031	3	42
30141031	4	26
30141031	4	27
30141039	20	42
30151011	15	34
30151033	3	31
30151038	16	34
30151069	14	34
30151075	5	34
30151096	21	36
30151105	13	34
30181025	4	39
30181026	5	39
30181029	13	39
30181045	18	39
30191038	14	26
30191048	25	38
30201064	17	50
31101173	7	6

PARTE No.	FIG. No.	PAG. No.
31181108	25	40
31201028	16	49
31201079	12	36
31201081	8	11
36DK0017	22	36
36DK0019	29	38
36-JE00-02-025/47	5	5
36-JE00-02-050/47	5	5
36-JE00-02-075/47	5	5
36-JE00-02-100/47	5	5
36-JE00-02-STD/47	5	5
36JE0001	1	53
36JE0001	7	3
36JE0002	5	5
36JE0016	2	17
36JE0016	2	53
36JE0017	3	17
36JE0017	3	53
36JE0018	4	17
36JE0018	4	53
36JE0019	5	17
36JE0019	5	53
36JE0020	6	17
36JE0020	6	53
36JE0021	7	17
36JE0021	7	54
36JE0022	8	17
36JE0022	8	54
36-JZ00-74-025/47	8	5
36-JZ00-74-050/47	8	5
36-JZ00-74-075/47	8	5
36-JZ00-74-100/47	8	5

PARTE No.	FIG. No.	PAG. No.
36-JZ00-74-STD/47	8	5
36JZ0008	9	20
36JZ0015	1	15
36JZ0023	3	16
36JZ0074	1	5
36JZ0075	1	14
36JZ0077	1	11
36JZ0078	1A	22
36JZ0079	1	2
36JZ0080	2	34
36JZ0080	9	54
36JZ0081	9	4
36JZ0081	10	54
36JZ0082	1	19
36JZ0089	9	41
36JZ0090	11	41
36JZ0091	9	41
36JZ0092	11	41
36JZ0093	9	41
36JZ0094	11	41
36JZ0095	9	41
36JZ0096	11	41
36JZ0098	11	13
36JZ0098	11	54
36JZ0099	6	16
36JZ0101	22	47
36JZ0107	9	39
39019811	10	36
39019811	15	26
39021911	1	47
39021911	8	46
39024211	6	28

PARTE No.	FIG. No.	PAG. No.
39024211	11	46
39029115	19	44
39029215	17	25
39029215	3A	36
39032615	8	28
39032615	12	46
39037511	6	47
39042215	9	29
39045411	13	25
39055302	12	25
39059417	3A	4
39069415	19	36
39071111	3	44
39072211	12	43
39073817	3	13
39074011	12	42
39074701	10A	11
39076101	4	42
39078408	6	26
39078408	6	27
39078912	17	36
39078912	20	39
39079708	6	29
39080708	20	36
39080808	6	9
39080808	11	36
39080808	16	26
39081715	1	9
39084914	10	20
39085517	11	54
39095615	16	47
39098004	10	16

PARTE No.	FIG. No.	PAG. No.
39098717	4	7
39099206	7	8
39099311	6	13
39099906	4	12
39099906	6	15
39099906	11	11
39100006	2	5
39100120	14	16
39104011	5	26
39104011	5	27
39104119	10	14
39105315	9	25
39106301	3	36
39118101	21	39
39118415	28	38
39122515	6	48
39128321	4	2
39130911	20	21
39150711	2	50
39153721	5	36
39154011	18	36
39155204	2	44
39155604	2	28
39166005	6	2
39167121	6A	14
39167304	19	21
39167504	5	21
39168004	9	46
39168304	12	47
39171404	3	37
39171404	17	47
39171519	3	11

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
39175904	12	11
39176511	19	47
39177802	5	47
39178001	15	17
39178924	8	43
39179104	8	26
39179211	18	47
39188020	3	4
39190204	3	22
39190701	1	49
39190701	2	47
39190701	7	47
39191204	22	38
39194004	3	50
39194004	6	23
39194304	8	18
39194304	11	43
39194304	18	21
39194304	21	47
39195104	1	43
39196404	9	22
39197015	2	23
39197015	5	51
39198104	22	7
39201719	1	53
39201719	3	3
39212415	10	49
39214124	9	47
39217924	2	42
39219019	6	11
39220404	9	18
39224020	8	34

PARTE No.	FIG. No.	PAG. No.
39224915	18	37
39231004	18	26
39240817	8	13
39242001	7	28
39242001	10	46
39242411	2	43
39245304	2	9
39247604	11	49
39248415	5	49
39248415	6	42
39249211	9	19
39249804	4	23
39249804	7	51
39253921	8	2
39255304	4	51
39256220	4	11
39260011	3A	16
39260801	3	2
39262921	5	2
39265912	19	26
39266921	14	4
39267104	13	26
39268620	3	34
39268720	4	34
39268820	1	31
39270411	20	9
39272315	8	23
39275404	8	19
39275821	5	42
40325E	8	22
41070-2717-NR2/18	2	30
41070-2717-NR53/18	2	30

PARTE No.	FIG. No.	PAG. No.
41070-3017-NR1/18	5	30
4652/00	7	51
4975/00	1	52
4976/00	2	52
4977/00	1	52
4978/00	2	52
4979/00	3	52
4980/00	4	52
4981/00	3	52
4982/00	4	52
4983/00	5	52
4984/00	6	52
4985/00	5	52
4986/00	6	52
4987/00	5	52
4988/00	6	52
4989/00	8	52
4990/00	9	52
4991/00	7	52
52DH0248	4	24
52JA0027	10	22
52JZ0264	14	9
56JZ0123	1	41
59040006	12A	39
59040014	16	21
59040031	7	4
59040038	2	1
59040038	4	14
59040038	10	15
59040038	11A	11
59040050	6	1
59110008	4	6

PARTE No.	FIG. No.	PAG. No.
59120003	3	6
59150014	2	6
59200036	2	11
59200036	4	22
59210023	16	11
59210024	19	7
6410/00	8	22
6411/00	8	22
AA121071	12	2
CL201023	14	47
CM201054	15	44
CS101128	11	4
DD101097	12	13
DD111011	12	21
DD111012	10	21
DD111018	17	21
DD111048	11	21
DD121181	8	14
DD181032	6	39
DD181090	15	39
DD181091	17	39
DD201002	4	49
DE151006	2	31
DE151008	5	31
DE151012	4	31
DE151043	9	33
DE151046	2	33
DE151047	3	33
DE151048	5	33
DE191010	10	32
DE191011	11	32
DE191028	7	32

PARTE No.	FIG. No.	PAG. No.
DE191029	6	32
DE191031	2	32
DE191032	3	32
DE191033	15	32
DE191035	4	32
DF161102	1	29
DG101029	1	53
DG101029	4	3
DG101418	12	14
DG121025	6	18
DG161121	7	43
DG171018	5	25
DG171019	6	25
DH101048	6	4
DH101264	9	11
DH101301	6	19
DH101302	5	19
DH101380	6	22
DH101380	7	21
DH101382	7	20
DH101392	10	4
DH101509	13	9
DH101781	8	20
DH111013	15	21
DH111015	13	21
DH121059	10	17
DH121063	14	17
DH121064	11	17
DH121088	8	54
DH121093	12	17
DH121101	19	17
DH121102	20	17

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
DH121118	5	53
DH121118	8	54
DH151029	16	36
DH161157	14	27
DH161158	12	28
DH161194	17	26
DH161233	2	22
DH171019	23	35
DH191037	15	47
DJ141008	4	43
DJ151074	7	33
DJ151075	8	33
DJ161069	4	28
DJ161072	12	49
DJ161228	11	15
DJ161229	3	49
DJ161229	9	43
DJ161229	20	47
DJ161280	11	33
DJ181115	5	24
DJ191023	14	32
DJ191030	5	32
DJ191032	8A	32
DJ191058	8	32
DJ191059	1	32
DJ191081	30	38
DJ191082	6	37
DJ191083	7	37
DJ201072	15	49
DJ201108	16	32
DJ201109	9	32
DJ201173	10	28

PARTE No.	FIG. No.	PAG. No.
DJ201219	5	50
DJ201246	9A	37
DJ221019	1	51
DK121041	9	17
DK141041	18	42
DK171006	7	25
DK221024	2	51
DL161015	9	49
DL181080	26	40
DL191014	27	38
DP101165	6	5
DP101269	9	14
DP121059	5	53
DP121059	8	54
DP121059	18	17
DP121067	5	53
DP121067	17	17
DP161145	13	49
DS101117	4	13
DS101154	8	6
DS101215	11	14
DS101276	5	4
DS121126	7	18
DS141012	5	43
DS141012	17	42
DS151025	15	36
DS151073	10	34
DS151090	17	34
DS151094	20	34
DS161125	3	28
DS161224	2	46
DS161224	10	50

PARTE No.	FIG. No.	PAG. No.
DS181007	14	37
DS181010	17	37
DS181012	12	39
DS181015	22	39
DS181016	23	39
DS191052	8	37
DS201025	6	50
DS211007	4	22
DU101213	21	7
DU161102	6A	43
DX151022	25	35
DX191001	20	37
DZ141075	21	42
FD101078	2	12
GF161143	3	27
GH201212	2	48
GT5AL-BS-GELAUTECO	12	50
JA113403	7	23
JA113404	3	23
JA113404	6	51
JA351600	4	20
JA511008	5	1
JA521017	12	4
JA521018	15	4
JA521019	5	14
JA521019	13	4
JA531007	15	16
JA531012	9	6
JA531015	6	6
JA541005	5	11
JA541005	7	15
JA541010	5	22

PARTE No.	FIG. No.	PAG. No.
JA541011	3	22
JA541012	8	22
JA541014	7	22
JA541016	3	12
JA541021	15	11
JA541028	6	21
JA541034	10	11
JA541044	4	15
JA541205	8	15
JA541211	14	14
JA541212	15	14
JA541221	13	15
JA541225	13	14
JA541233	2	15
JA541236	16	14
JA541237	17	14
JA551002	3	7
JA551004	8	7
JA551008	17	7
JA551009	18	7
JA551406	2	16
JA551416	13	16
JA551420	12	16
JA561209	19	9
JA581406	10	2
JA591040	2	19
JA621002	5	13
JA621006	2	13
JA621206	13	13
JA621402	1	20
JA621406	2	20
JA621410	3	20

PARTE No.	FIG. No.	PAG. No.
JA621414	6	20
JB131017	10	31
JB131018	11	31
JB131019	12	31
JB131224	19	34
JB401400	5	37
JB402202	7	5
JB531021	10	6
JB551408	4	16
JB551411	7	16
JB551412	8	16
JC141015	4	44
JC141016	5	44
JD111052	3	43
JD113019	2	27
JD131210	24	35
JD131212	26	35
JD141003	1	34
JD161002	6	36
JD161006	7	36
JD171052	9	42
JD171801	13	42
JD351206	14	21
JD401007	6	49
JD401803	13	50
JD511004	2	2
JD511008	7	2
JD511010	3	1
JD511204	1	53
JD511205	1	53
JD511209	6	3
JD521002	3	5

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
JD531004	5	6
JD541000	7	11
JD551400	11	16
JD561002	5	8
JD561004	3	8
JD561006	2	8
JD561011	6	8
JD561203	17	9
JD561204	18	9
JD561416	7	9
JE351002	1	21
JE351004	1	21
JE351005	2	21
JE351206	3	21
JE501006	1	22
JE511049	2	4
JE511050	4	4
JE511200	1	3
JE511201	2	3
JE511204	5	3
JE511206	1	4
JE511230	8	4
JE521019	9A	4
JE531001	11	6
JE531008	1	6
JE541008	9	13
JE541030	9B	4
JE541210	12	15
JE541230	5	15
JE541231	6	14
JE551209	5	7
JE551210	13	7

PARTE No.	FIG. No.	PAG. No.
JE561003	1	8
JE581218	5	53
JE581218	16	17
JE581223	13	17
JE581231	1	17
JE591002	3	19
JE621001	1	13
JG131219	6	34
JG181238	7	44
JG571024	13	11
JK121007	7	39
JK121009	8	39
JL113028	7	26
JL113028	9	27
JL131807	4	33
JL171060	15	42
JL171803	14	42
JL181219	10	43
JL181225	14	25
JL401600	1	50
JL561409	11	9
JL561410	10	9
JM191014	13	36
JN131003	8	31
JN131203	7	34
JN181211	14	31
JN351604	4	50
JP351007	2	21
JV402205	15	50
JW131801	1	33
JW131805	12	32
JW131807	6	33

PARTE No.	FIG. No.	PAG. No.
JW131810	10	33
JW161017	6	43
JW181241	13	31
JW351400	4	5
JW541000	3	14
JW541005	2	14
JW561206	15	9
JW561208	16	9
JW591030	7	19
JZ111072	14	36
JZ113020	20	26
JZ113021	9	26
JZ113023	10A	27
JZ113026	12	27
JZ113027	10	26
JZ113028	1	26
JZ113031	1	27
JZ113032	11	27
JZ113035	11	26
JZ113035	15	27
JZ113036	2	26
JZ113037	7	27
JZ113038	16	27
JZ113039	3	26
JZ113042	13	27
JZ113203	2	29
JZ113204	7	29
JZ113206	3	29
JZ113207	4	29
JZ113209	5	29
JZ113210	8	29
JZ113211	8A	29

PARTE No.	FIG. No.	PAG. No.
JZ113212	5A	29
JZ113214	4	29
JZ113410	5	23
JZ113411	9	23
JZ113426	1	23
JZ113435	1B	23
JZ113436	1A	23
JZ113805	2	24
JZ113806	10	25
JZ121015	19	39
JZ121027	1	39
JZ121030	2	39
JZ121031	3	39
JZ121040	10	39
JZ122001	3	25
JZ122003	1	25
JZ122005	11	25
JZ122008	15	25
JZ122010	4	25
JZ122011	8	25
JZ122012	16	25
JZ131028	1	30
JZ131224	4	30
JZ131601	9	31
JZ131803	18	34
JZ131810	8	36
JZ131813	9	34
JZ131818	6	31
JZ131875	9	36
JZ151045	15A	37
JZ151047	11	47
JZ151047	16	39

PARTE No.	FIG. No.	PAG. No.
JZ151064	9	37
JZ151065	19	37
JZ151069	10	37
JZ151070	2	37
JZ151078	15	37
JZ151079	16	37
JZ151083	1	24
JZ151084	3	24
JZ151091	27	40
JZ161009	1	36
JZ161011	4	36
JZ161019	2	36
JZ161024	12	26
JZ161207	2	45
JZ161208	3	45
JZ161210	1	45
JZ161217	7	22
JZ171004	1	42
JZ171017	8	42
JZ171807	10	42
JZ171817	16	42
JZ171818	19	42
JZ171829	11	42
JZ181007	4	37
JZ181009	5	46
JZ181012	13	37
JZ181013	12	37
JZ181015	10	47
JZ181214	1	46
JZ181227	5	41
JZ181231	6	41
JZ181233	4	41

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
JZ181237	8	47
JZ181238	2	41
JZ181260	8	48
JZ181261	9	48
JZ181269	14	43
JZ181270	13	43
JZ181271	16	43
JZ181414	3	41
JZ181415	1	28
JZ181416	5	28
JZ181419	9	28
JZ181420	3	46
JZ181421	4	46
JZ191000	1	22
JZ191010	5	22
JZ191011	6	22
JZ231211	3	51
JZ231225	3	51
JZ231403	8	51
JZ231410	11	51
JZ231411	10	51
JZ231600	23	38
JZ231601	24	38
JZ232600	26	38
JZ232805	14	49
JZ233145	10	41
JZ233153	10	41
JZ233161	10	41
JZ233169	10	41
JZ233177	8	41
JZ233178	7	41
JZ351211	8	21

PARTE No.	FIG. No.	PAG. No.
JZ351213	9	21
JZ401013	7	50
JZ401029	13	47
JZ401036	4	48
JZ401037	1	48
JZ401038	5	48
JZ401039	7	48
JZ401042	7	49
JZ401043	4	47
JZ401046	17	49
JZ401400	21	38
JZ401803	9	50
JZ401804	11	50
JZ401809	8	50
JZ402000	4	21
JZ402217	16	50
JZ402600	7	42
JZ511021	1	1
JZ541209	1	15
JZ541214	7	14
JZ541226	9	15
JZ551004	20	7
JZ551004	9	54
JZ551008	9	7
JZ551010	1	7
JZ551200	7	7
JZ551202	2	7
JZ551204	16	7
JZ551205	15	7
JZ551206	10	7
JZ551208	14	7
JZ551210	11	7

PARTE No.	FIG. No.	PAG. No.
JZ551211	12	7
JZ551213	6	7
JZ551413	1	16
JZ551415	9	16
JZ561002	4	8
JZ561201	3	9
JZ561402	9	9
JZ561404	5	9
JZ561405	8	9
JZ561407	4	9
JZ571000	1	12
JZ571001	5	12
JZ581020	1	18
JZ581025	5	18
JZ581026	4	18
JZ581032	3	18
JZ581229	11	2
JZ581405	9	2
JZ591095	4	19
JZ621000	7	13
JZ621200	10	13
KACA0820	9	51
KADA0618	2	18
KBUA0545	8	49
LAC00002	7	31
LAC00005	10	27
LAC00019	2	25
LAC00031	11	37
LAD00011	5	20
LAD00018	14	15
LAD00037	13	32
LAD00048	10	23

PARTE No.	FIG. No.	PAG. No.
LAD00082	6	46
LAE00001	7	46
LAE00022	11	28
LBU00004	15	31
LBU00005	16	31
LBU00007	15	43
LCA00005	3	48
LCB00005	12	34
LDB00001	22	35
LDB00007	18	44
LJA00004	14	11
MF12V5-3B-AUTECO	12	50
PA121017	11	39
PA131021	1	30
PA131241	4	30
PA181226	1	44
PA181227	3	47
PA233094	10	41
PA233101	10	41
PA233109	10	41
PA233117	10	41
PA401009	2	49
PA401405	1	37
PA401805	18	50
PA402216	14	50
PA402226	19	50
PA402422	6	44
PA402424	8	44
PA402425	9	44
PA402426	10	44
PA402427	16	44
PA402428	13	44

PARTE No.	FIG. No.	PAG. No.
PA402429	17	44
PA402431	11	44
PA402432	20	44
PF121028	14	39
PF131220	11	34
PF511027	4	1
PF541018	2	22
YJZ08001	8	44
YJZ08002	9	44
YJZ08003	10	44
YJZ08004	11	44
YJZ08006	13	44
YJZ08007	14	44
YJZ08008	12	44
YJZ08009	14	44
YJZ08010	17	44
YJZ08011	16	44

FICHA TÉCNICA DISCOVER 125 ST	
CARACTERÍSTICA	UNIDAD
MOTOR	
Potencia máxima	12.8 hp @ 9.000rpm
Tipo	Monocilindrico refrigerado por aire
Cilindrada	124.6cc
Torque máximo	10.8 Nm @ 6.500rpm
Relación de compresión	9.8 +/- 0.5 : 1
Arranque	Eléctrico y de pedal.
Bujía	Marca CHAMPION PRZ9HC ó BOSCH-UR4HC (2 Unds)
Lubricación	Forzada bomba húmeda
Transmisión	5 velocidades
Capacidad del tanque de combustible	10 litros (2.64 galones)
FRENOS	
Freno delantero	Disco
Freno trasero	Bandas expandibles.
SISTEMA ELÉCTRICO	
Farola	12V, 35/35W HS-1
Cola/luz de freno:	12V 21/5W
Direccionales	12V10W
Pito	12V DC
Batería	12V 5Amp MF
LLANTAS	
Llanta delantera	2.75-17
Llanta trasera	3.00-17
SUSPENSIÓN	
Delantera	Horquilla telescópica.
Trasera	Brazo oscilante con Mononitrox.



Discover
125 ST





Línea Gratuita Nacional
01 8000 52 00 90
servicioalcliente@auteco.com.co
www.auteco.com.co



Mobil