

pulsar
135LS

BAJAJ
Distinctly Ahead



CATÁLOGO DE PARTES

Mobil Super™
4T Ultra

IRC *LLANTAS* *TECNOLOGÍA JAPONESA*



**Los Expertos en motos
las usan y recomiendan:**

 **BAJAJ**
Distinctly Ahead

 **auteco**
www.auteco.com.co

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO CATALOGO	CÓDIGO SAP
PULSAR 200 NS, PULSAR AS 200, PULSAR RS 200	DELANTERA	100/80-17	IRC	NR73	PISTERA	41070-1017-NR73/18	10020077
		100/80-17		RX01	PISTERA	100/80-17-RX01-TL	10003160
		110/70-17		RX01	PISTERA	41070-1117-RX01/18	10020095
	TRASERA	130/70-17	IRC	RX01	PISTERA	41070-1317-RX01/18	10020115
PULSAR 220	DELANTERA	90/90X17	IRC	NF45	PISTERA TUBE LESS	41070-9017-NF45/18	10020217
				NF52TL	PISTERA TUBE LESS	90/90-17-NF52-TL	10029297
				NF42	PISTERA TUBE LESS	41070-9017-NF42/18	10020214
				NF46	PISTERA TUBE LESS	41070-9017-NF46/18	10020220
				RX01	PISTERA TUBE LESS	41070-1117-RX01/18	10020095
	TRASERA	130/70-17	IRC	RX01	PISTERA TUBE LESS	41070-1317-RX01/18	10020115
		120/80X17		NR57TL	PISTERA TUBE LESS	120/80-17-NR57-TL	10007401
AVENGER 220	DELANTERA	90/90X17	IRC	NF45	PISTERA	41070-9017-NF45/18	10020217
	TRASERA	130/90X15		NR66	SPORT	130/90-15-NR66-TT	10008722
PULSAR 200, PULSAR 180 UG	DELANTERA	2.75X17	IRC	NF53	PISTERA	41070-2717-NR53/18	10020143
		90/80X17		NR73	PISTERA	90/80-17-NR73-TT	10029270
		90/90X17		NF53	PISTERA	41070-9017-NF53/18	10020223
		100/80-17		NR73	PISTERA	41070-1017-NR73/18	10020077
		110/70-17		RX01	PISTERA	41070-1117-RX01/18	10020095
	TRASERA	130/70-17	IRC	RX01	PISTERA	41070-1317-RX01/18	10020115

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO CATALOGO	CÓDIGO SAP
PULSAR 135	DELANTERA	2.75X17	IRC	NR53	PISTERA	41070-2717-NR53/18	10020143
		90/80-17		NR73TT	PISTERA	90/80-17-NR73-TT	10029270
	TRASERA	110/80-17	IRC	NR53	PISTERA	41070-1117-NR53/18	10020089
		100/80X17		NR64 NR73	PISTERA PISTERA	41070-1117-NR64/18 41070-1017-NR73/18	10020092 10020077
PULSAR 150	DELANTERA	90/90-17	IRC	NF53	PISTERA TUBE LESS	90/90-17-NF53-TL	10029301
	TRASERA	110/80-17		NR48TL	PISTERA TUBE LESS	110/80-17-NR48-TL	10003355
PULSAR NS 150, PULSAR AS 150	DELANTERA	90/80-17	IRC	NR77UZ	PISTERA	90/80-17-NR77UZ-TL	10029272
	TRASERA	110/80-17		NR48TL	PISTERA	110/80-17-NR48-TL	10003355
PULSAR 180 (CLASSIC, DTS-i)	DELANTERA	2.75X18	IRC	NR21	SPORT	41070-2718-NR21/18	10020146
				NR53	PISTERA	41070-2718-NR53/18	10020149
	TRASERA	3.00X18	IRC	GP1	TRIAL ROMBO	41070-3018-GP1/18	10020171
				NR53	PISTERA	41070-3018-NR53/18	10020174
DISCOVER 125 ST DISCOVER 125 DISCOVER 100 DISCOVER 135 KS/ES DISCOVER DTSI PULSAR 180 DTS-i TEC,BLACK, PULSAR II	DELANTERA	2.75X17	IRC	NR53	PISTERA	41070-2717-NR53/18	10020143
		90/80-17		NR73TT	PISTERA	90/80-17-NR73-TT	10029270
	TRASERA	3.00X17	IRC	GP1	TRIAL ROMBO	41070-3017-GP1/18	10020163
				NR1	SPORT	41070-3017-NR1/18	10020166
		100/80-17		NR73	PISTERA	41070-1017-NR73/18	10020077
		80/90-17		NR78YL	PISTERA	80/90-17-NR78Y-TT	10027758

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO CATALOGO	CÓDIGO SAP
DISCOVER 100M, DISCOVER 110	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	90/80-17-NR73-TT	10029270
	TRASERA	100/80X17		NR73	PISTERA	100/80-17-NR73-TT	10020077
DISCOVER 150ST-F	DELANTERA	100/80-17	IRC	NR73S	PISTERA	100/80-17-NR73S-TL	10003158
	TRASERA	80/90-17		NR73	PISTERA	80/90-17-NR73S-TL	10027755
PLATINO 125 5S, PLATINO 125, PLATINO CT, PLATINO 100 SPORT, PLATINO 110, XCD 125	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	90/80-17-NR73-TT	10029270
		2.75X17		NR53	PISTERA	41070-2717-NR53/18	10020143
				GP1	TRIAL ROMBO	41070-2717-GP1/18	10020137
	TRASERA	100/80-17	IRC	NR73	PISTERA	41070-1017-NR73/18	10020077
		3.00X17		GP1	TRIAL ROMBO	41070-3017-GP1/18	10020163
				NR1	SPORT	41070-3017-NR1/18	10020166
BOXER CON RIN 17" BOXER BM 150, BOXER CT 100, BOXER BM 100	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	41070-9017-NR73TT/18	10029270
		90/90-17		NR53	PISTERA	41070-2717-NR53/18	10020143
		2.75X17		NR53	PISTERA	41070-2717-NR53/18	10020143
				GP1	TRIAL ROMBO	41070-2717-GP1/18	10020137
	TRASERA	100/80-17	IRC	NR73	PISTERA	41070-1017-NR73/18	10020077
		3.00X17		GP1	TRIAL ROMBO	41070-3017-GP1/18	10020163
				NR1	SPORT	41070-3017-NR1/18	10020166
		BOXER BM 100 CLASSIC ES		DELANTERA	2.75X17	IRC	NR53
TRASERA	3.00X17		NR1	SPORT	41070-3017-NR1/18		10020166
BOXER CON RIN 18" 4T, UG, K-TEC	DELANTERA	2.50X18		NR53	PISTERA	41070-2518-NR53/18	10020134
	TRASERA	3.00X18	IRC	GP1	TRIAL ROMBO	41070-3018-GP1/18	10020171
				NR53	PISTERA	41070-3018-NR53/18	10020174

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO CATALOGO	CÓDIGO SAP
BOXER CON RIN 18" (S1D) CALIBER 115 WIND 125	DELANTERA	2.75X18	IRC	NR21	SPORT	41070-2718-NR21/18	10020146
				NR53	PISTERA	41070-2718-NR53/18	10020149
	TRASERA	3.00X18	IRC	GP1	TRIAL ROMBO	41070-3018-GP1/18	10020171
				NR53	PISTERA	41070-3018-NR53/18	10020174
AVANTI	DELANTERA	2.50X17	IRC	TR1	TRIAL ROMBO	41070-2517-TR1/18	10020132
	TRASERA	2.75X17	IRC	NR2	SPORT	41070-2717-NR2/18	10020140
				NR53	PISTERA	41070-2717-NR53/18	10020143
				GP1	TRIAL ROMBO	41070-2717-GP1/18	10020137
PLUS, CLASSIC, LEGEND	DELANTERA	3.50X10	IRC	MB-27	SPORT	41070-3510-27/18	10020183
	TRASERA						

Advierta lo que le dicen las llantas mientras conduce:

- Si su respuesta a la dirección es lenta o si en las curvas y en el frenado la respuesta es pesada, es muy probable que sus llantas estén desinfladas.
- Vibración o tambaleo durante la conducción, puede significar que la presión en las llantas es mayor a la recomendada, o que ha ocurrido un daño en la llanta y la falla es inminente.
- La llanta puede vibrar a ciertas velocidades debido al desbalanceo, en este caso su desgaste será muy acelerado.

**RECUERDE SIEMPRE REVISAR LA PRESIÓN DE AIRE EN SUS LLANTAS
ANTES DE COMENZAR A RODAR**

PREFACIO

Es nuestro placer presentarles a ustedes el Catálogo de Partes.

Este Catálogo ha sido especialmente diseñado para ayudarle en la selección de las partes correctas con el fin de mantener el vehículo en las mejores condiciones.

Los repuestos originales están sujetos a un exigente estándar de control de calidad, por lo tanto es necesario que usted sólo use repuestos originales.

En nuestro constante esfuerzo para mejorar la eficiencia y desempeño de su vehículo, las especificaciones, diagramas y número de partes pueden cambiar sin previo aviso. Consecuentemente las descripciones de los repuestos en este Catálogo pueden no ser las finales y definitivas.

Las alteraciones y modificaciones que ocurren en la impresión de este Catálogo, serán informadas a nuestra red, a través de circulares de Servicio o en nuestra página web: www.auteco.com.co accediendo al link repuestos. Es requisito que usted actualice su Catálogo y haga las correcciones necesarias, una vez reciba dichas circulares. Lo anterior le asegurará un rápido y adecuado despacho de sus partes, pues las órdenes están siendo diligenciadas con las referencias más actualizadas.

En caso de necesitar asistencia técnica, comunicarse con el Distribuidor Autorizado o llamar al Departamento de Servicios Auteco-Kawasaki.



DIRECTORIO TELEFÓNICO - UN REPUESTOS Y ACCESORIOS ÁREA COMERCIAL Y ASESORES DE VENTAS

NOMBRE	CARGO	ZONA	CELULAR	CORREO ELECTRÓNICO
Alvaro Enrique Carreño	ASESOR COMERCIAL	Magdalena Medio	314 701 17 85	acarreno@auteco.com.co
Andres Julian Giraldo	ASESOR COMERCIAL	Risaralda y Armenia	301 375 43 57	ajgiraldo@auteco.com.co
Bernardo De Jesus Muriel	ASESOR COMERCIAL	Cucuta	312 257 61 75	bmuriel@auteco.com.co
Carlos Humberto Tobon	ASESOR COMERCIAL	Nariño y Putumayo	310 447 36 11	ctobon@auteco.com.co
Carlos Mario Salazar	ASESOR COMERCIAL	Sucre	310 414 88 45	csalazar@auteco.com.co
Eliecer Zamora Vasquez	ASESOR COMERCIAL	Cali y Cauca	313 584 47 13	ezamora@auteco.com.co
Elkin Humberto Gallego	ASESOR COMERCIAL	Sur de Area Metropolitana de Medellín y Amazonas	310 436 25 98	egallego@auteco.com.co
Esmeralda Forero Acosta	ASESOR COMERCIAL	Zona Centro Bogota	313 585 22 07	eforero@auteco.com.co
Gustavo Adolfo Cantillo	ASESOR COMERCIAL	Atlántico	300 447 41 57	gcantillo@auteco.com.co
Hernan Alonso Pedraza	ASESOR COMERCIAL	Pueblos de Condinamarca	311 899 77 28	hpedraza@auteco.com.co
Ivano Alexy Villota Arteaga	ASESOR COMERCIAL	Sur de Huila y Caqueta	313 767 78 43	ivillota@auteco.com.co
Jaime Alfonso Villalba	ASESOR COMERCIAL	Bolivar	313 584 72 62	jvillalba@auteco.com.co
John Jairo Lopez	ASESOR COMERCIAL	Antioquia Norte	310 444 22 15	jlopez@auteco.com.co
Julio Mario Moterrosa	ASESOR COMERCIAL	Magdalena	313 585 60 28	jmonterrosa@auteco.com.co
Karen Lorena Candanoza	ASESOR COMERCIAL	Zona Sur Bogota	313 585 35 61	kcandanoza@auteco.com.co
Marlon Santiago Blandon	ASESOR COMERCIAL	Cordoba y Bajo Cauca	310 373 90 19	msblandon@auteco.com.co
Miguel Angel Guerrero	ASESOR COMERCIAL	Norte del Valle y Buenaventura	314 772 07 98	mgguerrero@auteco.com.co
Miguel Arturo Osorio Ruiz	ASESOR COMERCIAL	Cesar y Guajira	321 799 78 87	mosorio@auteco.com.co
Miller Fabian Acosta	ASESOR COMERCIAL	Zona Norte Bogota	313 585 98 37	macosta@auteco.com.co
Milton Cesar Olaya Carvajal	ASESOR COMERCIAL	Neiva y Norte Huila	310 436 27 42	molaya@auteco.com.co
Nestor Raul Adarve	ASESOR COMERCIAL	Antioquia Sur y Choco	310 436 26 89	nadarve@auteco.com.co
Oscar Alejandro Posada Villa	ASESOR COMERCIAL	Norte Area Metropolitana Medellin y San Andres	314 811 04 09	aposada@auteco.com.co
Rubén Dario Campo Cárdena	ASESOR COMERCIAL	Caldas y Norte de Risaralda	321 799 79 06	rcampo@auteco.com.co
Uberney Ortiz Velez	ASESOR COMERCIAL	Casanare, Vichada, Boyaca	313 672 73 37	uortiz@auteco.com.co
Willinton Franco Tobon	ASESOR COMERCIAL	Tolima	312 257 67 91	wfranco@auteco.com.co
William De Jesus Gutierrez	ASESOR COMERCIAL	Meta	310 407 40 72	wgutierrez@auteco.com.co
Wilson Sabogal	ASESOR COMERCIAL	Bucaramanga y Area Metropolitana	300 542 85 48	wsabogal@auteco.com.co
Herica Linares Riaño	ASESOR COMERCIAL BAJAJ	Bogota	301 247 71 10	hlinares@auteco.com.co
Jorge Mario Gil	ASESOR COMERCIAL BAJAJ	Medellin	313 672 73 53	jgil@auteco.com.co
Jorge Mario Maya Velez	ASESOR COMERCIAL BAJAJ	Medellin	312 258 93 84	jmaya@auteco.com.co
Meryce Alejandra Cortazar P.	ASESOR COMERCIAL BAJAJ	Cali	320 732 97 60	mcortazar@auteco.com.co
Pilar Katherine Garcia Tique	ASESOR COMERCIAL BAJAJ	Bogota	300 541 93 34	pgarcia@auteco.com.co
Raul De Jesus Foronda	ASESOR COMERCIAL BAJAJ	Santa Marta	312 850 45 74	rforonda@auteco.com.co
Richard Andres Muñoz	ASESOR COMERCIAL BAJAJ	Popayan	321 799 79 26	rmunoz@auteco.com.co
Yeesdander Guzman Garcia	ASESOR COMERCIAL BAJAJ	Barranquilla	300 542 64 59	yguzman@auteco.com.co
Daniel Becerra Martinez	ASESOR COMERCIAL BOUTIQUE	Cali	300 542 43 98	dbecerra@auteco.com.co
German Alfredo Vivas	ASESOR COMERCIAL BOUTIQUE	Bogota	321 799 79 30	gvivas@auteco.com.co
Hilde Alexander Garcia Cano	ASESOR COMERCIAL BOUTIQUE	Medellin	321 641 50 63	hgarcia@auteco.com.co
Franz Caballero Castro	DESARROLLADOR UN RPTOS Y ACCS	BARRANQUILLA	301 375 25 32	fcaballero@auteco.com.co
Gonzalo Adolfo Saldarriaga	DESARROLLADOR UN RPTOS Y ACCS	MEDELLIN	310 406 88 74	gsaldarriaga@auteco.com.co
Gustavo Adolfo Corrales	DESARROLLADOR UN RPTOS Y ACCS	CALI	300 634 67 59	gcorrales@auteco.com.co
Gilberto Eduardo Ocampo	GERENTE REGIONAL ZONA SUR	GERENTE REGIONAL ZONA SUR	311 382 85 14	ecampo@auteco.com.co
Jhon Alexander Estrada Bello	GERENTE REGIONAL ZONA NORTE	GERENTE REGIONAL ZONA NORTE	311 737 37 48	jestrada@auteco.com.co
Jose Giovanni Suarez Martinez	GERENTE REGIONAL ZONA CENTRO	GERENTE REGIONAL ZONA CENTRO	320 766 49 45	jsuarez@auteco.com.co
Juan Guillermo Ospina	GERENTE COMERCIAL BAJAJ		313 767 78 36	jgospina@auteco.com.co
Laura Ocampo	COORDINADORA ALTA GAMA		320 682 09 64	locampo@auteco.com.co

SERVICIO AL CLIENTE

LÍNEA ÚNICA DE SERVICIO AL CLIENTE CANAL (4) 444 81 90 

UN DE REPUESTOS y ACCESORIOS • FAX OFICINAS: 373 03 75







ATENCIÓN EN:	NOMBRE	E-MAIL	TELÉFONO	FAX
SERVICIO A CONCESIONARIO Y MAYORISTAS	JHONATAN ZAPATA	servicioadistribuidoresymayoristas@auteco.com.co	(4) 444 81 90 OPCION (2)	
SERVICIO PAGO ANTICIPADO	DORIS CARMONA	serviciopagoanticipadorptos@auteco.com.co		(4) 373 83 94
COORDINADOR SERVICIO POSTVENTA	LUIS G. RODRIGUEZ	lrodriguez@auteco.com.co		
GARANTÍAS	ALEJANDRO FERNÁNDEZ	garantias2@auteco.com.co		
DEVOLUCIONES - RECLAMOS	LEONARDO AGUDELO	devolucionesrptos@auteco.com.co		
MOTO FUERA DE RUTA	JONI HOLGUIN	motofueraderuta@auteco.com.co	3004243097	
LÍNEA DE ATENCIÓN AL CLIENTE				
POSCONSUMO BATERIAS	YUDY DUQUE	yduque@auteco.com.co		(4) 277 5117
CARTERA		cartera@auteco.com.co		(4) 306 81 54
VENTA MOTOS		pedidosmotos@auteco.com.co		(4) 372 62 95

AUTOTECNICA COLOMBIANA S.A.S (AUTECO S.A.S) SEDE PRINCIPAL Cra. 42 N° 45-77 Itagüí Ant. - PBX: (4)306 81 81
Atención a clientes finales: LÍNEA GRATUITA NACIONAL - 01 8000 52 00 90







ÍNDICE

FIGURA Nº.	DESCRIPCIÓN	PÁG. Nº.	FIGURA Nº.	DESCRIPCIÓN	PÁG. Nº.
1	TAPA CULATA	1	30	DISCO DE FRENO DELANTERO	31
2	CULATA	2	31	BOMBA FRENO DELANTERO	32
3	VÁLVULAS	3	32	CALIPER DELANTERO	33
4	EJE DE LEVAS / TENSOR CADENILLA	4	33	RUEDA TRASERA	34-35
5	CILINDRO / PISTÓN	5	34	PEDAL FRENO TRASERO	36
6	CIGÜEÑAL	6	35	MANUBRIO	37-38
7	TRANSMISIÓN	7-8	36	SUSPENSIÓN DELANTERA	39
8	SELECTOR DE CAMBIOS	9	37	TANQUE DE GASOLINA/ GUARDABARRO/ TAPAS LATERALES	40-41
9	EJE DE CAMBIOS	10	37A	CALCOMANÍAS DUOTONO	42-43
10	CARCASA DERECHA	11	38	CALCOMANÍAS PULSARMANIA (2013)	44
11	CARCASA IZQUIERDA	12	38A	CALCOMANIAS Y ACCESORIOS PULSARMANIA (2016)	45
12	CUBIERTA CLUTCH	13	39	CALCOMANÍAS PULSAR GP	46
13	CUBIERTA VOLANTE / CUBIERTA CADENA	14	40	ACCESORIOS PULSAR GP	47
14	CLUTCH	15	41	CALCOMANÍAS PULSAR RACING	48-49
15	PEDAL CRANK	16	42	ACCESORIOS PULSAR RACING	50
16	CARBURADOR	17	43	CALCOMANÍAS PULSAR PRO	51
17	FILTRO DE AIRE	18	44	ACCESORIOS PULSAR PRO	52
18	SILENCIADOR	19	45	GRIFO DE GASOLINA	53
19	BOMBA DE ACEITE	20	46	ANTIVIBRANTES TANQUE GASOLINA Y TAPAS LATERALES	54
20	MOTOR DE ARRANQUE	21	47	VELOCÍMETRO	55
21	MAGNETO / C.D.I. / PLATO DE BOBINAS	22	48	CABLES	56
22	SILLÍN	23	49	PROTECTOR LLANTA	57
23	PARTES DEL CHASIS	24	50	FAROLA	58
24	CHASIS	25	51	DIRECCIONALES	59
25	AMORTIGUADOR TRASERO / BRAZO OSCILANTE	26	52	STOP / PORTA PLACA	60
26	REPOSAPIE CONDUCTOR / PASAJERO	27	53	EQUIPO ELÉCTRICO	61
27	GUARDABARRO TRASERO	28	54	ACCESORIOS / HERRAMIENTAS	62
28	GATO CENTRAL / GATO LATERAL	29		LISTA DE KITS	63-64
29	LLANTAS / RINES	30		ÍNDICE DE REFERENCIAS	65-70

ÍNDICE DE GRÁFICOS

		
FIGURA Nº 1 : TAPA CULATA	FIGURA Nº 2 : CULATA	FIGURA Nº 3 : VÁLVULAS
		
FIGURA Nº 4 : EJE DE LEVAS / TENSOR CADENILLA	FIGURA Nº 5 : CILINDRO / PISTÓN	FIGURA Nº 6 : CIGÜEÑAL

ÍNDICE DE GRÁFICOS

	FIGURA N° 7 : TRANSMISIÓN PÁG. N°. 7 - 8		FIGURA N° 8 : SELECTOR DE CAMBIOS PÁG. N°. 9		FIGURA N° 9 : EJE DE CAMBIOS PÁG. N°. 10
	FIGURA N° 10 : CARCASA DERECHA PÁG. N°. 11		FIGURA N° 11 : CARCASA IZQUIERDA PÁG. N°. 12		FIGURA N° 12 : CUBIERTA CLUTCH PÁG. N°. 13

ÍNDICE DE GRÁFICOS




FIGURA N° 13 : CUBIERTA VOLANTE /
CUBIERTA CADENA

PÁG. N°.
14




FIGURA N° 14 : CLUTCH

PÁG. N°.
15




FIGURA N° 15 : PEDAL CRANK

PÁG. N°.
16




FIGURA N° 16 : CARBURADOR

PÁG. N°.
17




FIGURA N° 17 : FILTRO DE AIRE

PÁG. N°.
18











FIGURA N° 18 : SILENCIADOR

PÁG. N°.
19

ÍNDICE DE GRÁFICOS


						
FIGURA N° 19 : BOMBA DE ACEITE	PÁG. N°. 20	FIGURA N° 20 : MOTOR DE ARRANQUE	PÁG. N°. 21	FIGURA N° 21 : MAGNETO / C.D.I. / PLATO DE BOBINAS	PÁG. N°. 22	
						
FIGURA N° 22 : SILLÍN	PÁG. N°. 23	FIGURA N° 23 : PARTES DEL CHASIS	PÁG. N°. 24	FIGURA N° 24 : CHASIS	PÁG. N°. 25	

ÍNDICE DE GRÁFICOS



**FIGURA Nº 25 : AMORTIGUADOR TRASERO /
BRAZO OSCILANTE**

**PÁG. Nº.
26**



**FIGURA Nº 26 : REPOSAPIE CONDUCTOR /
PASAJERO**

**PÁG. Nº.
27**





FIGURA Nº 27 : GUARDABARRO TRASERO

**PÁG. Nº.
28**



**FIGURA Nº 28 : GATO CENTRAL / GATO
LATERAL**

**PÁG. Nº.
29**





FIGURA Nº 29 : LLANTAS / RINES







**PÁG. Nº.
30**









**FIGURA Nº 30 : DISCO DE FRENO
DELANTERO**

**PÁG. Nº.
31**






ÍNDICE DE GRÁFICOS

	FIGURA Nº 31 : BOMBA FRENO DELANTERO PÁG. Nº. 32
	FIGURA Nº 32 : CALIPER DELANTERO PÁG. Nº. 33
	FIGURA Nº 33 : RUEDA TRASERA PÁG. Nº. 34 - 35
	FIGURA Nº 34 : PEDAL FRENO TRASERO PÁG. Nº. 36
	FIGURA Nº 35 : MANUBRIO PÁG. Nº. 37 - 38
	FIGURA Nº 36 : SUSPENSIÓN DELANTERA PÁG. Nº. 39







ÍNDICE DE GRÁFICOS

		
FIGURA N° 37 : TANQUE DE GASOLINA/ GUARDABARRO/ TAPAS LATERALES	FIGURA N° 37A : CALCOMANÍAS DUOTONO	FIGURA N° 38 : CALCOMANÍAS PULSARMANIA (2013)
		
FIGURA N° 38A : CALCOMANÍAS Y ACCESORIOS PULSARMANIA (2016)	FIGURA N° 39 : CALCOMANÍAS PULSAR GP	FIGURA N° 40 : ACCESORIOS PULSAR GP



ÍNDICE DE GRÁFICOS

	FIGURA N° 41: CALCOMANÍAS PULSAR RACING	PÁG. N°. 48 - 49		FIGURA N° 42: ACCESORIOS PULSAR RACING	PÁG. N°. 50		FIGURA N° 43 : CALCOMANÍAS PULSAR PRO	PÁG. N°. 51
	FIGURA N° 44 : ACCESORIOS PULSAR PRO	PÁG. N°. 52		FIGURA N° 45 : GRIFO DE GASOLINA	PÁG. N°. 53		FIGURA N° 46 : ANTIVIBRANTES TANQUE GASOLINA Y TAPAS LATERALES	PÁG. N°. 54

ÍNDICE DE GRÁFICOS

					
FIGURA N° 47 : VELOCÍMETRO	PÁG. N°. 55	FIGURA N° 48 : CABLES	PÁG. N°. 56	FIGURA N° 49 : PROTECTOR LLANTA	PÁG. N°. 57
					
FIGURA N° 50 : FAROLA	PÁG. N°. 58	FIGURA N° 51 : DIRECCIONALES	PÁG. N°. 59	FIGURA N° 52 : STOP / PORTA PLACA	PÁG. N°. 60

ÍNDICE DE GRÁFICOS

					
FIGURA N° 53 : EQUIPO ELÉCTRICO	PÁG. N°. 61	FIGURA N° 54: ACCESORIOS / HERRAMIENTAS	PÁG. N°. 62		

This exploded view diagram illustrates the assembly of a carburetor. The components are numbered as follows:

- 1**: Carburetor body (top view).
- 2**: Bolt for the top cover.
- 3**: Gasket for the top cover.
- 4**: Bolt for the float bowl.
- 5**: Float bowl.
- 6**: Fuel line.
- 7**: Fuel line fitting.
- 8**: Bolt for the float bowl.

The diagram shows the carburetor body (1) at the top, with a bolt (2) and gasket (3) for the top cover. Below it is the float bowl (5), which is secured with bolts (4) and (8). A fuel line (6) with a fitting (7) is shown connecting to the carburetor body. Dashed lines indicate the assembly sequence and alignment of the parts.

pulsar 135LS

This exploded view diagram illustrates the assembly of a carburetor. The components are numbered as follows:

- 1**: Main carburetor body.
- 2**: Two screws for the float bowl.
- 3**: Float bowl gasket.
- 4**: Jet needle assembly.
- 5**: Jet needle screw.
- 6**: Jet needle spring.
- 7**: Jet needle spring cap.
- 8**: Jet needle O-ring.
- 9**: Jet needle.
- 10**: Jet needle pin.
- 11**: Jet needle pin O-ring.
- 12**: Jet needle pin.

pulsar 135LS

This diagram illustrates the assembly of a mechanical component, likely a valve or actuator. The parts are numbered as follows:

- 1**: Two cylindrical rods or pins.
- 2**: A complex mechanical housing or bracket, shown in a dashed box with an inset detail of its internal structure.
- 3**: A small circular washer or spacer.
- 4/5**: A long, angled rod or lever arm with a circular base.
- 6**: A vertical support structure or frame.
- 7**: A small cylindrical component, possibly a pin or bush.

The assembly sequence is indicated by dashed lines and leader lines. The rods (1) are inserted into the housing (2). The washer (3) is placed on the rod. The lever arm (4/5) is attached to the housing. The support structure (6) is shown with the lever arm (4/5) and the washer (3) positioned for assembly. The small cylindrical component (7) is also shown in its assembly position.

pulsar 135LS

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor. The components are numbered 1 through 14:

- 1**: A large cylindrical housing or motor body.
- 2**: A small circular cap or seal.
- 3**: A small gear or pinion.
- 4**: A small screw or bolt.
- 5**: A small cylindrical component, possibly a bush or spacer.
- 6**: A rectangular base plate or mounting bracket.
- 7**: A small screw or bolt.
- 8**: A small circular component, possibly a seal or gasket.
- 9**: A small rectangular plate or bracket.
- 10**: A large screw or bolt.
- 11**: A small screw or bolt.
- 12**: A small circular component, possibly a seal or gasket.
- 13**: A small O-ring or seal.
- 14**: A long, curved, textured component, possibly a belt or chain.

The diagram shows the relative positions and assembly sequence of these parts. For example, the belt (14) is shown looping around a pulley (3) and a guide (6). The housing (1) is shown with the cap (2) and seal (8) being attached. The base plate (6) is shown with the mounting bracket (9) and screws (7, 11) being attached.

pulsar 135LS

This diagram illustrates the assembly of a piston and connecting rod. The components are labeled as follows:

- 1**: Piston crown and rings
- 2**: Piston pin
- 3**: Piston rings (shown in a separate view)
- 4**: Piston pin clip
- 5**: Connecting rod
- 6**: Piston pin clip
- 7**: Piston pin clip
- 8**: Piston pin clip

pulsar 135LS

This exploded view diagram illustrates the assembly of a mechanical component. The parts are numbered as follows:

- 1**: Hex nut
- 2A**: Washer
- 3**: Washer
- 4**: Main shaft assembly with a large gear and a smaller gear on the opposite side
- 5**: Washer
- 6**: Washer
- 7**: Bracket or housing component
- 8**: Small gear or pinion
- 9**: Pin or screw
- 10**: Lever or arm component
- 11**: Washer
- 12**: Large gear or pinion

The diagram shows the relative positions and assembly sequence of these parts. Dashed lines indicate the alignment and fit of the components. For example, part 1 is shown being threaded onto part 2A, which fits onto part 4. Part 11 is shown fitting onto part 4. Part 6 is shown fitting onto part 11. Part 8 is shown fitting onto part 4. Part 9 is shown fitting onto part 10. Part 12 is shown fitting onto part 7. Part 5 is shown fitting onto part 4. Part 3 is shown fitting onto part 4. Part 10 is shown fitting onto part 8.

pulsar 135LS

FIGURA N° 7 : TRANSMISIÓN (1/2)





FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JD551000	Eje Caja (Sin orificio de Lubricacion)	1	
	JZ551006	Eje Caja (Con orificio de Lubricacion)	1	Desde Abril-11
2	JD551207	Piñón Caja 4a. (4mm. de Grosor en el Pin)	1	
	JZ551202	Piñón Caja 4a. (3mm. de Grosor en el Pin)	1	Desde Abril-11
3	39098717	Pin Eje Caja	5	
4	JA551002	Arandela Caja	4	
5	JD551206	Piñón Caja 3a.(28mm. de Espesor- 21T)	1	
	JZ551201	Piñón Caja 3a.(29mm. de Espesor-21T)	1	Desde Abril-11
	JE551201	Piñón Caja 3a.(29mm. de Espesor-18T)	1	
6	JD551205	Piñón Caja 5a. (Altura del Buje 2mm.)	1	
	JZ551213	Piñón Caja 5a. (Altura del Buje 0.05mm.)	1	Desde Abril-11
7	JD551201	Piñón Caja 2a. (Espesor 9.4mm.)	1	
	JZ551200	Piñón Caja 2a. (Espesor 10.3mm.)	1	Desde Abril-11
8	JA551004	Arandela Caja	1	
9	JD551002	Eje de Salida (Punta de 12mm. de Diametro)	1	
	JZ551008	Eje de Salida (Punta de 13mm. de Diametro)	1	Desde Abril-11
10	JD551208	Buje Piñón (Requiere la JD551209)	1	
	JZ551210	Buje Piñón (No Requiere la JD551209)	1	
11	JD551202	Piñón Caja 2a.	1	
	JZ551206		1	Desde Abril-11
12	JD551203	Piñón Caja 5a. (24mm. de Altura)	1	
	JZ551211	Piñón Caja 5a. (22.7mm. de Altura)	1	Desde Abril-11
13	JD551204	Piñón Caja 3a.(Perforaciones Pasantes - 28T)	1	
	JZ551212	Piñón Caja 3a. 28 Dientes	1	Desde Abril-11
	JE551206	Piñón Caja 3a. 24 Dientes	1	
14	JD551200	Piñón Caja 4a.	1	
	JZ551208		1	Desde Abril-11

This exploded view diagram illustrates the assembly of a mechanical system, likely a gearbox or a drive mechanism. The components are numbered 1 through 23. The assembly is organized into three main horizontal sections. The top section features a long shaft (1) with a series of gears (2, 3, 4, 5, 6, 7, 8) mounted on it. The middle section shows a similar arrangement with a shaft (9) and gears (10, 11, 12, 13, 14, 15, 16, 17, 18). The bottom section, enclosed in a dashed box, shows a smaller assembly with a shaft (19) and gears (20, 21, 22, 23). The exploded view shows the relative positions and assembly sequence of the parts, with dashed lines indicating the alignment of the shafts and gears.

pulsar 135LS

FIGURA N° 8 : SELECTOR DE CAMBIOS

[illegible]

This exploded view diagram illustrates the assembly of a mechanical component, likely a bracket or lever. The components are numbered 1 through 19. The central part of the diagram shows a dashed outline of the main body, which has several circular openings. To the right, a long, thin arm (1) is shown with a hook-like end (2) and a small pin (3). Below the main body, a series of components (4, 5, 6, 7, 8) form a linkage or pivot mechanism. On the left, a coiled spring (16) is attached to a bracket (11), which is secured by a bolt (13) and a nut (12). Other components include a pin (14), a bracket (10), a pin (15), a clip (18), and a bolt (19). The diagram uses dashed lines to indicate the relative positions and assembly sequence of the parts.

pulsar 135LS

This diagram shows an exploded view of a mechanical component, likely a cylinder head or a similar engine part. The main component is labeled 2. Various fasteners and seals are shown being installed into it, with dashed lines indicating their positions:

- Part 10: Two long screws for the top edge.
- Part 11: A small pin or screw near the top center.
- Part 9: A long, dark, cylindrical seal or plug on the right side.
- Part 8: A small bracket or clip on the right side.
- Part 5: A small circular seal or plug below part 8.
- Part 12: A small screw or pin below part 5.
- Part 14: A small screw or pin below part 12.
- Part 13: A small bracket or clip on the bottom right.
- Part 7: A circular seal or plug on the left side.
- Part 6: A small screw or pin above part 7.
- Part 4: A circular seal or plug at the bottom center.

pulsar 135LS

This exploded view diagram illustrates the assembly of a motorcycle engine. The central component is the engine block (1). Surrounding it are various parts including: a timing cover (8), a timing chain (17), a timing chain sprocket (13), a timing chain tensioner (14), a timing chain guide (15), a timing chain cover (10), a timing chain cover gasket (9), a timing chain cover bolt (11), a timing chain cover nut (12), a timing chain cover washer (16), a timing chain cover seal (7), a timing chain cover O-ring (4), a timing chain cover gasket (5), a timing chain cover gasket (6), a timing chain cover gasket (18), a timing chain cover gasket (19), a timing chain cover gasket (20), a timing chain cover gasket (21), a timing chain cover gasket (22), a timing chain cover gasket (23), a timing chain cover gasket (24), a timing chain cover gasket (25), a timing chain cover gasket (26), a timing chain cover gasket (27), a timing chain cover gasket (28), a timing chain cover gasket (29), a timing chain cover gasket (30), a timing chain cover gasket (31), a timing chain cover gasket (32), a timing chain cover gasket (33), a timing chain cover gasket (34), a timing chain cover gasket (35), a timing chain cover gasket (36), a timing chain cover gasket (37), a timing chain cover gasket (38), a timing chain cover gasket (39), a timing chain cover gasket (40), a timing chain cover gasket (41), a timing chain cover gasket (42), a timing chain cover gasket (43), a timing chain cover gasket (44), a timing chain cover gasket (45), a timing chain cover gasket (46), a timing chain cover gasket (47), a timing chain cover gasket (48), a timing chain cover gasket (49), a timing chain cover gasket (50), a timing chain cover gasket (51), a timing chain cover gasket (52), a timing chain cover gasket (53), a timing chain cover gasket (54), a timing chain cover gasket (55), a timing chain cover gasket (56), a timing chain cover gasket (57), a timing chain cover gasket (58), a timing chain cover gasket (59), a timing chain cover gasket (60), a timing chain cover gasket (61), a timing chain cover gasket (62), a timing chain cover gasket (63), a timing chain cover gasket (64), a timing chain cover gasket (65), a timing chain cover gasket (66), a timing chain cover gasket (67), a timing chain cover gasket (68), a timing chain cover gasket (69), a timing chain cover gasket (70), a timing chain cover gasket (71), a timing chain cover gasket (72), a timing chain cover gasket (73), a timing chain cover gasket (74), a timing chain cover gasket (75), a timing chain cover gasket (76), a timing chain cover gasket (77), a timing chain cover gasket (78), a timing chain cover gasket (79), a timing chain cover gasket (80), a timing chain cover gasket (81), a timing chain cover gasket (82), a timing chain cover gasket (83), a timing chain cover gasket (84), a timing chain cover gasket (85), a timing chain cover gasket (86), a timing chain cover gasket (87), a timing chain cover gasket (88), a timing chain cover gasket (89), a timing chain cover gasket (90), a timing chain cover gasket (91), a timing chain cover gasket (92), a timing chain cover gasket (93), a timing chain cover gasket (94), a timing chain cover gasket (95), a timing chain cover gasket (96), a timing chain cover gasket (97), a timing chain cover gasket (98), a timing chain cover gasket (99), a timing chain cover gasket (100).

pulsar 135LS

FIGURA N° 12 : CUBIERTA CLUTCH




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	36JZ0013	Tapa Clutch	1	Negra
	36JD0010		1	Gris Tornado
2	JE541211	Calcomanía Tapa Clutch	1	
3	39104119	Retén Eje Leva Clutch (12-20-5.5)	1	
4	30101142	Retén Eje Crank (16-26-7)	1	
5	JV541208	Leva Interna Clutch	1	
6	JE551401	Empujador Clutch	1	
7	DG101418	Visor Nivel Aceite	1	
8	DS101215	Pin Seguridad	1	
9	JA541236	Arandela	1	Alt. 39244311
10	JA541237	Resorte Leva Interna Clutch	1	Alt. DS101123
11	JA541211	Tapon Aceite	1	
12	JA541225	Retén	1	
13	JE541209	Antivibrante Carcasa Clutch	1	
14	JA541216	Platina Antivibrante	1	
15	LAD00018	Tornillo	3	
16	JA541212	Empaque Carcasa Clutch	1	
	36JA0022	Kit Empaques	1	Ref. Pág. N° 63
17	59040038	Tornillo	8	
18	JW541000	Platina Guía Clutch	1	
19	DD121181	Filtro Aceite	1	
20	39167121	Retén	1	
21	JZ541214	Tapa Filtro Aceite	1	Negra
	JE541218		1	Gris Tornado
22	39167304	Tornillo	3	
23	14151033	Rodamiento Bolas Clutch	1	
24	39099906	Pin Guía Carcasa	2	
25	JB541201	Boqueres de Lubricación	1	

This exploded view diagram illustrates the assembly of a DTS-1 engine. The components are numbered as follows:

- 1**: The main engine block, featuring a central circular cover with the "DTS-1" logo.
- 2**: A screw used to secure the top cover of the engine block.
- 3**: A gasket or seal ring that fits around the perimeter of the engine block.
- 4**: A screw used to secure the side cover of the engine block.
- 5**: The side cover of the engine block.
- 6**: A circular component, likely a filter or a part of the intake system, shown in a shaded perspective view.
- 7**: A screw used to secure the circular component (6) to the main engine block.
- 8**: A circular component, likely a filter or a part of the intake system, shown in a line drawing view.
- 9**: A small cylindrical component, possibly a pin or a small bush.
- 10**: A small circular component, possibly a washer or a small gasket.
- 11**: A small ring or O-ring component.
- 12**: A small cylindrical component, possibly a pin or a small bush.
- 13**: A small rectangular component, possibly a pin or a small bush.

Dashed lines indicate the assembly sequence and the relative positions of the components.

pulsar 135LS

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor. The components are numbered 1 through 19. The diagram is organized into several dashed-line boxes to show the assembly sequence and sub-assemblies. At the top, a large dashed box labeled 18 contains the main housing assembly, which includes a large gear (1), a shaft (2), a bearing (3), and a flange (4). To the right, a smaller dashed box shows a sub-assembly consisting of a gear (8), a shaft (9), a bearing (10), and a flange (11). Below the main housing, a dashed box shows a series of components (5, 6, 7, 17) that form a seal or gasket. At the bottom, a dashed box shows a sub-assembly consisting of a gear (12), a shaft (13), a bearing (14), and a flange (15). The final assembly is shown at the bottom right, where the main housing (18) is joined to the sub-assembly (16) via a large bolt (19).

pulsar 135LS

This diagram illustrates the exploded view of a mechanical assembly, with components numbered 1 through 14. The assembly is shown in a disassembled state to identify individual parts and their relative positions.

- Part 1:** The main housing or frame, shown as a dashed outline.
- Part 2:** A small pin or screw used for fastening.
- Part 3:** A small component, possibly a bush or spacer, located near the base of the assembly.
- Part 4:** A small component, possibly a bush or spacer, located near the base of the assembly.
- Part 5:** A small ring or washer, shown in multiple locations (top left, middle left, and middle right).
- Part 6:** A small ring or washer, shown in multiple locations (middle right and top right).
- Part 7:** A long, cylindrical component with a threaded end, possibly a shaft or a long screw.
- Part 8:** A small ring or washer, shown in multiple locations (middle right and top right).
- Part 9:** A gear or sprocket component with a central hub.
- Part 10:** A gear or sprocket component with a central hub, shown in multiple locations (middle left and middle right).
- Part 11:** A small ring or washer, shown in multiple locations (top right and middle right).
- Part 12:** A small ring or washer, shown in multiple locations (middle left and middle right).
- Part 13:** A long, cylindrical component with a threaded end, possibly a shaft or a long screw.
- Part 14:** A coiled spring or wire, located at the bottom left of the assembly.

pulsar 135LS

This diagram illustrates the exploded view of a carburetor assembly, showing the following components and their assembly sequence:

- 1**: Main carburetor body.
- 2**: Jet needle assembly (needle and jet).
- 3**: Jet needle guide (needle holder).
- 4**: Jet needle guide pin.
- 5**: Jet needle guide pin O-ring.
- 6**: Jet needle guide housing.
- 7**: Jet needle guide housing pin.
- 8**: Jet needle guide O-ring.
- 9**: Jet needle guide assembly (needle, guide, and pin).
- 10**: Jet needle guide housing cap.
- 11**: Jet needle guide housing cap O-ring.
- 12**: Jet needle guide housing cap housing.
- 13**: Jet needle guide housing cap housing pin.
- 14**: Jet needle guide housing cap housing O-ring.
- 15**: Jet needle guide housing cap housing pin.
- 16**: Jet needle guide housing cap housing O-ring.
- 17**: Jet needle guide housing cap housing O-ring.
- 18**: Jet needle guide housing cap housing O-ring.
- 19**: Jet needle guide housing cap housing O-ring.

pulsar 135LS

pulsar 135LS

This diagram illustrates the exploded view of a car door latch assembly. The components are numbered as follows:

- 1**: The main door latch body.
- 2**: A circular component, likely a lock cylinder or keyhole cover, shown being aligned with the latch body.
- 3**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 4**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 5**: Three screws used to secure the latch body to the door panel.
- 6**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 7**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 8**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 9**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 10**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 11**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 12**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 13**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.
- 14**: A small circular component, possibly a pin or washer, shown being inserted into the latch body.

pulsar 135LS

This diagram illustrates the assembly of a mechanical component, likely a pump or valve. The components are numbered as follows:

- 1**: The main housing or body of the assembly.
- 2**: A circular flange or cover plate that fits onto the front of the housing.
- 3**: Two screws used to secure the flange (2) to the housing (1).
- 4**: A small cylindrical pin or plug that fits into the housing.
- 5**: A circular component with a serrated or gear-like outer edge, which is mounted on the front of the housing.

The diagram shows the housing (1) with a central opening. The flange (2) is shown being placed over this opening. The screws (3) are shown being inserted into the flange to tighten it against the housing. The pin (4) is shown being inserted into a hole in the housing. The serrated component (5) is shown being mounted on the front of the housing.

pulsar 135LS

FIGURA N° 20 : MOTOR DE ARRANQUE




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JA621414	Clutch de una Vía	1	
2	DH101781	Platina	1	
3	JA621410	Piñón Arranque	1	
4	JA621402	Arandela Piñón Arranque	2	
5	JA621406	Piñón Bendix	1	
6	36JW0014	Kit Reparación Motor Arranque	1	Ref. Pág. N° 64
7	JA351600	Arranque Electrico	1	
8	JA351613	Anillo Retenedor	1	
9	JA351606	Anillo Retenedor	2	
10	JA521019	Tornillo	2	
11	JA351602	Anillo Retenedor	1	Marca F
	JA351627		1	Marca L-T
12	JA351608	Porta Escobilla Positiva	1	
13	JA351609	Porta Escobilla Negativa	1	Marca F
	JA351618		1	Marca L-T
14	JA351624	Resorte Escobillas	1	No Ilustrado
15	JA351619	Terminal	1	
16	JA351605	Carcasa Motor Arranque	1	
17	JA351601	Tapa Delantera Motor Arranque	1	Marca F
	JA351616		1	Marca T
18	JA351607	Inducido	1	
19	JA351611	Tapa Trasera Motor Arranque	1	
20	JA351612	Anillo Retén	1	

This exploded view diagram illustrates the components of a 12V 100W LED light assembly. The parts are numbered as follows:

- 1**: LED light housing
- 2**: LED light module
- 3**: Mounting screw
- 4**: Mounting screw
- 5**: Electrical connector
- 6**: Electrical connector
- 7**: LED light module
- 8**: Spark plug
- 9**: Mounting bracket
- 10A**: Mounting bracket
- 10B**: Mounting bracket
- 11**: Mounting bracket
- 12**: Mounting screw
- 13**: LED light module
- 14**: Mounting screw
- 16**: Mounting bracket

pulsar 135LS

FIGURA N° 22 : SILLÍN




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JD191000	Sillín Del. (Platina Horizontal)	1	Hasta Sep. 2011
	JD191012	Sillín Del. (Platina Vertical)	1	Desde Oct. 2011
2	DS211005	Antivibrante Sillín	6	
3	JD191003	Sillín Trasero	1	
4	DK211008	Seguro Sillín	1	
5	39190204	Tornillo	2	
6	DK211007	Antivibrante Sillín	1	
7	JD191006	Antivibrante Sillín	2	
8	JD191007	Antivibrante Sillín	1	
	DJ181064		1	Para JD191012
9	JD191008	Buje	1	
	DJ181029		1	Para JD191012
10	DJ181077	Tornillo	1	Para JD191000
	KADA0618		1	Para JD191012
11	JD113807	Platina	1	Para JD191012
12	40359E	Forro de Sillín Delantero	1	
	59942E		1	Edición Pulsarmania
	5723		1	Edición Pulsar GP
	5747		1	Edición Pulsar Racing
	5802		1	Desde 2014
13	40360E	Forro de Sillín Trasero	1	
	59945E		1	Edición Pulsarmania
	5724		1	Edición Pulsar GP
	5748		1	Edición Pulsar Racing
	5803		1	Desde 2014

pulsar 135LS

[illegible]

pulsar 135LS

This exploded view diagram illustrates the assembly of a bicycle seat. The main components are labeled as follows:

- 1**: The main seat body, which is a large, curved plastic shell.
- 2**: The rear support structure, a smaller curved piece that fits behind the main seat body.
- 3**: The seat post, a long, tapered tube that passes through the seat body.
- 4**: The seat post clamp, a cylindrical component that secures the seat post within the seat body.
- 5**: The seat base, a rectangular plate that the seat body sits on.
- 6**: The seat post clamp bolt, which passes through the clamp and the seat post to tighten it.
- 7**: The seat post clamp nut, which threads onto the clamp bolt.
- 8**: The seat post clamp cap, a small plastic cover for the clamp.
- 9**: The seat post clamp cap, a small plastic cover for the clamp.
- 10**: The seat post clamp cap, a small plastic cover for the clamp.
- 11**: The seat post clamp cap, a small plastic cover for the clamp.
- 12**: The seat post clamp cap, a small plastic cover for the clamp.
- 13**: The seat post clamp cap, a small plastic cover for the clamp.

The diagram shows the following assembly steps:

- Insert the seat post (3) into the seat body (1) and the seat base (5).
- Attach the rear support structure (2) to the main seat body (1).
- Slide the seat post clamp (4) onto the seat post (3).
- Insert the seat post clamp bolt (6) through the clamp (4) and the seat post (3).
- Thread the seat post clamp nut (7) onto the bolt (6).
- Attach the seat post clamp cap (8) to the clamp (4).
- Attach the seat post clamp cap (9) to the clamp (4).
- Attach the seat post clamp cap (10) to the clamp (4).
- Attach the seat post clamp cap (11) to the clamp (4).
- Attach the seat post clamp cap (12) to the clamp (4).
- Attach the seat post clamp cap (13) to the clamp (4).

pulsar 135LS

This exploded view diagram illustrates the assembly of a rear window trim. The main component is the trim piece (10), which is shown with various mounting points. The assembly includes:

- 1**: A small bracket or clip that fits into the top of the trim.
- 2**: A small cylindrical cap or plug.
- 3**: A small cylindrical cap or plug.
- 4**: A small cylindrical cap or plug.
- 5**: A small screw or bolt used for securing the trim.
- 6**: A small screw or bolt used for securing the trim.
- 7**: A small screw or bolt used for securing the trim.
- 8**: A small screw or bolt used for securing the trim.
- 9**: A small bracket or clip that fits into the top of the trim.
- 11**: A small screw or bolt used for securing the trim.
- 12**: A small screw or bolt used for securing the trim.

Dashed lines indicate the alignment and assembly path for each component.

pulsar 135LS

This diagram illustrates the exploded view of a mechanical assembly, likely a vehicle's rear suspension or steering component. The parts are numbered 1 through 14:

- 1**: A small rectangular component with a grid pattern, possibly a sensor or a control unit.
- 2**: A long, thin cylindrical rod or pin.
- 3**: A small pin or screw.
- 4**: A coiled spring with hooks at both ends.
- 5**: A short, thick cylindrical component.
- 6**: A long, curved metal arm or lever.
- 7**: A bracket or support structure.
- 8**: A small bolt or screw.
- 9**: A hexagonal nut.
- 10**: A circular washer or spacer.
- 11**: A short, thick cylindrical component, similar to part 5.
- 12**: A complex metal bracket or housing.
- 13**: A small pin or screw.
- 14**: A small bolt or screw.

Dashed lines indicate the assembly sequence and the relative positions of the components. For example, part 2 is shown passing through part 1, and part 10 is shown being inserted into part 6. Part 8 is shown being inserted into part 6, and part 9 is shown being inserted into part 8. Part 12 is shown being attached to part 6 using part 13 and part 14.

pulsar 135LS

This diagram illustrates the components of a wheel assembly in an exploded view. The parts are numbered as follows:

- 1**: The complete wheel assembly, including the rim, spokes, and hub.
- 2**: A cross-section of a tire.
- 3**: A cross-section of a rim seal or gasket.
- 4**: Another view of the complete wheel assembly, showing the hub and spokes.
- 5**: Another cross-section of a tire.
- 6**: Another cross-section of a rim seal or gasket.

pulsar 135LS

This exploded view diagram illustrates the assembly of a bicycle wheel. The central component is the wheel rim (13). To its left, the hub assembly is shown, including the hub body (7), a spacer (8), a lockring (6), a lockring lock (5), a lockring lock washer (4), and a lockring lock nut (2). To the right of the rim, the brake disc (12) is shown, which is secured by a bolt (11). Below the rim, the axle assembly is depicted, consisting of the axle (16), a lockring (15), a lockring lock washer (14), and a lockring lock nut (17). A small set of screws (10) and a bracket (9) are also shown. The diagram uses dashed lines to indicate the assembly sequence and alignment of the components.

pulsar 135LS

This exploded view diagram illustrates the assembly of a mechanical component, likely a valve or actuator. The parts are numbered as follows:

- 1**: Main rectangular body with internal components like a spring and pins.
- 2**: A long, curved flexible hose or cable.
- 3**: A curved metal arm or lever.
- 4**: Small cylindrical connectors or fittings.
- 5**: O-rings or seals.
- 6**: A small mechanical bracket or connector.
- 7**: Small pins or screws.
- 8**: A small pin or screw.
- 9**: A small cylindrical component.
- 10**: Small screws or fasteners.
- 11**: A rectangular component, possibly a solenoid or coil.
- 12**: A small electrical connector or plug.
- 13**: A rectangular plate or cover.
- 14**: A rectangular frame or housing.
- 15**: A small cylindrical component.
- 16**: A small electrical wire.

The diagram shows the spatial relationship between these parts, with dashed lines indicating the assembly path. A callout labeled **11A** points to the area around part 11.

pulsar 135LS

The diagram illustrates the assembly of a motorcycle brake master cylinder. The main exploded view shows the following components:

- 1**: Master cylinder body
- 2**: Pin
- 3**: Brake shoe
- 4**: Bleeding screw
- 5**: Bleeding screw cap
- 6**: Piston
- 7**: Seal
- 8**: Dust cap
- 9**: Retainer
- 10**: Piston
- 11**: Piston

A detailed inset shows the master cylinder body with the following components labeled:

- 9**: Retenedor
- 10**: Sello de Pistón
- 5**: Capuchón Tornillo de Sangrado
- 8**: Guardapolvo
- 7**: Aislante
- 11**: Pistón

Additional components shown at the bottom are:

- 4**: Tornillo de Sangrado
- 3**: Resorte Pasta Freno

pulsar 135LS

FIGURA N° 33 : RUEDA TRASERA (1/2)




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JD141003	Empate Cadena	1	Con O'ring
	DX151081	Empate Cadena (Sin O'ring)	1	Opcional
2	36JE0007	Kit Sprocket y Cadena (Sin O'ring)	1	Ref. Pág. N° 64
3	39080115	Tuerca Porta Sprocket	1	
4	LDB00001	Arandela	1	
5	DJ151035	Buje Porta Sprocket	1	Para DJ151033
5A	JD131210		1	Para JD131212
6	39224020	Rodamiento Bolas Porta Sprocket	1	
7	JN131203	Porta Sprocket	1	
8	DS151073	Tornillo Sprocket	4	
9	39079415	Tuerca 10 mm.	4	
10	DS151074	Arandela	2	
11	DJ151033	Buje Porta Sprocket	1	Largo
11A	JD131212		1	Corto
12	39268620	Rodamiento Bolas Rin Trasero	1	
13	30151075	Buje Rueda Trasera	1	
14	DJ151088	Antivibrante Rueda Trasera	1	Alt. JG131219
15	39268720	Rodamiento Bolas Rin Trasero	1	
16	30151069	Resorte Banda Freno	2	
17	30151068	Banda Freno Trasero	2	Asbesto
	JN131812		2	No Asbesto
18	DJ151092	Plato Porta Banda Trasero	1	
19	30151011	Leva Porta Banda Freno	1	
19A	39072211	Retén	1	
20	30151038	Retén	1	

This exploded view diagram illustrates the assembly of a bicycle wheel. The components are numbered as follows:

- 1:** A set of three small, curved metal pieces, likely for the fender.
- 2:** A long, thin metal rod, possibly a fender stay.
- 3:** A small metal nut or washer.
- 4:** A small metal ring or washer.
- 5:** A small metal ring or washer.
- 6:** A small metal ring or washer.
- 7:** A large, circular metal flange or hub component.
- 8:** A small metal pin or clip.
- 9:** A small metal pin or clip.
- 10:** A small metal pin or clip.
- 11:** A small metal pin or clip.
- 11A:** A small metal pin or clip.
- 12:** A small metal ring or washer.
- 13:** A small metal pin or clip.
- 14:** A small metal pin or clip.
- 15:** A small metal ring or washer.
- 16:** Two small metal pins or clips.
- 17:** A large, curved metal bracket or fender stay.
- 18:** A large, circular metal flange or hub component.
- 19:** A small metal pin or clip.
- 19A:** A small metal pin or clip.
- 20:** A small metal pin or clip.
- 21:** A small metal pin or clip.
- 22:** A small metal pin or clip.
- 23:** A small metal pin or clip.
- 24:** A long, thin metal rod.
- 25:** A small metal pin or clip.
- 26:** A small metal pin or clip.
- 27:** A small metal pin or clip.
- 28:** A long, thin metal rod.
- 29:** A large, circular metal flange or hub component.

pulsar 135LS

pulsar 135LS

FIGURA N° 35 : MANUBRIO (1/2)




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JD151015	Cabeza Horquilla	1	Gris
	JD151054		1	Negra
2	JD151017	Soporte Manubrio Derecho	1	Gris
	JD151052		1	Negro
3	JD151016	Soporte Manubrio Izquierdo	1	Gris
	JD151051		1	Negro
4	DG181008	Tornillo	4	
5	JF401400	Comando Izquierdo	1	
6	JF401401	Comando Luces Derecho	1	
7	DJ191054	Soporte Leva Clutch	1	
	DJ191081		1	Tipo Diodo Transistor
8	DJ191055	Leva Clutch	1	
	DJ191083		1	Tipo Diodo Transistor
9	DL191014	Tornillo Leva	1	
10	30191017	Arandela Comando Izquierdo	1	
11	DD191147	Kit Tornillo Ajuste Cable	1	
12	DH191007	Manillar Izquierdo	1	
13	DH191014	Carretel Acelerador	1	
14	DS191052	Guardapolvo	1	
15	DH181022	Buje Manubrio	2	
16	39242704	Tornillo	2	
17	DS191018	Guardapolvo	1	
18	JB401402	Swiche Encendido	1	
19	39194304	Tornillo	2	
20	DK181031	Buje Manubrio	2	

This exploded view diagram illustrates the assembly of a bicycle headlight. The components are numbered as follows:

- 1**: Headlight housing (main body)
- 2**: Mounting bracket
- 3**: Mounting bracket (lower part)
- 4**: Screw
- 5**: Mounting bracket (upper part)
- 6**: Screw
- 7**: Screw
- 8**: Mounting bracket (lower part)
- 9**: Screw
- 10**: Mounting bracket (lower part)
- 11**: Mounting bracket (lower part)
- 12**: Mounting bracket (lower part)
- 13**: Mounting bracket (lower part)
- 14**: Mounting bracket (lower part)
- 15**: Mounting bracket (lower part)
- 16**: Mounting bracket (lower part)
- 17**: Mounting bracket (lower part)
- 18**: Mounting bracket (lower part)
- 19**: Mounting bracket (lower part)
- 20**: Mounting bracket (lower part)
- 21**: Mounting bracket (lower part)
- 22**: Mounting bracket (lower part)
- 23**: Mounting bracket (lower part)
- 24**: Mounting bracket (lower part)
- 25**: Mounting bracket (lower part)
- 26**: Mounting bracket (lower part)
- 27**: Mounting bracket (lower part)
- 28**: Mounting bracket (lower part)
- 29**: Mounting bracket (lower part)
- 30**: Mounting bracket (lower part)
- 31**: Mounting bracket (lower part)
- 32**: Mounting bracket (lower part)
- 33**: Mounting bracket (lower part)

pulsar 135LS

FIGURA N° 36 : SUSPENSIÓN DELANTERA





FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JD151000	Suspensión Delantera	1	
2	36DZ0020	Kit Retenes Tubo Telescópico	1	Ref. Pág. N° 63
3	30181026	Arandela Sellado	2	
4	30181025	Tornillo Camisa Telescópico	2	
5	JD151026	Tubo Telescópico	2	
6	DJ181104	Resorte Tubo Telescópico	2	
7	59040007	Tornillo Tubo Telescópico	2	
8	DS181015	Tapón Horquilla	1	
9	DS181016	Arandela	1	
10	36314001	Kit Cunas Dirección	1	Ref. Pág. N° 63
11	JD151029	Espiga Central	1	
12	39118101	Tornillo	2	
13	DM181010	Arandela	2	
14	JD151003	Camisa Tubo Telescópico Izq.	1	
15	JD151004	Camisa Tubo Telescópico Der.	1	
16	JK121007	Buje Guía	2	
17	JD121002	Tubo Interno Horquilla	2	
18	JK121009	Arandela	2	
19	JD151028	Tuerca Tubo Telescópico	2	
20	30181029	Retén	2	
21	JD151015	Cabeza Horquilla	1	Gris
	JD151054		1	Negra
22	39194304	Tornillo	1	
23	JD151006	Soporte Farola	1	
24	DJ181064	Antivibrante	1	No Ilustrado
25	DJ181029	Buje Soporte Carenaje	4	No Ilustrado
26	DJ181052	Arandela Espiga	4	
27	DJ181085	Caucho Espiga	4	

FIGURA N° 37 : TANQUE DE GASOLINA/ GUARDABARRO/ TAPAS LATERALES (1/2)



pulsar
135LS

FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JD710123	Tanque Gasolina	1	Sin Pintar
2	52JD0033	Tapa Lateral Izquierda	1	Sin Pintar
3	52JD0034	Tapa Lateral Derecha	1	Sin Pintar
4	JD181203	Cubierta Sillin	1	Sin Pintar
5	52JD0032	Guardabarro Delantero	1	Sin Pintar
6	52JD0067	Visor Carenaje	1	Sin Pintar
7	JD181208	Carenaje Izquierdo	1	Sin Pintar
8	JD181209	Carenaje Derecho	1	Sin Pintar
9	JD181226	Tapa Lateral Superior Derecha	1	
10	JD181224	Tapa Lateral Superior Izquierda	1	
11	52JD0035	Enfocador Central	1	
12	JD233012	Calcomania "pulsar"	2	
13	JD233014	Calcomania "135ls"	2	Negro/roja
	JD233002	Calcomania "135ls"	2	Negra
	JD233003	Calcomania "135ls"	2	Roja
14	JD233016	Calcomania Izquierda "4 Valve"	1	Negra
	JD233018	Calcomania Izquierda "4 Valve"	1	Roja
15	JD233017	Calcomania Derecha "4 Valve"	1	Negra
	JD233019	Calcomania Derecha "4 Valve"	1	Roja
16	JW171014	Antivibrante	3	
17	JW171015	Buje	3	
18	JD171016	Tornillo	1	
19	JW171007	Antivibrante	4	
20	JD171018	Antivibrante	8	

FIGURA N° 37 : TANQUE DE GASOLINA/ GUARDABARRO/ TAPAS LATERALES (2/2)


[illegible]

FIGURA N° 37A : CALCOMANÍAS DUOTONO (1/2)




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	36JD0015	Kit Calcomanías Tanque Gasolina	1	Negro-Rojo
	36JD0020		1	Negro-Azul
2	3960/00	Calcomanía Sup. Tanque Izquierda	1	Negro-Verde
	3974/00		1	Negro-Blanco
3	3961/00	Calcomanía Sup. Tanque Derecha	1	Negro-Verde
	3975/00		1	Negro-Blanco
4	3962/00	Calcomanía Inf. Tanque Izquierda	1	Negro-Verde
	3976/00		1	Negro-Blanco
5	3963/00	Calcomanía Inf. Tanque Derecha	1	Negro-Verde
	3977/00		1	Negro-Blanco
6	36JD0012	Kit Calcomanías Enfocador	1	Negro-Rojo
	36JD0017		1	Negro-Azul
7	3954/00	Calcomanía Sup. Enfocador Izquierda	1	Negro-Verde
	3968/00		1	Negro-Blanco
8	3955/00	Calcomanía Sup. Enfocador Derecha	1	Negro-Verde
	3969/00		1	Negro-Blanco
9	3958/00	Calcomanía Inf. Enfocador Izquierda	1	Negro-Verde
	3972/00			Negro-Blanco
10	3959/00	Calcomanía Inf. Enfocador Derecha	1	Negro-Verde
	3973/00			Negro-Blanco
11	36JD0014	Kit Calcomanías Cubierta Sillín	1	Negro-Rojo
	36JD0018		1	Negro-Azul
12	3966/00	Calcomanía Cubierta Sillín Izquierda	1	Negro-Verde
	3980/00		1	Negro-Blanco
13	3967/00	Calcomanía Cubierta Sillín Derecha	1	Negro-Verde
	3981/00		1	Negro-Blanco

pulsar 135LS

[illegible]

FIGURA N° 38 : CALCOMANÍAS PULSARMANIA (2013)




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	4318/00	Calcomania Rin	8	Verde
	4319/00		8	Azul
	6635/00		8	Amarilla
2	4335/00	Cal.cola Superior "135 Ls"	2	
3	4336/00	Cal.cola Inferior Derecha	1	Gris
4	4337/00	Cal.cola Inferior Izquierda	1	Gris
5	4338/00	Cal. Tanque Derecha	1	Gris
6	4339/00	Cal. Tanque Izquierda	1	Gris
7	4340/00	Cal. Carenaje Farola Sup. Derecha	1	Verde
7A	4342/00		1	Azul
8	4341/00	Cal. Carenaje Farola Sup. Izquierda	1	Verde
8A	4343/00		1	Azul
9	4344/00	Cal. Carenaje Farola Inf. Derecha	1	Gris
10	4345/00	Cal. Carenaje Farola Inf. Izquierda	1	Gris
11	4346/00	Cal. Enfocador Tanq. Sup. Derecha	1	Gris
12	4347/00	Cal. Enfocador Tanq. Sup. Izquierda	1	Gris
13	4348/00	Cal. Enfocador Tanq. Inf. Derecha	1	Verde
13A	4350/00		1	Azul
14	4349/00	Cal. Enfocador Tanq. Inf. Izquierda	1	Verde
14A	4351/00		1	Azul
15	KIT-433650/00	Kit Calcomanias Gris - Azul	1	Items: 3, 4, 5, 6, 7A, 8A
				9, 10, 11, 12, 13A, 14A
16	KIT-434041/00	Kit Calcomanias Gris - Verde	1	Items: 3, 4, 5, 6, 7, 8,
				9, 10, 11, 12, 13, 14

FIGURA N° 38A : CALCOMANÍAS Y ACCESORIOS PULSARMANIA (2016)


[illegible]

FIGURA N° 39 : CALCOMANÍAS PULSAR GP




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	4335/00	Calcomanía Cola "135 LS"	2	Blanca
2	4383/00	Cal. Tanque Derecha	1	Rojo
2A	4393/00		1	Naranja
2B	4403/00		1	Azul
3	4384/00	Cal. Tanque Izquierda	1	Rojo
3A	4394/00		1	Naranja
3B	4404/00		1	Azul
4	4385/00	Cal. Enfocador Tanque Der.	1	
5	4386/00	Cal. Enfocador Tanque Izq.	1	
6	4387/00	Cal. " Pulsar GP" Derecha	1	
7	4388/00	Cal. " Pulsar GP" Izquierda	1	
8	4389/00	Cal. Guardabarro Derecha	1	
9	4390/00	Cal. Guardabarro Izquierda	1	
10	4391/00	Cal. Cola Derecha	1	
11	4392/00	Cal. Cola Izquierda	1	
12	4414/00	Protector Tanque	1	
13	4413/00	Calcomanía Rin	8	Rojo
	4478/00		8	Naranja
	4479/00		8	Azul
14	KIT-438389/00	Kit Calcomanías	1	Items: 2, 3, 4, 5, 6, 7, 8,
				9, 10, 11
	KIT-439394/00		1	Items: 2A, 3A, 4, 5, 6,
				7, 8, 9, 10, 11

Diagram illustrating the components of a front suspension assembly, numbered 1 through 5:

- 1: Upper control arm bracket.
- 2: Lower control arm.
- 3: Ball joint.
- 4: Lower control arm end bush.
- 5: Lower control arm end plate.

pulsar 135LS

FIGURA N° 41: CALCOMANÍAS PULSAR RACING (1/2)




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	4414/00	Protector de Tanque	1	
2	JD233012	Calcomanía "Pulsar"	1	Negro-Gris
	4197/00		1	Gris (2014)
3	JD171058/00	Emblema Protector Tanque	1	
4	4335/00	Calcomanía Cola "135LS"	2	Blanca
	JD233014		2	Negra-Roja
5	4497/00	Calc. Guardabarro Del. Der.	1	Negra
5A	4537/00		1	Gris
6	4498/00	Calc. Guardabarro Del. Izq.	1	Negra
6A	4538/00		1	Gris
7	4499/00	Calc. Tapa Lateral Derecha	1	
8	4500/00	Calc. Tapa Lateral Izquierda	1	
9	4501/00	Calc. Enfocador Inf. Derecha	1	Negra
9A	4539/00		1	Gris
10	4502/00	Calc. Enfocador Inf. Izquierda	1	Negra
10A	4540/00		1	Gris
11	4503/00	Calc. Enfocador Sup. Derecha	1	Negra
11A	4541/00		1	Gris
12	4504/00	Calc. Enfocador Sup. Izquierda	1	Negra
12A	4542/00		1	Gris
13	4505/00	Calcomanía Carenaje Derecha	1	Negra
13A	4543/00		1	Gris
14	4506/00	Calcomanía Carenaje Izquierda	1	Negra
14A	4544/00		1	Gris
15	4507/00	Calcomanía Cola Derecha	1	Negra
15A	4545/00		1	Gris

1. Black engine cover with 'H' logo.

2. Pulsar logo with a stylized 'P'.

3. Grey wing with '135LS' text.

4. 135LS text.

5/5A. Grey wing with 'PULSAR' text.

6/6A. Grey wing with 'PULSAR' text.

7. Grey wing with 'PULSAR' text.

8. Grey wing with 'PULSAR' text.

9/9A. Grey wing with 'PULSAR' text.

10/10A. Grey wing with 'PULSAR' text.

11/11A. Grey wing with 'PULSAR' text.

12/12A. Grey wing with 'PULSAR' text.

13/13A. Grey wing with 'PULSAR' text.

14/14A. Grey wing with 'PULSAR' text.

15/15A. Grey wing with 'PULSAR' text.

16/16A. Grey wing with 'PULSAR' text.

17. Red curved wing.

18. Grey wing with 'PULSAR' text.

19. Grey wing with 'PULSAR' text.

20/21. Grey wing with 'PULSAR' text.

21/25. Grey wing with 'PULSAR' text.

22/26. Pulsar logo with a stylized 'P'.

pulsar 135LS

1/2

3/4

5/6

7/8

9/10

11/12

13/14

15/16

PRO

LH P135 4V

RH P135 4V

pulsar 135LS

This diagram illustrates the exploded view of a mechanical assembly, with components labeled 1 through 13. The assembly includes a main housing (1) with a central shaft (5) and a pulley (4). A cable (2) is connected to the pulley. A bracket (3) is attached to the side of the housing. A curved arm (11) is also shown. A separate component (13) is shown on the right. The diagram uses dashed lines to indicate the assembly path and alignment of the parts.

pulsar 135LS

This exploded view diagram illustrates the assembly of a bicycle seat. The components are numbered as follows:

- 1**: The main seat rail.
- 2**: A bolt for the rear seat post clamp.
- 3**: A bolt for the front seat post clamp.
- 4**: A square seat plate.
- 5**: A washer for the front seat post clamp.
- 6**: A bolt for the rear seat post clamp.
- 7**: A washer for the rear seat post clamp.
- 8**: A cap for the rear seat post clamp.
- 9**: A bracket for the rear seat post clamp.
- 10**: A bolt for the front seat post clamp.
- 11**: A washer for the front seat post clamp.
- 12**: A cap for the front seat post clamp.

The diagram shows the seat rail (1) with various clamps and plates attached. The rear clamp assembly includes a bolt (6), washer (7), cap (8), and bracket (9). The front clamp assembly includes a bolt (3), washer (5), and cap (12). The seat plate (4) is shown attached to the rail with a bolt (10) and washer (11). The diagram also shows the seat rail (1) with a bolt (2) and washer (5) attached to the rear, and a bolt (3) and washer (5) attached to the front.

pulsar 135LS

pulsar 135LS

pulsar 135LS

This diagram illustrates the assembly of a car seat, showing the seat backrest (1) and seat base (6) with various numbered components and fasteners. The components are labeled as follows:

- 1: Seat backrest
- 2: Seat base
- 3: Bolt
- 4: Washer
- 5: Bracket
- 6: Seat base
- 7: Bolt
- 8: Bracket
- 9: Bolt
- 10: Bolt
- 11: Washer
- 12: Bolt
- 13: Washer
- 14: Bolt
- 15: Washer

pulsar 135LS

This exploded view diagram illustrates the components of a car stereo system, numbered 1 through 19. The main components include:

- 1**: The main car stereo unit.
- 2**: A screw for mounting the unit to the dashboard.
- 3**: A power antenna relay.
- 4**: A fuse.
- 5**: A fuse holder.
- 6**: The wiring harness connecting the stereo to the vehicle's electrical system.
- 7**: A trim plate for the stereo unit.
- 8**: A screw for the trim plate.
- 9**: A mounting bracket.
- 10**: A screw for the mounting bracket.
- 11**: A screw for the mounting bracket.
- 12**: A screw for the mounting bracket.
- 13**: A screw for the mounting bracket.
- 14**: A mounting bracket.
- 15**: A mounting bracket.
- 16**: A screw for the mounting bracket.
- 17**: A screw for the antenna.
- 18**: A nut for the antenna.
- 19**: A washer for the antenna.

pulsar 135LS

This exploded view diagram illustrates the assembly of a power tool handle. The components are labeled as follows:

- 1**: Main handle body.
- 2**: Trigger switch.
- 3**: Trigger switch button.
- 4**: Trigger switch lever.
- 5**: Screws for the trigger switch assembly.
- 6**: Trigger switch housing.
- 7**: Trigger switch button cover.
- 8**: Screw for the main handle body.
- 9**: Main handle body cover.

The diagram shows the trigger switch assembly (2, 3, 4, 5, 6, 7) being attached to the main handle body (1) using screws (5) and (8). The main handle body cover (9) is shown being attached to the handle body (1). A dashed box labeled **1/2** indicates a sub-assembly or a specific step in the process.

pulsar 135LS

This diagram illustrates the assembly of a boat's transom. The main assembly includes the transom plate (1), transom bracket (3), and transom support (4). The transom plate (1) is secured with screws (2) and a transom cap (14). The transom bracket (3) is attached to the transom support (4) using screws (11) and a transom cap (12). The transom support (4) is secured to the transom plate (1) with screws (5) and a transom cap (16). The transom support (4) is also secured to the transom plate (1) with screws (6) and a transom cap (15). The transom support (4) is also secured to the transom plate (1) with screws (7) and a transom cap (13). The transom support (4) is also secured to the transom plate (1) with screws (8) and a transom cap (9). The transom support (4) is also secured to the transom plate (1) with screws (10) and a transom cap (11).

pulsar 135LS

FIGURA N° 53 : EQUIPO ELÉCTRICO




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	DK201037	Pito Izquierdo	1	
	DK201038	Pito Derecho	1	
2	39150711	Arandela	1	
3	39195604	Tornillo	1	
4	JD402214	Instalación Eléctrica Delantera	1	
5	JD402202	Instalación Eléctrica Trasera	1	
	JD402219		1	Moto con Unidad de Control
	JD402231		1	Moto con Flasher
6	DH191012	Resorte Swiche Stop	1	
7	JZ401013	Unidad de Control	1	
8	DS201081	Bateria	1	
9	JA401800	Caja Bateria	1	
10	JA401801	Soporte Bateria	1	
11	31201079	Swiche Stop	1	
12	DS201025	Flasher Direccionales	1	
13	DS161224	Tornillo	2	
14	JN351604	Relay Arranque	1	
15	30201104	Caja Fusible	2	
16	30201085	Fusible 15A	2	
17	JA402202	Cable Bateria	1	
18	JW402202	Cable Bateria	1	
19	30191048	Banda Cable	5	

pulsar 135LS

LISTA DE KITS

Item	Referencia	Descripción	Contenido del Kit		
			Referencia	Descripción	Cant.
1	36314001	Kit Cunas Dirección	NA	Cuna Dirección	1
			NA	Cuna Dirección	1
			DH181024	Cuna Superior Chasis	1
			DH181023	Cuna Inferior Chasis	1
2	36DK0013	Kit Pines Taco Reposapie	DJ161186	Arandela	2
			DH161061	Pin Pasador	2
			30141031	Anillo Retén	2
			39104011	Arandela Plana	2
			39078408	Pin Pasador	2
3	36DU1007	Kit Moñón Crank	NA	Moñón Crank	1
			30101234	Resorte Moñón Crank	1
			30101236	Balín Crank	1
			30101235	Pin	1
			39085517	Arandela Crank	1
4	36DZ0020	Kit Retenes Tubo Telescópico	DL181080	Retenedor Tubo Telescopio	1
			DD181032	Guardapolvo	1
5	36JA0022	Kit Empaques	CB101114	Empaque Tubo Escape	1
			JA541205	Empaque Tapa Volante	1
			JA541212	Empaque Carcasa Clutch	1
			JD511008	Empaque de Culata	1
			JD521002	Empaque de Cilindro	1
6	36JD0001	Kit Boquereles Carburador	NA	Difusor	1
			NA	Aguja de la Cortina	1
			NA	Pulverizador	1
			NA	Boquerel de Alta	1
			NA	Boquerel de Baja	1
7	36JD0002	Kit Tornillo Carburador	NA	Tornillo Ajuste	1
			NA	Retén	1
			NA	Resorte	1
			DH181023	Arandela	1
			NA	Retén	1
8	36DS1401	Kit Antivibrantes	DS141012	Antivibrante	2
			DS161082	Antivibrante	2

LISTA DE KITS

Item	Referencia	Descripción	Contenido del Kit		
			Referencia	Descripción	Cant.
9	36JD0004	Kit Diafragma Carburador	NA	Cortina Carburador	1
			JE581213	Diafragma Carburador	1
			NA	Resorte Cortina Carburador	1
10	36JD0005	Kit Retenes Carburador	DP121069	Soporte Porta Boquerel	1
			NA	Empaque Taza Carburador	1
			NA	Retén	3
			NA	Retén	1
			JE581215	Retén	1
11	36JD0006	Kit Aguja Cortina Carburador	DP121056	Pin Aguja Flota Carb	1
			NA	Pin Seguridad	1
			NA	Arandela de Fijación	1
			NA	Resorte Aguja	1
12	36JE0001	Kit Resortes Válvula	39201719	Reten Válvula	2
			DG101029	Cuna Válvula	2
			JD511205	Resorte Válvula	2
			JD511203	Asiento Válvula	2
			NA	Resorte Válvula	2
13	36JE0003	Kit Guías Cadenilla	NA	Guía Cadenilla	1
			NA	Guía Cadenilla	1
14	36JE0004	Kit Corona y Piñón Primario	NA	Corona Clutch	1
			JA531010	Piñón Primario	1
15	36JE0007	Kit Sprocket y Cadena (opcional)	DJ151086	Sprocket 43T	1
			JV551000	Piñón Delantero 14T	1
			JD141000	Cadena 420x130L (Sin O' ring)	1
16	36JW0014	Kit Reparación Motor Arranque	JA621411	Pin Resorte Arranque	5
			DH101163	Roller	5
			JA621412	Resorte Arranque	5
			DJ101109	Buje Resorte Arranque	5
17	DK121041	Kit Tornillo Carburador	NA	Tornillo Ralenti	1
			NA	Resorte	1

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
01160508	9	57
01160508	19	58
01160508	25	41
020229/00	2	62
020276/00	2	57
030622/00	16	60
100/80-17-MR109-TT	5	30
101-020	6	50
101-021	7	50
101-104	4	47
112-003	3	50
112-004	4	50
112-006	9	50
112-007	8	50
14151033	15	15
14151033	23	13
2.75-17-MR-109-6PR	2	30
22150241	4	16
22150451	11	27
30101142	4	13
30101195	11	14
30101234	2	63
30101235	2	63
30101236	2	63
30141031	2	63
30141039	5	53
30151011	19	34
30151033	1	31
30151038	20	34
30151068	17	34
30151069	16	34
30151075	13	34
30151096	14	36
30151118	18	31
30181006	5	25

PARTE No.	FIG. No.	PAG. No.
30181011	2	25
30181025	4	39
30181026	3	39
30181029	20	39
30191017	10	37
30191048	19	61
30201085	16	61
30201104	15	61
31101173	3	6
31201079	11	61
31201081	5	12
33141008	12	53
35161060	18	58
36314001	1	63
36314001	4	25
36314001	10	39
36DH1902	15	32
36DK0009	11	19
36DK0013	2	63
36DK0013	10	27
36DK0017	7	36
36DK0018	8	36
36DS1401	1	54
36DS1401	8	63
36DU1007	3	16
36DU1007	3	63
36DZ0020	2	39
36DZ0020	4	63
36JA0022	1	5
36JA0022	2	19
36JA0022	3	2
36JA0022	3	14
36JA0022	5	63
36JA0022	16	13
36JD0001	3	17

PARTE No.	FIG. No.	PAG. No.
36JD0001	6	63
36JD0002	2	17
36JD0002	7	63
36JD0004	9	64
36JD0004	17	17
36JD0005	10	64
36JD0005	18	17
36JD0006	9	17
36JD0006	11	64
36JD0009	1	14
36JD0010	1	13
36JD0011	17	43
36JD0012	6	42
36JD0013	14	43
36JD0014	11	42
36JD0015	1	42
36JD0016	17	43
36JD0017	6	42
36JD0018	11	42
36JD0019	14	43
36JD0020	1	42
36-JE00-02-025/47	3	5
36-JE00-02-050/47	3	5
36-JE00-02-075/47	3	5
36-JE00-02-100/47	3	5
36-JE00-02-STD/47	3	5
36JE0001	6	3
36JE0001	12	64
36JE0002	3	5
36JE0003	6	4
36JE0003	13	64
36JE0004	7	6
36JE0004	14	64
36JE0004	16	15
36JE0005	4	15

PARTE No.	FIG. No.	PAG. No.
36JE0007	2	34
36JE0007	15	64
36JE0012	5	5
36JE0013	1	2
36JW0013	9	62
36JW0014	6	21
36JW0014	16	64
36JZ0009	2	11
36JZ0011	1	12
36JZ0013	1	13
36JZ0015	1	14
36PA0115	6	4
39020111	13	19
39021911	11	57
39021911	13	57
39024011	13	15
39024211	7	28
39029215	14	26
39032615	6	28
39042215	9	29
39045411	9	26
39055302	8	26
39059417	12	4
39069415	12	36
39071111	6	55
39072211	19A	34
39073817	6	16
39074011	7	53
39074601	4	22
39074701	9	12
39077504	23	35
39078408	2	63
39078912	11	36
39079415	9	34
39079708	3	29

PARTE No.	FIG. No.	PAG. No.
39079815	3	62
39080115	3	34
39080708	13	36
39080808	18	10
39081715	8	10
39084001	10	31
39085517	2	63
39090012	9	31
39098717	3	7
39099206	4	20
39099311	5	16
39099906	12	12
39099906	24	13
39099206	2	9
39099906	6	11
39100006	2	5
39104011	2	63
39104119	3	13
39105411	7	54
39106504	2	14
39118011	27	38
39118101	12	39
39118415	15	57
39122515	4	59
39128215	12	27
39128321	8	2
39128321	12	2
39150711	2	61
39152301	9	60
39155304	3	60
39155304	11	15
39155304	11	58
39167121	20	13
39167304	22	13
39167504	3	22

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
39167704	14	18
39168004	5	57
39171519	4	12
39175904	17	12
39176511	4	57
39176511	12	58
39177304	17	18
39177802	2	58
39177802	3	55
39177802	17	58
39178301	5	60
39178924	5	54
39184401	13	58
39190204	5	23
39191204	11	28
39191304	5	59
39194304	3	54
39194304	12	22
39194304	13	60
39194304	16	58
39194304	19	37
39194304	22	39
39194604	5	62
39195604	3	61
39196404	14	11
39197015	2	24
39197215	11	60
39198104	23	8
39199819	4	36
39199819	17	10
39201719	7	3
39201719	12	64
39206004	3	57
39212104	7	32
39212415	2	60

PARTE No.	FIG. No.	PAG. No.
39217924	8	60
39219019	7	12
39220011	12	15
39220804	8	58
39224020	6	34
39231204	3	24
39238104	2	53
39240817	12	16
39242001	8	28
39242704	16	37
39245304	19	10
39247604	5	60
39248415	10	53
39249211	8	19
39249804	4	24
39256220	2	12
39258204	7	27
39260011	3	15
39260801	10	2
39262921	11	2
39266921	13	4
39268620	12	34
39268720	15	34
39268820	2	31
39270204	9	24
39270411	7	10
39272315	6	24
39272612	6	26
39275404	7	19
39275404	11	54
39275821	8A	53
3954/00	7	42
3955/00	8	42
3956/00	18	43
3957/00	19	43

PARTE No.	FIG. No.	PAG. No.
3958/00	9	42
3959/00	10	42
3960/00	2	42
3961/00	3	42
3962/00	4	42
3963/00	5	42
3964/00	15	43
3965/00	16	43
3966/00	12	42
3967/00	13	42
3968/00	7	42
3969/00	8	42
3970/00	18	43
3971/00	19	43
3972/00	9	42
3973/00	10	42
3974/00	2	42
3975/00	3	42
3976/00	4	42
3977/00	5	42
3978/00	15	43
3979/00	16	43
3980/00	12	42
3981/00	13	42
40359E	12	23
40360E	13	23
41070-1017-NR73/18	5	30
41070-2717-NR2/18	2	30
41070-2717-NR53/18	2	30
41075-2717/18	3	30
41075-3217/18	6	30
4197/00	2	48
4200/00	13	53
4202/00	19	49
4318/00	1	44

PARTE No.	FIG. No.	PAG. No.
4319/00	1	44
4335/00	1	46
4335/00	2	44
4335/00	4	48
4336/00	3	44
4337/00	4	44
4338/00	5	44
4339/00	6	44
4340/00	7	44
4341/00	8	44
4342/00	7A	44
4343/00	8A	44
4344/00	9	44
4345/00	10	44
4346/00	11	44
4347/00	12	44
4348/00	13	44
4349/00	14	44
4350/00	13A	44
4351/00	14A	44
4383/00	2	46
4384/00	3	46
4385/00	4	46
4386/00	5	46
4387/00	6	46
4388/00	7	46
4389/00	8	46
4390/00	9	46
4391/00	10	46
4392/00	11	46
4393/00	2A	46
4394/00	3A	46
4403/00	2B	46
4404/00	3B	46
4413/00	13	46

PARTE No.	FIG. No.	PAG. No.
4414/00	1	48
4414/00	12	46
4472/00	1	47
4474/00	2	47
4476/00	5	47
4476/00	5	50
4478/00	13	46
4479/00	13	46
4490/00	1	50
4492/00	2	50
4497/00	5	48
4498/00	6	48
4499/00	7	48
4500/00	8	48
4501/00	9	48
4502/00	10	48
4503/00	11	48
4504/00	12	48
4505/00	13	48
4506/00	14	48
4507/00	15	48
4508/00	16	49
4509/00	17	49
4510/00	17	49
4511/00	17	49
4537/00	5A	48
4538/00	6A	48
4539/00	9A	48
4540/00	10A	48
4541/00	11A	48
4542/00	12A	48
4543/00	13A	48
4544/00	14A	48
4545/00	15A	48
4546/00	16A	49

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
4615/00	17	49
4632/00	21	49
4633/00	21	49
4634/00	21	49
4635/00	21	49
4680/00	20	49
4681/00	20	49
5066/00	15	51
5067/00	16	51
5082/00	1	51
5083/00	2	51
5084/00	11	51
5085/00	12	51
5086/00	9	51
5087/00	10	51
5088/00	13	51
5089/00	14	51
5090/00	5	51
5091/00	6	51
5092/00	3	51
5093/00	4	51
5094/00	7	51
5095/00	8	51
52JA0023	1	20
52JA0027	9	11
52JA0029	12	11
52JD0032	5	40
52JD0033	2	40
52JD0034	3	40
52JD0035	11	40
52JD0067	6	40
52JE0049	5	14
52JZ0264	1	10
5723	12	23
5724	13	23

PARTE No.	FIG. No.	PAG. No.
5747	12	23
5748	13	23
5802	12	23
5803	13	23
59020001	22	41
59040007	7	39
59040014	15	22
59040025	2	16
59040025	2	33
59040038	2	1
59040038	4	14
59040038	11	11
59040038	16	12
59040038	17	13
59040050	8	1
59110008	2B	6
59120003	2A	6
59150014	1	6
59200036	3	12
59200036	3	11
59210019	4	56
59210019	8	31
59210023	14	12
59210024	20	8
59942E	12	23
59945E	13	23
6625/00	1	45
6626/00	2	45
6627/00	7	45
6628/00	8	45
6629/00	5	45
6630/00	6	45
6631/00	9	45
6632/00	10	45
6633/00	3	45

PARTE No.	FIG. No.	PAG. No.
6634/00	4	45
6635/00	1	44
6641/00	11	45
BOTON	3	47
CB101114	2	19
CB101114	5	63
CL201023	3	58
CS101128	9	4
DD101097	13	16
DD111011	10A	22
DD111012	11	22
DD111018	8	22
DD111048	9	22
DD121181	19	13
DD141022	6	53
DD15109	21	35
DD161071	14	19
DD181032	4	63
DD191147	11	37
DD201002	10	60
DD201002	12	60
DD201011	1	60
DE151006	3	31
DE151008	5	31
DE151012	4	31
DE151033	12	33
DE151046	4	33
DE151047	5	33
DE151048	3	33
DE191010	5	32
DE191011	4	32
DE191028	14	32
DE191029	13	32
DE191033	6	32
DF161102	8	29

PARTE No.	FIG. No.	PAG. No.
DG101029	3	3
DG101029	12	64
DG101418	7	13
DG121002	8	18
DG151049	11	31
DG161121	2	54
DG161124	10	29
DG181008	3	28
DG181008	4	37
DG181058	8	59
DH101048	5	4
DH101163	16	64
DH101301	12	19
DH101380	8	11
DH101392	7	4
DH101395	5	19
DH101509	16	10
DH101648	14	15
DH101781	2	21
DH101784	6	12
DH111013	10B	22
DH111015	9	22
DH121038	10	18
DH121059	6	17
DH121063	16	17
DH121064	13	17
DH121093	5	17
DH151029	10	36
DH161053	8	27
DH161056	13	27
DH161061	2	63
DH161145	5	29
DH161146	11	29
DH161239	4	29
DH161240	7	29

PARTE No.	FIG. No.	PAG. No.
DH161309	13	29
DH181014	3	25
DH181022	15	37
DH181023	5	63
DH181023	8	63
DH181024	8	63
DH191007	12	37
DH191012	6	61
DH191014	13	37
DH191017	24	38
DH201080	3	56
DH201081	7	31
DJ101109	16	64
DJ141002	9	53
DJ141008	8	54
DJ151033	11	34
DJ151035	5	34
DJ151036	12	26
DJ151037	13	26
DJ151047	16	26
DJ151072	7	33
DJ151073	8	33
DJ151074	9	33
DJ151075	10	33
DJ151086	15	64
DJ151086	29	35
DJ151088	14	34
DJ151092	18	34
DJ151094	6	31
DJ161012	13	14
DJ161069	5	28
DJ161079	7	62
DJ161080	8	62
DJ161091	2	28
DJ161122	9	27

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
DJ161128	3	27
DJ161129	4	27
DJ161186	2	63
DJ161229	13	60
DJ171033	27	35
DJ181029	9	23
DJ181029	25	39
DJ181052	26	39
DJ181064	8	23
DJ181064	24	39
DJ181077	7	55
DJ181077	10	23
DJ181083	1	60
DJ181085	27	39
DJ181104	6	39
DJ191023	1	32
DJ191029	8	32
DJ191030	9	32
DJ191031	10	32
DJ191032	11	32
DJ191054	7	37
DJ191055	8	37
DJ191058	11A	32
DJ191059	3	32
DJ191081	7	37
DJ191083	8	37
DJ201072	5	58
DJ201072	7	60
DJ201108	16	32
DJ201109	12	32
DJ201183	3	56
DJ201195	21	38
DJ201246	21	38
DJ221019	1	62
DK101314	9	19

PARTE No.	FIG. No.	PAG. No.
DK121041	4	17
DK121041	17	64
DK181031	20	37
DK181058	26	38
DK201037	1	61
DK201038	1	61
DK211007	6	23
DK211008	4	23
DL161015	10	54
DL161015	12	28
DL181080	4	63
DL191014	9	37
DM181010	13	39
DP101107	5	15
DP101111	6	15
DP101114	17	15
DP101165	4	5
DP101198	7	2
DP101243	7	15
DP121056	11	64
DP121067	7	17
DP121069	10	64
DP161144	5	60
DP161145	4	60
DP171006	17	26
DS101117	8	16
DS101154	6	6
DS101215	8	13
DS101276	3	4
DS121126	7	18
DS141012	8	63
DS151073	8	34
DS151074	10	34
DS161082	8	63
DS161125	4	28

PARTE No.	FIG. No.	PAG. No.
DS161224	10	57
DS161224	13	61
DS171014	15	26
DS181015	8	39
DS181016	9	39
DS191018	17	37
DS191052	14	37
DS201025	12	61
DS201036	4	58
DS211005	2	23
DU101085	7	11
DU101213	22	8
DU101225	4	4
Dx151022	25	35
Dx151081	1	34
FD101078	3	20
GH201012	3	59
GT5AL-BS-GELAUTECO	8	61
JA113011	14	29
JA113201	2	29
JA113402	7	24
JA113403	1	24
JA113404	5	24
JA351600	7	21
JA351601	17	21
JA351602	11	21
JA351605	16	21
JA351606	9	21
JA351607	18	21
JA351608	12	21
JA351609	13	21
JA351611	19	21
JA351612	20	21
JA351613	8	21
JA351616	17	21

PARTE No.	FIG. No.	PAG. No.
JA351618	13	21
JA351619	15	21
JA351624	14	21
JA351627	11	21
JA401800	9	61
JA401801	10	61
JA402202	17	61
JA511008	4	1
JA511011	6	1
JA511011	9	18
JA511028	2	2
JA511029	7	1
JA511029	13	18
JA511216	2	4
JA521017	8	4
JA521018	10	4
JA521019	10	21
JA521019	11	4
JA521019	18	18
JA531010	12	6
JA531010	12	64
JA531010	19	15
JA531012	8	6
JA531015	9	6
JA541005	8	12
JA541005	9	14
JA541010	5	11
JA541011	4	11
JA541012	13	11
JA541016	2	20
JA541018	5	20
JA541019	13	12
JA541020	18	12
JA541021	15	12
JA541028	14	22

PARTE No.	FIG. No.	PAG. No.
JA541034	10	12
JA541205	3	14
JA541205	5	63
JA541211	11	13
JA541212	5	63
JA541212	16	13
JA541216	14	13
JA541221	8	14
JA541225	12	13
JA541233	10	14
JA541235	10	11
JA541236	9	13
JA541237	10	13
JA551002	4	7
JA551004	8	7
JA551007	15	8
JA551008	18	8
JA551009	19	8
JA551206	16	8
JA551406	2	15
JA561209	6	10
JA581005	3	18
JA581006	4	18
JA581009	5	18
JA581011	16	18
JA581012	6	18
JA581013	15	18
JA581406	5	2
JA591040	3	19
JA621002	9	16
JA621006	11	16
JA621402	4	21
JA621406	5	21
JA621410	3	21
JA621411	16	64

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
JA621412	16	64
JA621414	1	21
JB111033	1	25
JB113005	10	19
JB122009	5	26
JB122010	2B	26
JB122011	2A	26
JB122016	1	26
JB131017	16	31
JB131018	14	31
JB131019	11	26
JB131019	17	31
JB401402	18	37
JB402202	7	5
JB511020	5	1
JB531021	10	6
JB541201	25	13
JB621003	10	16
JC141015	4	55
JC141016	5	55
JC141017	23	41
JC191009	2	36
JC191009	13	10
JD111011	12	54
JD111012	9	54
JD111012	11	18
JD113026	1	27
JD113027	2	27
JD113031	5	27
JD113032	6	27
JD113035	1	27
JD113036	2	27
JD113200	6	29
JD113201	12	29
JD113400	8	24

PARTE No.	FIG. No.	PAG. No.
JD113800	15	60
JD113801	9	59
JD113801	10	60
JD113802	3	60
JD113802	10	60
JD113807	11	23
JD121002	17	39
JD122002	10	26
JD122003	3	26
JD122004	9	36
JD122008	4	26
JD122013	7	26
JD131002	1	30
JD131002	13	31
JD131210	5A	34
JD131212	11A	34
JD131213	24	35
JD131601	22	35
JD131808	2	32
JD131809	13	28
JD131809	17	32
JD131810	12	31
JD131813	1	33
JD141000	15	64
JD141000	28	35
JD141001	28	35
JD141003	1	34
JD151000	1	39
JD151003	14	39
JD151004	15	39
JD151006	23	39
JD151015	1	37
JD151015	21	39
JD151016	3	37
JD151017	2	37

PARTE No.	FIG. No.	PAG. No.
JD151023	6	59
JD151024	7	59
JD151026	5	39
JD151028	19	39
JD151029	11	39
JD151032	28	38
JD151034	22	38
JD151035	23	38
JD151036	32	38
JD151037	10	58
JD151038	9	58
JD151045	22	38
JD151048	23	38
JD151051	3	37
JD151052	2	37
JD151054	1	37
JD151054	21	39
JD161000	1	36
JD161002	5	36
JD161003	6	36
JD161200	1	56
JD161201	2	56
JD171016	18	40
JD171018	20	40
JD171030	3	53
JD171058/00	3	48
JD171600	1	53
JD171800	11	53
JD181000	14	28
JD181001	15	28
JD181003	10	28
JD181006	2	57
JD181203	4	40
JD181208	7	40
JD181209	8	40

PARTE No.	FIG. No.	PAG. No.
JD181211	2	55
JD181221	7	58
JD181224	10	40
JD181226	9	40
JD181228	14	58
JD181229	15	58
JD181232	7	57
JD181233	6	57
JD181234	8	57
JD181401	1	28
JD181402	9	28
JD181408	1	57
JD181409	12	57
JD191000	1	23
JD191003	3	23
JD191006	7	23
JD191007	8	23
JD191008	9	23
JD191012	1	23
JD191082	33	38
JD231402	4	62
JD231403	6	62
JD231408	4	62
JD231409	6	62
JD231600	29	38
JD231601	30	38
JD232801	13	60
JD232802	5	60
JD233002	13	40
JD233003	13	40
JD233012	2	48
JD233012	12	40
JD233014	4	48
JD233014	13	40
JD233014	20	43

PARTE No.	FIG. No.	PAG. No.
JD233016	14	40
JD233016	19	49
JD233017	15	40
JD233017	18	49
JD233018	14	40
JD233018	19	49
JD233019	15	40
JD233019	18	49
JD351206	16	22
JD351800	12	17
JD401003	1	59
JD401004	2	59
JD401007	6	60
JD401008	1	60
JD401024	1	58
JD401025	6	58
JD402202	5	61
JD402214	4	61
JD402219	5	61
JD402231	5	61
JD402401	1	55
JD402402	8	55
JD402601	8	53
JD511004	9	2
JD511006	1	1
JD511008	3	2
JD511008	5	63
JD511010	3	1
JD511201	4	3
JD511202	5	3
JD511203	12	64
JD511205	12	64
JD511207	2	3
JD511209	1	3
JD511211	1	4

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
JD521002	1	5
JD521002	5	63
JD531004	11	6
JD541000	11	12
JD551000	1	7
JD551002	9	7
JD551200	14	7
JD551201	7	7
JD551202	11	7
JD551203	12	7
JD551204	13	7
JD551205	6	7
JD551206	5	7
JD551207	2	7
JD551208	10	7
JD551209	17	8
JD551400	1	15
JD561001	1	9
JD561002	7	9
JD561004	5	9
JD561005	6	9
JD561006	4	9
JD561011	3	9
JD561203	4	10
JD561204	5	10
JD561411	9	10
JD561413	10	10
JD561414	11	10
JD561416	12	10
JD561417	14	10
JD561418	15	10
JD581001	2	18
JD581005	1	18
JD581202	12	17
JD591026	4	19

PARTE No.	FIG. No.	PAG. No.
JD591056	1	19
JD621001	7	16
JD710123	1	40
JE351002	1	22
JE351200	7	22
JE351203	5	22
JE351204	6	22
JE501000	1	11
JE501001	1	11
JE511230	14	4
JE-5212-00-025/47	8	5
JE-5212-00-050/47	8	5
JE-5212-00-075/47	8	5
JE-5212-00-100/47	8	5
JE-5212-00-STD/47	8	5
JE521200	8	5
JE531001	5	6
JE541008	14	16
JE541207	5	14
JE541209	13	13
JE541210	6	14
JE541211	2	13
JE541212	12	14
JE541218	21	13
JE551201	5	7
JE551206	13	7
JE551400	18	15
JE551401	6	13
JE551403	8	15
JE551404	9	15
JE551405	10	15
JE561001	1A	9
JE581000	12	18
JE581200	1	17
JE581213	17	64

PARTE No.	FIG. No.	PAG. No.
JE581215	10	64
JE581215	11	17
JE581218	15	17
JE581219	19	17
JE581220	8	17
JE581221	10	17
JE581223	14	17
JE581230	1	17
JE581400	4	2
JE581401	6	2
JE621200	1	16
JF401400	5	37
JF401401	6	37
JK121007	16	39
JK121009	18	39
JK161000	3	36
JL233003	21	43
JL233004	22	43
JN131003	15	31
JN131203	7	34
JN131211	24	35
JN131603	7	31
JN131806	1	33
JN131812	17	34
JN351604	14	61
JN402402	9	55
JP351007	2	22
JV521003	8	4
JV541208	5	13
JV551000	15	64
JV551000	21	8
JW111025	6	54
JW113200	1	29
JW131210	4	30
JW131807	6	33

PARTE No.	FIG. No.	PAG. No.
JW131810	11	33
JW171006	24	41
JW171007	19	40
JW171014	16	40
JW171015	17	40
JW171016	21	41
JW171017	4	54
JW232601	4	53
JW232601	25	38
JW351400	6	5
JW401010	14	60
JW402001	13	22
JW402202	18	61
JW541000	18	13
JW561206	2	10
JW561208	3	10
JW591030	6	19
JZ401013	7	61
JZ511020	5	1
JZ511021	1	1
JZ531003	4	6
JZ541214	21	13
JZ551006	1	7
JZ551008	9	7
JZ551200	7	7
JZ551201	5	7
JZ551202	2	7
JZ551204	16	8
JZ551205	15	8
JZ551206	11	7
JZ551208	14	7
JZ551210	10	7
JZ551211	12	7
JZ551212	13	7
JZ551213	6	7

PARTE No.	FIG. No.	PAG. No.
JZ561002	6	9
JZ621000	10	16
KADA0618	10	23
KIT-433650/00	15	44
KIT-434041/00	16	44
KIT-438389/00	14	46
KIT-439394/00	14	46
KIT-449801/00	24	49
KIT-449945/00	22	49
KIT-450708/00	23	49
KIT-453738/00	24	49
KIT-454546/00	23	49
KIT-463233/00	25	49
KIT-468081/00	26	49
LAA00004	15	36
LAC00009	31	38
LAC00020	26	38
LAD00018	7	14
LAD00018	15	13
LBB00001	14	57
LDB00001	4	34
LDB00002	26	35
MF12V5-3B-AUTECO	8	61
PN100.096-RD	7	52
PN101.041	1	52
PN101.041-GR	12	45
PN101.043	8	52
PN101.044	9	52
PN112.001	6	52
PN112.003	3	52
PN112.004	2	52
PN112.006	4	52
PN112.007	5	52

FICHA TÉCNICA PULSAR 135LS

Motor :	4T DTS-I , MONOCILÍNDRICO
Diámetro x Carrera :	54.0mm X 58.8mm
Desplazamiento :	134.66
Radio de compresión :	9,8:1
Potencia máxima :	13.38 HP @9000RPM
Torque máximo :	11.4Nm@7500RPM
Sistema de encendido:	CDI, TRICS
Bujías :	CHAMPION P-RZ9HC
Tolerancia de las bujías :	0.6 a 0.7 mm
Lubricación :	FORZADA, CÁRTER HÚMEDO
Arranque :	Eléctrico.
Transmisión :	5 VELOCIDADES
Freno delantero :	DISCO 240mm
Freno trasero :	TAMBOR 130mm
Capacidad del Tanque	
Lleno :	8 LITROS
Reserva :	2,5 LITROS
Reserva inutilizable :	1,6 LITROS
Dimensiones	
Largo x Ancho x Alto :	1995mm x 765mm x 1045mm
Distancia entre ejes :	1325mm
Altura al piso :	170mm
Llantas	
Delantera :	2,75 X17" 41P
Trasera :	100/90 X 17" 55P
Presión de aire:	
Delantera :	25PSI
Trasera (Solo) :	28PSI
Trasera (Con Parrillero) :	32PSI
Sistema Eléctrico	
Faro delantero :	35/35W
Luz de día :	5W
Luz de Stop :	LED
Luces direccionales :	10 W
Indicadores del tablero :	LED
Luz Velocímetro :	LED
Pito :	12V DC 2A
Batería :	12V5Ah
Peso neto :	
122 KG	

pulsar

135LS





Línea Gratuita Nacional
01 8000 52 00 90
servicioalcliente@auteco.com.co
www.auteco.com.co



Mobil