



PARTS CATALOGUE
MODEL YEAR 2000
RAZZ
SH50M (3EPU)

STARTING VIN: JYA3EPA0*YA256269

Color Code	Color Name	Abbreviation
409	VERY DARK VIOLET COCKTAIL 2	VDVC2
376	DEEP RED COCKTAIL 2	DRC2

OWNERS LIT-11626-13-25
ASSEMBLY LIT-11666-05-80
SERVICE LIT-11616-05-80

FOREWORD

-INTRODUCTION-
To The Yamaha Parts Fiche

This parts fiche lists parts and sub-assemblies for the SH50M. When preparing a parts order, please refer to the most recently updated microfiche for this model.

THE YAMAHA PARTS FICHE

SYMBOLS

[]	Inactive, no longer available
UR	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD,SO,SW	"SD", "SO", or "SW" type oil seal
E,R	"E" or "R" type circlip
F/No.	Frame No. (Applicable Machine No.)
L.M.	Locally made
O.L.	Obtain locally
AP	Alternate Part

SUPERSEDED PART NUMBERS

If part 'A' has been superseded by part 'B', the superseding part number "B" will appear in the part number listing with the superseded part number "A" appearing in parentheses immediately following the description.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
	(Part 'B')	(Part 'A')	
8	25G-16537-01-00	PLATE, SPRING STOP (25G-16537-00-00) ...	1

A part that has been supersede to a kit may be identified by a 99999-00000-00 part number appearing in the part number column. The old superseded part number will appear in parentheses immediately following the description. Listed directly below the 99999 part number will be those parts making up the kit. The description of the parts making up the kit will be preceded by a small black dot (.) and the description will be indented one letter space.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
8	99999-01683-00	FORK COVER SET (50W-23310-00-00)...	1
	50W-23310-20-00	• FORK COVER	1
	90105-10393-00	• BOLT, WASHER BASED	1

SIZES

Except for steel balls (ball sizes are indicated in inches), all parts sizes are indicated in millimeters as in the following examples:

Hose (Rubber or Vinyl)	Inside Diameter - Length
O-Ring	Section Area - Inside Diameter
Washer, Shim, Collar	Inside Diameter - Outside Diameter Thickness (Length)

ASSEMBLIES AND COMPONENT PARTS

Assemblies and their component parts, are identified by an indentation of one letter space, and the description is preceded by a dot (.). If two main assemblies are listed, and have the same basic description (i.e.: left and right sides of the same assembly), one will immediately follow the other. If each of these main assemblies is made up of almost the same components, these component parts will be listed immediately under the second main assembly line and will be indicated, as noted above.


If the component is the same for both main assemblies, the quantity indicated will be the total required. If the component is not the same for both main assemblies, the quantity for each separate item will be listed separately.

EXAMPLE:


Description	Qty
CARBURETOR ASSY, LEFT	1
CARBURETOR ASSY, RIGHT	1
. JET, PILOT	2
. NOZZLE, MAIN	2
. LEVER, STARTER, LEFT	1
. LEVER, STARTER, RIGHT	1

APPLICABLE SERIAL NO.

(1) Frame Serial No.



(2) Engine Serial No.




FOREWORD

THE YAMAHA PART NUMBER

The Yamaha part number consists of 12 digits. Each number represents a specific piece of information relating to a replacement part. The following is a guide for reading and interpreting the Yamaha part number.

BASIC PART NUMBER CONFIGURATION:



MODEL CODE NUMBER

FIRST THREE DIGITS . . . 000-00000-00-00


Every model in each Yamaha product line is assigned a model number to identify that particular model. All component parts are given the model code number relating to the model on which they were first used.

Example: 4F3-00000-00-00 identifies the CY50E.
3EP-00000-00-00 identifies the SH50E.

BASIC CODE NUMBER


MIDDLE FIVE DIGITS . . . 000-00000-00-00

These "Middle Five Digits" indicate the type of part i.e., piston, rings, lower units, etc. The five digits are broken down as follows:



The "Major Classification" indicates the section to which the parts belong, i.e., engine, electrical etc. The "Intermediate" and "Minor Classifications" indicate more specific details.

Example:



DESIGN CODE NUMBER: 000-00000-00-00

The design code distinguishes like component parts from one another when specification differences are involved. For example, distinguishing a standard size piston ring from an oversized piston ring.

Example:

50M-11610- 0 0-00 Standard Piston Ring Set for XC125F
50M-11610- 2 0-00 Oversize Piston Ring Set for XC125F

DESIGN CHANGE CODE NUMBER: 000-00000-00-00

This code number is used to identify a difference between a new component part and old one when a new part is created by changing the old one.

Example: XC125

50W-23310-0 0 -00 PISTON RING SET, STD. - ORIGINAL
50W-23310-0 1 -00 PISTON RING SET, STD. - FIRST DESIGN CHANGE


Only major changes to performance, durability, quality, appearance, cost or interchangeability will affect a part number change.

COLOR CODE & SIZE CODE NUMBER: 000-00000-00-00

When applicable, the last two digits of the part number identify:

1. Color Code: The painted color or type of plating or surface treatment used on certain parts.
2. Size Code: The last two digits are also used to show the size of parts (mm). Such as the thickness of shims or the size of pistons.

HARDWARE (Fastener) PART NUMBER CONFIGURATION:



TYPE:

A fastener part number always begins with the number "9" followed by either a 0, 1, 2, 3, 4, 5, 6, 7 or 8 designating one of eight major divisions within this group.

FOREWORD

Example:

- 90

000-00000-00 "0" designates various types.
- 91

000-00000-00 "1" designates bolts, cotter pins, etc.
- 92

000-00000-00 "2" designates screw, nuts, etc.
- 93

000-00000-00 "3" designates oil seals, o-rings, bearings, etc.
- 94

000-00000-00 "4" designates spark plugs.
- 95


000-00000-00 "5" designates bolts and nuts.
- 97

000-00000-00 "7" designates ISO bolts.
- 98

000-00000-00 "8" designates ISO screws and nuts.

The only major divisions which the mechanic should become familiar with are those related to the general hardware (nuts, bolts, and washers), since these are the most commonly used and most often replaced items. By knowing how to interpret the part number, the dimensions of a piece of hardware can be determined. This can be very helpful during major engine repair, and general parts replacement.


BOLT EXAMPLE:




EXCEPTION:

It is NOT possible to identify the LENGTH of bolts having a 901 prefix. Only the bolt diameter can be identified with this number.


NUT AND WASHER EXAMPLE:





CYLINDER


Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-11111-00-00	HEAD, CYLINDER 1	1	
2	517-11181-00-00	GASKET, CYLINDER HEAD 1 . .	1	
3	NGK-BPR6H-S1-00	SPARK PLUG (NGK BPR6HS10)	1	
4	90116-06418-00	BOLT, STUD	4	
5	95707-06500-00	NUT, FLANGE	4	
6	1YU-11311-00-00	CYLINDER 1	1	
7	3HK-11351-00-00	GASKET, CYLINDER	1	



1YU010-6020

CRANKSHAFT-PISTON

Ref. No.	Part Number	Description	Qty	Remarks
1	1YU-11400-00-00	CRANKSHAFT ASSY	1	
2	1YU-11412-00-00	. CRANK 1	1	
3	1YU-11681-00-00	. PIN, CRANK 1	1	
4	93310-416N7-00	. BEARING	1	
5	2E9-11651-00-00	. ROD, CONNECTING	1	
6	14T-11422-01-00	. CRANK 2	1	
7	90280-03017-00	KEY, WOODRUFF	1	
8	93306-20468-00	BEARING	2	
9	93102-20371-00	OIL SEAL	1	
10	93101-20138-00	OIL SEAL	1	
11	90387-160R6-00	COLLAR	1	
12	3CP-11631-00-96	PISTON (STD)	1	
	3CP-11636-00-00	PISTON (0.50MM O/S)	1	
13	2E9-11633-00-00	PIN, PISTON	1	
14	260-11601-02-00	PISTON RING SET (STD)	1	
	260-11601-22-00	PISTON RING SET (0.50MM O/S)	1	
15	93450-11021-00	CIRCLIP	2	
16	93310-210M0-00	BEARING, CYLINDRICAL	1	




AIR SHROUD-FAN

Ref. No.	Part Number	Description	Qty	Remarks
1	1YU-12651-00-00	AIR SHROUD, CYLINDER 1 ...	1	
2	90153-06022-00	SCREW, HEXAGON	2	
3	90387-067T6-00	COLLAR	2	
4	90480-12237-00	GROMMET	2	
5	1YU-12653-00-00	AIR SHROUD, CYLINDER 3 ...	1	
6	53L-14462-00-00	SEAL	1	
7	98517-06020-00	SCREW, PAN HEAD	2	
8	1YU-12611-01-00	FAN	1	
9	98507-06016-00	SCREW, PAN HEAD	3	
10	92907-06100-00	WASHER, SPRING	3	
11	92907-06600-00	WASHER, PLATE	3	




1YU010-6031

OIL PUMP



IYU010-6040

Ref. No.	Part Number	Description	Qty	Remarks
1	1YU-13100-02-00	OIL PUMP ASSY	1	
2	3WF-13185-00-00	. BOLT, BREATHER	1	
3	1YU-13187-00-00	. O-RING	1	
4	1YU-13473-00-00	. O-RING	1	
5	3AA-13124-00-00	. GEAR, WORM WHEEL	1	
6	1YU-13516-00-00	. PIN, DOWEL	1	
7	1YU-13577-00-00	. CLIP	1	
8	1YU-13416-00-00	. PIPE, OIL 1	1	
9	90467-08003-00	. CLIP	2	
10	1YU-13418-00-00	. PIPE, OIL 2	1	
11	90468-02033-00	. CLIP	1	
12	90468-02033-00	CLIP	1	
13	98507-05020-00	SCREW, PAN HEAD	2	
14	1YU-13178-00-00	GEAR, PUMP DRIVE	1	
15	29615-64400-00	SHIM	1	
16	93603-12007-00	PIN, DOWEL	1	
17	99009-19400-00	CIRCLIP	2	
18	90206-19027-00	WASHER, WAVE	1	




1YU010-6050

INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
1	27V-13610-00-00	REED VALVE ASSY	1	
2	24G-13613-00-00	. REED, VALVE	1	
3	27V-13616-00-00	. STOPPER, REED VALVE	1	
4	98507-03008-00	. SCREW, PAN HEAD	2	
5	92990-03100-00	. WASHER, SPRING	2	
6	3HK-13621-00-00	GASKET, VALVE SEAT	1	
7	27V-13555-00-00	MANIFOLD, INTAKE	1	
8	90450-32081-00	HOSE CLAMP ASSY	1	
9	91317-06020-00	BOLT	4	
10	3HK-14453-00-00	JOINT, AIR CLEANER 1	1	
11	90467-24140-00	CLIP	1	
12	1YU-14411-00-00	CASE, AIR CLEANER 1	1	
13	1YU-14451-00-00	ELEMENT, AIR CLEANER	1	
14	1YU-14412-00-00	CAP, CLEANER CASE 1	1	
15	1YU-14437-00-00	DUCT	1	
16	97780-40116-00	SCREW, TAPPING	2	
17	97780-50125-00	SCREW, TAPPING	4	
18	50M-14462-00	SEAL	1	
19	98517-06020-00	SCREW, PAN HEAD	2	

CARBURETOR


Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-14301-01-00	CARBURETOR ASSY 1	1	
2	1YU-14126-00-00	. GASKET	1	
3	2T4-14331-00-00	. SPRING, THROTTLE VALVE	1	
4	1YU-14312-30-00	. VALVE, THROTTLE 1	1	
5	1YU-14384-00-00	. GASKET, FLOAT CHAMBER	1	
6	14T-14343-41-00	. JET, MAIN (82)	1	
7	1YU-14341-00-00	. NOZZLE, MAIN	1	
8	1YU-14353-23-00	. JET, PILOT (46)	1	
9	1YU-14169-00-00	. CAP	1	
10	98580-05012-00	. SCREW, PAN HEAD	1	
11	92990-05100-00	. WASHER, SPRING	1	
12	98580-04016-00	. SCREW, PAN HEAD	2	
13	92990-04100-00	. WASHER, SPRING	2	
14	5Y1-14197-00-00	. PIPE	1	
15	14T-14392-01-00	. VALVE, NEEDLE	1	
16	1YU-14385-00-00	. FLOAT	1	
17	14T-14386-00-00	. PIN, FLOAT	1	
18	98580-03006-00	. SCREW, PAN HEAD	1	
19	14T-14104-00-00	. SCREW, AIR ADJUSTING	1	
20	1YU-14335-00-00	. SPRING, PLUNGER	1	
21	1YU-14371-00-00	. PLUNGER, STARTER	1	
22	56R-14196-00-00	. PIPE	1	
23	1YU-14103-00-00	. THROTTLE SCREW SET	1	
24	2EK-1490J-00-00	. NEEDLE SET	1	
25	1UV-14106-00-00	. CABLE ADJUST SCREW SET	1	
26	14T-14104-00-00	. SCREW, AIR ADJUSTING	1	
27	14T-14169-00-00	. CAP	1	
28	1YU-14283-00-00	COVER, CARBURETOR 1	1	




1YU010-6061

EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
1	2HU-14610-01-00	EXHAUST PIPE ASSY 1	1	
2	97707-30606-00	SCREW, TAPPING	1	
3	3HK-14613-00-00	GASKET, EXHAUST PIPE	1	
4	90153-06061-00	SCREW, HEXAGON	2	
5	95817-08025-00	BOLT, FLANGE	2	
6	1YU-14718-00-00	PROTECTOR, MUFFLER 1	1	
7	98907-06016-00	SCREW, BIND	2	
8	90387-060G7-00	COLLAR	2	
9	90480-12237-00	GROMMET	2	
10	3HK-14766-01-00	WASHER, PROTECTOR	2	
11	92907-06200-00	WASHER	2	





3EPH100-6070



1YU010-6080

CRANKCASE

Ref. No.	Part Number	Description	Qty	Remarks
1	2EJ-15110-00-00	CRANKCASE ASSY 1	1	
2	164-22216-00-00	. BUSH, REAR SHOCK ABS . .	1	
3	1YU-15316-00-00	. DAMPER, ENGINE MOUNT 1 .	1	
4	58315-37100-00	. BREATHER	1	
5	99510-12016-00	PIN, DOWEL	2	
6	98507-06035-00	SCREW, PAN HEAD	6	
7	1YU-15120-00-00	CRANKCASE ASSY 2	1	
8	1YU-15316-00-00	. DAMPER, ENGINE MOUNT 1 .	1	
9	3HK-15462-00-00	GASKET, CRANKCASE COVER 3	1	
10	90560-10288-00	SPACER	1	
11	1YU-15376-00-00	HOLDER, GUIDE	1	
12	1YU-15128-00-00	HOLDER	1	
13	98517-06012-00	SCREW, PAN HEAD	1	
14	1YU-15411-00-00	COVER, CRANKCASE 1	1	
15	3HK-15451-00-00	GASKET, CRANKCASE COVER 1	1	
16	99530-10014-00	PIN, DOWEL	2	
17	98517-06025-00	SCREW, PAN HEAD	8	
18	98517-06025-00	SCREW, PAN HEAD	1	UR
	98580-06025-00	SCREW, PAN HEAD	1	UR
19	98507-06050-00	SCREW, PAN HEAD	1	
20	98507-06035-00	SCREW, PAN HEAD	2	
21	95817-08035-00	BOLT, FLANGE	1	
22	90201-08087-00	WASHER, PLATE	1	
23	4J2-15363-00-00	PLUG, OIL	1	
24	93210-14104-00	O-RING	1	
25	90446-07200-00	HOSE	1	
26	90465-10296-00	CLAMP	1	




3HK8010-4090


STARTER

Ref. No.	Part Number	Description	Qty	Remarks
1	1YU-15601-00-00	KICK SHAFT ASSY	1	
2	90508-32609-00	SPRING, TORSION	1	
3	90201-15701-00	WASHER, PLATE (1.0T)	1	
4	99009-15400-00	CIRCLIP	1	
5	93102-15212-00	OIL SEAL	1	
6	1NT-156301-01-00	KICK PINION ASSY	1	
7	2E9-15673-00-00	CLIP	1	
8	33A-15659-00-00	SHAFT	1	
9	1YU-15620-00-00	KICK CRANK ASSY	1	
10	90153-06008-00	SCREW, HEXAGON	1	
11	3AA-15513-00-00	GEAR 1	1	
12	93310-257R1-00	BEARING, CYLINDRICAL	1	
13	1YU-15570-00-00	STARTER CLUTCH ASSY	1	
14	1YU-15512-00-00	GEAR, IDLER 1 (48T-15T)	1	
15	50M-13342-00-00	SHAFT, IDLE GEAR	1	
16	1YU-15532-00-00	PLATE, IDLE GEAR	1	
17	98517-06012-00	SCREW, PAN HEAD	2	
18	53L-15528-00-00	BOSS, GEAR	1	
19	90201-573J7-00	WASHER, PLATE	1	
20	1YU-81800-M1-00	STARTING MOTOR ASSY	1	
21	1YU-81847-50-00	. O-RING	1	
	93210-19501-00	. O-RING	1	
22	1YU-81801-M0-00	. BRUSH SET	1	
	52W-81801-50-00	. BRUSH SET	1	
23	91317-06020-00	BOLT	2	

CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	2E9-16611-01-00	CLUTCH HOUSING COMP	1	
2	1YU-16620-00-00	CLUTCH CARRIER ASSY	1	
3	1YU-16626-00-00	. SPRING, CLUTCH WEIGHT 1 .	2	
4	1YU-15657-00-00	CLUTCH, ONE WAY	1	
5	90201-166K2-00	WASHER, PLATE (2.4T)	1	
6	90170-10219-00	NUT	1	
7	90208-10012-00	WASHER, CONICAL SPRING . .	1	
8	90201-166K3-00	WASHER, PLATE	2	
9	90387-16680-00	COLLAR	1	
10	1YU-16110-01-00	PRIMARY DRIVE GEAR ASSY .	1	
11	93306-20116-00	BEARING	1	
12	90201-123K4-00	WASHER, PLATE	1	
13	90208-12027-00	WASHER, CONICAL SPRING . .	1	






IYU010-6120


TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-17410-00-00	MAIN AXLE COMP. (57T-11T)	1	
2	90208-12044-00	WASHER, CONICAL SPRING	1	
3	90201-123K4-00	WASHER, PLATE	1	
4	94580-12058-00	CHAIN (D.I.D. 270H 58LE)	1	
5	1YU-17468-00-00	GUIDE, CHAIN 1	1	
6	1YU-17467-00-00	GUIDE, CHAIN 1	1	
7	1YU-17471-00-00	PLATE, COVER	1	
8	98517-06012-00	SCREW, PAN HEAD	2	
9	2FU-17420-00-00	DRIVE AXLE ASSY (37T)	1	
10	93306-20310-00	BEARING (B6203DU)	1	
11	93102-22314-00	OIL SEAL	1	
12	93420-40064-00	CIRCLIP, R-TYPE	1	




FRAME

Ref. No.	Part Number	Description	Qty	Remarks
1	2NM-21110-01-33	FRAME COMP.	1	YAMAHA BLACK
2	90105-10117-00	BOLT, WASHER BASED	1	
3	1YU-21481-00-00	BOLT, ENGINE MOUNTING 1 .	1	
4	95704-10500-00	NUT, FLANGE (95701-10500-00)	2	
5	1YU-21410-00-00	ENGINE BRACKET COMP. ...	1	
6	90465-12302-00	CLAMP	1	
7	1YU-24816-00-00	BRACKET, CARRIER	1	
8	95814-08016-00	BOLT, FLANGE	2	
9	2E9-24182-00-00	DAMPER, LOCATING 2	2	
10	90464-30040-00	CLAMP	3	
11	34M-2139X-00-00	DAMPER	1	
12	3MX-21568-A0-00	LABEL, WARNING	1	



FENDER


Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-21511-00-P0	FENDER, FRONT	1	UR VERY DARK VIOLET COCKTAIL 2
	2EK-21511-00-P3	FENDER, FRONT	1	UR DEEP RED COCKTAIL 2
2	90119-06085-00	BOLT, WITH WASHER	2	
3	1UY-21629-00-00	GUARD, MUD	1	



3EPH100-6140


SIDE COVER

Ref. No.	Part Number	Description	Qty	Remarks
1	1UY-21711-00-P3	COVER, SIDE 1	1	UR VDVC2 (409)
	1UY-21711-00-P5	COVER, SIDE 1	1	UR DRC2 (376)
2	90149-06184-00	SCREW	2	
3	1UY-21721-00-P3	COVER, SIDE 2	1	UR VDVC2 (409)
	1UY-21721-00-P5	COVER, SIDE 2	1	UR DRC2 (376)
4	3KL-21781-21-00	EMBLEM 1	2	UR DRC2
	3KL-21781-31-00	EMBLEM 1	2	UR VDVC2
5	99231-00080-00	EMBLEM, YAMAHA	2	UR DRC2
	99236-00080-00	EMBLEM, YAMAHA	2	UR VDVC2
6	1UY-2171L-40-00	MOLE, SIDE COVER 1	1	RADICAL GRAY (06A)
7	1UY-2171M-40-00	MOLE, SIDE COVER 2	1	RADICAL GRAY (06A)
8	14T-21719-01-00	GROMMET	2	
9	3MX-24875-00-00	LABEL 1	1	ENGLISH
10	3TB-24877-00-00	LABEL, CAUTION	1	ENGLISH
11	3JJ-28446-00-00	LABEL, CAUTION	1	ENGLISH




OIL TANK

Ref. No.	Part Number	Description	Qty	Remarks
1	1UY-21751-00-00	TANK, OIL	1	
2	27V-24181-00-00	DAMPER, LOCATING 1	2	
3	52W-21770-00-00	OIL TANK CAP ASSY.	1	
4	26H-21746-00-00	DAMPER	1	



REAR SUSPENSION

Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-22210-01-00	SHOCK ABSORBER ASSY, REAR	1	
2	90105-08121-00	BOLT, WASHER BASED	1	
3	90101-10776-00	BOLT	1	
4	95707-10500-00	NUT, FLANGE	1	




FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-23100-03-00	FRONT FORK ASSY	1	
2	2EK-23110-00-00	. INNER TUBE COMP 1	1	
3	2EK-23120-00-00	. INNER TUBE COMP 2	1	
4	2EK-23141-00-00	. SPRING, FRONT FORK	2	
5	52W-23195-00-00	. RUBBER	2	
6	2E9-23143-00-00	. SEAT, SPRING LOWER	2	
7	3YJ-23414-00-00	. INNER TUBE COMP. 1	1	
8	3KJ-23411-01-00	RACE, BALL 1	1	
9	2E9-23412-00-00	RACE, BALL 2	1	
10	2E9-23413-01-00	RACE, BALL 3	1	
11	93505-32002-00	BALL	52	
12	2E9-23454-00-00	NUT, FITTING 2	1	
13	53L-23389-00-00	GUIDE, CABLE	1	
14	95807-06008-00	BOLT, FLANGE	1	



FUEL TANK

Ref. No.	Part Number	Description	Qty	Remarks
1	1YU-24110-00-00	FUEL TANK COMP.	1	
2	1UV-24610-00-00	CAP ASSY	1	
3	1L4-24615-00-00	. GASKET, PLATE 1	1	
4	1L4-24616-00-00	. GASKET, PLATE 2	1	
5	53L-24261-00-00	HOUSING, FUEL METER	1	
6	53L-85753-00-00	GASKET, SENDER UNIT	1	
7	1UV-24629-00-00	RING	1	
8	1YU-24312-00-00	PIPE 2	1	
9	90467-10008-00	CLIP	2	
10	2EK-24198-00-00	SEAT, RUBBER	1	
11	2EK-24500-00-00	FUEL COCK ASSY 1	1	
12	1YU-24311-00-00	PIPE, FUEL 1	1	
13	90501-061E8-00	SPRING, COMPRESSION	1	
14	90467-09006-00	CLIP	2	
15	90445-07176-00	HOSE	1	
16	98517-06012-00	SCREW, PAN HEAD	2	
17	92907-06100-00	WASHER, SPRING	2	




SEAT

Ref. No.	Part Number	Description	Qty	Remarks
1	3HK-24710-30-00	SINGLE SEAT ASSY	1	RADICAL GRAY (06A)
2	1L9-24741-00-00	. PAD, SEAT	2	
3	90468-12006-00	CLIP	1	
4	91701-06055-00	PIN, CLEVIS	1	
5	2EK-24842-00-00	CARRIER, REAR	1	
6	95817-06012-00	BOLT, FLANGE	2	
7	90176-06041-00	NUT, CROWN	2	
8	3KL-21243-00-00	PLATE, BRIDGE	1	
9	90105-08352-00	BOLT, WASHER BASED	4	
10	27V-24181-00-00	DAMPER, LOCATING 1	3	
11	1YU-21171-00-00	BOX	1	
12	18A-21778-00-00	DAMPER, LOCATING 1	1	
13	90119-06018-00	BOLT, WITH WASHER	3	
14	1YU-2474F-00-00	STAY, FRONT 1	1	
15	95817-06010-00	BOLT, FLANGE	2	
16	1YU-2484700-00	HOLDER 1	1	
17	95817-06010-00	BOLT, FLANGE	1	
18	3TB-28415-00-00	DAMPER 1	1	
19	1YUW2470-00-00	SEAT LOCK ASSY	1	
20	1YU-2474E-00-00	ARM	1	
21	53L-24754-00-00	HOOK, SEAT	1	
22	90508-09673-00	SPRING, TORSION	1	



3EPH100-6190




FRONT WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
1	25K-25180-00-35	FRONT WHEEL COMP.	1	SILVER (035)
2	90560-10236-00	SPACER	1	
3	25K-25116-00-00	FLANGE, SPACER 2	1	
4	93106-17015-00	OIL SEAL	1	
5	1YU-25121-00-35	PLATE, BRAKE SHOE	1	SILVER (035)
6	93109-34057-00	OIL SEAL	1	
7	3EP-W2535-00-00	BRAKE SHOE SET	1	
8	2E9-25133-00-00	SPRING, RETURN	1	
9	2T4-25137-00-00	RING, STOP	1	
10	2E9-25138-00-00	GEAR, METER	1	
11	2E9-25135-00-00	GEAR, DRIVE (14T)	1	
12	90201-064L6-00	WASHER, PLATE	1	
13	3EP-25155-00-00	LEVER, CAMSHAFT 1	1	
14	25K-25151-00-00	CAMSHAFT	1	
15	97027-05020-00	BOLT	1	
16	95307-05600-00	NUT	1	
17	3L8-2513A-00-00	PLATE, INDICATOR	1	
18	93306-20005-00	BEARING (B6200)	2	KOYO
19	2T4-25185-00-00	RING 1	1	
20	94125-107J4-00	TIRE (2.50-10 4PR MB27)	1	INOUE
21	94225-10270-00	TUBE (2.50/2.75-10)	1	INOUE
22	95617-10200-00	BOLT, STUD	1	
23	54V-25181-00-00	AXLE, WHEEL	1	
24	90387-10620-00	COLLAR	1	
25	93210-10096-00	O-RING	1	
26	2E9-25137-01-00	RING, STOP	1	

REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	14T-25390-01-35	REAR WHEEL COMP	1	SILVER (035)
2	52W-25336-00-00	RING 2	1	
3	94125-107J4-00	TIRE (2.50-10 4PR MB27)	1	INOUE
4	94225-10270-00	TUBE (2.50/2.75-10)	1	INOUE
5	3EP-W2536-00-00	BRAKE SHOE SET	2	
6	90506-14081-00	SPRING, TENSION	2	
7	25L-25326-00-00	PIN, PIVOT	1	
8	95707-08500-00	NUT, FLANGE	1	
9	93210-06632-00	O-RING	1	
10	1YU-25351-00-00	CAMSHAFT	1	
11	53L-25355-00-00	LEVER, CAMSHAFT	1	
12	3L8-2513A-00-00	PLATE, INDICATOR	1	
13	97017-06025-00	BOLT	1	
14	90201-17255-00	WASHER, PLATE	1	
15	90201-14740-00	WASHER, PLATE	1	
16	90185-14081-00	NUT, SELF-LOCKING	1	





STEERING HANDLE-CABLE



2EK110-7221


Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-26110-00-00	HANDLE COMP.	1	
2	90105-10036-00	BOLT, WASHER BASED	1	
3	95617-10200-00	BOLT, STUD	1	
4	3RY-26241-01-00	GRIP (LEFT)	1	
5	3RY-26242-01-00	GRIP (RIGHT)	1	
6	2GN-26243-00-00	TUBE, THROTTLE GUIDE	1	
7	2EK-26311-02-00	CABLE, THROTTLE 1	1	
8	1UY-26312-01-00	CABLE, THROTTLE 2	1	
9	53L-26261-01-00	CONNECTOR, CABLE	1	
10	98517-05012-00	SCREW, PAN HEAD	1	
11	53L-26331-00-00	CABLE, STARTER 1	1	
12	1YU-26334-01-00	CABLE, STARTER 2	1	
13	53L-26261-00-00	CONNECTOR, CABLE	1	
14	2EK-26341-00-00	CABLE, BRAKE	1	
15	14T-26342-00-00	BOOT, CABLE	1	
16	90501-10513-00	SPRING, COMPRESSION	1	
17	90179-06411-00	NUT	1	
18	90249-12008-00	PIN	1	
19	1YU-26351-00-00	CABLE, BRAKE	1	
20	90202-08175-00	WASHER, PLATE	1	
21	90501-122E1-00	SPRING, COMPRESSION	1	
22	90179-06411-00	NUT	1	
23	90249-12008-00	PIN	1	
24	2EK-26393-00-00	HOLDER	1	
25	97017-06016-00	BOLT	1	
26	92907-06600-00	WASHER, PLATE	1	
27	1YU-26329-00-00	CAP, RUBBER	2	
28	2EK-26293-00-00	BAND	1	



3EPH100-6230

STAND-FOOTREST

Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-27111-00-00	STAND, MAIN	1	
2	90387-064A4-00	COLLAR	1	
3	2E9-27116-01-00	SPRING, MAIN STAND	1	
4	90240-08121-00	PIN, CLEVIS	1	
5	90468-12006-00	CLIP	1	
6	1YU-27481-40-00	BOARD, FOOTREST	1	RADICAL GRAY (06A)
7	25G-21535-00-00	NUT 1	2	
8	90119-06060-00	BOLT, WITH WASHER	4	
9	97707-50012-00	SCREW, TAPPING	2	
10	90183-05072-00	NUT, SPRING	2	




LEG SHIELD

Ref. No.	Part Number	Description	Qty	Remarks
1	1YU-28311-01-P0	LEG SHIELD 1	1	VDVC2 (409)
	1YU-28311-01-P4	LEG SHEILD 1	1	DRC2 (376)
2	90159-06182-00	SCREW, WITH WASHER	1	
3	1YU-23391-00-P4	PANEL, FRONT	1	VDVC2 (409)
	1YU-23391-00-P5	PANEL, FRONT	1	DRC2 (376)
4	3KL-28315-01-00	EMBLEM	1	
5	3KL-2839H-01-00	EMBLEM 1	1	
6	3WF-2153E-10-00	EMBLEM, YAMAHA	1	
7	14T-28349-F0-00	CAP	1	RIPE RED
	14T-28349-J0-00	CAP	1	SOLID COSMIC BLUE
8	90159-06178-00	SCREW, WITH WASHER	2	
9	3HK-82552-20-00	CAP, SWITCH	1	
10	3LL-21668-00-00	LABEL, TIRE	1	
11	3EP-2179X-20-00	PLATE, EPA 0	1	
12	3SL-2118K-00-00	LABEL, CAUTION	1	




3EPH100-6240



2EK110-7250

COWLING 1


Ref. No.	Part Number	Description	Qty	Remarks
1	14T-26290-10-00	REAR VIEW MIRROR ASSY (LEFT)	1	
2	2EK-26143-00-P2	COVER, HANDLE BAR UPPER 1	1	VDVC2 (409)
	2EK-26143-00-P3	COVER, HANDLE BAR UPPER 1	1	DRC22 (376)
3	2EK-26145-50-00	COVER, HANDLE BAR UPPER 2	1	
4	90159-05121-00	SCREW, WITH WASHER	2	
5	90154-05042-00	SCREW, BINDING	2	
6	35R-26294-00-00	NUT 1	3	
7	90338-09012-00	PLUG	1	
8	14T-26290-00-00	REAR VIEW MIRROR ASSY (RIGHT)	1	AP



IYU010-6350


GENERATOR

Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-85550-M0-00	ROTOR ASSY	1	
2	3KL-85560-00-00	BASE ASSY	1	
3	37A-85520-M1-00	. COIL, CHARGE	1	
4	52W-81313-M0-00	. COIL, LIGHTING 1	1	
5	1HH-85580-M0-00	. COIL, PULSER	1	
6	98517-04012-00	. SCREW, PAN HEAD	2	
7	98517-04025-00	. SCREW, PAN HEAD	2	
8	98507-04010-00	. SCREW, PAN HEAD	1	
9	92907-04100-00	. WASHER, SPRING	1	
10	98507-04006-00	. SCREW	1	
11	92907-04100-00	. WASHER, SPRING	1	
12	93104-19097-00	. OIL SEAL	1	
13	95317-12600-00	NUT	1	
14	92907-12600-00	WASHER	1	
15	98707-06016-00	SCREW, FLAT HEAD	2	



FLASHER LIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-83310-00-00	FRONT FLASHER LIGHT ASSY 1	1	
2	3NS-83331-00-00	. BULB	1	
3	2EK-83312-00-00	. LENS, FLASHER	1	
4	2EK-83313-00-00	. GASKET, FLASHER LENS ...	1	
5	97707-40116-00	. SCREW, TAPPING	1	
6	2EK-83320-00-00	FRONT FLASHER LIGHT ASSY 2	1	
7	3NS-83331-00-00	. BULB	1	
8	2EK-83322-00-00	. LENS, FLASHER 2	1	
9	2EK-83313-00-00	. GASKET, FLASHER LENS ...	1	
10	97707-40116-00	. SCREW, TAPPING	1	
11	97707-50012-00	SCREW, TAPPING	4	
12	2EK-85111-00-00	REFLECTOR, FRONT 1	2	
13	95707-05500-00	NUT, FLANGE	4	
14	90101-05579-00	BOLT	2	
15	2EK-85127-00-00	BASE, REFLECTOR (L.H)	1	
16	2EK-851137-00-00	BASE, REFLECTOR (R.H)	1	
17	2EK-83330-00-00	REAR FLASHER LIGHT ASSY 1	1	
18	2EK-853332-00-00	. LENS, FLASHER	1	
19	97707-40620-00	. SCREW, TAPPING	1	
20	3NS-83331-00-00	. BULB	1	LM
21	2EK-83340-00-00	FLASHER LIGHT ASSY 2	1	
22	2EK-8334200-00	. LENS, FLASHER 2	1	
23	97707-40620-00	. SCREW, TAPPING	1	
24	3NS-83331-00-00	. BULB	1	LM
25	95317-12600-00	NUT	2	
26	10V-83365-00-00	CAP	2	



METER


Ref. No.	Part Number	Description	Qty	Remarks
1	3YE-83510-00-00	SPEEDOMETER ASSY	1	UR
2	3GM-83517-00-00	. BULB (12V-1.7W)	2	
3	4G1-84744-00-XX	. BULB (12V-3.4W T-10)	2	
4	3SA83509-00-00	. SOCKET CORD ASSY	1	
5	90159-03102-00	. SCREW, WITH WASHER	3	
6	36F-83549-00-00	. SCREW, TAPPING	2	
7	90167-05030-00	SCREW, TAPPING	3	
8	52W-83550-20-00	SPEEDOMETER CABLE ASSY	1	


2VK110-8280



HEADLIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-84320-00-00	LENS ASSY	1	
2	2EK-84395-00-00	RING, RETAINING	1	
3	2EK-84394-00-00	RING, MOUNTING	1	
4	2EK-84132-00-00	SPRING, SCREW	2	
5	50W-84334-00-00	NUT, ADJUSTING	2	
6	1M1-84524-60-00	SCREW, LENS FITTING	2	
7	92990-05100-00	WASHER, SPRING	4	
8	50W-84333-00-00	SCREW	4	
9	92990-05600-00	WASHER, PLATE	4	
10	90159-05089-00	SCREW, WITH WASHER	3	



2KG351-7300


TAILLIGHT

Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-84710-00-00	TAILLIGHT UNIT ASSY	1	
2	1A2-84714-41-00	. BULB (12V-21/5W)	1	
3	1M1-84521-60-00	. LENS, TAILLIGHT	1	
4	1M1-84523-60-00	. GASKET, LENS	1	
5	1M1-84524-60-00	. SCREW, LENS FITTING	2	
6	95707-06500-00	NUT, FLANGE	2	
7	1UV-84751-00-R4	BRACKET, LICENSE	1	BLACK (FOR ELECTRO DEPOSIT)
8	3L8-84544-00-00	COVER	1	
9	90387-06681-00	COLLAR	2	
10	2EK-21630-00-00	TAIL COVER ASSY	1	LOW GLOSS GRAY (OT2)
11	2EK-2163A-00-00	. COVER 1	1	LOW GLOSS GRAY (OT2)
12	2EK-2163E-00-00	. COVER 2 (LH)	1	LOW GLOSS GRAY (OT2)
13	2EK-2163F-00-00	. COVER 3 (RH)	1	LOW GLOSS GRAY (OT2)
14	97780-40120-00	. SCREW, TAPPING	2	
15	98507-06016-00	SCREW, PAN HEAD	2	
16	92907-06100-00	WASHER, SPRING	2	
17	92907-06600-00	WASHER, PLATE	2	
18	90480-10334-00	GROMMET	3	
19	3Y6-85130-02-00	REAR REFLECTOR ASSY	1	
20	95707-05500-00	NUT, FLANGE	1	



HANDLE SWITCH-LEVER

Ref. No.	Part Number	Description	Qty	Remarks
1	2EK-82910-10-00	LEVER HOLDER ASSY (LEFT)	1	
2	13T-83973-30-00	. SWITCH, HANDLE 3	1	
3	14T-83912-01-00	. LEVER 1	1	
4	90149-05119-00	. SCREW	1	
5	3E1-83980-02-00	. FRONT STOP SWITCH ASSY	1	
6	98580-05012-00	. SCREW, PAN HEAD	1	
7	98511-05020-00	. SCREW, PAN HEAD 4CU	1	
8	95707-05300-00	. NUT, FLANGE	1	
9	3L4-83943-00-00	. WASHER, STARTER	1	
10	98580-05012-00	. SCREW, PAN HEAD	1	
11	92990-05600-00	. WASHER, PLATE	1	
12	98906-04010-00	. SCREW, BLIND	2	
13	4K3-83941-00-00	. LEVER, STARTER	1	
14	3EP-82920-00-00	LEVER HOLDER ASSY (RIGHT)	1	
15	14T-83922-01-00	. LEVER 2	1	
16	90149-05119-00	. SCREW	1	
17	95617-05100-00	. NUT, U	1	
18	98517-05012-00	. SCREW, PAN HEAD	1	
19	98507-05020-00	. SCREW, PAN HEAD	1	
20	3E1-83980-02-00	. FRONT STOP SWITCH ASSY	1	



3EPH100-6320

ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
1	3JG-85540-10-00	C.D.I. UNIT ASSY	1	
2	95027-06016-00	BOLT, FLANGE	1	
3	2EX-82310-M0-00	IGNITION COIL ASSY	1	
4	56J-82370-00-00	PLUG CAP ASSY	1	
5	50W-82372-00-00	SEAL, PLUG CAP	1	
6	BTG-CB4LB-00-00	BATTERY ASSY	1	
7	133-82131-00-00	BAND, BATTERY	1	
8	90445-084A7-00	HOSE	1	
9	54V-82116-00-00	WIRE, MINUS LEAD	1	
10	4CK-81960-01-00	RECTIFIER & REGULATOR ASSY	1	
11	90153-06034-00	SCREW, HEXAGON	1	
12	29U-81950-93-00	RELAY ASSY	1	
13	3KL-82501-00-00	MAIN SWITCH STEERING LOCK	1	
14	90149-06250-00	SCREW	2	
15	3EP-82590-00-00	WIRE HARNESS ASSY	1	
16	27V-82151-00-00	. FUSE	1	
17	25G-83936-01-00	BAND, SWITCH CORD	3	
18	437-83936-11-00	BAND, SWITCH CORD	1	
19	53L-85720-00-00	OIL LEVEL GAUGE ASSY	1	
20	29G-83350-20-00	FLASHER RELAY ASSY	1	
21	3XV-83371-00-00	HORN	1	
22	98507-06010-00	SCREW, PAN HEAD	1	
23	1YU-85752-00-00	SENDER UNIT ASSY FUEL METER	1	