

PARTS CATALOGUE
MODEL YEAR 2000
BANSHEE
YFZ350M (5FK6)

Color Code	Color Name	Abbrevi- ation
0UJ	RADICAL WHITE	RW
583	DEEP PURPLISH BLUE SOLID E	DPBSE
0TR	ROMANTIQUE ROUGE	RTR

OWNERS LIT-11626-13-09
ASSEMBLY LIT-11666-07-86
SERVICE LIT-11616-YF-35 MAIN
LIT-11616-10-95 SUPPL

FOREWORD

-INTRODUCTION- To The Yamaha Parts Fiche

This parts fiche lists parts and sub-assemblies for the YFZ350M. When preparing a parts order, please refer to the most recently updated microfiche for this model.

THE YAMAHA PARTS FICHE

SYMBOLS

[] Inactive, no longer available
U.R. Use size (thickness) and/or number as required
U.N. Use as many as you need
T Number of teeth in a gear
V Voltage for light bulbs
S "S" type oil seal or "S" type circlip
SD,SO,SW "SD", "SO", or "SW" type oil seal
E,R "E" or "R" type circlip
F/No. Frame No. (Applicable Machine No.)
L.M. Locally made
O.L. Obtain locally
AP Alternate Part

SUPERSEDED PART NUMBERS

If part 'A' has been superseded by part 'B', the superseding part number "B" will appear in the part number listing with the superseded part number "A" appearing in parentheses immediately following the description.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
	(Part 'B')	(Part 'A')	
8	123-45678-00-00	CYLINDER (111-12345-00-00)	1

A part that has been supersede to a kit may be identified by a 99999-00000-00 part number appearing in the part number column. The old superseded part number will appear in parentheses immediately following the description. Listed directly below the 99999 part number will be those parts making up the kit. The description of the parts making up the kit will be preceded by a small black dot (.) and the description will be indented one letter space.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
8	99999-12345-00	CYLINDER (111-12345-00-00)	1
	234-56789-00-00	• HEAD, CYLINDER	1
	345-67890-00-00	• GASKET, CYLINDER	1

SIZES

Except for steel balls (ball sizes are indicated in inches), all parts sizes are indicated in millimeters as in the following examples:

Hose (Rubber or Vinyl)Inside Diameter - Length

O-RingSection Area - Inside Diameter

Washer, Shim, Collar.....Inside Diameter - Outside Diameter
Thickness (Length)

ASSEMBLIES AND COMPONENT PARTS

Assemblies and their component parts, are identified by an indentation of one letter space, and the description is preceded by a dot (.). If two main assemblies are listed, and have the same basic description (i.e.: left and right sides of the same assembly), one will immediately follow the other. If each of these main assemblies is made up of almost the same components, these component parts will be listed immediately under the second main assembly line and will be indicated, as noted above.


If the component is the same for both main assemblies, the quantity indicated will be the total required. If the component is not the same for both main assemblies, the quantity for each separate item will be listed separately.

EXAMPLE:


Description	Qty
CARBURETOR ASSY, LEFT	1
CARBURETOR ASSY, RIGHT	1
. JET, PILOT	2
. NOZZLE, MAIN	2
. LEVER, STARTER, LEFT	1
. LEVER, STARTER, RIGHT	1

APPLICABLE SERIAL NO.

(1) Engine Serial No.



(2) Frame Serial No.




FOREWORD

THE YAMAHA PART NUMBER

The Yamaha part number consists of 12 digits. Each number represents a specific piece of information relating to a replacement part. The following is a guide for reading and interpreting the Yamaha part number.

BASIC PART NUMBER CONFIGURATION:



MODEL CODE NUMBER

FIRST THREE DIGITS . . . 000-00000-00-00


Every model in each Yamaha product line is assigned a model number to identify that particular model. All component parts are given the model code number relating to the model on which they were first used.

Example: 4DU-00000-00-00 identifies the XJ600SE.
3FA-00000-00-00 identifies the YFA1E.

BASIC CODE NUMBER


MIDDLE FIVE DIGITS . . . 000-00000-00-00

These “Middle Five Digits” indicate the type of part i.e., piston, rings, lower units, etc. The five digits are broken down as follows:



The “Major Classification” indicates the section to which the parts belong, i.e., engine, electrical etc. The “Intermediate” and “Minor Classifications” indicate more specific details.

Example:



DESIGN CODE NUMBER: 000-00000-00-00

The design code distinguishes like component parts from one another when specification differences are involved. For example, distinguishing a standard size piston ring from an oversized piston ring.

Example:

4BR-11610- 0 0-00 Standard Piston Ring Set for XJ600SE
4BR-11610- 2 0-00 Oversize Piston Ring Set for XJ600SE

DESIGN CHANGE CODE NUMBER: 000-00000-00-00

This code number is used to identify a difference between a new component part and old one when a new part is created by changing the old one.

Example: YFZ350E

2GU-11610-0 0 -00 PISTON RING SET, STD. - ORIGINAL
2GU-11610-0 1 -00 PISTON RING SET, STD. - FIRST DESIGN CHANGE


Only major changes to performance, durability, quality, appearance, cost or interchangeability will affect a part number change.

COLOR CODE & SIZE CODE NUMBER: 000-00000-00-00

When applicable, the last two digits of the part number identify:

1. Color Code: The painted color or type of plating or surface treatment used on certain parts.
2. Size Code: The last two digits are also used to show the size of parts (mm). Such as the thickness of shims or the size of pistons.

HARDWARE (Fastener) PART NUMBER CONFIGURATION:



TYPE:

A fastener part number always begins with the number “9” followed by either a 0, 1, 2, 3, 4, 5, 6, 7 or 8 designating one of eight major divisions within this group.


FOREWORD

Example:

9 0 000-00000-00 "0" designates various types.
9 1 000-00000-00 "1" designates bolts, cotter pins, etc.
9 2 000-00000-00 "2" designates screw, nuts, etc.
9 3 000-00000-00 "3" designates oil seals, o-rings, bearings, etc.
9 4 000-00000-00 "4" designates spark plugs.
9 5 000-00000-00 "5" designates bolts and nuts.
9 7 000-00000-00 "7" designates ISO bolts.
9 8 000-00000-00 "8" designates ISO screws and nuts.

The only major divisions which the mechanic should become familiar with are those related to the general hardware (nuts, bolts, and washers), since these are the most commonly used and most often replaced items. By knowing how to interpret the part number, the dimensions of a piece of hardware can be determined. This can be very helpful during major engine repair, and general parts replacement.


BOLT EXAMPLE:



EXCEPTION:

It is NOT possible to identify the LENGTH of bolts having a 901 prefix. Only the bolt diameter can be identified with this number.


NUT AND WASHER EXAMPLE:




-MODEL LABEL-

A label called "Model Label" is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross-reference the "model code - production code No." in the catalogue to the "model code - production code No." indicated on the Model Label affixed onto the product concerned.

"MODEL LABEL" INDICATION



MODEL LABEL AFFIXING LOCATION




MODEL CODE - PRODUCTION CODE NUMBER OF MODEL LISTED
IN THIS PARTS CATALOG

Model Code	Production Code No.	Country (destination)
5FK6	010	USA

CYLINDER


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-11111-00-00	HEAD, CYLINDER 1	1	
2	NGK-B8ES0-00-00	NGK B8ES 10PK	2	UR
3	90116-08394-00	BOLT, STUD	8	
4	95917-08640-00	BOLT, STUD	2	
5	90179-08299-00	NUT	10	
6	47X-11355-00-00	SEAL, CYLINDER 1	2	
7	2GU-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
8	2GU-11311-00-00	CYLINDER 1	1	
9	2GU-11321-00-00	CYLINDER 2	1	
10	95827-06010-00	BOLT, FLANGE	2	
11	90430-06166-00	GASKET	2	
12	3GG-11351-00-00	GASKET, CYLINDER	2	
13	90116-08318-00	BOLT, STUD	4	
14	90116-08388-00	BOLT, STUD	2	
15	90116-08064-00	BOLT, STUD	2	
16	99510-10114-00	PIN, DOWEL	4	
17	90179-08299-00	NUT	8	



2GU110-7010

CRANKSHAFT - PISTON



Ref. No.	Part Number	Description	Qty	Remarks
1	29L-11400-30-00	CRANKSHAFT ASSEMBLY . . .	1	
2	29L-11412-00-00	. CRANK 1	1	
3	29L-11409-30-00	. CRANK SUB ASSEMBLY	1	
4	29L-11442-10-00	. CRANK 4	1	
5	93306-30548-00	. BEARING	1	
6	90209-22292-00	. WASHER	4	
7	93310-522L4-00	. BEARING	2	
8	29L-11651-00-00	. ROD, CONNECTING	2	
9	93306-30549-00	. BEARING	1	
10	90280-05033-00	KEY, WOODRUFF	1	
11	93103-25108-00	OIL SEAL	1	
12	278-17424-01-00	CIRCLIP 1	1	
13	93103-40077-00	OIL SEAL	1	
14	2GU-11631-00-94	PISTON (STD)	2	
	2GU-11635-00-00	PISTON (0.25MM O/S)	2	AP
	2GU-11636-00-00	PISTON (0.50MM O/S)	2	AP
15	2GU-11610-01-00	PISTON RING SET (STD)	2	
	2GU-11610-11-00	PISTON RING SET (0.25MM O/S)	2	AP
	2GU-11610-21-00	PISTON RING SET (0.50MM O/S)	2	AP
16	4L0-11633-00-00	PIN, PISTON	2	
17	93310-316H6-00	BEARING	2	
18	93450-17129-00	CIRCLIP	4	



 29L010-3021

WATER PUMP


Ref. No.	Part Number	Description	Qty	Remarks
1	4L0-12450-01-00	IMPELLER SHAFT ASSEMBLY	1	
2	93306-30002-00	BEARING	1	
3	93103-10147-00	OIL SEAL	1	
4	93603-22028-00	PIN, DOWEL	1	
5	4L0-12459-00-00	GEAR, IMPELLER SHAFT	1	
6	99001-07600-00	CIRCLIP	1	
7	90201-08784-00	WASHER, PLATE	1	
8	4L0-12436-00-00	GEAR, DRIVE	1	
9	4L0-12422-00-00	COVER, HOUSING	1	
10	3GG-12428-00-00	GASKET, HOUSING COVER 2 .	1	
11	98507-06016-00	SCREW, PAN HEAD	5	



29L010-3040

RADIATOR - HOSE

Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-12485-00-00	PIPE 5	1	
2	90467-13083-00	CLIP	2	
3	2GU-12460-01-00	RADIATOR ASSEMBLY	1	
4	22W-12462-00-00	. CAP, RADIATOR	1	
5	90480-15470-00	GROMMET	3	
6	95807-06025-00	BOLT, FLANGE	3	
7	90387-0714B-00	COLLAR	2	
8	90387-063G3-00	COLLAR	1	
9	90201-060A3-00	WASHER, PLATE	3	
10	29L-12481-00-00	PIPE 1	1	
11	90460-27219-00	CLAMP, HOSE	2	
12	4L0-12479-00-00	JOINT	1	
13	3XV-12435-00-00	GASKET	1	
14	91317-06020-00	BOLT	2	
15	29L-12469-00-00	JOINT 1	1	
16	93210-17239-00	O-RING	1	
17	93440-19083-00	CIRCLIP	1	
18	2GU-12482-00-00	PIPE 2	1	
19	90460-27219-00	CLAMP, HOSE	2	
20	2GU-12484-00-00	PIPE 4	1	
21	11H-12516-00-00	COVER, WATER INLET	1	
22	90460-27219-00	CLAMP, HOSE	2	




2G110-7040

INTAKE


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-13610-01-00	REED VALVE ASSEMBLY	2	
2	2GU-13613-00-00	. REED, VALVE	2	
3	2GU-13616-00-00	. STOPPER, REED VALVE	2	
4	98507-03008-00	SCREW, PAN HEAD	4	
5	92907-03100-00	WASHER	4	
6	3GG-13621-00-00	GASKET, VALVE SEAT	2	
7	31K-13565-01-00	JOINT, CARBURETOR	2	
8	91317-06025-00	BOLT	8	
9	29L-14465-00-00	PIPE	1	
10	90467-20085-00	CLIP	2	
11	90450-44046-00	HOSE CLAMP ASSEMBLY . . .	2	
12	2GU-14411-00-00	CASE, AIR CLEANER 1	1	
13	2GU-14421-00-00	CASE, AIR CLEANER 2	1	
14	2GU-14412-00-00	CAP, CLEANER CASE 1	1	
15	2GU-14451-00-00	ELEMENT, AIR CLEANER	1	
16	2GU-14458-00-00	GUIDE	1	
17	2GU-14468-00-00	PLATE, ELEMENT FITTING . . .	1	
18	2GU-14459-00-00	HOLDER, GUIDE	1	
19	29L-14453-01-00	JOINT, AIR CLEANER 1	2	
20	90460-68230-00	CLAMP, HOSE	2	
21	12R-14452-00-00	SEAL	1	
22	97707-50525-00	SCREW, TAPPING	6	
23	29L-14452-00-00	SEAL	1	
24	90465-18312-00	CLAMP	4	
25	90468-05184-00	CLIP	4	
26	2GU-14437-00-00	DUCT	1	
27	90460-99291-00	CLAMP, HOSE	1	
28	59V-14457-00-00	SEAL	1	
29	90467-22080-00	CLIP	1	

CONTINUED ON NEXT FRAME ►



INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
30	90480-18171-00	GROMMET	2	
31	90119-06096-00	BOLT, WITH WASHER	2	




3GG2100-0050

CARBURETOR


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-14101-01-00	CARBURETOR ASSEMBLY 1 .	1	
2	2GU-14102-01-00	CARBURETOR ASSEMBLY 2 .	1	
3	304-14184-00-00	. GASKET, FLOAT CHMBR ...	1	
4	260-14142-25-00	. JET, PILOT (# 25)	1	
5	98502-04008-00	. SCREW, PAN HEAD	1	
6	2H0-14146-00-00	. PLATE	1	
7	4L0-14185-00-00	. FLOAT	1	
8	1UA-14190-28-00	. NEEDLE VALVE ASSEMBLY .	1	
9	537-14186-00-00	. PIN, FLOAT	1	
10	2GU-14112-20-00	. VALVE, THROTTLE 1	1	UR FOR LEFT
	2GU-14113-20-00	. VALVE, THROTTLE 2	1	UR FOR RIGHT
11	137-14143-38-00	. JET, MAIN (#190)	1	UR
	137-14143-40-00	. JET, MAIN (#200)	1	UR STD
	137-14143-44-00	. JET, MAIN (#220)	1	UR
	137-14143-48-00	. JET, MAIN (#240)	1	UR
12	137-14153-00-00	. WASHER, MAIN JET	1	
13	4L0-14141-38-00	. NOZZLE, MAIN	1	
14	2GU-14196-00-00	. PIPE	1	
15	98511-04016-00	. SCREW, PAN HEAD	4	
16	92990-04100-00	. WASHER, SPRING	4	
17	4L0-14197-00-00	. PIPE	2	
18	2GU-14153-00-00	. RING	1	
19	2GU-14131-00-00	. SPRING, THROTTLE VALVE .	1	
20	239-14172-16-00	. PILOT JET, AIR (1.6)	1	
21	12R-14191-00-00	. PLUG, DRAIN	1	
22	10W-14104-00-00	. AIR SCREW SET	1	
23	2GU-1490J-00-00	. NEEDLE SET	1	
24	500-14146-00-00	. PLATE	1	
25	2GU-14171-00-00	. PLUNGER, STARTER	1	


CONTINUED ON NEXT FRAME ➤



CARBURETOR

Ref. No.	Part Number	Description	Qty	Remarks
26	558-14147-00-00	. O-RING	1	
27	2GU-14161-00-00	. NUT, CABLE ADJUSTING ...	1	
28	98501-05008-00	. SCREW, PAN HEAD	1	
29	92901-05100-00	. WASHER, SPRING	1	
30	2GU-14146-00-00	. PLATE	1	UR FOR RIGHT
	2GU-14243-00-00	. PLATE	1	UR FOR LEFT
31	2GU-14952-00-00	. WASHER	1	
32	3GG-8259E-00-00	SWITCH ASSEMBLY	2	
33	2GU-2633K-00-00	WIRE, INNER 1	2	
34	98507-03010-00	SCREW, PAN HEAD	6	
35	92907-03100-00	WASHER	6	
36	92907-03600-00	WASHER	6	
37	4X7-24311-00-00	PIPE, FUEL 1	1	
38	48H-24311-00-00	PIPE, FUEL 1	1	
39	90413-08009-00	WAY 3	1	
40	90467-10008-00	CLIP	2	
41	90467-11106-00	CLIP	2	
42	90445-09012-00	HOSE	1	
43	90460-49058-00	CLAMP, HOSE	2	






EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-14610-00-00	EXHAUST PIPE ASSEMBLY 1 .	1	
2	2GU-14620-00-00	EXHAUST PIPE ASSEMBLY 2 .	1	
3	90507-20030-00	SPRING, TENSION	4	
4	93210-45742-00	O-RING	2	
5	2GU-14771-00-00	STAY, MUFFLER 1	2	
6	95817-08014-00	BOLT, FLANGE	4	
7	90201-08326-00	WASHER, PLATE	4	
8	2GU-14635-00-00	JOINT, EXHAUST 3	1	
9	2GU-14645-00-00	JOINT, EXHAUST 4	1	
10	2GU-14718-00-00	PROTECTOR, MUFFLER 1	1	
11	2GU-14728-00-00	PROTECTOR, MUFFLER 2	1	
12	98907-06010-00	SCREW, BIND	4	
13	4BD-14766-00-00	WASHER, PROTECTOR	8	
14	90206-06090-00	WASHER, WAVE	4	
15	1W2-14714-00-00	GASKET, MUFFLER	2	
16	2GU-14615-00-00	JOINT, EXHAUST 1	2	
17	90460-37026-00	CLAMP, HOSE	4	
18	90460-37026-00	CLAMP, HOSE	4	
19	2GU-14753-01-00	SILENCER, EXHAUST	1	
20	2GU-14765-01-00	SILENCER	1	
21	2GU-14752-00-00	PIPE, OUTLET	2	
22	2GU-14613-10-00	GASKET, EXHAUST PIPE	2	
23	98907-06010-00	SCREW, BIND	6	
24	95817-08014-00	BOLT, FLANGE	2	
25	95817-08014-00	BOLT, FLANGE	2	
26	95817-08014-00	BOLT, FLANGE	2	
27	90506-18398-00	SPRING, TENSION	1	


CRANKCASE

Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-15100-01-00	CRANKCASE ASSEMBLY	1	
2	99510-12016-00	. PIN, DOWEL	2	
3	2GU-15316-00-00	. DAMPER, ENGINE MOUNT 1 .	2	
4	2GU-15326-00-00	. DAMPER, ENGINE MOUNT 2 .	2	
5	2GU-15328-00-00	. SPACER, DAMPER	2	
6	120-15371-00-00	. BREATHER	1	
7	90445-09109-00	. HOSE	1	
8	90383-12022-00	. BUSH, FORMED	1	
9	90445-081F1-00	HOSE	1	
10	90445-09123-00	HOSE	1	
11	90413-05014-00	WAY 3	1	
12	90467-08021-00	CLIP	1	
13	90467-07093-00	CLIP	1	
14	90467-08075-00	CLIP	3	
15	278-15492-01-00	COVER	1	
16	98507-05010-00	SCREW, PAN HEAD	2	
17	90340-14132-00	PLUG, STRAIGHT SCREW	1	
18	90430-14043-00	GASKET	1	
19	90116-08064-00	BOLT, STUD	6	
20	90116-08232-00	BOLT, STUD	2	
21	95707-08500-00	NUT, FLANGE	8	
22	97017-06045-00	BOLT	2	
23	97017-06060-00	BOLT	5	
24	97017-06090-00	BOLT	1	
25	92907-06200-00	WASHER	8	
26	90462-16130-00	CLAMP	1	
27	90465-06094-00	CLAMP	1	
28	90338-06190-00	PLUG	1	



CRANKCASE COVER 1


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-15411-00-00	COVER, CRANKCASE 1	1	
2	2GU-15379-00-00	SEAL, CRANKCASE	1	
3	98507-06055-00	SCREW, PAN HEAD	3	
4	98507-06020-00	SCREW, PAN HEAD	4	
5	2GU-15421-00-00	COVER, CRANKCASE 2	1	
6	2GU-15189-00-00	PLUG	1	
7	90338-15189-00	PLUG	1	
8	3GG-15461-01-00	GASKET, CRANKCASE COVER 2	1	
9	99510-12016-00	PIN, DOWEL	1	
10	98507-06040-00	SCREW, PAN HEAD	1	
11	98507-06030-00	SCREW, PAN HEAD	8	
12	4L0-15362-00-00	PLUG, OIL LEVEL	1	
13	93210-19123-00	O-RING	1	
14	2GU-15416-00-00	COVER, OIL PUMP	1	
15	2GU-15337-00-00	DAMPER 4	1	
16	2GU-15338-00-00	DAMPER, ENGINE MOUNT 5	1	
17	98507-06020-00	SCREW, PAN HEAD	3	
18	4L0-15431-01-00	COVER, CRANKCASE 3	1	
19	31K-15317-00-00	SPACER, ENGINE MOUNT	1	
20	48H-15327-00-00	SPACER, ENGINE MOUNT	1	
21	98507-05014-00	SCREW, PAN HEAD	3	
22	90465-32317-00	CLAMP	1	




2GU110-7090

STARTER

Ref. No.	Part Number	Description	Qty	Remarks
1	4L0-15660-01-00	KICK AXLE ASSEMBLY	1	
2	4L0-15641-00-00	GEAR, KICK (22T)	1	
3	90468-26091-00	CLIP	1	
4	90508-30051-00	SPRING, TORSION	1	
5	4L0-15666-00-00	SPACER	1	
6	248-15668-00-00	STOPPER	1	
7	93102-20484-00	OIL SEAL	1	
8	4L0-15651-00-00	GEAR, KICK IDLE (26T)	1	
9	164-17417-00-10	SHIM 1 (1.0T)	1	
10	90214-15020-00	WASHER, CLAW	1	
11	99009-15400-00	CIRCLIP	1	
12	2GU-15620-01-00	KICK CRANK ASSEMBLY	1	
13	93507-32031-00	. BALL 7/ 2	1	
14	90501-12081-00	. SPRING, COMPRESSION	1	
15	93210-14369-00	. O-RING	1	
16	90152-06010-00	. SCREW, COUNTERSUNK ...	1	
17	90336-42049-00	. PLUG, TAPER	1	
18	97027-08030-00	BOLT	1	



2GU110-7100




CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	4L0-16111-00-00	GEAR, PRIMARY DRIVE (23T)	1	
2	90282-07023-00	KEY, STRAIGHT	1	
3	90208-16019-00	WASHER, CONICAL SPRING	1	
4	90170-16425-00	NUT	1	
5	31K-16150-10-00	PRIMARY DRIVEN GEAR COMP.	1	
6	1A0-16371-00-00	BOSS, CLUTCH	1	
7	5Y1-16331-01-00	PLATE, FRICTION 2	7	
8	498-16325-00-00	PLATE, CLUTCH 2	6	
9	29L-16351-00-00	PLATE, PRESSURE 1	1	
10	29L-16356-00-00	ROD, PUSH 1	1	
11	90149-08143-00	SCREW, SPEC'L SHAPE	1	
12	92907-08200-00	WASHER	1	
13	95317-08700-00	NUT	1	
14	90501-23138-00	SPRING, COMPRESSION	6	
15	90159-06016-00	SCREW, WITH WASHER	6	
16	360-16154-00-00	PLATE, THRUST 1	1	
17	278-16367-00-00	RING, CUSHION	7	
18	278-16181-01-00	SPACER 1	1	
19	360-16154-00-00	PLATE, THRUST 1	1	
20	90215-20223-00	WASHER, LOCK	1	
21	90170-20320-00	NUT, HEXAGON	1	
22	93515-32029-00	BALL	1	
23	29L-16357-00-00	ROD, PUSH 2	1	
24	29L-16380-00-00	PUSH LEVER ASSEMBLY	1	
25	93102-17004-00	OIL SEAL, SD-TYPE	1	
26	93315-11720-00	BEARING	1	
27	90201-17327-00	WASHER, PLATE	1	
28	90508-16599-00	SPRING, TORSION	1	

CONTINUED ON NEXT FRAME ►

CLUTCH


Ref. No.	Part Number	Description	Qty	Remarks
29	90465-16239-00	CLAMP	1	
30	97007-06010-00	BOLT	1	



TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-17411-00-00	AXLE, MAIN	1	
2	93305-20508-00	BEARING	1	
3	93440-52009-00	CIRCLIP	1	
4	2GU-17121-00-00	GEAR, 2ND PINION (16T)	1	
5	2GU-17131-00-00	GEAR, 3RD/4TH PINION (18T/20T)	1	
6	2GU-17151-00-00	GEAR, 5TH PINION (22T)	1	
7	2GU-17161-00-00	GEAR, 6TH PINION (24T)	1	
8	90201-256E6-00	WASHER, PLATE (T=0.9)	1	
9	93440-25084-00	CIRCLIP	2	
10	90209-21105-00	WASHER	1	
11	90201-20266-00	WASHER, PLATE (1.0T)	1	
12	99009-20400-00	CIRCLIP	1	
13	93311-22005-00	BEARING	1	
14	4L0-17471-00-00	PLATE, COVER	1	
15	98507-06012-00	SCREW, PAN HEAD	2	
16	29L-17421-00-00	AXLE, DRIVE	1	
17	93311-42006-00	BEARING	1	
18	278-17425-00-00	CIRCLIP 2	1	
19	2GU-17211-00-00	GEAR, 1ST WHEEL (32T)	1	
20	2GU-17221-00-00	GEAR, 2ND WHEEL (29T)	1	
21	2GU-17231-00-00	GEAR, 3RD WHEEL (27T)	1	
22	2GU-17241-00-00	GEAR, 4TH WHEEL (25T)	1	
23	2GU-17251-00-00	GEAR, 5TH WHEEL (23T)	1	
24	2GU-17261-01-00	GEAR, 6TH WHEEL (21T)	1	
25	90209-21105-00	WASHER	2	
26	93440-25084-00	CIRCLIP	4	
27	90201-20276-00	WASHER, PLATE (1.0T)	1	
28	99009-20400-00	CIRCLIP	1	


CONTINUED ON NEXT FRAME ►



2GU110-7120

TRANSMISSION


Ref. No.	Part Number	Description	Qty	Remarks
29	90201-25490-00	WASHER, PLATE	1	
30	93306-30504-00	BEARING (B6305N)	1	
31	278-17424-01-00	CIRCLIP 1	1	
32	90387-257N4-00	COLLAR	1	
33	93102-35369-00	OIL SEAL	1	
34	93834-14050-00	SPROCKET, DRIVE 14T (23X1746140)	1	
35	90215-21121-00	WASHER, LOCK	1	
36	90179-18020-00	NUT	1	



26U110-7120

SHIFT CAM - FORK


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-18540-00-00	SHIFT CAM ASSEMBLY	1	
2	93315-23612-00	. BEARING	1	
3	93440-34025-00	. CIRCLIP	1	
4	4L0-18185-00-00	. SEGMENT	1	
5	3R4-18561-00-00	. PLATE, SIDE 1	1	
6	98707-05016-00	. SCREW, FLAT HEAD	1	
7	93604-12037-00	PIN, DOWEL	1	
8	4L0-18562-00-00	PLATE, STOPPER 2	1	
9	98707-06014-00	SCREW, FLAT HEAD	2	
10	4L0-18140-00-00	STOPPER LEVER ASSEMBLY	1	
11	90508-29728-00	SPRING, TORSION	1	
12	90109-063F7-00	BOLT	1	
13	2GU-18511-00-00	FORK, SHIFT 1	2	
14	2GU-18512-00-00	FORK, SHIFT 2	1	
15	4L0-18531-01-00	BAR, SHIFT FORK GUIDE 1	1	
16	29L-18535-00-00	BAR, SHIFT FORK GUIDE 2	1	
17	93430-08007-00	CIRCLIP, E-TYPE	2	
18	90334-10006-00	PLUG, STRAIGHT	2	



2G0110 - 7130

SHIFT SHAFT


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-18101-00-00	SHIFT SHAFT ASSEMBLY	1	
2	90560-12171-00	SPACER	1	
3	90508-32374-00	SPRING, TORSION	1	
4	90149-08256-00	SCREW	1	
5	90215-08174-00	WASHER, LOCK	1	
6	90170-08029-00	NUT	1	
7	93102-12106-00	OIL SEAL (SD 12-22-5 HS)	1	
8	2GU-18110-01-00	SHIFT PEDAL ASSEMBLY	1	
9	132-18113-01-00	. COVER, SHIFT PEDAL	1	
10	97017-08020-00	BOLT	1	



3GGA010-2140

FRAME

Ref. No.	Part Number	Description	Qty	Remarks
1	3GG-21110-21-35	FRAME COMP.	1	SL
2	2GU-21315-00-00	STAY, ENGINE 2	1	
3	2GU-21316-00-00	STAY, ENGINE 3	1	
4	95817-08025-00	BOLT, FLANGE	4	
5	90105-10444-00	BOLT, WASHER BASED	1	
6	92907-10100-00	WASHER, SPRING	1	
7	95317-10600-00	NUT	1	
8	92990-10600-00	WASHER, PLATE	1	
9	90105-10328-00	BOLT, WASHER BASED	1	
10	92907-10100-00	WASHER, SPRING	1	
11	95317-10600-00	NUT	1	
12	92990-10600-00	WASHER, PLATE	1	
13	2HH-22178-00-00	TENSIONER	2	
14	93300-60804-00	BEARING	2	
15	90201-086P8-00	WASHER, PLATE	2	
16	90387-086N4-00	COLLAR	2	
17	95027-08045-00	BOLT, FLANGE	2	
18	95607-08200-00	NUT, SELF-LOCKING	2	
19	93306-20331-00	BEARING	1	
20	93102-25081-00	OIL SEAL	1	
21	93102-25099-00	OIL SEAL	1	
22	2GU-23872-00-00	HOLDER, BEARING	1	
23	90480-12299-00	GROMMET	2	
24	2GU-21317-00-00	STAY, ENGINE 3	1	
25	2GU-21318-00-00	STAY, ENGINE 4	1	
26	97027-10020-00	BOLT	2	
27	92907-10100-00	WASHER, SPRING	2	
28	92907-10600-00	WASHER, PLATE	2	
29	2GU-21314-00-00	STAY, ENGINE 5	2	




3GG4100-1150

CONTINUED ON NEXT FRAME ➤

FRAME


Ref. No.	Part Number	Description	Qty	Remarks
30	4L0-21485-00-00	DAMPER, RUBBER 1	4	
31	92907-10600-00	WASHER, PLATE	2	
32	97027-10045-00	BOLT	2	
33	92907-10100-00	WASHER, SPRING	2	
34	92907-10600-00	WASHER, PLATE	2	
35	97027-10040-00	BOLT	2	
36	92907-10100-00	WASHER, SPRING	2	
37	4N0-27114-00-00	STOPPER, MAIN STAND	2	
38	2GU-28100-10-00	TOOL KIT	1	
39	1NV-2811A-00-00	GAUGE, AIR	1	




3GG4100-1150

FRONT FENDER


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-W2151-91-00	FRONT FENDER COMP.	1	UR RW
	2GU-W2151-B1-00	FRONT FENDER COMP.	1	UR DPBSE
2	90149-06306-00	SCREW	4	
3	2GU-21513-00-00	STAY, FENDER 1	1	
4	95827-06010-00	BOLT, FLANGE	1	
5	90149-06306-00	SCREW	1	
6	95607-06100-00	NUT, U	1	
7	2GU-21514-00-00	STAY, FENDER 2	1	
8	95827-06010-00	BOLT, FLANGE	1	
9	90149-06306-00	SCREW	1	
10	95607-06100-00	NUT, U	1	
11	2GU-21587-00-00	STAY 1	1	
12	97027-08016-00	BOLT	1	
13	2GU-21588-00-00	STAY 2	1	
14	97027-08016-00	BOLT	1	
15	95607-06100-00	NUT, U	1	
16	95607-06100-00	NUT, U	1	



3GGI00-9I60

REAR FENDER


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-W2161-91-00	REAR FENDER COMP.	1	UR RW
	2GU-W2161-B1-00	REAR FENDER COMP.	1	UR DPBSE
2	90119-06056-00	BOLT, WITH WASHER	4	
3	90149-06306-00	SCREW	2	
4	90150-06037-00	SCREW, ROUND HEAD	2	
5	95607-06100-00	NUT, U	4	
6	92907-06200-00	WASHER	4	
7	3GG-21691-00-00	FLAP	1	YB
8	3GG-21621-00-00	FLAP	1	YB
9	90149-06306-00	SCREW	2	
10	95607-06100-00	NUT, U	2	
11	92907-06200-00	WASHER	2	



3GG2100-0170

SIDE COVER

Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-W2175-80-00	SIDE COVER 1	1	UR FOR DPBSE
	2GU-W2175-90-00	SIDE COVER 1	1	UR RTR
2	2GU-21721-80-00	COVER, SIDE 2	1	UR DPBSE
	2GU-21721-90-00	COVER, SIDE 2	1	UR FOR RTR
3	90267-40076-00	RIVET, BLIND	2	
4	90201-047A2-00	WASHER, PLATE	2	
5	2GU-21747-00-00	DAMPER	1	
6	90183-05024-00	NUT, SPRING	2	
7	2GU-23391-60-00	PANEL, FRONT	1	UR ROMANTIQUE ROUGE
	2GU-23391-80-00	PANEL, FRONT	1	UR DPBSE
8	90154-05013-00	SCREW, BINDING	5	
9	90159-06082-00	SCREW, WITH WASHER	2	
10	2GU-2171L-00-00	MOLE, SIDE COVER 1	2	
11	2GU-21871-00-00	TANK, RECOVERY	1	
12	90480-48399-00	GROMMET	1	
13	10V-21875-00-00	CAP	1	
14	90445-084J0-00	HOSE	1	
15	90467-08075-00	CLIP	1	
16	90445-090F7-00	HOSE	1	
17	90467-08003-00	CLIP	2	




5FK6100-0180

REAR ARM


Ref. No.	Part Number	Description	Qty	Remarks
1	3GG-22110-00-35	REAR ARM COMP.	1	SL
2	93317-22237-00	BEARING	2	
3	93108-35004-00	OIL SEAL (35-41-8)	2	
4	2K6-22128-01-00	COVER, THRUST 1	2	
5	90201-244A9-00	WASHER, PLATE (2.05T)	2	
6	2GU-22184-00-00	BUSH	1	
7	2GU-22141-00-00	SHAFT, PIVOT	1	
8	90201-160F6-00	WASHER, PLATE	1	
9	90185-16127-00	NUT, SELF-LOCKING	1	
10	2GU-22151-10-00	SEAL, GUARD	1	
11	4N0-27114-00-00	STOPPER, MAIN STAND	1	
12	5X4-22199-00-00	SUPPORT, CHAIN	1	
13	95807-08040-00	BOLT, FLANGE	2	
14	1UY-2217A-00-00	ARM, RELAY	1	
15	90383-20033-00	BUSH, FORMED	2	
16	93109-20076-00	OIL SEAL	2	
17	90387-125N9-00	COLLAR	1	
18	90109-10752-00	BOLT	1	
19	93700-06004-00	NIPPLE, GREASE	1	
20	90201-10430-00	WASHER, PLATE	1	
21	90185-10120-00	NUT, SELF-LOCKING	1	
22	3GG-2217F-00-00	ROD, CONNECTING 1	1	
23	90383-20032-00	BUSH, FORMED	4	
24	23X-22129-00-00	COVER, THRUST 2	4	
25	90387-125N8-00	COLLAR	2	
26	93700-06004-00	NIPPLE, GREASE	2	
27	90109-102A6-00	BOLT	1	
28	90201-120E6-00	WASHER, PLATE	1	
29	90201-100E9-00	WASHER, PLATE	1	

CONTINUED ON NEXT FRAME ➤




REAR ARM

Ref. No.	Part Number	Description	Qty	Remarks
30	90185-10120-00	NUT, SELF-LOCKING	1	
31	90109-10654-00	BOLT	1	
32	90201-10430-00	WASHER, PLATE	1	
33	90185-10120-00	NUT, SELF-LOCKING	1	
34	3GG-2219X-00-00	COVER	1	
35	95827-08020-00	BOLT, FLANGE	4	
36	2GU-22153-00-00	GUARD, CHAIN	1	
37	97027-06045-00	BOLT	2	
38	92907-06600-00	WASHER, PLATE	2	
39	95607-06100-00	NUT, U	2	
40	92907-08600-00	WASHER, PLATE	4	
41	95607-08100-00	NUT, U	4	
42	2GU-22155-00-00	PIPE	1	



REAR SUSPENSION

Ref. No.	Part Number	Description	Qty	Remarks
1	3GG-22210-40-36	SHOCK ABSORBER ASSEMBLY, REAR	1	UR WW
	3GG-22210-40-6W	SHOCK ABSORBER ASSEMBLY, REAR	1	UR NTR
2	3GG-22201-40-00	. DAMPER SUB ASSEMBLY ..	1	
3	98507-04006-00	.. SCREW, PAN HEAD	1	
4	39W-22464-00-00	.. KNOB, CONTROL	1	
5	93399-99916-00	.. BEARING	2	
6	93440-30113-00	.. CIRCLIP	4	
7	93104-18077-00	.. OIL SEAL	4	
8	1RK-22215-00-00	.. RING, COVER	1	
9	38W-22223-00-00	.. SEAT, SPRING LOWER	1	
10	22W-22214-01-00	. GUIDE, SPRING 1	1	
11	38W-22212-10-36	. SPRING	1	UR WW
	38W-22212-10-6W	. SPRING	1	UR NTR
12	4AA-22259-00-00	. LABEL, WARNING	1	
13	90109-10704-00	BOLT	1	
14	90201-10430-00	WASHER, PLATE	1	
15	90185-10120-00	NUT, SELF-LOCKING	2	
16	90387-127G8-00	COLLAR	2	
17	90109-102A6-00	BOLT	1	
18	90201-120E6-00	WASHER, PLATE	1	
19	90201-100E9-00	WASHER, PLATE	1	
20	90387-126H8-00	COLLAR	2	






C7

Ref. No.	Part Number	Description	Qty	Remarks
1	3GG-23813-01-00	COLUMN, STEERING 2	1	
2	90336-28053-00	PLUG, TAPER	1	
3	8K1-23814-00-00	HOLDER, HANDLE	2	
4	2GU-2629K-00-00	STAY	1	
5	95827-08035-00	BOLT, FLANGE	4	
6	1UY-23812-00-00	PLANE BEARING, STEERING	2	
7	93112-31011-00	OIL SEAL	2	
8	2GU-23868-00-00	BRACKET, STEERING LOWER	1	
9	97027-08060-00	BOLT	1	
10	90109-082E9-00	BOLT	1	
11	1UY-23894-01-00	WASHER, LOCK 1	1	
12	90387-090R0-00	COLLAR	2	
13	90387-176R6-00	COLLAR	1	
14	90201-10774-00	WASHER, PLATE	1	
15	90185-10115-00	NUT, SELF-LOCKING	1	
16	91401-20020-00	PIN, COTTER	1	
17	2GU-23831-01-00	ROD, TIE	1	
18	1UY-23841-01-00	JOINT, UNIVERSAL 1	1	
19	1UY-23845-01-00	JOINT, UNIVERSAL 2	1	
20	95307-10700-00	NUT	1	
21	90170-10186-00	NUT	1	(L.H. THREAD)
22	2GU-23831-01-00	ROD, TIE	1	
23	1UY-23841-01-00	JOINT, UNIVERSAL 1	1	
24	1UY-23845-01-00	JOINT, UNIVERSAL 2	1	
25	95307-10700-00	NUT	1	
26	90170-10186-00	NUT	1	(L.H. THREAD)
27	90171-10046-00	NUT, CASTLE	2	
28	90171-10046-00	NUT, CASTLE	2	
29	91401-20020-00	PIN, COTTER	2	

CONTINUED ON NEXT FRAME ►

STEERING

Ref. No.	Part Number	Description	Qty	Remarks
30	91401-20020-00	PIN, COTTER	2	




36GS100-7220

FRONT SUSPENSION - WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-23570-00-35	FRONT LOWER ARM COMP. (LEFT)	1	SL
2	2GU-23580-00-35	FRONT LOWER ARM COMP. (RIGHT)	1	SL
3	3GG-23540-00-35	FRONT UPPER ARM COMP. (LEFT)	1	SL
4	3GG-23550-00-35	FRONT UPPER ARM COMP. (RIGHT)	1	SL
5	90381-15088-00	BUSH, SOLID	4	
6	90381-15088-00	BUSH, SOLID	4	
7	90381-15088-00	BUSH, SOLID	2	
8	90381-15088-00	BUSH, SOLID	2	
9	90387-101R3-00	COLLAR	2	
10	90387-101R3-00	COLLAR	2	
11	90387-100Y6-00	COLLAR	1	
12	90387-100Y6-00	COLLAR	1	
13	1UY-23517-00-00	COVER, THRUST 1	4	
14	1UY-23517-00-00	COVER, THRUST 1	4	
15	1UY-23517-00-00	COVER, THRUST 1	2	
16	1UY-23517-00-00	COVER, THRUST 1	2	
17	90101-10655-00	BOLT	2	
18	90101-10655-00	BOLT	2	
19	90105-10651-00	BOLT, WASHER BASED	1	
20	90105-10651-00	BOLT, WASHER BASED	1	
21	90201-10430-00	WASHER, PLATE	2	
22	90201-10430-00	WASHER, PLATE	2	
23	90201-10430-00	WASHER, PLATE	1	
24	90201-10430-00	WASHER, PLATE	1	
25	90185-10120-00	NUT, SELF-LOCKING	2	
26	90185-10120-00	NUT, SELF-LOCKING	2	

CONTINUED ON NEXT FRAME ➤




FRONT SUSPENSION - WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
27	90185-10120-00	NUT, SELF-LOCKING	1	
28	90185-10120-00	NUT, SELF-LOCKING	1	
29	93700-06004-00	NIPPLE, GREASE	2	
30	93700-06004-00	NIPPLE, GREASE	2	
31	93700-06004-00	NIPPLE, GREASE	1	
32	93700-06004-00	NIPPLE, GREASE	1	
33	3GG-23350-20-36	SHOCK ABSORBER ASSEMBLY	2	WW
	3GG-23350-20-6W	SHOCK ABSORBER ASSEMBLY	2	NTR
34	59V-2331R-00-00	. DAMPER, BUSH B	1	
35	90105-10388-00	BOLT, WASHER BASED	4	
36	90185-10060-00	NUT, SELF-LOCKING	4	



FUEL TANK


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-24110-00-00	FUEL TANK COMP.	1	
2	1UY-24610-00-00	CAP ASSY	1	
3	2GU-24500-01-00	FUEL COCK ASSY 1	1	
4	3AJ-24534-00-00	. SEAL, COCK	1	
5	97801-03008-00	. SCREW, PAN HEAD	2	
6	4X8-24512-00-00	. O-RING	1	
7	3AJ-24523-00-00	. VALVE PACKING	1	
8	90202-05193-00	WASHER, PLATE	2	
9	90149-06011-00	SCREW	2	
10	90480-18290-00	GROMMET	2	
11	90387-066J1-00	COLLAR	2	
12	97027-06030-00	BOLT	2	
13	92907-06100-00	WASHER, SPRING	2	
14	90480-01400-00	GROMMET	2	
15	90201-060L5-00	WASHER, PLATE	2	
16	90387-07598-00	COLLAR	2	
17	97027-06030-00	BOLT	2	
18	92907-06100-00	WASHER, SPRING	2	
19	90445-13693-00	HOSE	1	
20	90467-11106-00	CLIP	2	
21	90445-084J1-00	HOSE	1	



FWD
36G2100-0230

SEAT


Ref. No.	Part Number	Description	Qty	Remarks
1	5FK-24710-A0-00	SINGLE SEAT ASSEMBLY ...	1	UR DEEP PURPLE BLUE SOLID E
	5FK-24710-B0-00	SINGLE SEAT ASSEMBLY ...	1	UR HEAT RED
2	5FK-24731-A0-00	. COVER, SEAT	1	UR DEEP PURPLE BLUE SOLID E
	5FK-24731-B0-00	. COVER, SEAT	1	UR HEAT RED
3	22W-24741-00-00	. PAD, SEAT	2	
4	371-27114-00-00	. STOPPER, MAIN STAND	2	
5	95707-06500-00	. NUT, FLANGE	2	
6	3GD-24776-00-00	. LEVER, SEAT	1	
7	4K0-24775-00-00	. BRACKET, SEAT LEVER	1	
8	4K0-24774-01-00	. PIN	1	
9	90508-20454-00	. SPRING, TORSION	1	
10	93430-04002-00	. CIRCLIP	1	



2G0110-7240

FRONT WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
1	2XK-25180-01-HM	WHEEL COMP.	2	AMS
2	94107-100X3-00	TIRE (AT21X7-10**KT851A T/L N) ...	2	DUNLOP
3	93900-00022-00	VALVE, RIM	2	TAIHEIYO
4	3GD-25111-01-00	HUB, FRONT	2	
5	90114-10007-00	. BOLT, SERRATION	4	
6	1UY-25117-00-00	SPACER, BEARING	2	
7	93306-00406-00	BEARING (B6004Z)	2	UR NTN
	93306-00438-00	BEARING	2	UR
8	93306-20227-00	BEARING	2	
9	93105-26026-00	OIL SEAL	2	
10	93102-22216-00	OIL SEAL	2	
11	95707-10500-00	NUT, FLANGE	8	
12	92907-10200-00	WASHER, PLAIN	8	
13	90387-150R1-00	COLLAR	2	
14	90201-14586-00	WASHER, PLATE	2	
15	90171-14020-00	NUT, CASTLE	2	
16	91401-30025-00	PIN, COTTER	2	
17	3GD-25127-10-00	COVER, PLATE	2	
18	3GD-23501-00-00	STEERING, KNUCKLE ASSEMBLY (LEFT)	1	
19	3GD-23502-00-00	STEERING, KNUCKLE ASSEMBLY (RIGHT)	1	
20	90171-10046-00	NUT, CASTLE	2	
21	90171-10046-00	NUT, CASTLE	2	
22	91401-20020-00	PIN, COTTER	2	
23	91401-20020-00	PIN, COTTER	2	



3GGM100-6250


FRONT BRAKE CALIPER

Ref. No.	Part Number	Description	Qty	Remarks
1	3GD-2582T-00-00	DISC, BRAKE	2	
2	90149-08268-00	SCREW	8	
3	3GD-2580T-00-00	CALIPER ASSY (LEFT)	1	
4	3GD-W0057-00-00	. PISTON ASSY, CALIPER	1	
5	3GD-W0047-00-00	. . CALIPER SEAL KIT	1	
6	1UY-W0048-50-00	. BLEED SCREW KIT	1	
7	3GD-W0045-00-00	. BRAKE PAD KIT	1	
8	3GD-25827-00-00	. SHIM, CALIPER	1	
9	3GD-25933-00-00	. PIN, PAD	2	
10	3GD-2580U-00-00	CALIPER ASSY (RIGHT)	1	
11	3GD-W0057-00-00	. PISTON ASSY, CALIPER	1	
12	3GD-W0047-00-00	. . CALIPER SEAL KIT	1	
13	1UY-W0048-50-00	. BLEED SCREW KIT	1	
14	3GD-W0045-00-00	. BRAKE PAD KIT	1	
15	3GD-25828-00-00	. SHIM, CALIPER	1	
16	3GD-25933-00-00	. PIN, PAD	2	
17	90105-08538-00	BOLT, WASHER BASED	4	
18	3GD-2514A-10-00	RING, WHEEL 1 (LEFT)	1	
19	3GD-2515A-10-00	RING, WHEEL 2 (RIGHT)	1	
20	95807-06010-00	BOLT, FLANGE	4	



REAR WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-25383-01-00	COLLAR, WHEEL	2	
2	90114-10009-00	. BOLT, SERRATION	4	
3	2XK-25390-01-HM	REAR WHEEL COMP.	2	AMS
4	94110-090Y3-00	TIRE (AT20X10-9**KT877 T/L) .	2	DUNLOP
5	93900-00022-00	VALVE, RIM	2	TAIHEIYO
6	95707-10500-00	NUT, FLANGE	8	
7	92907-10200-00	WASHER, PLAIN	8	
8	90201-14226-00	WASHER, PLATE	2	
9	90171-14037-00	NUT, CASTLE	2	
10	91401-30030-00	PIN, COTTER	2	
11	38W-25381-02-00	AXLE, WHEEL	1	
12	2XJ-25386-00-00	COLLAR, SPROCKET AXLE ..	1	
13	90116-08507-00	BOLT, STUD	6	
14	2XJ-25441-20-00	SPROCKET, DRIVEN (41T) ...	1	
15	2XJ-25412-00-00	WASHER	3	
16	90170-08258-00	NUT	6	
17	3GG-25311-01-35	HUB, REAR	1	SL
18	90560-35263-00	SPACER	1	
19	93306-00705-00	BEARING	2	
20	93102-42260-00	OIL SEAL	1	
21	93102-43341-00	OIL SEAL	1	
22	2XJ-25388-00-00	PULLER, CHAIN 1	2	
23	90101-08777-00	BOLT	2	
24	95307-08600-00	NUT	2	
25	94581-08104-00	CHAIN (D.I.D 520V6 104LL) ...	1	
26	94681-08011-00	. JOINT, CHAIN (D.I.D 520V6-FJ)	1	
27	90101-10685-00	BOLT	1	
28	90201-106F2-00	WASHER, PLATE	2	
29	90101-12694-00	BOLT	1	



CONTINUED ON NEXT FRAME ➤


REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
30	90201-126A7-00	WASHER, PLATE	2	
31	90179-10247-00	NUT	1	
32	90179-12588-00	NUT	1	



REAR BRAKE CALIPER


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-25712-00-00	BRACKET, DISC	1	
2	2GU-25831-51-00	DISC, BRAKE	1	
3	90109-081F0-00	BOLT	4	
4	90170-33376-00	NUT	2	
5	1UY-2580W-00-00	CALIPER ASSEMBLY, REAR 2	1	
6	1UY-W0057-50-00	. PISTON ASSEMBLY, CALIPER	1	
7	1UY-W0047-50-00	. . CALIPER SEAL KIT	1	
8	1UY-25972-51-00	. ADJUSTBOLT	1	
9	1UY-W0046-00-00	. BRAKE PAD KIT 2	1	
10	1UY-W0048-50-00	. BLEED SCREW KIT	1	
11	1UY-25924-51-00	. PIN, PAD	2	
12	1UY-25917-51-00	. BOOT, CALIPER	2	
13	90105-08440-00	BOLT, WASHER BASED	2	



3GGW100-8280

STEERING HANDLE - CABLE

Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-26111-00-00	HANDLEBAR	1	
2	3GB-26241-00-00	GRIP (LEFT)	2	
3	2GU-26124-01-00	PROTECTOR, HANDLEBAR ..	1	
4	5GT-2836B-00-00	TUNING FORK MARK	1	
5	90159-06093-00	SCREW, WITH WASHER	2	
6	3GD-2622K-00-00	PROTECTOR 1	1	
7	437-83936-01-00	BAND, SWITCH CORD	2	
8	3GG-26250-00-00	THROTTLE LEVER ASSEMBLY	1	
9	2GU-2628F-00-00	. CAP, GEAR	1	
10	2GU-2625G-01-00	. LEVER, THROTTLE	1	
11	2GU-2625H-00-00	. ARM, THROTTLE	1	
12	2GU-2625J-00-00	. ARM, THROTTLE 2	1	
13	2GU-26259-00-00	. COLLAR	1	
14	2GU-26314-00-00	. SPRING	1	
15	2GU-2628G-00-00	. GASKET	1	
16	2GU-26398-00-00	. WASHER	1	
17	1NV-26129-00-00	. WASHER	1	
18	95602-05100-00	. NUT, U	1	
19	95306-05700-00	. NUT	1	
20	98506-05020-00	. SCREW, PAN HEAD	4	
21	98902-03006-00	. SCREW, BIND	1	
22	93104-09025-00	. OIL SEAL	1	
23	3GG-82567-00-00	. SWITCH, THROTTLE	1	
24	437-83936-01-00	BAND, SWITCH CORD	2	
25	4V4-82913-00-00	HOLDER, LEVER LOWER 1 ...	1	
26	98507-05020-00	SCREW, PAN HEAD	2	
27	92907-05100-00	WASHER, SPRING	2	
28	2GU-26260-01-00	CABLE ASSEMBLY, THROTTLE & PUMP	1	




5FK6100-0290

CONTINUED ON NEXT FRAME ➤

STEERING HANDLE - CABLE


Ref. No.	Part Number	Description	Qty	Remarks
29	2GU-26335-01-00	CABLE, CLUTCH	1	
30	1UY-2637A-01-00	COVER, HANDLE LEVER 2 ...	1	
31	1UY-26341-02-00	CABLE, BRAKE	1	



5FK6100-0290


FRONT MASTER CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-25870-00-00	MASTER CYLINDER SUB ASSEMBLY	1	
2	4H7-W0041-50-00	. CYLINDER KIT, MASTER	1	
3	4L0-25854-00-00	. DIAPHRAGM, RESERVOIR ..	1	
4	4H7-25852-00-00	. CAP, RESERVOIR	1	
5	98706-04012-00	. SCREW, FLAT HEAD	2	
6	56A-25867-00-00	BRACKET, MASTER CYLINDER	1	
7	97007-06025-00	BOLT	2	
8	92907-06600-00	WASHER, PLATE	2	
9	1UY-26259-00-00	COLLAR	1	
10	2GU-25872-02-00	HOSE, BRAKE 1	1	
11	3GG-25873-11-00	HOSE, BRAKE 2	2	
12	2GU-25871-00-00	PIPE, BRAKE	1	
13	2GU-25882-00-00	PIPE, BRAKE 2	1	
14	2GU-25866-00-00	CIRCLIP	2	
15	97027-08025-00	BOLT	1	
16	92907-08600-00	WASHER, PLATE	1	
17	90401-10159-00	BOLT, UNION	3	
18	90201-10118-00	WASHER, PLATE	6	



STAND - FOOTREST


Ref. No.	Part Number	Description	Qty	Remarks
1	2GU-27211-00-00	PEDAL, BRAKE	1	
2	90201-15797-00	WASHER, PLATE	1	
3	93430-12008-00	CIRCLIP	1	
4	90506-20380-00	SPRING, TENSION	1	
5	3GG-27411-01-00	FOOTREST 1	1	
6	3GD-27445-00-00	PLATE 1	1	
7	3GG-27421-01-00	FOOTREST 2	1	
8	3GG-27446-00-00	PLATE 2	1	
9	95817-10025-00	BOLT, FLANGE	4	
10	95827-08016-00	BOLT, FLANGE	2	
11	95707-08500-00	NUT, FLANGE	4	
12	90480-18411-00	GROMMET	4	
13	92017-08016-00	BOLT, BUTTON HEAD	4	
14	90480-05201-00	GROMMET	1	



3GG2100-0310


REAR MASTER CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	29L-25850-51-00	MASTER CYLINDER ASSEMBLY	1	
2	29L-W0042-50-00	. CYLINDER KIT, MASTER	1	
3	29L-2582A-50-00	. JOINT	1	
4	93210-15620-00	. O-RING	1	
5	98502-04012-00	. SCREW, PAN HEAD	1	
6	92902-04100-00	. WASHER, SPRING	1	
7	92902-04600-00	. WASHER, PLATE	1	
8	92017-08025-00	BOLT, BUTTON HEAD	2	
9	31A-27222-00-00	JOINT	1	
10	95307-08700-00	NUT	1	
11	90240-08013-00	PIN, CLEVIS	1	
12	90201-08083-00	WASHER, PLATE	1	
13	91401-16012-00	PIN, COTTER	1	
14	1A1-25894-01-00	TANK, RESERVOIR	1	
15	2GU-25852-50-00	CAP, RESERVOIR	1	
16	360-25854-01-00	DIAPHRAGM, RESERVOIR ...	1	
17	2GU-25855-00-00	BUSH, DIAPHRAGM	1	
18	90159-06056-00	SCREW, WITH WASHER	1	
19	3GG-25874-02-00	HOSE, BRAKE	1	
20	90401-10159-00	BOLT, UNION	2	
21	90201-10118-00	WASHER, PLATE	4	
22	2GU-25895-00-00	HOSE, RESERVOIR	1	
23	90467-14057-00	CLIP	2	



GUARD


Ref. No.	Part Number	Description	Qty	Remarks
1	3GG-2845N-00-35	BAR, CARRY FRONT	1	SL
2	1UY-28415-00-00	DAMPER 1	2	
3	95817-08014-00	BOLT, FLANGE	4	
4	3GG-2845R-00-00	BAR, CARRY REAR	1	
5	95827-08016-00	BOLT, FLANGE	2	



2G1110 - 7330

GENERATOR


Ref. No.	Part Number	Description	Qty	Remarks
1	3GG-85510-01-00	STATOR ASSEMBLY	1	
2	3GG-85550-00-00	ROTOR ASSEMBLY	1	
3	90159-06076-00	SCREW, WITH WASHER	3	
4	90179-12248-00	NUT	1	



3GGH100-5340

HEADLIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	4KB-84314-00-00	BULB (12V30/30W)	2	
2	4WV-84320-00-00	LENS ASSY	2	
3	4WV-84340-00-00	SOCKET CORD ASSEMBLY 1 .	2	
4	2GU-84330-70-00	BODY ASSEMBLY	2	YB
5	4KB-84169-00-00	GUARD, HEADLIGHT	2	
6	2GU-84331-00-00	SCREW, RIM ADJUSTING	2	
7	2GU-84332-00-00	SPRING, SCREW	2	
8	2GU-84334-00-00	NUT, ADJUSTING	2	
9	2GU-84345-00-00	DAMPER, HEADLIGHT	4	
10	2GU-84338-00-00	COLLAR, BODY FITTING	4	
11	95807-08055-00	BOLT, FLANGE	2	
12	4KB-84344-00-00	WASHER, PLAIN	2	
13	4KB-84117-00-00	NUT	2	
14	4KB-84526-00-00	SCREW	2	



5FK6100-0350

TAILLIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	38W-84710-00-00	TAILLIGHT UNIT ASSY	1	
2	38W-84721-00-00	. LENS, TAILLIGHT	1	
3	38W-84714-00-00	. BULB (12V-3.8W)	1	
4	1UY-84702-00-00	BRACKET, TAILLIGHT	1	
5	98507-04020-00	SCREW, PAN HEAD	2	
6	92907-04600-00	WASHER	2	
7	38W-84736-00-00	DAMPER, TAIL 1	2	
8	90387-06299-00	COLLAR	4	
9	97007-06025-00	BOLT	4	
10	92907-06100-00	WASHER, SPRING	4	
11	90201-06380-00	WASHER, PLATE	4	



3GDD110-4380

HANDLE SWITCH - LEVER

Ref. No.	Part Number	Description	Qty	Remarks
1	3GG-83975-10-00	SWITCH, HANDLE 2	1	
2	437-83936-01-00	BAND, SWITCH CORD	2	
3	3GG-82910-00-00	LEVER HOLDER ASSEMBLY (LEFT)	1	
4	4KB-82911-00-00	. HOLDER, LEVER 1	1	
5	1UY-83912-01-00	. LEVER 1	1	
6	1UY-83922-01-00	. LEVER 2	1	
7	4KB-W8393-00-00	. LOCK, LEVER ASSEMBLY ..	1	
8	1UY-83935-00-00	. COVER	1	
9	1UY-83909-00-00	. WASHER, SPECIAL	1	
10	1UY-83967-00-00	. PIN, LOCK 1	1	
11	1UY-83913-00-00	. COLLAR, LEVER 1	1	
12	1UY-83966-00-00	. SPRING, RETURN	1	
13	1UY-83962-00-00	. SPRING	1	
14	2XJ-82913-00-00	. HOLDER, LEVER LOWER 1 ..	1	
15	90109-06576-00	. BOLT	1	
16	95607-06100-00	. NUT, U	2	
17	97027-06025-00	. BOLT	2	
18	92907-06600-00	. WASHER, PLATE	2	
19	98507-05010-00	. SCREW, PAN HEAD	1	
20	92907-05600-00	. WASHER, PLATE	1	
21	98507-03008-00	. SCREW, PAN HEAD	1	
22	92907-03600-00	. WASHER	1	
23	97007-06040-00	. BOLT	1	
24	91690-40022-00	. PIN, SPRING	1	
25	90201-082A9-00	. WASHER, PLATE	1	
26	92907-06200-00	. WASHER	1	
27	1UY-83956-00-00	. CAP 1	1	
28	90338-12192-00	. PLUG	1	




3GGW100-8370

CONTINUED ON NEXT FRAME ➤

HANDLE SWITCH - LEVER


Ref. No.	Part Number	Description	Qty	Remarks
29	90123-08046-00	. BOLT	2	
30	90179-08148-00	. NUT	2	
31	4KB-82917-00-00	. SWITCH	1	
32	1RX-83922-01-00	LEVER 2	1	
33	90109-06577-00	BOLT	1	
34	95607-06100-00	NUT, U	1	
35	90149-06131-00	SCREW	1	
36	90170-06010-00	NUT	1	
37	90501-10312-00	SPRING, COMPRESSION	1	



 3GGW100-8370

ELECTRICAL 1


Ref. No.	Part Number	Description	Qty	Remarks
1	3GG-85540-10-00	C.D.I. UNIT ASSEMBLY	1	
2	97007-06016-00	BOLT	2	
3	92907-06600-00	WASHER, PLATE	2	
4	90462-08078-00	CLAMP	1	
5	437-83936-01-00	BAND, SWITCH CORD	1	
6	2GU-82310-51-00	IGNITION COIL ASSEMBLY ...	1	
7	97007-06020-00	BOLT	2	
8	92907-06100-00	WASHER, SPRING	2	
9	1M1-82370-30-00	PLUG CAP ASSEMBLY	2	
10	3GG-82590-20-00	WIRE HARNESS ASSEMBLY ..	1	
11	437-83936-11-00	BAND, SWITCH CORD	4	
12	82F-81910-A0-00	VOLTAGE REGULATOR ASSEMBLY	1	UR
	898-81910-12-00	VOLTAGE REGULATOR ASSEMBLY	1	UR
13	90109-06557-00	BOLT	2	
14	3GG-82510-00-00	MAIN SWITCH ASSEMBLY ...	1	
15	3HN-82579-00-00	. CAP, KEY	1	
16	3GG-85590-00-00	C.D.I. UNIT ASSEMBLY	1	
17	98507-06020-00	SCREW, PAN HEAD	1	
18	92907-06100-00	WASHER, SPRING	1	
19	92907-06600-00	WASHER, PLATE	1	
20	278-82540-01-00	NEUTRAL SWITCH ASSEMBLY	1	
21	93210-29147-00	O-RING	1	
22	98707-05012-00	SCREW, FLAT HEAD	3	



EMBLEM - LABEL 1

Ref. No.	Part Number	Description	Qty	Remarks
1	99241-00160-00	EMBLEM, YAMAHA	1	UR FOR DPBSE
	99244-00160-00	EMBLEM, YAMAHA	1	UR FOR RW
2	99241-00280-00	EMBLEM, YAMAHA	2	UR FOR DPBSE
	99244-00280-00	EMBLEM, YAMAHA	2	UR FOR RW
3	5FE-21568-01-00	LABEL, WARNING	1	
4	4EM-21581-00-00	STAY, PLATE FITTING 1	1	UR FOR RW
	4EM-21581-20-00	STAY, PLATE FITTING 1	1	UR DPBSE
5	90267-32198-00	RIVET, BLIND	6	
6	90201-03313-00	WASHER, PLATE	6	
7	5FE-21697-01-00	LABEL, CAUTION 2	1	
8	3JM-21591-00-00	STAY, PLATE FITTING 2	1	UR RADICAL WHITE
	3JM-21591-10-00	STAY, PLATE FITTING 2	1	UR DPBSE (BLUE)
9	90267-32198-00	RIVET, BLIND	4	
10	90201-03313-00	WASHER, PLATE	4	
11	3GG-21570-E0-00	GRAPHIC SET, FRONT FENDER	1	
12	3GG-2165A-E0-00	GRAPHIC SET, REAR FENDER	1	UR FOR RW
	5FK-2165A-01-00	GRAPHIC SET, REAR FENDER	1	UR FOR DPBSE
13	3GG-21783-D0-00	EMBLEM 3	2	UR FOR DPBSE
	3GG-21783-F0-00	EMBLEM 3	2	UR FOR RW
14	5FE-2151H-01-00	LABEL 5	1	
15	90267-32109-00	RIVET, BLIND	4	
16	90201-03313-00	WASHER, PLATE	4	
17	5FK-21696-01-00	LABEL, CAUTION	1	
18	90267-32109-00	RIVET, BLIND	4	
19	90201-03313-00	WASHER, PLATE	4	
20	3XJ-2415E-A0-00	LABEL, CAUTION	1	
21	3GG-2173E-30-00	GRAPHIC 1	1	UR FOR RW
	5FK-2173E-00-00	GRAPHIC 1	1	UR FOR DPBSE

CONTINUED ON NEXT FRAME ➤



EMBLEM - LABEL 1

Ref. No.	Part Number	Description	Qty	Remarks
22	3GG-2173F-30-00	GRAPHIC 2	1	UR FOR RW
	5FK-2173F-00-00	GRAPHIC 2	1	UR FOR DPBSE

