




PARTS CATALOGUE

MODEL YEAR 1998

YZ400FK (5BE1)

OWNERS

LIT-11626-11-19


SERVICE

LIT-11626-11-19

ASSEMBLY

LIT-11666-11-19


YAMAHA
GENUINE
Parts & Accessories



CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-11102-00-00	CYLINDER HEAD ASSEMBLY .	1	
2	5BE-11133-10-00	. GUIDE, INTAKE VALVE	3	
3	5BE-11134-10-00	. GUIDE, EXHAUST VALVE . . .	2	
4	93440-10153-00	. CIRCLIP	5	
5	91808-16023-00	. PIN, DOWEL	4	
6	90105-06153-00	. BOLT, WASHER BASED	10	
7	90340-12112-00	. PLUG, STRAIGHT SCREW . . .	1	
8	5BE-13582-00-00	PIPE	1	
9	95617-06635-00	BOLT, STUD	2	
10	95617-08635-00	BOLT, STUD	2	
11	95617-08620-00	BOLT, STUD	1	
12	95707-08500-00	NUT, FLANGE	1	
13	NGK-CR8E0-00-00	PLUG, SPARK (NGK-R CR8E) .	1	UR
14	5BE-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
15	90105-104A7-00	BOLT, WASHER BASED	2	
16	90105-106A3-00	BOLT, WASHER BASED	2	
17	90201-101A4-00	WASHER, PLATE	4	
18	5BE-11191-00-00	COVER, CYLINDER HEAD 1 . .	1	
19	5BE-11167-00-00	PIPE, BREATHER 2	1	
20	90109-066F0-00	BOLT	2	
21	4KG-1111G-00-00	RUBBER, MOUNT 1	2	
22	371-11167-01-00	PIPE, BREATHER 2	1	
23	5BE-11166-00-00	PIPE, BREATHER 1	1	
24	90445-112K0-00	HOSE	1	
25	90467-11106-00	CLIP	2	
26	90467-14015-00	CLIP	1	
27	5BE-11193-00-00	GASKET, HEAD COVER 1 . . .	1	
28	5BE-11311-00-00	CYLINDER 1	1	
29	5BE-11351-00-00	GASKET, CYLINDER	1	

CONTINUED ON NEXT FRAME ►




CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
30	90179-06500-00	NUT	2	
31	93612-16254-00	PIN, DOWEL	2	
32	90179-08270-00	NUT	2	
33	95027-06040-00	BOLT, FLANGE	1	



5BE100-8010

CRANKSHAFT - PISTON




Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-11400-00-00	CRANKSHAFT ASSEMBLY ...	1	
2	5BE-11412-00-00	. CRANK 1	1	
3	5BE-11422-00-00	. CRANK 2	1	
4	5BE-11681-00-00	. PIN, CRANK 1	1	
5	93310-6340F-00	. BEARING	1	
6	5BE-11651-00-00	. ROD, CONNECTING	1	
7	93306-30633-00	BEARING	2	
8	5BE-11536-00-00	GEAR, DRIVE	1	
9	90282-05034-00	KEY, STRAIGHT	1	
10	5BE-11455-00-00	SHAFT 1	1	
11	5BE-11454-00-00	WEIGHT 1	1	
12	5BE-11531-00-00	GEAR, BALANCE WT	1	
13	90149-06250-00	SCREW	3	
14	93306-20335-00	BEARING	1	
15	93311-62574-00	BEARING	1	
16	90170-14171-00	NUT	1	
17	90215-14204-00	WASHER, LOCK	1	
18	90280-03045-00	KEY, WOODRUFF	1	
19	5BE-11631-01-A0	PISTON (STD)	1	UR
	5BE-11631-01-B0	PISTON (STD)	1	UR
20	5BE-11603-00-00	PISTON RING SET (STD)	1	
21	5BE-11633-00-00	PIN, PISTON	1	
22	93420-18082-00	CIRCLIP	2	

FWD
5BE100-8020

VALVE

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-12111-00-00	VALVE, INTAKE	1	
2	5BE-12112-00-00	VALVE, INTAKE 2	2	
3	5BE-12121-00-00	VALVE, EXHAUST	2	
4	3GM-12126-00-00	SEAT, VALVE SPRING 2	5	
5	5BE-12113-00-00	SPRING, VALVE INNER	3	
6	5BE-12114-00-00	SPRING, VALVE OUTER	2	
7	5BE-12117-00-00	RETAINER, VALVE SPRING ..	3	
8	4GY-12117-00-00	RETAINER, VALVE SPRING ..	2	
9	1AA-12118-00-00	COTTER, VALVE	4	
10	1WG-12118-00-00	COTTER, VALVE	6	
11	33M-12119-00-00	SEAL, VALVE STEM	2	
12	4SV-12119-00-00	SEAL, VALVE STEM	3	
13	3LD-12168-00-00	PAD, ADJUSTING (1.20)	5	UR
	3LD-12168-20-00	PAD, ADJUSTING (1.25)	5	UR
	3LD-12168-40-00	PAD, ADJUSTING (1.30)	5	UR
	3LD-12168-60-00	PAD, ADJUSTING (1.35)	5	UR
	3LD-12168-80-00	PAD, ADJUSTING (1.40)	5	UR
	3LD-12168-A0-00	PAD, ADJUSTING (1.45)	5	UR
	3LD-12168-F0-00	PAD, ADJUSTING (1.50)	5	UR
	3LD-12168-H1-00	PAD, ADJUSTING (1.55)	5	UR
	3LD-12168-K1-00	PAD, ADJUSTING (1.60)	5	UR
	3LD-12168-M1-00	PAD, ADJUSTING (1.65)	5	UR
	3LD-12168-R1-00	PAD, ADJUSTING (1.70)	5	UR
	3LD-12168-U1-00	PAD, ADJUSTING (1.75)	5	UR
	3LD-12168-W1-00	PAD, ADJUSTING (1.80)	5	UR
	3LD-12168-Y1-00	PAD, ADJUSTING (1.85)	5	UR
	3LD-12169-11-00	PAD, ADJUSTING (1.90)	5	UR
	3LD-12169-31-00	PAD, ADJUSTING (1.95)	5	UR
	3LD-12169-50-00	PAD, ADJUSTING (2.00)	5	UR


CONTINUED ON NEXT FRAME ➤




5BE100-8030

VALVE

Ref. No.	Part Number	Description	Qty	Remarks
13	3LD-12169-70-00	PAD, ADJUSTING (2.05)	5	UR
	3LD-12169-90-00	PAD, ADJUSTING (2.10)	5	UR
	3LD-12169-E0-00	PAD, ADJUSTING (2.15)	5	UR
	3LD-12169-G0-00	PAD, ADJUSTING (2.20)	5	UR
	3LD-12169-J0-00	PAD, ADJUSTING (2.25)	5	UR
	3LD-12169-L0-00	PAD, ADJUSTING (2.30)	5	UR
	3LD-12169-N0-00	PAD, ADJUSTING (2.35)	5	UR
	3LD-12169-T0-00	PAD, ADJUSTING (2.40)	5	UR
14	3FV-12153-10-00	LIFTER, VALVE	5	UR YELLOW
	3FV-12153-20-00	LIFTER, VALVE	5	UR BLUE



5BE100-8030




CAMSHAFT - CHAIN

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-12170-00-00	CAMSHAFT ASSEMBLY 1	1	
2	5BE-12180-00-00	CAMSHAFT ASSEMBLY 2	1	
3	93440-41178-00	CIRCLIP	2	
4	94591-50120-00	CHAIN	1	
5	5BE-12210-00-00	TENSIONER ASSEMBLY, CAM CHAIN	1	
6	4FM-12213-00-00	GASKET, TENSIONER CASE . .	1	
7	95027-06025-00	BOLT, FLANGE	2	
8	5BE-12251-00-00	DAMPER, CHAIN 1	1	
9	5BE-12252-00-00	DAMPER, CHAIN 2	1	
10	97027-06016-00	BOLT	2	
11	92907-06600-00	WASHER, PLATE	2	
12	5BE-12241-00-00	GUIDE, STOPPER 2	1	
13	90109-06418-00	BOLT	1	
14	90430-06014-00	GASKET	1	
15	93102-12224-00	OIL SEAL	1	
16	5BE-12280-00-00	DECOMPRESSION ASSEMBLY	1	
17	90508-162B2-00	SPRING, TORSION	1	
18	5BE-12283-00-00	BRACKET, DECOMPRESSION .	1	
19	5BE-12292-00-00	CABLE, DECOMPRESSION ...	1	
20	95827-06014-00	BOLT, FLANGE	1	


WATER PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-12458-00-00	SHAFT, IMPELLER	1	
2	5DJ-12451-00-00	IMPELLER, WATER PUMP	1	
3	90201-08512-00	WASHER, PLATE	1	
4	93109-11073-00	OIL SEAL	1	
5	93102-12106-00	OIL SEAL (SD 12-22-5 HS)	1	
6	93306-00105-00	BEARING (B6001)	1	
7	5BE-12422-00-00	COVER, HOUSING	1	
8	5BE-12439-00-00	O-RING	1	
9	93604-10011-00	PIN, DOWEL	2	
10	90430-06166-00	GASKET	1	
11	95027-06025-00	BOLT, FLANGE	4	
12	5BE-12564-00-00	PIPE, WATER	2	
13	93210-19758-00	O-RING	2	




5BE100-8050


RADIATOR - HOSE



Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-1240A-00-00	RADIATOR ASSEMBLY	1	
2	5BE-12461-00-00	RADIATOR ASSEMBLY	1	
3	22W-12462-00-00	CAP, RADIATOR	1	
4	91A20-05065-00	TUBE, FLEXIBLE VINYL	1	
5	90467-09006-00	CLIP	1	
6	5BE-12481-00-00	PIPE 1	1	
7	95027-06012-00	BOLT, FLANGE	1	
8	93210-18397-00	O-RING	1	
9	5BE-12576-00-00	HOSE 1	1	
10	5BE-12577-00-00	HOSE 2	1	
11	5BE-12578-00-00	HOSE 3	1	
12	5BE-12579-00-00	HOSE 4	1	
13	5BE-12482-00-00	PIPE 2	1	
14	95027-06012-00	BOLT, FLANGE	1	
15	93210-18397-00	O-RING	1	
16	90450-28014-00	HOSE CLAMP ASSEMBLY ...	3	
17	90450-25037-00	HOSE CLAMP ASSEMBLY ...	5	
18	90480-15528-00	GROMMET	6	
19	90387-0614M-00	COLLAR	6	
20	95027-06025-00	BOLT, FLANGE	6	
21	90201-06071-00	WASHER, PLATE	6	


5BE100-8060


OIL PUMP



Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-13300-00-00	OIL PUMP ASSEMBLY	1	
2	1HX-13310-00-00	ROTOR ASSEMBLY 1	1	
3	93603-17070-00	PIN, DOWEL	1	
4	93440-10085-00	CIRCLIP	1	
5	93210-10197-00	O-RING	1	
6	99530-10114-00	PIN, DOWEL	1	
7	99530-08012-00	PIN, DOWEL	1	
8	91317-06025-00	BOLT	2	
9	91314-06030-00	BOLT	1	
10	99001-08600-00	CIRCLIP	1	
11	5BE-13341-00-00	GEAR, OIL PUMP IDLE	1	
12	5BE-13342-00-00	SHAFT, IDLE GEAR	1	
13	99009-12400-00	CIRCLIP	1	
14	90201-12166-00	WASHER, PLATE	1	
15	5BE-13412-00-00	HOUSING, STRAINER	1	
16	95027-06025-00	BOLT, FLANGE	2	
17	5BE-13411-00-00	STRAINER, OIL	1	
18	5BE-13464-00-00	HOSE, OIL 1	1	
19	93210-10197-00	O-RING	1	
20	99530-10114-00	PIN, DOWEL	1	
21	95027-06025-00	BOLT, FLANGE	1	
22	90450-22017-00	HOSE CLAMP ASSEMBLY ...	1	
23	5BE-13416-00-00	PIPE, OIL 1	1	
24	5BE-13465-00-00	HOSE, OIL 2	1	
25	90450-22017-00	HOSE CLAMP ASSEMBLY ...	1	
26	93210-10197-00	O-RING	2	
27	99530-10114-00	PIN, DOWEL	2	
28	95027-06025-00	BOLT, FLANGE	1	
29	95024-06020-00	BOLT, FLANGE	1	

FWD
5BE100-8070


OIL CLEANER



Ref. No.	Part Number	Description	Qty	Remarks
1	1UY-13440-02-00	ELEMENT ASSEMBLY, OIL CLEANER	1	
2	5BE-13447-00-00	COVER, OIL ELEMENT	1	
3	93210-50553-00	O-RING	1	
4	93210-07135-00	O-RING	3	
5	90109-065G2-00	BOLT	1	
6	95027-06065-00	BOLT, FLANGE	1	
7	95027-06020-00	BOLT, FLANGE	1	
8	5BE-13161-00-00	PIPE, DELIVERY 1	1	
9	90401-10159-00	BOLT, UNION	1	
10	90430-10188-00	GASKET	2	
11	90401-08038-00	BOLT, UNION	2	
12	90430-08119-00	GASKET	4	
13	5BE-13171-00-00	PIPE, DELIVERY 2	1	
14	93210-07003-00	O-RING	1	
15	93210-09008-00	O-RING	1	
16	93210-12759-00	O-RING	1	
17	95027-06012-00	BOLT, FLANGE	1	



5BE100-8080




INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-13597-00-00	JOINT, CARBURETOR 3	1	
2	90450-57092-00	HOSE CLAMP ASSEMBLY	1	
3	90450-59091-00	HOSE CLAMP ASSEMBLY	1	
4	5BE-1440F-00-00	JOINT, AIR FILTER 1	1	
5	91317-05014-00	BOLT	2	
6	4FN-14561-00-00	O-RING	1	
7	90460-61162-00	CLAMP, HOSE	1	
8	5BE-14293-00-00	COVER 1	1	
9	90111-06017-00	BOLT	2	
10	5BE-14401-00-00	AIR CLEANER CASE ASSEMBLY	1	
11	5BE-14453-00-00	JOINT, AIR CLEANER 1	1	
12	3JD-14459-01-00	HOLDER, GUIDE	1	
13	3JD-14477-00-00	PLATE	1	
14	95607-05100-00	NUT, U	5	
15	5BE-1443E-00-00	PIPE, DRAIN	1	
16	90467-17089-00	CLIP	1	
17	4XM-14451-00-00	ELEMENT, AIR CLEANER	1	
18	90209-06096-00	WASHER	1	
19	90122-06035-00	BOLT, WING	1	
20	5BE-14458-00-00	GUIDE	1	
21	5BE-1441A-00-00	COVER, CLEANER CASE 1	1	
22	5BE-1441E-00-00	COVER, CLEANER CASE 2	1	
23	90267-32070-00	RIVET, BLIND	5	
24	90201-03313-00	WASHER, PLATE	5	
25	90183-06023-00	NUT, SPRING	2	
26	95027-06012-00	BOLT, FLANGE	1	
27	5BE-14340-00-00	VALVE ASSEMBLY	1	
28	95027-06016-00	BOLT, FLANGE	1	


CONTINUED ON NEXT FRAME ➤

INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
29	5BE-14349-00-00	PIPE	1	
30	90467-09103-00	CLIP	3	
31	5BE-14417-00-00	COVER 1	1	AP




CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-14101-00-00	CARBURETOR ASSEMBLY 1	1	
2	3TJ-14496-40-00	. BOLT	5	
3	5BE-14959-00-00	. GASKET	1	
4	91316-04012-00	. BOLT	4	
5	91316-04012-00	. BOLT	2	
6	91316-04008-00	. BOLT	3	
7	90202-08045-00	. WASHER, PLATE	1	
8	3TJ-14393-40-00	. NUT, CROWN	1	
9	3TJ-14522-40-00	. SCREW, ADJUST	1	
10	5BE-14388-00-00	. VALVE ASSEMBLY	1	
11	3TJ-14267-40-00	. ROLLER	1	
12	4FN-14546-00-00	. VALVE, NEEDLE	1	
13	4FN-14997-00-00	. SEAL	1	
14	5BE-14916-CP-00	. NEEDLE (#CVP)	1	AP
	5BE-14916-CQ-00	. NEEDLE (#CVQ)	1	AP
	5BE-14916-CR-00	. NEEDLE (#CVR)	1	AP
	5BE-14916-CS-00	. NEEDLE (#CVS)	1	AP
	5BE-14916-CT-00	. NEEDLE (#CVT)	1	AP
	5BE-14916-CU-00	. NEEDLE (#CVU)	1	AP
	5BE-14916-DP-00	. NEEDLE (#DVP)	1	AP
	5BE-14916-DQ-00	. NEEDLE (#DVQ)	1	AP
	5BE-14916-DR-00	. NEEDLE (#DVR)	1	STD
	5BE-14916-DS-00	. NEEDLE (#DVS)	1	AP
	5BE-14916-DT-00	. NEEDLE (#DVT)	1	AP
	5BE-14916-DU-00	. NEEDLE (#DVU)	1	AP
	5BE-14916-EP-00	. NEEDLE (#EVP)	1	AP
	5BE-14916-EQ-00	. NEEDLE (#EVQ)	1	AP
	5BE-14916-ER-00	. NEEDLE (#EVR)	1	AP
	5BE-14916-ES-00	. NEEDLE (#EVS)	1	AP

CONTINUED ON NEXT FRAME ➤


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
14	5BE-14916-ET-00	. NEEDLE (#EVT)	1	AP
	5BE-14916-EU-00	. NEEDLE (#EVU)	1	AP
15	3TJ-14159-40-00	. CLIP	1	
16	5BE-14521-00-00	. SCREW, ADJUST	1	
17	5BE-14947-00-00	. JET, NEEDLE	1	
18	4MX-14943-40-00	. JET, MAIN (#165)	1	AP
	4MX-14943-41-00	. JET, MAIN (#170)	1	AP
	4MX-14943-42-00	. JET, MAIN (#175)	1	STD
	4MX-14943-43-00	. JET, MAIN (#180)	1	AP
	4MX-14943-44-00	. JET, MAIN (#185)	1	AP
	4MX-14943-45-00	. JET, MAIN (#190)	1	AP
	4MX-14943-91-00	. JET, MAIN (#168)	1	AP
	4MX-14943-92-00	. JET, MAIN (#172)	1	AP
	4MX-14943-93-00	. JET, MAIN (#178)	1	AP
	4MX-14943-94-00	. JET, MAIN (#182)	1	AP
	4MX-14943-95-00	. JET, MAIN (#188)	1	AP
19	3TJ-14943-47-00	. JET (#200)	1	
20	3TJ-14948-02-00	. JET (#38)	1	AP
	3TJ-14948-03-00	. JET (#40)	1	AP
	3TJ-14948-04-00	. JET (#42)	1	AP
	3TJ-14948-05-00	. JET (#45)	1	STD
	3TJ-14948-06-00	. JET (#48)	1	AP
	3TJ-14948-07-00	. JET (#50)	1	AP
	3TJ-14948-08-00	. JET (#52)	1	AP
21	3TJ-1494F-09-00	. JET (#55)	1	AP
	3TJ-1494F-10-00	. JET (#58)	1	AP
	3TJ-1494F-11-00	. JET (#60)	1	AP
	3TJ-1494F-12-00	. JET (#62)	1	AP
	3TJ-1494F-13-00	. JET (#65)	1	STD

CONTINUED ON NEXT FRAME ➤


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
21	3TJ-1494F-14-00	. JET (#68)	1	AP
	3TJ-1494F-15-00	. JET (#70)	1	AP
	3TJ-1494F-16-00	. JET (#72)	1	AP
	3TJ-1494F-17-00	. JET (#75)	1	AP
22	7A9-14943-27-00	. JET (#100)	1	
23	3TJ-14105-40-00	. PILOT SCREW SET	1	
24	5BE-14107-00-00	. NEEDLE VALVE SET	1	
25	5BE-14216-00-00	. SCREW	1	
26	5BE-14985-00-00	. FLOAT	1	
27	676-14548-00-00	. PIN, FLOAT ARM	1	
28	688-14592-00-00	. SCREW	1	
29	3TJ-14984-40-00	. GASKET, FLOAT CHAMBER .	1	
30	3TJ-14293-40-00	. COVER 1	1	
31	5BE-14940-05-00	. DIAPHRAGM ASSEMBLY ...	1	AP
	5BE-14940-07-00	. DIAPHRAGM ASSEMBLY ...	1	AP
	5BE-14940-08-00	. DIAPHRAGM ASSEMBLY ...	1	STD
	5BE-14940-09-00	. DIAPHRAGM ASSEMBLY ...	1	AP
32	3TJ-14536-40-00	. GASKET	1	
33	3TJ-14933-40-00	. SPRING, DIAPHRAGM	1	
34	6H4-14561-00-00	. O-RING	1	
35	5BE-14171-00-00	. PLUNGER, STARTER	1	
36	90202-03052-00	. WASHER, PLATE	2	
37	3TJ-14365-40-00	. PIN, CLEVIS	2	
38	5BE-14968-00-00	. CAP	1	
39	5BE-14379-00-00	. ROD, STARTER	1	
40	5BE-14557-00-00	. WASHER	1	
41	5BE-14162-00-00	. BOLT, HOLDING	1	
42	95704-05500-00	. NUT, FLANGE	2	
43	5BE-14326-00-00	. SCREW, GUIDE	1	

CONTINUED ON NEXT FRAME ➤


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
44	5BE-14534-00-00	. COLLAR	1	
45	5BE-14922-00-00	. SCREW, THROTTLE	1	
46	90201-08410-00	. WASHER, PLATE	1	
47	4FN-14934-00-00	. SPRING, THROTTLE STOP ..	1	
48	5BE-14535-00-00	. COLLAR	1	
49	5BE-14561-00-00	. O-RING	1	
50	5BE-14115-00-00	. PLUG, SCREW	1	
51	91317-05050-00	. BOLT	1	
52	5BE-85885-00-00	. THROTTLE SENSOR ASSEMBLY	1	
53	5BE-14449-00-00	. COLLAR	1	
54	5BE-14562-00-00	. O-RING	1	
55	5BE-14265-00-00	. COLLAR	1	
56	5BE-14596-00-00	. WASHER	2	
57	3TJ-14137-40-00	. CLIP	4	
58	5BE-14137-00-00	. CLIP	1	
59	5BE-14146-00-00	. PLATE	2	
60	5BE-14197-00-00	. PIPE	1	
61	5BE-14148-00-00	. PIPE	2	
62	5BE-14987-00-00	. HOSE	1	
63	5BE-14937-00-00	. CLIP	1	
64	5BE-14346-00-00	. PLATE	1	


EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-14611-00-00	PIPE, EXHAUST 1	1	
2	5BE-14628-00-00	PROTECTOR, EXHAUST PIPE .	1	
3	4BD-14766-00-00	WASHER, PROTECTOR	6	
4	98980-06008-00	SCREW, BIND	3	
5	90206-06090-00	WASHER, WAVE	3	
6	3VD-14613-00-00	GASKET, EXHAUST PIPE	1	
7	91317-08020-00	BOLT	1	
8	5BE-14753-00-00	SILENCER, EXHAUST	1	
9	5BE-1469A-00-00	. FIBER	1	
10	3GW-14714-00-00	GASKET, MUFFLER	1	
11	22W-24181-00-00	DAMPER, LOCATING 1	2	
12	5BE-14788-00-00	BAND, SILENCER	1	
13	95827-08012-00	BOLT, FLANGE	1	
14	95827-08030-00	BOLT, FLANGE	1	
15	90201-081R9-00	WASHER, PLATE	1	
16	90387-0814J-00	COLLAR	1	
17	5BE-14747-00-00	DAMPER, MUFFLER	1	



5BE100-8110


CRANKCASE



5BE100-8120

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-15150-00-00	CRANKCASE ASSEMBLY	1	
2	99530-14016-00	PIN, DOWEL	2	
3	91317-06040-00	BOLT	3	
4	91317-06050-00	BOLT	4	
5	91317-06060-00	BOLT	2	
6	91317-06075-00	BOLT	3	
7	5BE-15441-00-00	HOLDER, CLUTCH CABLE	1	
8	5BE-15421-00-00	COVER, CRANKCASE 2	1	
9	98507-06025-00	SCREW, PAN HEAD	2	
10	5BE-17466-00-00	GUIDE, CHAIN	1	
11	90340-12059-00	PLUG, STRAIGHT SCREW	1	
12	90430-12213-00	GASKET	1	
13	4L0-17471-00-00	PLATE, COVER	1	
14	90105-06553-00	BOLT, WASHER BASED	2	
15	4JT-15381-01-00	PLATE, BEARING COVER	5	
16	5BE-15383-00-00	PLATE, BEARING COVER	4	
17	90149-06286-00	SCREW	4	
18	90149-06326-00	SCREW	5	
19	5DH-18562-00-00	PLATE, STOPPER 2	4	
20	90105-06553-00	BOLT, WASHER BASED	4	
21	93210-10197-00	O-RING	1	
22	99530-10114-00	PIN, DOWEL	1	
23	90387-1712Y-00	COLLAR	2	
24	99530-10116-00	PIN, DOWEL	2	
25	90461-10136-00	CLAMP	1	

CRANKCASE COVER 1




Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-15411-00-00	COVER, CRANKCASE 1	1	
2	90340-32123-00	PLUG, STRAIGHT SCREW	1	
3	93210-32172-00	O-RING	1	
4	90340-14128-00	PLUG, STRAIGHT SCREW	1	
5	93210-14369-00	O-RING	1	
6	5BE-15451-00-00	GASKET, CRANKCASE COVER 1	1	
7	99530-08016-00	PIN, DOWEL	2	
8	95027-06040-00	BOLT, FLANGE	2	
9	95027-06030-00	BOLT, FLANGE	6	
10	5BE-15431-00-00	COVER, CRANKCASE 3	1	
11	93101-14164-00	OIL SEAL	1	
12	90201-15701-00	WASHER, PLATE (1.0T)	1	
13	99009-22500-00	CIRCLIP	1	
14	5BE-15462-00-00	GASKET, CRANKCASE COVER 3	1	
15	91812-16001-00	PIN, DOWEL	2	
16	95027-06030-00	BOLT, FLANGE	10	
17	5BE-15415-00-00	COVER, GENERATOR	1	
18	95027-06030-00	BOLT, FLANGE	4	
19	95027-06040-00	BOLT, FLANGE	1	
20	90105-065A1-00	BOLT, WASHER BASED	2	
21	99530-08016-00	PIN, DOWEL	2	
22	5BE-15453-00-00	GASKET	1	
23	90462-10241-00	CLAMP	1	
24	583-13113-00-00	SEAT, CHECK BALL	1	
25	93503-08007-00	BALL	1	
26	90501-043E0-00	SPRING, COMPRESSION	1	



5BE100-8130

STARTER

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-15601-00-00	KICK SHAFT ASSEMBLY	1	
2	90201-20685-00	. WASHER, PLATE (0.5T)	1	
3	93410-20038-00	. CIRCLIP	1	
4	90501-16107-00	. SPRING, COMPRESSION	1	
5	90201-167P7-00	. WASHER, PLATE	1	
6	99009-16400-00	. CIRCLIP	1	
7	5BE-15664-00-00	. GUIDE, SPRING	1	
8	90508-30743-00	. SPRING, TORSION	1	
9	90201-162H4-00	WASHER, PLATE	1	
10	5BE-15668-00-00	STOPPER	1	
11	5BE-15674-00-00	GUIDE, RATCHET WHEEL	1	
12	5BE-15686-00-00	WASHER, LOCK	1	
13	97027-06016-00	BOLT	2	
14	93102-20108-00	OIL SEAL	1	
15	5BE-15651-00-00	GEAR, KICK IDLE	1	
16	90201-20276-00	WASHER, PLATE (1.0T)	1	
17	99009-20400-00	CIRCLIP	1	
18	5BE-15620-00-00	KICK CRANK ASSEMBLY	1	
19	90105-08752-00	BOLT, WASHER BASED	1	
20	90201-087A9-00	WASHER, PLATE	1	



FWD
5BE100-8140



5BE100-8150


CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-16111-00-00	GEAR, PRIMARY DRIVE	1	
2	90215-21290-00	WASHER, LOCK	1	
3	90179-20255-00	NUT	1	
4	5BE-16150-00-00	PRIMARY DRIVEN GEAR COMP.	1	
5	2JN-16371-00-00	BOSS, CLUTCH	1	
6	3YF-16351-00-00	PLATE, PRESSURE 1	1	
7	360-16325-00-00	PLATE, CLUTCH 2	7	
8	5BE-16321-00-00	PLATE, FRICTION	7	
9	90501-244L9-00	SPRING, COMPRESSION	5	
10	90159-06092-00	SCREW, WITH WASHER	5	
11	2JN-16154-00-00	PLATE, THRUST 1	1	
12	5BE-16331-00-00	PLATE, FRICTION 2	1	
13	90215-20231-00	WASHER, LOCK	1	
14	90170-20327-00	NUT	1	
15	5BE-16356-00-00	ROD, PUSH 1	1	
16	93340-21505-00	BEARING	1	
17	90201-125L6-00	WASHER, PLATE	1	
18	93440-10085-00	CIRCLIP	1	
19	5BE-16357-00-00	ROD, PUSH 2	1	
20	5BE-16381-00-00	PUSH LEVER COMP.	1	
21	93315-11206-00	BEARING	1	
22	93102-12224-00	OIL SEAL	1	
23	4JT-16384-00-00	PLATE, SEAT	1	
24	95027-06010-00	BOLT, FLANGE	1	
25	90508-142B5-00	SPRING, TORSION	1	

TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-17411-00-00	AXLE, MAIN	1	
2	93306-20532-00	BEARING	1	
3	5BE-17151-00-00	GEAR, 5TH PINION	1	
4	90201-253K0-00	WASHER, PLATE (T=1.0)	1	
5	93440-25084-00	CIRCLIP	3	
6	5BE-17131-00-00	GEAR, 3RD PINION	1	
7	5BE-17141-00-00	GEAR, 4TH PINION	1	
8	90387-2113G-00	COLLAR	1	
9	5BE-17121-00-00	GEAR, 2ND PINION	1	
10	90209-21332-00	WASHER	1	
11	93306-00431-00	BEARING	1	
12	93306-00426-00	BEARING	1	
13	5BE-17421-00-00	AXLE, DRIVE	1	
14	5BE-17211-00-00	GEAR, 1ST WHEEL	1	
15	5BE-17251-00-00	GEAR, 5TH WHEEL	1	
16	93440-25084-00	CIRCLIP	1	
17	90209-21332-00	WASHER	1	
18	90201-253K0-00	WASHER, PLATE (T=1.0)	1	
19	5BE-17231-00-00	GEAR, 3RD WHEEL	1	
20	93440-28062-00	CIRCLIP	1	
21	5BE-17241-00-00	GEAR, 4TH WHEEL	1	
22	90209-26348-00	WASHER	1	
23	5BE-17221-00-00	GEAR, 2ND WHEEL	1	
24	93306-20593-00	BEARING	1	
25	93102-32480-00	OIL SEAL	1	
26	90387-2513F-00	COLLAR	1	
27	93210-22298-00	O-RING	1	
28	9383E-14210-00	SPROCKET, DRIVE (14T)	1	UR STD
29	90215-21256-00	WASHER, LOCK	1	


CONTINUED ON NEXT FRAME ➤



5BE100-8160

TRANSMISSION


Ref. No.	Part Number	Description	Qty	Remarks
30	90179-20255-00	NUT	1	
31	5BE-17471-00-00	PLATE, COVER	1	
32	90105-06553-00	BOLT, WASHER BASED	2	



5BE100-8160

SHIFT CAM - SHIFT FORK


Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-18541-00-00	CAM, SHIFT	1	
2	93306-90501-00	BEARING	1	
3	4BA-18542-00-00	POINT, NEUTRAL	1	
4	90501-06022-00	SPRING, COMPRESSION	1	
5	3XK-18140-00-00	STOPPER LEVER ASSEMBLY .	1	
6	90508-26561-00	SPRING, TORSION	1	
7	90109-063F8-00	BOLT	1	
8	5BE-18501-00-00	FORK, SHIFT 1	1	
9	5BE-18502-00-00	FORK, SHIFT 2	1	
10	5BE-18503-00-00	FORK, SHIFT 3	1	



5BE100-8170

SHIFT SHAFT

Ref. No.	Part Number	Description	Qty	Remarks
1	3XK-18101-02-00	SHIFT SHAFT ASSEMBLY	1	
2	3XK-18122-00-00	LEVER, SHIFT 2	1	
3	90387-124F4-00	COLLAR	1	
4	90508-291A8-00	SPRING, TORSION	1	
5	93608-33046-00	PIN, DOWEL	1	
6	5BE-18110-00-00	SHIFT PEDAL ASSEMBLY	1	
7	95027-06020-00	BOLT, FLANGE	1	
8	93102-12106-00	OIL SEAL (SD 12-22-5 HS)	1	
9	3XJ-18173-00-00	PIN, SHIFT	1	
10	3XJ-18178-00-00	ROLLER, SHIFT LEVER	1	
11	3XJ-18182-00-00	PAWL, SHIFTER	2	
12	90501-052G5-00	SPRING, COMPRESSION	2	
13	3XJ-18184-00-00	PIN, PAWL	2	
14	5BE-18172-00-00	GUIDE, SHIFT	1	
15	90101-06664-00	BOLT	2	
16	4EW-18185-00-00	SEGMENT	1	




5BE100-8180

FRAME


Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-21101-00-P0	FRONT FRAME COMP.	1	DPBMC
2	5BE-21190-00-P0	REAR FRAME COMP.	1	DPBMC
3	90110-08096-00	BOLT, HEXAGON SOCKET HEAD	2	
4	90105-08099-00	BOLT, WASHER BASED	1	
5	95817-10160-00	BOLT, FLANGE	1	
6	95617-10200-00	NUT, SELF-LOCKING	1	
7	5BE-21425-00-00	BRACKET, REAR UPPER 1 ...	2	
8	92017-08055-00	BOLT, BUTTON HEAD	3	
9	90201-086P8-00	WASHER, PLATE	6	
10	95607-08200-00	NUT, SELF-LOCKING	3	
11	95027-10055-00	BOLT, FLANGE	1	
12	92907-10200-00	WASHER, PLAIN	1	
13	95617-10200-00	NUT, SELF-LOCKING	1	
14	90105-10733-00	BOLT, WASHER BASED	1	
15	95617-10200-00	NUT, SELF-LOCKING	1	
16	95027-08040-00	BOLT, FLANGE	1	
17	3JD-22178-10-00	TENSIONER	1	
18	4EW-22178-00-00	TENSIONER	1	
19	93300-60804-00	BEARING	2	
20	90387-086N4-00	COLLAR	2	
21	95027-08065-00	BOLT, FLANGE	1	
22	95707-08500-00	NUT, FLANGE	1	
23	90201-086P8-00	WASHER, PLATE	3	
24	90338-16148-00	PLUG	2	
25	5BE-21417-00-00	BRACKET, FRONT LOWER 1 .	2	
26	95827-08016-00	BOLT, FLANGE	4	
27	5BE-21471-00-00	PROTECTOR, ENGINE	1	
28	5BE-15362-00-00	PLUG, OIL LEVEL	1	

CONTINUED ON NEXT FRAME ➤




FRAME

Ref. No.	Part Number	Description	Qty	Remarks
29	93210-19123-00	O-RING	1	
30	5BE-2147A-00-00	GUARD, ENGINE 1	1	
31	95027-08012-00	BOLT, FLANGE	5	
32	56A-28166-00-00	WRENCH, HEXAGON	1	



FENDER


Ref. No.	Part Number	Description	Qty	Remarks
1	4DA-21511-20-00	FENDER, FRONT	1	
2	3JD-21748-00-00	COLLAR	4	
3	90119-06096-00	BOLT, WITH WASHER	4	
4	99241-00080-00	EMBLEM, YAMAHA	1	
5	5BE-21611-10-00	FENDER, REAR	1	
6	95027-06012-00	BOLT, FLANGE	2	
7	90183-06023-00	NUT, SPRING	2	
8	90387-0701A-00	COLLAR	2	
9	5BE-21642-00-00	GUARD, FLAP	1	
10	95027-06014-00	BOLT, FLANGE	2	
11	90387-0600F-00	COLLAR	2	
12	97707-60016-00	SCREW, TAPPING	2	
13	90201-06557-00	WASHER, PLATE	2	
14	99241-00080-00	EMBLEM, YAMAHA	1	
15	5BE-2163G-00-00	EMBLEM 1	2	



5BE100-8200


SIDE COVER

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-21711-00-00	COVER, SIDE 1	1	
2	95827-06016-00	BOLT, FLANGE	1	
3	90119-08238-00	BOLT, WITH WASHER	1	
4	5BE-21721-00-00	COVER, SIDE 2	1	
5	5BE-2174A-00-00	INSULATOR, SIDE COVER ...	1	
6	3FY-21575-01-00	SEAL 1	1	
7	95827-06016-00	BOLT, FLANGE	1	
8	90119-08238-00	BOLT, WITH WASHER	1	
9	5BE-21731-10-00	COVER, SIDE 3	1	
10	5BE-2173E-01-00	GRAPHIC 1	1	
11	90159-06182-00	SCREW, TAPPING	2	
12	90159-06078-00	SCREW, WITH WASHER	1	
13	4EW-2172A-10-00	PANEL 1	1	
14	5BE-21741-10-00	COVER, SIDE 4	1	
15	5BE-2173F-01-00	GRAPHIC 2	1	
16	90159-06182-00	SCREW, TAPPING	2	
17	90159-06078-00	SCREW, WITH WASHER	1	
18	4EW-2172A-10-00	PANEL 1	1	
19	90183-06069-00	NUT, SPRING	2	



5BE100-8210

REAR ARM




5BE100-8220

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-22110-00-00	REAR ARM COMP.	1	
2	90151-04048-00	SCREW, COUNTERSUNK	4	
3	4SS-22355-00-00	PATCH	2	
4	93317-22262-00	BEARING	4	
5	90338-16148-00	PLUG	2	
6	93106-22019-00	OIL SEAL (DC 22-28-8)	2	
7	93342-22215-00	BEARING	2	
8	5DH-22129-00-00	COVER, THRUST 2	2	
9	90387-1712R-00	COLLAR	2	
10	156-22127-00-00	SHIM (0.3T)	1	UN
11	4EW-22151-20-00	SEAL, GUARD	1	
12	90110-05201-00	BOLT, HEXAGON SOCKET HEAD	4	
13	4XM-22199-00-00	SUPPORT, CHAIN	1	
14	4XM-22128-00-00	COVER, THRUST 1	1	
15	95027-06050-00	BOLT, FLANGE	2	
16	90179-06568-00	NUT	2	
17	95027-06010-00	BOLT, FLANGE	1	
18	5DH-22141-00-00	SHAFT, PIVOT	1	
19	90185-16127-00	NUT, SELF-LOCKING	1	
20	90201-164H4-00	WASHER, PLATE	1	
21	5DH-2217A-00-00	ARM, RELAY	1	
22	93315-32056-00	BEARING	2	
23	93109-20076-00	OIL SEAL	4	
24	90387-164N2-00	COLLAR	2	
25	90387-164N3-00	COLLAR	2	
26	90387-167Y9-00	COLLAR	1	
27	90109-147F2-00	BOLT	1	
28	90109-142F4-00	BOLT	2	

CONTINUED ON NEXT FRAME ➤

REAR ARM




Ref. No.	Part Number	Description	Qty	Remarks
29	90201-164H4-00	WASHER, PLATE	2	
30	90201-14740-00	WASHER, PLATE	3	
31	90185-14112-00	NUT, SELF-LOCKING	3	
32	5DH-2217F-00-00	ROD, CONNECTING 1	1	
33	93315-32056-00	BEARING	2	
34	93109-20076-00	OIL SEAL	2	
35	1HX-2135F-10-00	COVER	2	
36	99244-00200-00	EMBLEM, YAMAHA	2	



5BE100-8220


REAR SUSPENSION



Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-22210-00-00	SHOCK ABSORBER ASSEMBLY, REAR	1	
2	5BE-22201-00-00	. DAMPER SUB ASSEMBLY ..	1	
3	3SP-22234-00-00	.. GUIDE, SPRING 3	1	
4	3SP-22213-00-00	.. SEAT, SPRING UPPER	1	
5	509-23184-L0-00	.. CAP, AIR VALVE	1	
6	4JX-22226-00-00	.. BUSH, SHOCK ABSORBER LOWER	1	
7	5DH-23183-00-00	.. CIRCLIP	1	
8	5DH-23183-00-00	.. CIRCLIP	1	
9	4JX-22226-00-00	.. BUSH, SHOCK ABSORBER LOWER	1	
10	5DH-22212-50-00	. SPRING (K=5.4)	1	
11	5DH-22214-00-00	. GUIDE, SPRING 1	1	
12	5DH-22224-00-00	. GUIDE, SPRING 2	1	
13	5DH-22253-00-00	. COLLAR, DISTANCE	2	
14	3JE-22475-00-00	. SEAL, DUST	4	
15	4EW-22253-00-00	. COLLAR, DISTANCE	2	
16	4EW-22474-00-00	. SEAL, RING	4	
17	90105-10323-00	BOLT, WASHER BASED	1	
18	95617-10200-00	NUT, SELF-LOCKING	1	
19	90105-105A2-00	BOLT, WASHER BASED	1	
20	90201-112U6-00	WASHER, PLATE	1	



5BE100-8230



STEERING

Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00081-00	BEARING	1	
2	93332-00068-00	BEARING	1	
3	4EW-23416-00-00	COVER, BALL RACE 2	1	
4	90179-28650-00	NUT	1	
5	4SS-23435-00-00	CROWN, HANDLE	1	
6	90170-24373-00	NUT	1	
7	90201-247L2-00	WASHER, PLATE	1	
8	3SP-23441-00-00	HOLDER, HANDLE UPPER ...	2	
9	95027-08035-00	BOLT, FLANGE	4	
10	95027-08040-00	BOLT, FLANGE	4	
11	4DA-23485-20-00	PLATE, NUMBER	1	
12	90119-06185-00	BOLT, WITH WASHER	1	
13	5DH-2339E-00-00	GRAPHIC 1	1	
14	90201-286K9-00	WASHER, PLATE	2	
15	4DA-23389-00-00	GUIDE, CABLE	1	
16	90105-05361-00	BOLT, WASHER BASED	1	



5BE100-8240

FRONT FORK


Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-23102-L0-00	FRONT FORK ASSEMBLY (L.H)	1	
2	5DH-23136-L0-00	. TUBE, OUTER (RIGHT)	1	
3	5DH-23120-L0-00	. INNER TUBE COMP 2	1	
4	4SS-23171-L0-00	. PISTON, FRONT FORK	1	
5	4SS-23125-L0-00	. METAL, SLIDE 1	1	
6	4SS-23146-L0-00	. WASHER, OIL SEAL	1	
7	5DH-23145-L0-00	. OIL SEAL	1	
8	4SS-23153-L0-00	. RING, SNAP	1	
9	4SS-23144-L0-00	. SEAL, DUST	1	
10	5BE-23170-L0-00	. CYLINDER COMP., FRONT FORK	1	
11	5BE-2316A-L0-00	. VALVE COMP.	1	
12	5DH-23111-L0-00	. BOLT, CAP	1	
13	5DH-23142-L0-00	. SEAT, SPRING UPPER	1	
14	5DH-23393-L0-00	. NUT, SPECIAL	1	
15	5DH-23195-L0-00	. RUBBER	1	
16	5DH-23149-L0-00	. WASHER, SPRING UPPER	1	
17	5DH-23118-L0-00	. SPACER	1	
18	4SS-23158-L0-00	. GASKET	1	
19	5BE-23141-L0-00	. SPRING, FRONT FORK (K=0.45)	1	
20	3JD-2312G-L0-00	. PLUG	1	
21	5BE-23103-L0-00	FRONT FORK ASSEMBLY (R.H)	1	
22	5DH-23136-L0-00	. TUBE, OUTER (RIGHT)	1	
23	5BF-23110-L0-00	. INNER TUBE COMP 1	1	
24	4SS-23171-L0-00	. PISTON, FRONT FORK	1	
25	4SS-23125-L0-00	. METAL, SLIDE 1	1	
26	4SS-23146-L0-00	. WASHER, OIL SEAL	1	
27	5DH-23145-L0-00	. OIL SEAL	1	

CONTINUED ON NEXT FRAME ➤




FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
28	4SS-23153-L0-00	. RING, SNAP	1	
29	4SS-23144-L0-00	. SEAL, DUST	1	
30	5BE-23170-L0-00	. CYLINDER COMP., FRONT FORK	1	
31	5BE-2316A-L0-00	. VALVE COMP.	1	
32	5DH-23111-L0-00	. BOLT, CAP	1	
33	5DH-23142-L0-00	. SEAT, SPRING UPPER	1	
34	5DH-23393-L0-00	. NUT, SPECIAL	1	
35	5DH-23195-L0-00	. RUBBER	1	
36	5DH-23149-L0-00	. WASHER, SPRING UPPER ..	1	
37	5DH-23118-L0-00	. SPACER	1	
38	4SS-23158-L0-00	. GASKET	1	
39	5BE-23141-L0-00	. SPRING, FRONT FORK (K=0.45)	1	
40	3JD-2312G-L0-00	. PLUG	1	
41	5DJ-23340-L0-00	UNDER BRACKET COMP.	1	
42	95021-08040-00	BOLT, FLANGE	8	
43	4SS-2314G-L0-00	PROTECTOR GUIDE COMP., 2	1	
44	5DH-2314F-L0-00	PROTECTOR GUIDE COMP., 1	1	
45	4SS-23346-L0-00	BOLT 1	2	
46	5DH-2314J-00-00	PROTECTOR COMP., 2	1	
47	5DH-2314H-00-00	PROTECTOR COMP., 1	1	
48	3SP-23356-L0-00	BOLT 2	6	
49	4EW-2331E-L0-00	GUIDE, CABLE	1	



5BE100-8250

FUEL TANK




Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-24110-10-00	FUEL TANK COMP.	1	
2	1UY-24610-00-00	CAP ASSEMBLY	1	
3	90445-09220-00	HOSE	1	
4	3XJ-24380-00-00	PIPE JOINT ASSEMBLY	1	
5	90445-09100-00	HOSE	1	
6	24X-24144-00-00	HOLDER, DAMPER	2	
7	90480-18549-00	GROMMET	2	
8	95027-06016-00	BOLT, FLANGE	4	
9	90119-06214-00	BOLT, WITH WASHER	2	
10	3JD-24186-00-00	WASHER, SPECIAL	2	
11	98907-06020-00	SCREW, BIND	1	
12	3SP-24173-00-00	BAND, TANK FITTING 1	1	
13	4EW-2412F-00-00	BRACKET, SEAT	1	
14	98707-06025-00	SCREW, FLAT HEAD	1	
15	4SS-24181-00-00	DAMPER, LOCATING 1	1	
16	4DP-24500-00-00	FUEL COCK ASSEMBLY 1 ...	1	
17	3AJ-24534-00-00	. SEAL, COCK	1	
18	97801-03008-00	. SCREW, PAN HEAD	2	
19	4X8-24512-00-00	. O-RING	1	
20	3AJ-24523-00-00	. VALVE PACKING	1	
21	90445-114K9-00	HOSE	1	
22	90467-10008-00	CLIP	2	
23	90202-05193-00	WASHER, PLATE	2	
24	90149-06011-00	SCREW	2	
25	5BE-24182-00-00	DAMPER, LOCATING 2	1	
26	3V6-22358-00-00	SEAL 1	2	
27	5BE-24240-00-00	GRAPHIC SET	1	



5BE100-8260

SEAT


Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-24710-10-00	SINGLE SEAT ASSEMBLY ...	1	
2	5BE-24731-10-00	. COVER, SEAT	1	
3	5BE-24728-00-00	. BRACKET, SEAT	2	
4	97007-06012-00	. BOLT	4	
5	92907-06100-00	. WASHER, SPRING	4	



5BE100-8270


FRONT WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	4SS-25111-00-00	HUB, FRONT	1	
2	93306-90403-00	BEARING	2	
3	5DH-25117-00-00	SPACER, BEARING	1	
4	93102-26468-00	OIL SEAL	2	
5	94416-21509-00	RIM (1.60-21)	1	
6	4DA-25104-00-00	SPOKE SET, FRONT	1	
7	94108-217X2-00	TIRE (80/100-21 K490)	1	DUNLOP
8	94227-21101-00	TUBE (80/100-21 TR4 BTL) ...	1	DUNLOP
9	94307-21145-00	BAND, RIM (70-80/100-21)	1	DUNLOP
10	2J5-25394-01-00	SPACER, BEAD	1	
11	5BE-25181-00-00	AXLE, WHEEL	1	
12	5DH-25183-00-00	COLLAR, WHEEL	1	
13	5BE-25186-00-00	COLLAR, WHEEL	1	
14	90179-16672-00	NUT	1	



5BE100-8280

FRONT BRAKE CALIPER



Ref. No.	Part Number	Description	Qty	Remarks
1	4XM-2582T-00-00	DISC, BRAKE	1	
2	90149-06327-00	SCREW	6	
3	5DH-2580T-00-00	CALIPER ASSEMBLY (LEFT) ..	1	
4	4EW-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
5	3JD-W0047-00-00	.. CALIPER SEAL KIT	1	
6	5DH-25919-00-00	. SUPPORT, PAD	1	
7	1UY-W0048-50-00	. BLEED SCREW KIT	1	
8	5DH-W0045-00-00	. BRAKE PAD KIT	1	
9	5DH-25933-00-00	. PIN, PAD	1	
10	5DH-25916-00-00	. PLUG	1	
11	90105-08659-00	BOLT, WASHER BASED	2	
12	5DH-2314E-00-00	COVER, HOSE	1	
13	95827-06012-00	BOLT, FLANGE	1	
14	95027-08020-00	BOLT, FLANGE	1	
15	5DH-25875-00-00	HOLDER, BRAKE HOSE 1	1	
16	92907-08200-00	WASHER	1	




5BE100-8290

REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	4EW-25311-00-00	HUB, REAR	1	
2	4EW-25317-00-00	SPACER, BEARING	1	
3	93306-00418-00	BEARING	3	
4	93106-28023-00	OIL SEAL	2	
5	94421-19538-00	RIM (2.15-19)	1	
6	4XM-25304-00-00	SPOKE SET, REAR	1	
7	94111-1902Y-00	TIRE (110/90-19 62M K695) ...	1	DUNLOP
8	94211-19273-00	TUBE (110/90 110/100-19TR4) .	1	DUNLOP
9	94311-19155-00	BAND, RIM (110/90 110/100-19)	1	DUNLOP
10	3JE-25394-00-00	SPACER, BEAD	1	
11	4XM-25364-00-00	DAMPER	1	
12	4SS-25447-00-00	SPROCKET, DRIVEN (47T) ...	1	AP
	4SS-25448-00-00	SPROCKET, DRIVEN (48T) ...	1	AP
	4SS-25449-00-00	SPROCKET, DRIVEN (49T) ...	1	STD
	4SS-25450-00-00	SPROCKET, DRIVEN (50T) ...	1	AP
	4SS-25451-00-00	SPROCKET, DRIVEN (51T) ...	1	AP
	4SS-25452-00-00	SPROCKET, DRIVEN (52T) ...	1	AP
13	90109-081G1-00	BOLT	6	
14	95617-08200-00	NUT, SELF-LOCKING	6	
15	90201-08326-00	WASHER, PLATE	6	
16	90480-08608-00	GROMMET	1	
17	90387-2000B-00	COLLAR	1	
18	90387-2000C-00	COLLAR	1	
19	3SP-25388-00-00	PULLER, CHAIN 1	2	
20	90101-08777-00	BOLT	2	
21	95707-08500-00	NUT, FLANGE	2	
22	3JD-25381-01-00	AXLE, WHEEL	1	
23	90185-18104-00	NUT, SELF-LOCKING	1	
24	92907-18600-00	WASHER	1	


CONTINUED ON NEXT FRAME ➤



 5BE100-8300


REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
25	94581-68114-00	CHAIN (D.I.D.520DM 114LL) ...	1	
26	94681-68001-00	. JOINT, CHAIN	1	
27	4V4-25367-00-00	COVER, HUB DUST	2	



 5BE100-8300

REAR BRAKE CALIPER




Ref. No.	Part Number	Description	Qty	Remarks
1	4MX-2582W-00-00	DISC, REAR BRAKE 2	1	
2	90149-06327-00	SCREW	6	
3	4XL-2580W-00-00	CALIPER ASSEMBLY, REAR 2	1	
4	3SP-W0057-50-00	. PISTON ASSEMBLY, CALIPER	1	
5	3JD-W0047-50-00	. . CALIPER SEAL KIT	1	
6	4GY-25919-50-00	. SUPPORT, PAD	1	
7	1UY-W0048-50-00	. BLEED SCREW KIT	1	
8	4GY-W0046-00-00	. BRAKE PAD KIT 2	1	
9	3SP-25924-51-00	. PIN, PAD	2	
10	4XM-25827-50-00	. SHIM, CALIPER	1	
11	4GY-22898-50-00	. INSULATOR, HEAT	1	
12	4MX-25718-00-00	PROTECTOR, DISK BRAKE ...	1	
13	95027-06012-00	BOLT, FLANGE	2	
14	4GY-27491-00-00	PROTECTOR	1	
15	95027-06016-00	BOLT, FLANGE	2	



5BE100-8310


STEERING HANDLE - CABLE

Ref. No.	Part Number	Description	Qty	Remarks
1	4XM-26111-00-00	HANDLEBAR	1	
2	4GY-26241-00-00	GRIP (LEFT)	1	
3	5BE-26240-00-00	GRIP ASSEMBLY	1	
4	5BE-26281-00-00	CAP, GRIP UPPER	1	
5	5BE-26282-00-00	CAP, GRIP LOWER	1	
6	98507-05020-00	SCREW, PAN HEAD	2	
7	5BE-26302-00-00	THROTTLE CABLE ASSEMBLY	1	
8	5BE-26335-00-00	CABLE, CLUTCH	1	
9	90387-225N2-00	COLLAR	1	



5BE100-8320

FRONT MASTER CYLINDER




Ref. No.	Part Number	Description	Qty	Remarks
1	5DH-25872-00-00	HOSE, BRAKE 1	1	
2	90201-10118-00	WASHER, PLATE	4	
3	90401-10172-00	BOLT, UNION	2	
4	4SS-W2587-00-00	MASTER CYLINDER SUB ASSEMBLY	1	
5	4SS-W0041-00-00	. CYLINDER KIT, MASTER	1	
6	98706-04012-00	. SCREW, FLAT HEAD	2	
7	4SS-25852-00-00	. CAP, RESERVOIR	1	
8	4SS-25854-00-00	. DIAPHRAGM, RESERVOIR ..	1	
9	4SS-25889-00-00	. SEPARATOR ASSEMBLY ...	1	
10	4SS-25880-00-00	. PUSH ROD COMP.	1	
11	4SS-25868-00-00	. BOOT, MASTER CYLINDER ..	1	
12	4SS-2538E-00-00	NUT, ADJUSTING	2	
13	4SS-83913-00-00	COLLAR, LEVER 1	1	
14	3YX-25866-10-00	CIRCLIP	1	
15	4SS-25866-00-00	CIRCLIP	1	
16	4SS-2583G-00-00	WASHER	1	
17	4SS-83922-01-00	LEVER 2	1	
18	95606-06100-00	NUT, U	1	
19	4SS-2589F-00-00	BOLT, LEVER	1	
20	3YK-25867-00-00	BRACKET, MASTER CYLINDER	1	
21	4SS-25833-00-00	BOLT, FITTING	2	
22	90465-16258-00	CLAMP	2	
23	91317-06014-00	BOLT	2	



5BE100-8330

STAND - FOOTREST




Ref. No.	Part Number	Description	Qty	Remarks
1	4XM-27200-00-00	PEDAL, BRAKE	1	
2	4SS-27217-00-00	BOLT	1	
3	93210-11073-00	O-RING	2	
4	91401-20012-00	PIN, COTTER	1	
5	90506-16500-00	SPRING, TENSION	1	
6	90240-08120-00	PIN, CLEVIS	1	
7	90201-08089-00	WASHER, PLATE	1	
8	90468-16191-00	CLIP	1	
9	4XM-27411-00-00	FOOTREST 1	1	
10	4XM-27421-00-00	FOOTREST 2	1	
11	90240-10142-00	PIN, CLEVIS	2	
12	91401-25015-00	PIN, COTTER	2	
13	90508-282B8-00	SPRING, TORSION	1	
14	90508-282B9-00	SPRING, TORSION	1	
15	3SP-27311-00-00	STAND, SIDE	1	
16	90201-10119-00	WASHER, PLATE	2	



5BE100-8340


REAR MASTER CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-2583V-00-00	RR. MASTER CYLINDER ASSEMBLY.	1	
2	5BE-W0042-00-00	. CYLINDER KIT, MASTER	1	
3	93210-15620-00	. O-RING	1	
4	2VN-25866-00-00	. CIRCLIP	1	
5	4ML-2582A-50-00	. JOINT	1	
6	3SP-27222-00-00	. JOINT	1	
7	95301-08700-00	. NUT	2	
8	5BE-25894-00-00	. TANK, RESERVOIR	1	
9	5BE-25852-00-00	. CAP, RESERVOIR	1	
10	98706-04040-00	. SCREW, FLAT HEAD	2	
11	56A-25854-00-00	. DIAPHRAGM, RESERVOIR ..	1	
12	90467-12085-00	. CLIP	2	
13	5BE-25895-00-00	. HOSE, RESERVOIR	1	
14	3FV-2589A-00-00	. COVER, DUST	1	
15	5BE-2117M-00-00	COVER 2	1	
16	92014-06016-00	BOLT, BUTTON HEAD	2	
17	95027-06012-00	BOLT, FLANGE	1	
18	4SS-25873-01-00	HOSE, BRAKE 2	1	
19	90401-10172-00	BOLT, UNION	2	
20	90201-10118-00	WASHER, PLATE	3	
21	2VM-25876-00-00	HOLDER, BRAKE HOSE 2	2	
22	97780-50510-00	SCREW, TAPPING	4	
23	5BE-25844-00-00	WASHER, LOCK	1	




GENERATOR

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-85560-00-00	BASE ASSEMBLY	1	
2	5BE-85550-00-00	ROTOR ASSEMBLY	1	
3	90149-06324-00	SCREW	3	
4	90179-10394-00	NUT	1	
5	90201-10591-00	WASHER, PLATE	1	




5BE100-8360

HANDLE SWITCH - LEVER




Ref. No.	Part Number	Description	Qty	Remarks
1	38V-82911-00-00	HOLDER, LEVER 1	1	
2	38V-82913-00-00	HOLDER, LEVER LOWER 1 ...	1	
3	4GY-83912-00-00	LEVER 1	1	
4	90109-06799-00	BOLT	1	
5	95607-06100-00	NUT, U	1	
6	97007-05016-00	BOLT	2	
7	90123-08090-00	BOLT	1	
8	90179-08401-00	NUT	1	
9	23X-83976-00-00	SWITCH, HANDLE 1	1	
10	583-83981-00-00	LEVER, DECOMPRESSION ...	1	
11	5BE-83913-00-00	COLLAR, LEVER 1	1	
12	98907-05020-00	SCREW, BIND	1	
13	95607-05100-00	NUT, U	1	
14	5BE-82912-00-00	HOLDER, LEVER UPPER 1 ...	1	
15	38V-82913-00-00	HOLDER, LEVER LOWER 1 ...	1	
16	97007-05016-00	BOLT	2	
17	583-26352-00-00	COVER, DECOMPRESSION CABLE	1	



5BE100-8370

ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-85540-00-00	C.D.I. UNIT ASSEMBLY	1	
2	5BE-85546-00-00	BAND	1	
3	5BE-82310-00-00	IGNITION COIL ASSEMBLY ...	1	
4	91317-06016-00	BOLT	2	
5	5BE-82370-00-00	PLUG CAP ASSEMBLY	1	
6	5BE-82540-00-00	NEUTRAL SWITCH ASSEMBLY	1	
7	93210-21276-00	O-RING	1	
8	90154-05073-00	SCREW, BINDING	2	
9	90464-16061-00	CLAMP	2	
10	90464-13073-00	CLAMP	1	
11	90464-15195-00	CLAMP	1	
12	90460-15126-00	CLAMP, HOSE	1	
13	90464-13077-00	CLAMP	2	
14	90464-15152-00	CLAMP	1	
15	90464-13073-00	CLAMP	1	
16	90465-13275-00	CLAMP	2	
17	90464-15195-00	CLAMP	1	
18	5BE-82509-00-00	WIRE, SUB LEAD	1	



ALTERNATE (CHASSIS)



Ref. No.	Part Number	Description	Qty	Remarks
1	5DH-22212-10-00	SPRING (K=4.6)	1	AP
	5DH-22212-20-00	SPRING (K=4.8)	1	AP
	5DH-22212-30-00	SPRING (K=5.0)	1	AP
	5DH-22212-40-00	SPRING (K=5.2)	1	AP
	5DH-22212-50-00	SPRING (K=5.4)	1	AP
	5DH-22212-60-00	SPRING (K=5.6)	1	AP
2	4SS-23141-10-00	SPRING, FRONT FORK (K=0.38)	2	AP
	4SS-23141-20-00	SPRING, FRONT FORK (K=0.39)	2	AP
	4SS-23141-30-00	SPRING, FRONT FORK (K=0.40)	2	AP
	4SS-23141-40-00	SPRING, FRONT FORK (K=0.41)	2	AP
	4SS-23141-50-00	SPRING, FRONT FORK (K=0.42)	2	AP
	4SS-23141-60-00	SPRING, FRONT FORK (K=0.43)	2	AP
	4SS-23141-70-00	SPRING, FRONT FORK (K=0.44)	2	AP
	5BE-23141-00-00	SPRING, FRONT FORK (K=0.46)	2	AP
3	4SS-23364-L0-00	COLLAR 2	1	UN



5BE100-8390