

PARTS CATALOGUE
MODEL YEAR 2001
COMPETITION
YZ426FN (5JG5)

STARTING VIN: JYACJ01C*1A011312 and following

Color Code	Color Name	Abbreviation
583	DEEP PURPLISH BLUE SOLID E	DPBSE

OWNERS LIT-11626-14-41
ASSEMBLY LIT-11666-14-41
SERVICE LIT-11616-14-41

FOREWORD

-INTRODUCTION-
To The Yamaha Parts Fiche

This parts fiche lists parts and sub assemblies for the YZ426FN. When preparing a parts order, please refer to the most recently updated microfiche for this model.

THE YAMAHA PARTS FICHE

SYMBOLS

I	J	Inactive, no longer available
U	R	Use size (thickness) and/or number as required
U	N	Use as many as you need
T		Number of teeth in a gear
V		Voltage for light bulbs
S		
SD	SO	SW
E	R	
F	No	
L	M	Locally made
O	L	Obtain locally
A	P	Alternate Part

SUPERSEDED PART NUMBERS

If part 'A' has been superseded by part B, the superseding part number B will appear in the part number listing with the superseded part number "A" appearing in parentheses immediately following the description.

EXAMPLE

Ref. No.	Part No.	Description	Qty.
8	(Part B') 123 45678 00 00	(Part A) CYLINDER (111 12345 00 00)	1

A part that has been superseded to a kit may be identified by a 99999 00000 00 part number appearing in the part number column. The old superseded part number will appear in parentheses immediately following the description. Listed directly below the 99999 part number will be those parts making up the kit. The description of the parts making up the kit will be preceded by a small black dot (•) and the description will be indented one letter space.

EXAMPLE

Ref. No.	Part No.	Description	Qty.
8	99999 12345 00	CYLINDER (111-12345 00 00)	1
	234 56789 00 00	• HEAD CYLINDER	1
	345 67890 00 00	• GASKET CYLINDER	1

SIZES

Except for steel balls (ball sizes are indicated in inches), all parts sizes are indicated in millimeters as in the following examples:

Hose (Rubber or Vinyl)	Inside Diameter	Length
O Ring	Section Area - Inside Diameter	
Washer Shim Collar	Inside Diameter - Outside Diameter	Thickness (Length)

ASSEMBLIES AND COMPONENT PARTS

Assemblies and their component parts, are identified by an indentation of one letter space, and the description is preceded by a dot (•). If two main assemblies are listed and have the same basic description (i.e., left and right sides of the same assembly), one will immediately follow the other. If each of these main assemblies is made up of almost the same components, these component parts will be listed immediately under the second main assembly line and will be indicated, as noted above.


If the component is the same for both main assemblies, the quantity indicated will be the total required. If the component is not the same for both main assemblies, the quantity for each separate item will be listed separately.

EXAMPLE


Description	Qty.
CARBURETOR ASSY, LEFT	1
CARBURETOR ASSY, RIGHT	1
JET, PILOT	2
NOZZLE, MAIN	2
LEVER, STARTER, LEFT	1
LEVER, STARTER, RIGHT	1

APPLICABLE SERIAL NO.

(1) Engine Serial No.



(2) Frame Serial No.




FOREWORD

THE YAMAHA PART NUMBER

The Yamaha part number consists of 12 digits. Each number represents a specific piece of information relating to a replacement part. The following is a guide for reading and interpreting the Yamaha part number.

BASIC PART NUMBER CONFIGURATION



MODEL CODE NUMBER

FIRST THREE DIGITS 000 00000 00 00


Every model in each Yamaha product line is assigned a model number to identify that particular model. All component parts are given the model code number relating to the model on which they were first used.

Example 4DU 00000 00 00 identifies the XJ600SE
3FA 00000 00 00 identifies the YFA1E

BASIC CODE NUMBER


MIDDLE FIVE DIGITS 000 00000 00 00

These 'Middle Five Digits' indicate the type of part, i.e., piston, rings, lower units, etc. The five digits are broken down as follows:



The Major Classification indicates the section to which the parts belong, i.e., engine, electrical, etc. The Intermediate and Minor Classifications indicate more specific details.

Example



DESIGN CODE NUMBER 000 00000 00 00

The design code distinguishes like component parts from one another when specification differences are involved. For example, distinguishing a standard size piston ring from an oversized piston ring.

Example

4BR 11610 0 0 00 Standard Piston Ring Set for XJ600SE
4BR 11610 2 0 00 Oversize Piston Ring Set for XJ600SE

DESIGN CHANGE CODE NUMBER 000 00000 00 00

This code number is used to identify a difference between a new component part and old one when a new part is created by changing the old one.

Example YFZ350E

2GU-11610 0 0 00 PISTON RING SET STD - ORIGINAL
2GU-11610 0 1 00 PISTON RING SET STD - FIRST DESIGN CHANGE


Only major changes to performance, durability, quality, appearance, cost, or interchangeability will affect a part number change.

COLOR CODE & SIZE CODE NUMBER 000 00000 00 00

When applicable, the last two digits of the part number identify:

- 1 Color Code: The painted color or type of plating or surface treatment used on certain parts.
- 2 Size Code: The last two digits are also used to show the size of parts (mm). Such as the thickness of shims or the size of pistons.

HARDWARE (Fastener) PART NUMBER CONFIGURATION



TYPE

A fastener part number always begins with the number 9, followed by either a 0, 1, 2, 3, 4, 5, 6, 7, or 8 designating one of eight major divisions within this group.

FOREWORD

Example

9 0 000 00000 00 "0" designates various types
9 1 000 00000 00 1 designates bolts cotter pins etc
9 2 000 00000 00 2 designates screw nuts etc
9 3 000 00000 00 3 designates oil seals, o rings bearings, etc
9 4 000 00000 00 4 designates spark plugs
9 5 000 00000 00 5" designates bolts and nuts
9 7 000 00000 00 7 designates ISO bolts
9 8 000 00000 00 8 designates ISO screws and nuts

The only major divisions which the mechanic should become familiar with are those related to the general hardware (nuts, bolts and washers), since these are the most commonly used and most often replaced items. By knowing how to interpret the part number, the dimensions of a piece of hardware can be determined. This can be very helpful during major engine repair, and general parts replacement.

BOLT EXAMPLE

91311 - 06 018 00
6mm outside diameter 18mm in length

EXCEPTION

It is NOT possible to identify the LENGTH of bolts having a 901 prefix. Only the bolt diameter can be identified with this number.

NUT AND WASHER EXAMPLE

95301 08600 - 00 NUT
8mm inside diameter

90201 - 25290 00 WASHER
25mm inside diameter

-MODEL LABEL-

A label called "Model Label" is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross reference the "model code - production code No." in the catalogue to the "model code - production code No." indicated on the Model Label affixed onto the product concerned.

"MODEL LABEL" INDICATION

1
xxxx - xxx
x³

2
Model Type Code


2
Production Code No.

3
Coloring Type

○ 4TW1-010


● A

MODEL LABEL AFFIXING LOCATION



MODEL CODE PRODUCTION CODE NUMBER OF MODEL LISTED IN THIS PARTS CATALOG

Model Code	Production Code No	Country (destination)
5JG5	010	USA




CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-11102-10-00	CYLINDER HEAD ASSY	1	(5JG5)
2	5BE-11133-10-00	. GUIDE, INTAKE VALVE	3	(5JG5)
3	5BE-11134-10-00	. GUIDE, EXHAUST VALVE	2	(5JG5)
4	93440-10153-00	. CIRCLIP	5	(5JG5)
5	91808-16023-00	. PIN, DOWEL	4	(5JG5)
6	90105-067A6-00	. BOLT, WASHER BASED	10	(5JG5)
7	90340-12112-00	. PLUG, STRAIGHT SCREW	1	(5JG5)
8	95617-06635-00	BOLT, STUD	2	(5JG5)
9	95617-08635-00	BOLT, STUD	2	(5JG5)
10	95617-08620-00	BOLT, STUD	1	(5JG5)
11	95707-08500-00	NUT, FLANGE	1	(5JG5)
12	NGK-CR9E0-00-00	PLUG, SPARK (NGK R CR9E)	1	UR(5JG5)
13	5JG-11181-00-00	GASKET, CYLINDER HEAD 1	1	(5JG5)
14	90105-104A7-00	BOLT, WASHER BASED	2	(5JG5)
15	90105-106A3-00	BOLT, WASHER BASED	2	(5JG5)
16	90201-101A4-00	WASHER, PLATE	4	(5JG5)
17	5BE-11191-00-00	COVER, CYLINDER HEAD 1	1	(5JG5)
18	5BE-11167-00-00	PIPE, BREATHER 2	1	(5JG5)
19	90109-066F0-00	BOLT	2	(5JG5)
20	4KG-1111G-00-00	RUBBER, MOUNT 1	2	(5JG5)
21	371-11167-01-00	PIPE, BREATHER 2	1	(5JG5)
22	5BE-11166-00-00	PIPE, BREATHER 1	1	(5JG5)
23	90445-112K0-00	HOSE (L285)	1	(5JG5)
24	90467-11106-00	CLIP	2	(5JG5)
25	90467-14015-00	CLIP	1	(5JG5)
26	5BE-11193-10-00	GASKET, HEAD COVER 1	1	(5JG5)
27	5JG-11311-00-00	CYLINDER 1	1	(5JG5)
28	5BE-11351-00-00	GASKET, CYLINDER	1	(5JG5)
29	90179-06500-00	NUT	2	(5JG5)

CONTINUED ON NEXT FRAME ➤



5JG1100-0010




5JG1100-0010

YZ426FN

CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
30	93612-16254-00	PIN, DOWEL	2	(5JG5)
31	90179-08270-00	NUT	2	(5JG5)
32	95027-06040-00	BOLT, FLANGE	1	(5JG5)
33	5JG-11387-00-00	CLAMP, HOSE 1	1	(5JG5)


CRANKSHAFT. PISTON



Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-11400-10-00	CRANKSHAFT ASSY	1	(5JG5)
2	5JG-11412-10-00	. CRANK 1	1	(5JG5)
3	5JG-11422-10-00	. CRANK 2	1	(5JG5)
4	5BE-11681-00-00	. PIN, CRANK 1	1	(5JG5)
5	93310-634B0-00	. BEARING	1	(5JG5)
6	5JG-11651-00-00	. ROD, CONNECTING	1	(5JG5)
7	93306-30633-00	BEARING	2	(5JG5)
8	5JG-11536-00-00	GEAR, DRIVE	1	(5JG5)
9	5BE-11455-00-00	SHAFT 1	1	(5JG5)
10	5BE-11454-00-00	WEIGHT 1	1	(5JG5)
11	5BE-11531-00-00	GEAR, BALANCE WT	1	(5JG5)
12	90149-06250-00	SCREW	3	(5JG5)
13	93306-20335-00	BEARING	1	(5JG5)
14	93311-62574-00	BEARING	1	(5JG5)
15	90170-14171-00	NUT	1	(5JG5)
16	90215-14204-00	WASHER, LOCK	1	(5JG5)
17	90280-03001-00	KEY, WOODRUFF	1	(5JG5)
18	5JG-11631-10-00	PISTON (STD)	1	(5JG5)
19	5JG-11603-00-00	PISTON RING SET (STD)	1	(5JG5)
20	5JG-11633-00-00	PIN, PISTON	1	(5JG5)
21	93420-19084-00	CIRCLIP	2	(5JG5)



5JG5100-1020




VALVE

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-12111-00-00	VALVE, INTAKE	1	(5JG5)
2	5JG-12112-00-00	VALVE, INTAKE 2	2	(5JG5)
3	5JG-12121-00-00	VALVE, EXHAUST	2	(5JG5)
4	3GM-12126-00-00	SEAT, VALVE SPRING 2	5	(5JG5)
5	5JG-12113-00-00	SPRING, VALVE INNER	3	(5JG5)
6	5JG-12114-00-00	SPRING, VALVE OUTER	2	(5JG5)
7	5BE-12117-00-00	RETAINER, VALVE SPRING ..	3	(5JG5)
8	4GY-12117-00-00	RETAINER, VALVE SPRING ..	2	(5JG5)
9	1AA-12118-00-00	COTTER, VALVE	4	(5JG5)
10	1WG-12118-00-00	COTTER, VALVE	6	(5JG5)
11	33M-12119-00-00	SEAL, VALVE STEM	2	(5JG5)
12	4SV-12119-00-00	SEAL, VALVE STEM	3	(5JG5)
13	3LD-12168-00-00	PAD, ADJUSTING (1.20)	5	UR(5JG5)
	3LD-12168-20-00	PAD, ADJUSTING (1.25)	5	UR(5JG5)
	3LD-12168-40-00	PAD, ADJUSTING (1.30)	5	UR(5JG5)
	3LD-12168-60-00	PAD, ADJUSTING (1.35)	5	UR(5JG5)
	3LD-12168-80-00	PAD, ADJUSTING (1.40)	5	UR(5JG5)
	3LD-12168-A0-00	PAD, ADJUSTING (1.45)	5	UR(5JG5)
	3LD-12168-F0-00	PAD, ADJUSTING (1.50)	5	UR(5JG5)
	3LD-12168-H1-00	PAD, ADJUSTING (1.55)	5	UR(5JG5)
	3LD-12168-K1-00	PAD, ADJUSTING (1.60)	5	UR(5JG5)
	3LD-12168-M1-00	PAD, ADJUSTING (1.65)	5	UR(5JG5)
	3LD-12168-R1-00	PAD, ADJUSTING (1.70)	5	UR(5JG5)
	3LD-12168-U1-00	PAD, ADJUSTING (1.75)	5	UR(5JG5)
	3LD-12168-W1-00	PAD, ADJUSTING (1.80)	5	UR(5JG5)
	3LD-12168-Y1-00	PAD, ADJUSTING (1.85)	5	UR(5JG5)
	3LD-12169-11-00	PAD, ADJUSTING (1.90)	5	UR(5JG5)
	3LD-12169-31-00	PAD, ADJUSTING (1.95)	5	UR(5JG5)
	3LD-12169-50-00	PAD, ADJUSTING (2.00)	5	UR(5JG5)

CONTINUED ON NEXT FRAME ➤



5BE100-8030




VALVE

Ref. No.	Part Number	Description	Qty	Remarks
13	3LD-12169-70-00	PAD, ADJUSTING (2.05)	5	UR(5JG5)
	3LD-12169-90-00	PAD, ADJUSTING (2.10)	5	UR(5JG5)
	3LD-12169-E0-00	PAD, ADJUSTING (2.15)	5	UR(5JG5)
	3LD-12169-G0-00	PAD, ADJUSTING (2.20)	5	UR(5JG5)
	3LD-12169-J0-00	PAD, ADJUSTING (2.25)	5	UR(5JG5)
	3LD-12169-L0-00	PAD, ADJUSTING (2.30)	5	UR(5JG5)
	3LD-12169-N0-00	PAD, ADJUSTING (2.35)	5	UR(5JG5)
	3LD-12169-T0-00	PAD, ADJUSTING (2.40)	5	UR(5JG5)
14	3FV-12153-00-00	LIFTER, VALVE	5	UR BLACK(5JG5)
	3FV-12153-10-00	LIFTER, VALVE	5	UR YELLOW(5JG5)
	3FV-12153-20-00	LIFTER, VALVE	5	UR BLUE(5JG5)



5BE100-8030



5JG1100-0040


CAMSHAFT. CHAIN

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-12170-10-00	CAMSHAFT ASSY 1	1	(5JG5)
2	5BE-12180-01-00	CAMSHAFT ASSY 2	1	(5JG5)
3	93440-41178-00	CIRCLIP	2	(5JG5)
4	94591-50120-00	CHAIN	1	(5JG5)
5	5BE-12210-00-00	TENSIONER ASSY, CAM CHAIN	1	(5JG5)
6	4FM-12213-00-00	GASKET, TENSIONER CASE ..	1	(5JG5)
7	95027-06025-00	BOLT, FLANGE	2	(5JG5)
8	5BE-12251-10-00	DAMPER, CHAIN 1	1	(5JG5)
9	5BE-12252-00-00	DAMPER, CHAIN 2	1	(5JG5)
10	97027-06016-00	BOLT	2	(5JG5)
11	92907-06600-00	WASHER, PLATE	2	(5JG5)
12	5BE-12241-00-00	GUIDE, STOPPER 2	1	(5JG5)
13	90109-06418-00	BOLT	1	(5JG5)
14	90430-06014-00	GASKET	1	(5JG5)
15	93102-12224-00	OIL SEAL	1	(5JG5)
16	5BE-12280-10-00	DECOMPRESSION ASSY	1	(5JG5)
17	90508-162B2-00	SPRING, TORSION	1	(5JG5)
18	5BE-12283-00-00	BRACKET, DECOMPRESSION .	1	(5JG5)
19	5BE-12292-10-00	CABLE, DECOMPRESSION ...	1	(5JG5)
20	95827-06014-00	BOLT, FLANGE	1	(5JG5)




5BE100-8050

YZ426FN



WATER PUMP


Ref. No.	Part Number	Description	Qty	Remarks
1	5GR-12458-00-00	SHAFT, IMPELLER	1	(5JG5)
2	5DJ-12451-00-00	IMPELLER, WATER PUMP	1	(5JG5)
3	90201-08512-00	WASHER, PLATE	1	(5JG5)
4	93109-11073-00	OIL SEAL	1	(5JG5)
5	93102-12106-00	OIL SEAL (SD 12-22-5 HS)	1	(5JG5)
6	93306-00105-00	BEARING (B6001)	1	(5JG5)
7	5BE-12422-10-00	COVER, HOUSING	1	(5JG5)
8	5BE-12439-00-00	O-RING	1	(5JG5)
9	93604-10011-00	PIN, DOWEL	2	(5JG5)
10	90430-06014-00	GASKET	1	(5JG5)
11	95027-06025-00	BOLT, FLANGE	4	(5JG5)
12	5BE-12564-00-00	PIPE, WATER	2	(5JG5)
13	93210-19758-00	O-RING	2	(5JG5)



5JG1100-0060

RADIATOR. HOSE

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-1240A-00-00	RADIATOR ASSY	1	(5JG5)
2	5JG-12461-00-00	RADIATOR ASSY	1	(5JG5)
3	5HD-12462-00-00	CAP, RADIATOR	1	(5JG5)
4	91A20-05065-00	TUBE, FLEXIBLE VINYL	1	(5JG5)
5	90467-09006-00	CLIP	1	(5JG5)
6	5BE-12481-10-00	PIPE 1	1	(5JG5)
7	95027-06012-00	BOLT, FLANGE	1	(5JG5)
8	93210-16500-00	O-RING	1	(5JG5)
9	5BE-12576-00-00	HOSE 1	1	(5JG5)
10	5BE-12577-01-00	HOSE 2	1	(5JG5)
11	5BE-12578-00-00	HOSE 3	1	(5JG5)
12	5BE-12579-02-00	HOSE 4	1	(5JG5)
13	5BE-12482-00-00	PIPE 2	1	(5JG5)
14	95027-06012-00	BOLT, FLANGE	1	(5JG5)
15	93210-16500-00	O-RING	1	(5JG5)
16	90450-28014-00	HOSE CLAMP ASSY	3	(5JG5)
17	90450-25037-00	HOSE CLAMP ASSY	5	(5JG5)
18	90480-15528-00	GROMMET	6	(5JG5)
19	90387-0614M-00	COLLAR	6	(5JG5)
20	95027-06025-00	BOLT, FLANGE	6	(5JG5)
21	90201-06071-00	WASHER, PLATE	6	(5JG5)
22	95827-06010-00	BOLT, FLANGE	2	(5JG5)




5BE100-8070

OIL PUMP


Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-13300-10-00	OIL PUMP ASSY	1	(5JG5)
2	1HX-13310-10-00	ROTOR ASSY 1	1	(5JG5)
3	93603-17070-00	PIN, DOWEL	1	(5JG5)
4	93440-10085-00	CIRCLIP	1	(5JG5)
5	93210-10197-00	O-RING	1	(5JG5)
6	99530-10114-00	PIN, DOWEL	1	(5JG5)
7	99530-08012-00	PIN, DOWEL	1	(5JG5)
8	91317-06025-00	BOLT	2	(5JG5)
9	91314-06030-00	BOLT	1	(5JG5)
10	99001-08600-00	CIRCLIP	1	(5JG5)
11	5BE-13341-00-00	GEAR, OIL PUMP IDLE	1	(5JG5)
12	5BE-13342-00-00	SHAFT, IDLE GEAR	1	(5JG5)
13	99009-12400-00	CIRCLIP	1	(5JG5)
14	90201-12166-00	WASHER, PLATE	1	(5JG5)
15	5BE-13412-00-00	HOUSING, STRAINER	1	(5JG5)
16	95027-06025-00	BOLT, FLANGE	2	(5JG5)
17	5BE-13411-00-00	STRAINER, OIL	1	(5JG5)
18	5BE-13464-10-00	HOSE, OIL 1	1	(5JG5)
19	93210-10197-00	O-RING	1	(5JG5)
20	99530-10114-00	PIN, DOWEL	1	(5JG5)
21	95027-06025-00	BOLT, FLANGE	1	(5JG5)
22	90450-22017-00	HOSE CLAMP ASSY	1	(5JG5)
23	5BE-13416-00-00	PIPE, OIL 1	1	(5JG5)
24	5BE-13465-10-00	HOSE, OIL 2	1	(5JG5)
25	90450-22017-00	HOSE CLAMP ASSY	1	(5JG5)
26	93210-10197-00	O-RING	2	(5JG5)
27	99530-10114-00	PIN, DOWEL	2	(5JG5)
28	95027-06025-00	BOLT, FLANGE	1	(5JG5)
29	95024-06020-00	BOLT, FLANGE	1	(5JG5)

OIL CLEANER

Ref. No.	Part Number	Description	Qty	Remarks
1	1UY-13440-02-00	ELEMENT ASSY, OIL CLEANER	1	(5JG5)
2	5BE-13447-00-00	COVER, OIL ELEMENT	1	(5JG5)
3	93210-47675-00	O-RING	1	(5JG5)
4	93210-07135-00	O-RING	3	(5JG5)
5	90109-065G2-00	BOLT	1	(5JG5)
6	95027-06065-00	BOLT, FLANGE	1	(5JG5)
7	95027-06020-00	BOLT, FLANGE	1	(5JG5)
8	5BE-13161-01-00	PIPE, DELIVERY 1	1	(5JG5)
9	90401-10159-00	BOLT, UNION	1	(5JG5)
10	90430-10188-00	GASKET	2	(5JG5)
11	90401-08038-00	BOLT, UNION	2	(5JG5)
12	90430-08119-00	GASKET	4	(5JG5)
13	5BE-13171-01-00	PIPE, DELIVERY 2	1	(5JG5)
14	93210-07003-00	O-RING	1	(5JG5)
15	93210-09008-00	O-RING	1	(5JG5)
16	93210-12759-00	O-RING	1	(5JG5)
17	95027-06012-00	BOLT, FLANGE	1	(5JG5)




5BE100-8080



INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-13597-00-00	JOINT, CARBURETOR 3	1	(5JG5)
2	90450-57092-00	HOSE CLAMP ASSY	1	(5JG5)
3	90450-59091-00	HOSE CLAMP ASSY	1	(5JG5)
4	5JG-1440F-01-00	JOINT, AIR FILTER 1	1	(5JG5)
5	91317-05014-00	BOLT	2	(5JG5)
6	4FN-14561-00-00	O-RING	1	(5JG5)
7	90450-61001-00	HOSE CLAMP ASSY	1	(5JG5)
8	5JG-14293-01-00	COVER 1	1	(5JG5)
9	5JG-14428-00-00	BOLT	1	(5JG5)
10	5JG-14401-00-00	AIR CLEANER CASE ASSY	1	(5JG5)
11	5JG-14453-00-00	JOINT, AIR CLEANER 1	1	(5JG5)
12	3JD-14459-01-00	HOLDER, GUIDE	1	(5JG5)
13	5MV-14477-00-00	PLATE	1	(5JG5)
14	95607-05100-00	NUT, U	5	(5JG5)
15	5BE-1443E-00-00	PIPE, DRAIN	1	(5JG5)
16	90467-17089-00	CLIP	1	(5JG5)
17	4XM-14451-00-00	ELEMENT, AIR CLEANER	1	(5JG5)
18	90209-06096-00	WASHER	1	(5JG5)
19	90122-06035-00	BOLT, WING	1	(5JG5)
20	5BE-14458-00-00	GUIDE	1	(5JG5)
21	5BE-1441A-10-00	COVER, CLEANER CASE 1	1	(5JG5)
22	5BE-1441E-10-00	COVER, CLEANER CASE 2	1	(5JG5)
23	90267-32070-00	RIVET, BLIND	5	(5JG5)
24	90201-03313-00	WASHER, PLATE	5	(5JG5)
25	90183-06023-00	NUT, SPRING	2	(5JG5)
26	95027-06012-00	BOLT, FLANGE	1	(5JG5)
27	5JG-14417-00-00	COVER 1	1	AP(5JG5)


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-14101-50-00	CARBURETOR ASSY 1	1	(5JG5)
2	5JG-14959-00-00	. GASKET	1	(5JG5)
3	91316-04012-00	. BOLT	4	(5JG5)
4	91316-04012-00	. BOLT	2	(5JG5)
5	91316-04008-00	. BOLT	3	(5JG5)
6	90202-08045-00	. WASHER, PLATE	1	(5JG5)
7	5JG-14951-00-00	. WASHER	1	(5JG5)
8	5JG-14522-00-00	. SCREW, ADJUST	1	(5JG5)
9	5JG-14388-00-00	. VALVE, VACUUM CONTROL .	1	(5JG5)
10	3TJ-14267-40-00	. ROLLER	1	(5JG5)
11	5JG-14546-00-00	. VALVE, NEEDLE	1	(5JG5)
12	4FN-14997-00-00	. SEAL	1	(5JG5)
13	5JG-14916-J1-00	. NEEDLE (EJQ)	1	AP(5JG5)
	5JG-14916-JL-00	. NEEDLE (EJL)	1	AP(5JG5)
	5JG-14916-JM-00	. NEEDLE (EJM)	1	AP(5JG5)
	5JG-14916-JN-00	. NEEDLE (EJN)	1	AP(5JG5)
	5JG-14916-JP-00	. NEEDLE (EJP)	1	STD(5JG5)
	5JG-14916-JR-00	. NEEDLE (EJR)	1	AP(5JG5)
	5JG-14916-JS-00	. NEEDLE (EJS)	1	AP(5JG5)
14	3TJ-14159-40-00	. CLIP	1	(5JG5)
15	5JG-14521-00-00	. SCREW, ADJUST	1	(5JG5)
16	5JG-14275-00-00	. SPRING	1	(5JG5)
17	5JG-14264-00-00	. COLLAR	1	(5JG5)
18	5JG-14947-00-00	. NOZZLE, MAIN	1	(5JG5)
19	4MX-14943-38-00	. JET, MAIN (155)	1	AP(5JG5)
	4MX-14943-39-00	. JET, MAIN (160)	1	AP(5JG5)
	4MX-14943-40-00	. JET, MAIN (165)	1	AP(5JG5)
	4MX-14943-41-00	. JET, MAIN (170)	1	AP(5JG5)
	4MX-14943-42-00	. JET, MAIN (175)	1	AP(5JG5)

CONTINUED ON NEXT FRAME ➤

CARBURETOR




Ref. No.	Part Number	Description	Qty	Remarks
19	4MX-14943-88-00	. JET, MAIN (152)	1	AP(5JG5)
	4MX-14943-89-00	. JET, MAIN (158)	1	AP(5JG5)
	4MX-14943-90-00	. JET, MAIN (162)	1	STD(5JG5)
	4MX-14943-91-00	. JET, MAIN (168)	1	AP(5JG5)
	4MX-14943-92-00	. JET, MAIN (172)	1	AP(5JG5)
	4MX-14943-93-00	. JET, MAIN (178)	1	AP(5JG5)
20	3TJ-14943-47-00	. JET (200)	1	(5JG5)
21	4MX-14948-01-00	. JET, SLOW (35)	1	AP(5JG5)
	4MX-14948-02-00	. JET, SLOW (38)	1	AP(5JG5)
	4MX-14948-03-00	. JET, SLOW (40)	1	AP(5JG5)
	4MX-14948-04-00	. JET, SLOW (42)	1	STD(5JG5)
	4MX-14948-05-00	. JET, SLOW (45)	1	AP(5JG5)
	4MX-14948-06-00	. JET, SLOW (48)	1	AP(5JG5)
	4MX-14948-07-00	. JET, SLOW (50)	1	AP(5JG5)
22	3TJ-1494F-12-00	. JET (62)	1	AP(5JG5)
	3TJ-1494F-13-00	. JET (65)	1	AP(5JG5)
	3TJ-1494F-14-00	. JET (68)	1	AP(5JG5)
	3TJ-1494F-15-00	. JET (70)	1	AP(5JG5)
	3TJ-1494F-16-00	. JET (72)	1	STD(5JG5)
	3TJ-1494F-17-00	. JET (75)	1	AP(5JG5)
	3TJ-1494F-18-00	. JET (78)	1	AP(5JG5)
	3TJ-1494F-19-00	. JET (80)	1	AP(5JG5)
	3TJ-1494F-20-00	. JET (82)	1	AP(5JG5)
23	7A9-14943-27-00	. JET (100)	1	(5JG5)
24	3TJ-14105-40-00	. PILOT SCREW SET	1	(5JG5)
25	5BE-14107-00-00	. NEEDLE VALVE SET	1	(5JG5)
26	5BE-14216-00-00	. SCREW	1	(5JG5)
27	4SR-14985-00-00	. FLOAT	1	(5JG5)
28	676-14548-00-00	. PIN, FLOAT ARM	1	(5JG5)

CONTINUED ON NEXT FRAME ➤

5JG5100-1100


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
29	5JG-14984-00-00	. GASKET, FLOAT CHAMBER .	1	(5JG5)
30	3TJ-14293-40-00	. COVER 1	1	(5JG5)
31	5JG-14940-06-00	. DIAPHRAGM ASSY	1	AP(5JG5)
	5JG-14940-07-00	. DIAPHRAGM ASSY	1	STD(5JG5)
	5JG-14940-08-00	. DIAPHRAGM ASSY	1	AP(5JG5)
32	3TJ-14536-40-00	. GASKET	1	(5JG5)
33	3TJ-14933-40-00	. SPRING, DIAPHRAGM	1	(5JG5)
34	6H4-14561-00-00	. O-RING	1	(5JG5)
35	5JG-14171-00-00	. PLUNGER, STARTER	1	(5JG5)
36	5JG-14371-00-00	. PLUNGER, STARTER	1	(5JG5)
37	5JG-14379-00-00	. ROD, STARTER	1	(5JG5)
38	3TJ-14325-40-00	. SCREW, PAN HEAD	1	(5JG5)
39	5JG-14922-00-00	. SCREW, THROTTLE	1	(5JG5)
40	90201-08410-00	. WASHER, PLATE	1	(5JG5)
41	4FN-14934-00-00	. SPRING, THROTTLE STOP . .	1	(5JG5)
42	5JG-85885-00-00	. THROTTLE SENSOR ASSY . .	1	(5JG5)
43	5BE-14449-00-00	. COLLAR	1	(5JG5)
44	5BE-14562-00-00	. O-RING	1	(5JG5)
45	4YR-14557-00-00	. WASHER	2	(5JG5)
46	4YR-14216-00-00	. SCREW	2	(5JG5)
47	4MX-14561-00-00	. O-RING	1	(5JG5)
48	4MX-14115-00-00	. PLUG, SCREW	1	(5JG5)
49	3TJ-14137-40-00	. CLIP	5	(5JG5)
50	5BE-14146-00-00	. PLATE	2	(5JG5)
51	5JG-14196-00-00	. PIPE	1	(5JG5)
52	5JG-14197-00-00	. PIPE	2	(5JG5)
53	5JG-14987-00-00	. HOSE	1	(5JG5)
54	5JG-14346-00-00	. PLATE	1	(5JG5)
55	5JG-14565-00-00	. SCREW	1	(5JG5)


CONTINUED ON NEXT FRAME ➤

CARBURETOR



5JG5100-1100


Ref. No.	Part Number	Description	Qty	Remarks
56	5JG-14531-00-00	. SPRING, ADJUST SCREW . . .	1	(5JG5)
57	5JG-14591-00-00	. SCREW	1	(5JG5)



5BE100-8111

EXHAUST


Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-14611-00-00	PIPE, EXHAUST 1	1	(5JG5)
2	5JG-14628-00-00	PROTECTOR, EXHAUST PIPE .	1	(5JG5)
3	4BD-14766-00-00	WASHER, PROTECTOR	6	(5JG5)
4	98980-06008-00	SCREW, BIND	3	(5JG5)
5	90206-06090-00	WASHER, WAVE	3	(5JG5)
6	3VD-14613-00-00	GASKET, EXHAUST PIPE	1	(5JG5)
7	91317-08020-00	BOLT	1	(5JG5)
8	5JG-14753-50-00	SILENCER, EXHAUST	1	(5JG5)
9	90267-48121-00	. RIVET, BLIND	8	(5JG5)
10	5JG-1469A-50-00	. FIBER	1	(5JG5)
11	5BE-1469E-00-00	. FIBER	2	(5JG5)
12	3GW-14714-00-00	GASKET, MUFFLER	1	(5JG5)
13	22W-24181-00-00	DAMPER, LOCATING 1	2	(5JG5)
14	5BE-14788-00-00	BAND, SILENCER	1	(5JG5)
15	95817-08016-00	BOLT, FLANGE	1	(5JG5)
16	95817-08030-00	BOLT, FLANGE	1	(5JG5)
17	90201-081R9-00	WASHER, PLATE	1	(5JG5)
18	90387-0814J-00	COLLAR	1	(5JG5)
19	5BE-14747-00-00	DAMPER, MUFFLER	1	(5JG5)



5BE100-8120

CRANKCASE


Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-15150-03-00	CRANKCASE ASSY	1	(5JG5)
2	99530-14016-00	PIN, DOWEL	2	(5JG5)
3	91317-06040-00	BOLT	3	(5JG5)
4	91317-06050-00	BOLT	4	(5JG5)
5	91317-06060-00	BOLT	2	(5JG5)
6	91317-06075-00	BOLT	3	(5JG5)
7	5JG-15441-01-00	HOLDER, CLUTCH CABLE ...	1	(5JG5)
8	5BE-15421-00-00	COVER, CRANKCASE 2	1	(5JG5)
9	98507-06025-00	SCREW, PAN HEAD	2	(5JG5)
10	5BE-17466-10-00	GUIDE, CHAIN	1	(5JG5)
11	90340-12059-00	PLUG, STRAIGHT SCREW	1	(5JG5)
12	90430-12213-00	GASKET	1	(5JG5)
13	4L0-17471-00-00	PLATE, COVER	1	(5JG5)
14	90105-06553-00	BOLT, WASHER BASED	2	(5JG5)
15	4JT-15381-01-00	PLATE, BEARING COVER	5	(5JG5)
16	5BE-15383-01-00	PLATE, BEARING COVER	4	(5JG5)
17	90149-06126-00	SCREW	4	(5JG5)
18	90149-06326-00	SCREW	5	(5JG5)
19	5DH-18562-00-00	PLATE, STOPPER 2	4	(5JG5)
20	90105-06553-00	BOLT, WASHER BASED	4	(5JG5)
21	93210-10197-00	O-RING	1	(5JG5)
22	99530-10114-00	PIN, DOWEL	1	(5JG5)
23	90387-1712Y-00	COLLAR	2	(5JG5)
24	99530-10116-00	PIN, DOWEL	2	(5JG5)
25	90461-10136-00	CLAMP	1	(5JG5)



5BE100-8130

CRANKCASE COVER 1


Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-15411-00-00	COVER, CRANKCASE 1	1	(5JG5)
2	90340-32123-00	PLUG, STRAIGHT SCREW	1	(5JG5)
3	93210-32172-00	O-RING	1	(5JG5)
4	90340-14128-00	PLUG, STRAIGHT SCREW	1	(5JG5)
5	93210-14369-00	O-RING	1	(5JG5)
6	5BE-15451-00-00	GASKET, CRANKCASE COVER 1	1	(5JG5)
7	99530-08016-00	PIN, DOWEL	2	(5JG5)
8	95027-06040-00	BOLT, FLANGE	2	(5JG5)
9	95027-06030-00	BOLT, FLANGE	6	(5JG5)
10	5JG-15431-00-00	COVER, CRANKCASE 3	1	(5JG5)
11	93101-14164-00	OIL SEAL	1	(5JG5)
12	90201-15701-00	WASHER, PLATE (1.0T)	1	(5JG5)
13	99009-22500-00	CIRCLIP	1	(5JG5)
14	5BE-15462-00-00	GASKET, CRANKCASE COVER 3	1	(5JG5)
15	91812-16001-00	PIN, DOWEL	2	(5JG5)
16	95027-06030-00	BOLT, FLANGE	10	(5JG5)
17	5JG-15415-00-00	COVER, GENERATOR	1	(5JG5)
18	95027-06030-00	BOLT, FLANGE	4	(5JG5)
19	95027-06040-00	BOLT, FLANGE	1	(5JG5)
20	90105-065A1-00	BOLT, WASHER BASED	2	(5JG5)
21	99530-08016-00	PIN, DOWEL	2	(5JG5)
22	5JG-15453-00-00	GASKET, CARBURETOR COVER	1	(5JG5)
23	90462-10241-00	CLAMP	1	(5JG5)
24	583-13113-00-00	SEAT, CHECK BALL	1	(5JG5)
25	93503-08007-00	BALL	1	(5JG5)
26	90501-043E0-00	SPRING, COMPRESSION	1	(5JG5)



5BE100-8141

STARTER


Ref. No.	Part Number	Description	Qty	Remarks
1	5GR-15601-00-00	KICK SHAFT ASSY	1	(5JG5)
2	90201-20685-00	. WASHER, PLATE (0.5T)	1	(5JG5)
3	93410-20038-00	. CIRCLIP	1	(5JG5)
4	90501-16107-00	. SPRING, COMPRESSION	1	(5JG5)
5	90201-167P7-00	. WASHER, PLATE	1	(5JG5)
6	99009-16400-00	. CIRCLIP	1	(5JG5)
7	5GR-15664-00-00	. GUIDE, SPRING	1	(5JG5)
8	90508-30743-00	. SPRING, TORSION	1	(5JG5)
9	90201-162H4-00	WASHER, PLATE	1	(5JG5)
10	5BE-15668-00-00	STOPPER	1	(5JG5)
11	5BE-15674-00-00	GUIDE, RATCHET WHEEL	1	(5JG5)
12	5BE-15686-01-00	WASHER, LOCK	1	(5JG5)
13	90101-06001-00	BOLT	2	(5JG5)
14	93102-20108-00	OIL SEAL	1	(5JG5)
15	5BE-15651-00-00	GEAR, KICK IDLE	1	(5JG5)
16	90201-20276-00	WASHER, PLATE (1.0T)	1	(5JG5)
17	99009-20400-00	CIRCLIP	1	(5JG5)
18	5BE-15620-02-00	KICK CRANK ASSY	1	(5JG5)
19	3SP-15621-02-00	. BOSS, KICK CRANK	1	(5JG5)
20	90501-13720-00	. SPRING, COMPRESSION	1	(5JG5)
21	93501-04011-00	. BALL	1	(5JG5)
22	90152-06010-00	. SCREW, COUNTERSUNK	1	(5JG5)
23	93210-19216-00	. O-RING	1	(5JG5)
24	90105-08752-00	BOLT, WASHER BASED	1	(5JG5)
25	90201-087A9-00	WASHER, PLATE	1	(5JG5)



5JG5100-1150

CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-16111-00-00	GEAR, PRIMARY DRIVE	1	(5JG5)
2	90215-21001-00	WASHER, LOCK	1	(5JG5)
3	90179-20001-00	NUT	1	(5JG5)
4	5JG-16150-10-00	PRIMARY DRIVEN GEAR COMP.	1	(5JG5)
5	5JG-16371-10-00	BOSS, CLUTCH	1	(5JG5)
6	5JG-16351-00-00	PLATE, PRESSURE 1	1	(5JG5)
7	5JG-16325-00-00	PLATE, CLUTCH 2	8	(5JG5)
8	3XK-16321-00-00	PLATE, FRICTION	8	(5JG5)
9	90501-237L0-00	SPRING, COMPRESSION	6	(5JG5)
10	90159-06092-00	SCREW, WITH WASHER	6	(5JG5)
11	2JN-16154-00-00	PLATE, THRUST 1	1	(5JG5)
12	5JG-16321-00-00	PLATE, FRICTION	1	(5JG5)
13	5JG-16383-00-00	SPRING, CLUTCH BOSS	1	(5JG5)
14	5JG-16384-00-00	PLATE, SEAT	1	(5JG5)
15	90215-20231-00	WASHER, LOCK	1	(5JG5)
16	90170-20327-00	NUT	1	(5JG5)
17	5JG-16356-00-00	ROD, PUSH 1	1	(5JG5)
18	93340-21505-00	BEARING	1	(5JG5)
19	90201-125L6-00	WASHER, PLATE	1	(5JG5)
20	93440-10085-00	CIRCLIP	1	(5JG5)
21	93511-32027-00	BALL	1	(5JG5)
22	5JG-16357-10-00	ROD, PUSH 2	1	(5JG5)
23	5JG-16381-00-00	PUSH LEVER COMP.	1	(5JG5)
24	93315-11206-00	BEARING	1	(5JG5)
25	93102-12224-00	OIL SEAL	1	(5JG5)
26	4JT-16384-00-00	PLATE, SEAT	1	(5JG5)
27	95027-06010-00	BOLT, FLANGE	1	(5JG5)
28	90508-142B5-00	SPRING, TORSION	1	(5JG5)




5JG1100-0160

YZ426FN

TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-17411-00-00	AXLE, MAIN	1	(5JG5)
2	93306-20532-00	BEARING	1	(5JG5)
3	5BE-17151-00-00	GEAR, 5TH PINION (21T)	1	(5JG5)
4	90201-253K0-00	WASHER, PLATE (T=1.0)	1	(5JG5)
5	93440-25084-00	CIRCLIP	3	(5JG5)
6	5BE-17131-20-00	GEAR, 3RD PINION	1	(5JG5)
7	5BE-17141-30-00	GEAR, 4TH PINION	1	(5JG5)
8	90387-2113G-00	COLLAR	1	(5JG5)
9	5JG-17121-10-00	GEAR, 2ND PINION	1	(5JG5)
10	90209-21332-00	WASHER	1	(5JG5)
11	93306-00431-00	BEARING	1	(5JG5)
12	93306-00426-00	BEARING	1	(5JG5)
13	5BE-17421-00-00	AXLE, DRIVE	1	(5JG5)
14	5JG-17211-00-00	GEAR, 1ST WHEEL (34T)	1	(5JG5)
15	5BE-17251-10-00	GEAR, 5TH WHEEL (20T)	1	(5JG5)
16	93440-25084-00	CIRCLIP	1	(5JG5)
17	90209-21332-00	WASHER	1	(5JG5)
18	90201-253K0-00	WASHER, PLATE (T=1.0)	1	(5JG5)
19	5BE-17231-00-00	GEAR, 3RD WHEEL (23T)	1	(5JG5)
20	93440-28062-00	CIRCLIP	1	(5JG5)
21	5JG-17241-00-00	GEAR, 4TH WHEEL	1	(5JG5)
22	90209-26348-00	WASHER	1	(5JG5)
23	5JG-17221-10-00	GEAR, 2ND WHEEL	1	(5JG5)
24	93306-20593-00	BEARING	1	(5JG5)
25	93102-32480-00	OIL SEAL	1	(5JG5)
26	90387-2513F-00	COLLAR	1	(5JG5)
27	93210-22298-00	O-RING	1	(5JG5)
28	9383E-14215-00	SPROCKET, DRIVE (14T)	1	(5JG5)
29	90215-21001-00	WASHER, LOCK	1	(5JG5)


CONTINUED ON NEXT FRAME ➤



5JG1100-0160

TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
30	90179-20001-00	NUT	1	(5JG5)
31	5GR-17471-00-00	PLATE, COVER	1	(5JG5)
32	90105-06553-00	BOLT, WASHER BASED	2	(5JG5)




SHIFT CAM. FORK

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-18541-00-00	CAM, SHIFT	1	(5JG5)
2	93306-90501-00	BEARING	1	(5JG5)
3	4BA-18542-00-00	POINT, NEUTRAL	1	(5JG5)
4	90501-06022-00	SPRING, COMPRESSION	1	(5JG5)
5	3XK-18140-00-00	STOPPER LEVER ASSY	1	(5JG5)
6	90508-26561-00	SPRING, TORSION	1	(5JG5)
7	90109-063F8-00	BOLT	1	(5JG5)
8	5BE-18501-00-00	FORK, SHIFT 1	1	(5JG5)
9	5BE-18502-10-00	FORK, SHIFT 2	1	(5JG5)
10	5BE-18503-00-00	FORK, SHIFT 3	1	(5JG5)




5BE100-8170



SHIFT SHAFT

Ref. No.	Part Number	Description	Qty	Remarks
1	3XK-18101-02-00	SHIFT SHAFT ASSY	1	(5JG5)
2	5LP-18122-00-00	LEVER, SHIFT 2	1	(5JG5)
3	90387-124F4-00	COLLAR	1	(5JG5)
4	90508-291A8-00	SPRING, TORSION	1	(5JG5)
5	93608-33002-00	PIN, DOWEL	1	(5JG5)
6	5BE-18110-00-00	SHIFT PEDAL ASSY	1	(5JG5)
7	95027-06020-00	BOLT, FLANGE	1	(5JG5)
8	93102-12106-00	OIL SEAL (SD 12-22-5 HS)	1	(5JG5)
9	3XJ-18173-00-00	PIN, SHIFT	1	(5JG5)
10	3XJ-18178-00-00	ROLLER, SHIFT LEVER	1	(5JG5)
11	3XJ-18182-00-00	PAWL, SHIFTER	2	(5JG5)
12	90501-052G5-00	SPRING, COMPRESSION	2	(5JG5)
13	3XJ-18184-00-00	PIN, PAWL	2	(5JG5)
14	5BE-18172-00-00	GUIDE, SHIFT	1	(5JG5)
15	90101-06664-00	BOLT	2	(5JG5)
16	4EW-18185-00-00	SEGMENT	1	(5JG5)



5BE100-8180



FRAME


Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-21101-50-P0	FRONT FRAME COMP.	1	DPBMC(5JG5)
2	5BE-21756-00-00	. NET, FILTER	1	(5JG5)
3	90430-18130-00	. GASKET	1	(5JG5)
4	95827-08012-00	. BOLT, FLANGE	1	(5JG5)
5	90430-08119-00	. GASKET	1	(5JG5)
6	5JG-21190-50-P0	REAR FRAME COMP.	1	DPBMC(5JG5)
7	90110-08096-00	BOLT, HEXAGON SOCKET HEAD	2	(5JG5)
8	90105-08099-00	BOLT, WASHER BASED	1	(5JG5)
9	95817-10160-00	BOLT, FLANGE	1	(5JG5)
10	95607-10200-00	NUT, SELF-LOCKING	1	(5JG5)
11	5GR-21425-01-00	BRACKET, REAR UPPER 1 ...	1	(5JG5)
12	5BE-21425-01-00	BRACKET, REAR UPPER 1 ...	1	(5JG5)
13	92017-08055-00	BOLT, BUTTON HEAD	3	(5JG5)
14	90201-086P8-00	WASHER, PLATE	6	(5JG5)
15	90185-08169-00	NUT, SELF-LOCKING	3	(5JG5)
16	95817-10050-00	BOLT, FLANGE	1	(5JG5)
17	90105-10733-00	BOLT, WASHER BASED	1	(5JG5)
18	95607-10200-00	NUT, SELF-LOCKING	1	(5JG5)
19	95027-08040-00	BOLT, FLANGE	1	(5JG5)
20	3JD-22178-10-00	TENSIONER	1	(5JG5)
21	4EW-22178-00-00	TENSIONER	1	(5JG5)
22	93300-60804-00	BEARING	2	(5JG5)
23	90387-086N4-00	COLLAR	2	(5JG5)
24	95027-08065-00	BOLT, FLANGE	1	(5JG5)
25	95707-08500-00	NUT, FLANGE	1	(5JG5)
26	90201-086P8-00	WASHER, PLATE	3	(5JG5)
27	90338-16148-00	PLUG	2	(5JG5)
28	5BE-21417-00-00	BRACKET, FRONT LOWER 1 .	2	(5JG5)

CONTINUED ON NEXT FRAME ►



FRAME

Ref. No.	Part Number	Description	Qty	Remarks
29	95817-08016-00	BOLT, FLANGE	4	(5JG5)
30	5BE-21471-00-00	PROTECTOR, ENGINE	1	(5JG5)
31	5BE-15362-00-00	PLUG, OIL LEVEL	1	(5JG5)
32	93210-19123-00	O-RING	1	(5JG5)
33	5BE-2147A-00-00	GUARD, ENGINE 1	1	(5JG5)
34	95027-08012-00	BOLT, FLANGE	5	(5JG5)
35	90157-08028-00	SCREW, PAN HEAD	1	(5JG5)
36	90202-08204-00	WASHER, PLATE	1	(5JG5)
37	5ET-28166-00-00	WRENCH, HEXAGON	1	(5JG5)
38	5BE-2814F-00-00	BOX, SPARK PLUG	1	(5JG5)



FENDER


Ref. No.	Part Number	Description	Qty	Remarks
1	5HD-21511-00-00	FENDER, FRONT	1	(5JG5)
2	3JD-21748-00-00	COLLAR	4	(5JG5)
3	90119-06096-00	BOLT, WITH WASHER	4	(5JG5)
4	4ES-2153E-01-00	EMBLEM, YAMAHA	1	(5JG5)
5	5BE-21611-10-00	FENDER, REAR	1	(5JG5)
6	90105-06553-00	BOLT, WASHER BASED	2	(5JG5)
7	90183-06023-00	NUT, SPRING	2	(5JG5)
8	90387-0701A-00	COLLAR	2	(5JG5)
9	5BE-21642-00-00	GUARD, FLAP	1	(5JG5)
10	90105-06690-00	BOLT, WASHER BASED	2	(5JG5)
11	90387-06009-00	COLLAR	2	(5JG5)
12	97707-60016-00	SCREW, TAPPING	2	(5JG5)
13	90201-06557-00	WASHER, PLATE	2	(5JG5)
14	4ES-2153E-01-00	EMBLEM, YAMAHA	1	EXCEPT FOR CAN(5JG5)
15	5JG-2163G-50-00	EMBLEM 1	2	(5JG5)




5JG1100-0200

SIDE COVER

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-21711-00-00	COVER, SIDE 1	1	(5JG5)
2	95827-06016-00	BOLT, FLANGE	1	(5JG5)
3	90119-08238-00	BOLT, WITH WASHER	1	(5JG5)
4	5JG-21781-50-00	EMBLEM 1	1	(5JG5)
5	5BE-21721-00-00	COVER, SIDE 2	1	(5JG5)
6	5BE-2174A-00-00	INSULATOR, SIDE COVER ...	1	(5JG5)
7	3FY-21575-01-00	SEAL 1	1	(5JG5)
8	95827-06016-00	BOLT, FLANGE	1	(5JG5)
9	90119-08238-00	BOLT, WITH WASHER	1	(5JG5)
10	5JG-21781-50-00	EMBLEM 1	1	(5JG5)
11	5JG-21731-01-00	COVER, SIDE 3	1	(5JG5)
12	5JG-2173E-50-00	GRAPHIC 1	1	(5JG5)
13	90159-06182-00	SCREW, WITH WASHER	2	(5JG5)
14	90159-06078-00	SCREW, WITH WASHER	1	(5JG5)
15	5JG-2172A-10-00	PANEL 1	1	(5JG5)
16	5JG-21741-01-00	COVER, SIDE 4	1	(5JG5)
17	5JG-2173F-50-00	GRAPHIC 2	1	(5JG5)
18	90159-06182-00	SCREW, WITH WASHER	2	(5JG5)
19	90159-06078-00	SCREW, WITH WASHER	1	(5JG5)
20	5JG-2172A-10-00	PANEL 1	1	(5JG5)
21	5MV-2175C-00-00	TUNING FORK MARK	2	(5JG5)



5JG5100-1210




5JG5100-1220

YZ426FN

REAR ARM

Ref. No.	Part Number	Description	Qty	Remarks
1	5MV-22110-00-00	REAR ARM COMP.	1	(5JG5)
2	90151-04048-00	SCREW, COUNTERSUNK	4	(5JG5)
3	5ET-22355-00-00	PATCH	2	(5JG5)
4	93317-22262-00	BEARING	4	(5JG5)
5	90338-16148-00	PLUG	2	(5JG5)
6	93106-22019-00	OIL SEAL (DC 22-28-8)	2	(5JG5)
7	93342-22217-00	BEARING	2	(5JG5)
8	93109-28043-00	OIL SEAL	2	(5JG5)
9	90387-1714R-00	COLLAR	2	(5JG5)
10	90387-1714S-00	COLLAR	2	(5JG5)
11	5MV-22151-00-00	SEAL, GUARD	1	(5JG5)
12	91317-05008-00	BOLT	4	(5JG5)
13	5JG-22156-00-00	WASHER, PLATE	4	(5JG5)
14	4XM-22199-00-00	SUPPORT, CHAIN	1	(5JG5)
15	4XM-22128-00-00	COVER, THRUST 1	1	(5JG5)
16	95027-06050-00	BOLT, FLANGE	2	(5JG5)
17	90179-06568-00	NUT	2	(5JG5)
18	95027-06010-00	BOLT, FLANGE	1	(5JG5)
19	5DH-22141-00-00	SHAFT, PIVOT	1	(5JG5)
20	90185-16127-00	NUT, SELF-LOCKING	1	(5JG5)
21	90201-164H4-00	WASHER, PLATE	1	(5JG5)
22	5ET-2217A-00-00	ARM, RELAY	1	(5JG5)
23	93315-32056-00	BEARING	2	(5JG5)
24	93109-20076-00	OIL SEAL	4	(5JG5)
25	90387-16005-00	COLLAR	2	(5JG5)
26	90387-16007-00	COLLAR	2	(5JG5)
27	90387-167Y9-00	COLLAR	1	(5JG5)
28	90109-147F2-00	BOLT	1	(5JG5)
29	90109-142F4-00	BOLT	2	(5JG5)

CONTINUED ON NEXT FRAME ►




5JG5100-1220

YZ426FN

REAR ARM

Ref. No.	Part Number	Description	Qty	Remarks
30	90201-164H4-00	WASHER, PLATE	2	(5JG5)
31	90201-14740-00	WASHER, PLATE	3	(5JG5)
32	90185-14112-00	NUT, SELF-LOCKING	1	(5JG5)
33	95617-14100-00	NUT, U	2	(5JG5)
34	5DH-2217F-01-00	ROD, CONNECTING 1	1	(5JG5)
35	93315-32056-00	BEARING	2	(5JG5)
36	93109-20076-00	OIL SEAL	2	(5JG5)
37	5HD-2135F-00-00	COVER	2	(5JG5)
38	99244-00200-00	EMBLEM, YAMAHA	2	(5JG5)


REAR SUSPENSION



Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-22210-50-00	SHOCK ABSORBER ASSY, REAR	1	(5JG5)
2	5JG-22201-50-00	. DAMPER SUB ASSY	1	(5JG5)
3	3SP-22234-00-00	. . GUIDE, SPRING 3	1	(5JG5)
4	3SP-22213-00-00	. . SEAT, SPRING UPPER	1	(5JG5)
5	509-23184-L0-00	. . CAP, AIR VALVE	1	(5JG5)
6	4JX-22226-00-00	. . BUSH, SHOCK ABSORBER LOWER	1	(5JG5)
7	5DH-23183-00-00	. . CIRCLIP	1	(5JG5)
8	5DH-22212-50-00	. SPRING (K=5.4)	1	(5JG5)
9	5DH-22214-00-00	. GUIDE, SPRING 1	1	(5JG5)
10	5MV-22224-00-00	. GUIDE, SPRING 2	1	(5JG5)
11	5DH-22253-00-00	. COLLAR, DISTANCE	2	(5JG5)
12	3JE-22475-00-00	. SEAL, DUST	2	(5JG5)
13	4EW-22474-00-00	. SEAL, RING	2	(5JG5)
14	5MV-22253-00-00	. COLLAR, DISTANCE	2	(5JG5)
15	5MV-22176-00-00	. BEARING	1	(5JG5)
16	5MV-22184-00-00	. BUSH	1	(5JG5)
17	5MV-22475-00-00	. SEAL, DUST	2	(5JG5)
18	90105-10323-00	BOLT, WASHER BASED	1	(5JG5)
19	95607-10200-00	NUT, SELF-LOCKING	1	(5JG5)
20	90105-105A2-00	BOLT, WASHER BASED	1	(5JG5)
21	90201-112U6-00	WASHER, PLATE	1	(5JG5)



5JG5100-1230




STEERING

Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00081-00	BEARING	1	(5JG5)
2	93332-00068-00	BEARING	1	(5JG5)
3	4EW-23416-00-00	COVER, BALL RACE 2	1	(5JG5)
4	90179-28650-00	NUT	1	(5JG5)
5	5HC-23435-11-00	CROWN, HANDLE	1	(5JG5)
6	90170-24373-00	NUT	1	(5JG5)
7	90201-247L2-00	WASHER, PLATE	1	(5JG5)
8	3SP-23441-00-00	HOLDER, HANDLE UPPER ...	2	(5JG5)
9	95027-08035-00	BOLT, FLANGE	4	(5JG5)
10	95027-08040-00	BOLT, FLANGE	4	(5JG5)
11	5HD-23485-00-00	PLATE, NUMBER	1	(5JG5)
12	95027-06014-00	BOLT, FLANGE	1	(5JG5)
13	90201-286K9-00	WASHER, PLATE	2	(5JG5)
14	4DA-23389-00-00	GUIDE, CABLE	1	(5JG5)
15	90119-05071-00	BOLT, WITH WASHER	1	(5JG5)
16	5HD-2339E-00-00	GRAPHIC 1	1	(5JG5)



5JG1100-0240

FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-23102-50-00	FRONT FORK ASSY (L.H)	1	(5JG5)
2	5HD-23136-L0-00	. TUBE, OUTER (RIGHT)	1	(5JG5)
3	5HD-23120-L0-00	. INNER TUBE COMP 2	1	(5JG5)
4	5ET-23171-L0-00	. PISTON, FRONT FORK	1	(5JG5)
5	5ET-23125-L0-00	. METAL, SLIDE 1	1	(5JG5)
6	4SS-23146-L0-00	. WASHER, OIL SEAL	1	(5JG5)
7	5ET-23145-L0-00	. OIL SEAL	1	(5JG5)
8	4SS-23153-L0-00	. RING, SNAP	1	(5JG5)
9	5HD-23144-L0-00	. SEAL, DUST	1	(5JG5)
10	5JG-23170-50-00	. CYLINDER COMP., FRONT FORK	1	(5JG5)
11	5JG-2316A-50-00	. VALVE COMP.	1	(5JG5)
12	5MV-23111-L0-00	. BOLT, CAP	1	(5JG5)
13	5DH-23142-L0-00	. SEAT, SPRING UPPER	1	(5JG5)
14	5HD-23393-L0-00	. NUT, SPECIAL	1	(5JG5)
15	5MV-23195-L0-00	. RUBBER	1	(5JG5)
16	5DH-23149-L0-00	. WASHER, SPRING UPPER	1	(5JG5)
17	5DH-23118-L0-00	. SPACER	1	(5JG5)
18	4SS-23158-L0-00	. GASKET	1	(5JG5)
19	5GR-23141-L0-00	. SPRING, FRONT FORK (K=0.46)	1	(5JG5)
20	3JD-2312G-L0-00	. PLUG	1	(5JG5)
21	5JG-23103-50-00	FRONT FORK ASSY (R.H)	1	(5JG5)
22	5HD-23136-L0-00	. TUBE, OUTER (RIGHT)	1	(5JG5)
23	5BF-23110-L0-00	. INNER TUBE COMP 1	1	(5JG5)
24	5ET-23171-L0-00	. PISTON, FRONT FORK	1	(5JG5)
25	5ET-23125-L0-00	. METAL, SLIDE 1	1	(5JG5)
26	4SS-23146-L0-00	. WASHER, OIL SEAL	1	(5JG5)
27	5ET-23145-L0-00	. OIL SEAL	1	(5JG5)


CONTINUED ON NEXT FRAME ►



5JG5100-1250


FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
28	4SS-23153-L0-00	. RING, SNAP	1	(5JG5)
29	5HD-23144-L0-00	. SEAL, DUST	1	(5JG5)
30	5JG-23170-50-00	. CYLINDER COMP., FRONT FORK	1	(5JG5)
31	5JG-2316A-50-00	. VALVE COMP.	1	(5JG5)
32	5MV-23111-L0-00	. BOLT, CAP	1	(5JG5)
33	5DH-23142-L0-00	. SEAT, SPRING UPPER	1	(5JG5)
34	5HD-23393-L0-00	. NUT, SPECIAL	1	(5JG5)
35	5MV-23195-L0-00	. RUBBER	1	(5JG5)
36	5DH-23149-L0-00	. WASHER, SPRING UPPER ..	1	(5JG5)
37	5DH-23118-L0-00	. SPACER	1	(5JG5)
38	4SS-23158-L0-00	. GASKET	1	(5JG5)
39	5GR-23141-L0-00	. SPRING, FRONT FORK (K=0.46)	1	(5JG5)
40	3JD-2312G-L0-00	. PLUG	1	(5JG5)
41	5HC-23340-M0-00	UNDER BRACKET COMP.	1	(5JG5)
42	5MV-23346-L0-00	BOLT 1	8	(5JG5)
43	4SS-2314G-L0-00	PROTECTOR GUIDE COMP., 2	1	(5JG5)
44	5DH-2314F-L0-00	PROTECTOR GUIDE COMP., 1	1	(5JG5)
45	4SS-23346-L0-00	BOLT 1	2	(5JG5)
46	5DH-2314J-00-00	PROTECTOR COMP., 2	1	(5JG5)
47	5DH-2314H-00-00	PROTECTOR COMP., 1	1	(5JG5)
48	3SP-23356-L0-00	BOLT 2	6	(5JG5)
49	5HC-2331E-00-00	GUIDE, CABLE	1	(5JG5)
50	4XL-2153A-10-00	EMBLEM, YAMAHA	2	(5JG5)




5JG5100-1250

FUEL TANK



Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-24110-50-00	FUEL TANK COMP.	1	(5JG5)
2	5MV-24610-00-00	CAP ASSY	1	(5JG5)
3	90445-09220-00	HOSE	1	(5JG5)
4	3XJ-24380-00-00	PIPE JOINT ASSY	1	(5JG5)
5	90445-09104-00	HOSE	1	(5JG5)
6	24X-24144-00-00	HOLDER, DAMPER	2	(5JG5)
7	90480-18549-00	GROMMET	2	(5JG5)
8	95027-06016-00	BOLT, FLANGE	4	(5JG5)
9	90119-06214-00	BOLT, WITH WASHER	2	(5JG5)
10	3JD-24186-00-00	WASHER, SPECIAL	2	(5JG5)
11	98907-06020-00	SCREW, BIND	1	(5JG5)
12	3SP-24173-00-00	BAND, TANK FITTING 1	1	(5JG5)
13	4EW-2412F-00-00	BRACKET, SEAT	1	(5JG5)
14	98707-06025-00	SCREW, FLAT HEAD	1	(5JG5)
15	4SS-24181-00-00	DAMPER, LOCATING 1	1	(5JG5)
16	4DP-24500-00-00	FUEL COCK ASSY 1	1	(5JG5)
17	3AJ-24534-00-00	. SEAL, COCK	1	(5JG5)
18	97801-03008-00	. SCREW, PAN HEAD	2	(5JG5)
19	4X8-24512-00-00	. O-RING	1	(5JG5)
20	3AJ-24523-00-00	. VALVE PACKING	1	(5JG5)
21	90445-11002-00	HOSE (L195)	1	(5JG5)
22	90467-10008-00	CLIP	2	(5JG5)
23	90202-05193-00	WASHER, PLATE	2	(5JG5)
24	90149-06011-00	SCREW	2	(5JG5)
25	5BE-24182-00-00	DAMPER, LOCATING 2	1	(5JG5)
26	3V6-22358-00-00	SEAL 1	2	(5JG5)
27	5JG-24240-50-00	GRAPHIC SET	1	(5JG5)




SEAT

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-24710-50-00	SINGLE SEAT ASSY	1	(5JG5)
2	5JG-24731-50-00	. COVER, SEAT	1	(5JG5)
3	5BE-24728-00-00	. BRACKET, SEAT	2	(5JG5)
4	97007-06012-00	. BOLT	4	(5JG5)
5	92907-06100-00	. WASHER, SPRING	4	(5JG5)



5BE100-8270



FRONT WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
1	4SS-25111-01-00	HUB, FRONT	1	(5JG5)
2	93306-90403-00	BEARING	2	(5JG5)
3	5DH-25117-00-00	SPACER, BEARING	1	(5JG5)
4	93102-26468-00	OIL SEAL	2	(5JG5)
5	94416-21613-00	RIM (1.60-21)	1	(5JG5)
6	4DA-25104-00-00	SPOKE SET, FRONT	1	(5JG5)
7	94108-21008-00	TIRE (80/100-21 51M D739F) ..	1	DUNLOP(5JG5)
8	94227-21101-00	TUBE (80/100-21 TR4 BTL) ...	1	DUNLOP FOR FRA(5JG5)
9	94309-21161-00	BAND, RIM (70-80/100-21)	1	DUNLOP FOR FRA(5JG5)
10	2J5-25394-01-00	SPACER, BEAD	1	(5JG5)
11	5BE-25181-00-00	AXLE, WHEEL	1	(5JG5)
12	5DH-25183-00-00	COLLAR, WHEEL	1	(5JG5)
13	5BE-25186-00-00	COLLAR, WHEEL	1	(5JG5)
14	90179-16672-00	NUT	1	(5JG5)




5BE100-8280

FRONT BRAKE CALIPER

Ref. No.	Part Number	Description	Qty	Remarks
1	5MV-2581T-00-00	DISC BRAKE ASSY	1	(5JG5)
2	90149-06327-00	SCREW	6	(5JG5)
3	5MV-2580T-10-00	CALIPER ASSY (LEFT)	1	(5JG5)
4	4EW-W0057-00-00	. PISTON ASSY, CALIPER	1	(5JG5)
5	3JD-W0047-00-00	. . CALIPER SEAL KIT	1	(5JG5)
6	5DH-25919-00-00	. SUPPORT, PAD	1	(5JG5)
7	1UY-W0048-50-00	. BLEED SCREW KIT	1	(5JG5)
8	5MV-W0045-00-00	. BRAKE PAD KIT	1	(5JG5)
9	5DH-25933-00-00	. PIN, PAD	1	(5JG5)
10	5DH-25916-00-00	. PLUG	1	(5JG5)
11	90105-08659-00	BOLT, WASHER BASED	2	(5JG5)
12	5DH-2314E-00-00	COVER, HOSE	1	(5JG5)
13	95827-06012-00	BOLT, FLANGE	1	(5JG5)
14	95027-08020-00	BOLT, FLANGE	1	(5JG5)
15	5DH-25875-00-00	HOLDER, BRAKE HOSE 1	1	(5JG5)
16	92907-08200-00	WASHER	1	(5JG5)



5JG5100-1290




5GR100-9300

REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	5ET-25311-00-00	HUB, REAR	1	(5JG5)
2	5ET-25317-00-00	SPACER, BEARING	1	(5JG5)
3	93306-27205-00	BEARING	1	(5JG5)
4	93306-07202-00	BEARING	1	(5JG5)
5	93106-30044-00	OIL SEAL	1	(5JG5)
6	93106-30045-00	OIL SEAL	1	(5JG5)
7	99009-45500-00	CIRCLIP	1	(5JG5)
8	94421-19602-00	RIM (2.15-19)	1	(5JG5)
9	5HD-25304-00-00	SPOKE SET, REAR	1	(5JG5)
10	94111-19008-00	TIRE (110/90-19 62M D739)	1	DUNLOP(5JG5)
11	94211-19273-00	TUBE (110/90 110/100-19TR4)	1	DUNLOP FOR FRA(5JG5)
12	94311-19155-00	BAND, RIM (110/90 110/100-19)	1	DUNLOP FOR FRA(5JG5)
13	3JE-25394-00-00	SPACER, BEAD	1	(5JG5)
14	4XM-25364-00-00	DAMPER	1	(5JG5)
15	5ET-25447-00-00	SPROCKET, DRIVEN (47T)	1	AP(5JG5)
	5ET-25448-00-00	SPROCKET, DRIVEN (48T)	1	AP(5JG5)
	5ET-25449-00-00	SPROCKET, DRIVEN (49T)	1	STD(5JG5)
	5ET-25450-00-00	SPROCKET, DRIVEN (50T)	1	AP(5JG5)
	5ET-25451-00-00	SPROCKET, DRIVEN (51T)	1	AP(5JG5)
	5ET-25452-00-00	SPROCKET, DRIVEN (52T)	1	AP(5JG5)
16	90109-081G1-00	BOLT	6	(5JG5)
17	90185-08169-00	NUT, SELF-LOCKING	6	(5JG5)
18	90201-08326-00	WASHER, PLATE	6	(5JG5)
19	90480-08608-00	GROMMET	1	(5JG5)
20	5ET-25383-00-00	COLLAR, WHEEL	2	(5JG5)
21	5ET-25388-00-00	PULLER, CHAIN 1	1	(5JG5)
22	5ET-25389-00-00	PULLER, CHAIN 2	1	(5JG5)

CONTINUED ON NEXT FRAME ➤




5GR100-9300

REAR WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
23	90101-08777-00	BOLT	2	(5JG5)
24	90179-08299-00	NUT	2	(5JG5)
25	5ET-25381-00-00	AXLE, WHEEL	1	(5JG5)
26	90185-20168-00	NUT, SELF-LOCKING	1	(5JG5)
27	90201-203U1-00	WASHER, PLATE	1	(5JG5)
28	9Y581-92113-00	CHAIN	1	(5JG5)
29	94681-68001-00	. JOINT, CHAIN	1	(5JG5)
30	5ET-25367-00-00	COVER, HUB DUST	2	(5JG5)

REAR BRAKE CALIPER



Ref. No.	Part Number	Description	Qty	Remarks
1	5DH-2582W-00-00	DISC, REAR BRAKE 2	1	(5JG5)
2	90109-065G4-00	BOLT	6	(5JG5)
3	5GR-2580W-00-00	CALIPER ASSY, REAR 2	1	(5JG5)
4	5ET-W0057-50-00	. PISTON ASSY, CALIPER	1	(5JG5)
5	5ET-W0047-50-00	. . CALIPER SEAL KIT	1	(5JG5)
6	5DH-25919-50-00	. SUPPORT, PAD	1	(5JG5)
7	1UY-W0048-50-00	. BLEED SCREW KIT	1	(5JG5)
8	5GR-W0046-00-00	. BRAKE PAD KIT 2	1	(5JG5)
9	5DH-25828-50-00	. . SHIM, CALIPER	1	(5JG5)
10	5DH-25827-50-00	. . SHIM, CALIPER	1	(5JG5)
11	5GR-22898-50-00	. . INSULATOR, HEAT	2	(5JG5)
12	8CR-25924-00-00	. PIN, PAD	1	(5JG5)
13	5DH-25916-00-00	. PLUG	1	(5JG5)
14	5DH-25718-01-00	PROTECTOR, DISK BRAKE	1	(5JG5)
15	95027-06012-00	BOLT, FLANGE	2	(5JG5)
16	4GY-27491-00-00	PROTECTOR	1	(5JG5)
17	95027-06016-00	BOLT, FLANGE	2	(5JG5)


5ET1100-9280



5JG5100-1320

STEERING HANDLE. CABLE

Ref. No.	Part Number	Description	Qty	Remarks
1	4XM-26111-00-00	HANDLEBAR	1	(5JG5)
2	4GY-26241-00-00	GRIP (LEFT)	1	(5JG5)
3	5BE-26240-00-00	GRIP ASSY	1	(5JG5)
4	4GY-26242-00-00	. GRIP (RIGHT)	1	(5JG5)
5	3Y1-26249-00-00	. RING, LEAF	1	(5JG5)
6	5BE-26281-00-00	CAP, GRIP UPPER	1	(5JG5)
7	5BE-26282-00-00	CAP, GRIP LOWER	1	(5JG5)
8	98507-05020-00	SCREW, PAN HEAD	2	(5JG5)
9	5JG-26302-50-00	THROTTLE CABLE ASSY	1	(5JG5)
10	5JG-26335-00-00	CABLE, CLUTCH	1	(5JG5)
11	90387-225N2-00	COLLAR	1	(5JG5)
12	5HD-26342-00-00	BOOT, CABLE	1	(5JG5)




FRONT MASTER CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	5ET-25872-00-00	HOSE, BRAKE 1	1	(5JG5)
2	90201-10118-00	WASHER, PLATE	4	(5JG5)
3	90401-10172-00	BOLT, UNION	2	(5JG5)
4	5MV-W2587-00-00	MASTER CYLINDER SUB ASSY	1	(5JG5)
5	5MV-W0041-00-00	. CYLINDER KIT, MASTER	1	(5JG5)
6	98706-04012-00	. SCREW, FLAT HEAD	2	(5JG5)
7	5MV-25852-00-00	. CAP, RESERVOIR	1	(5JG5)
8	56A-25854-00-00	. DIAPHRAGM, RESERVOIR ..	1	(5JG5)
9	8CR-25715-00-00	. SEPARATOR ASSY	1	(5JG5)
10	5G2-25868-00-00	. BOOT, MASTER CYLINDER ..	1	(5JG5)
11	5MV-83922-00-00	LEVER 2	1	(5JG5)
12	5MV-2589F-00-00	BOLT, LEVER	1	(5JG5)
13	95701-06500-00	NUT, FLANGE	1	(5JG5)
14	5MV-25867-00-00	BRACKET, MASTER CYLINDER	1	(5JG5)
15	5MV-25833-00-00	BOLT, FITTING	2	(5JG5)
16	90465-16258-00	CLAMP	2	(5JG5)
17	91317-06014-00	BOLT	2	(5JG5)
18	5MV-26372-00-00	COVER, HANDLE LEVER 1 ...	1	(5JG5)



5JG5100-1330



STAND. FOOTREST


Ref. No.	Part Number	Description	Qty	Remarks
1	4XM-27200-00-00	PEDAL, BRAKE	1	(5JG5)
2	5JG-27217-00-00	BOLT	1	(5JG5)
3	93210-11073-00	O-RING	2	(5JG5)
4	91401-20012-00	PIN, COTTER	1	(5JG5)
5	90506-16500-00	SPRING, TENSION	1	(5JG5)
6	90240-08120-00	PIN, CLEVIS	1	(5JG5)
7	90201-08089-00	WASHER, PLATE	1	(5JG5)
8	90468-16191-00	CLIP	1	(5JG5)
9	5ET-27411-00-00	FOOTREST 1	1	(5JG5)
10	5ET-27421-00-00	FOOTREST 2	1	(5JG5)
11	90240-10142-00	PIN, CLEVIS	2	(5JG5)
12	91401-25015-00	PIN, COTTER	2	(5JG5)
13	90508-282B8-00	SPRING, TORSION	1	(5JG5)
14	90508-282B9-00	SPRING, TORSION	1	(5JG5)
15	5ET-27311-00-00	STAND, SIDE	1	(5JG5)
16	90201-10119-00	WASHER, PLATE	2	(5JG5)



5BE100-8340

REAR MASTER CYLINDER


Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-2583V-00-00	RR. MASTER CYLINDER ASSY.	1	(5JG5)
2	4SS-W0042-50-00	. CYLINDER KIT, MASTER	1	(5JG5)
3	93210-15620-00	. O-RING	1	(5JG5)
4	2VN-25866-00-00	. CIRCLIP	1	(5JG5)
5	4ML-2582A-50-00	. JOINT	1	(5JG5)
6	3SP-27222-00-00	. JOINT	1	(5JG5)
7	95301-08700-00	. NUT	2	(5JG5)
8	5BE-25894-00-00	. TANK, RESERVOIR	1	(5JG5)
9	5BE-25852-00-00	. CAP, RESERVOIR	1	(5JG5)
10	98706-04040-00	. SCREW, FLAT HEAD	2	(5JG5)
11	56A-25854-00-00	. DIAPHRAGM, RESERVOIR . .	1	(5JG5)
12	90467-12085-00	. CLIP	2	(5JG5)
13	5BE-25895-00-00	. HOSE, RESERVOIR	1	(5JG5)
14	3FV-2589A-00-00	. COVER, DUST	1	(5JG5)
15	5BE-2117M-01-00	COVER 2	1	(5JG5)
16	92014-06016-00	BOLT, BUTTON HEAD	2	(5JG5)
17	90105-06553-00	BOLT, WASHER BASED	1	(5JG5)
18	5MV-25873-00-00	HOSE, BRAKE 2	1	(5JG5)
19	90401-10172-00	BOLT, UNION	2	(5JG5)
20	90201-10118-00	WASHER, PLATE	3	(5JG5)
21	2VM-25876-00-00	HOLDER, BRAKE HOSE 2 . . .	2	(5JG5)
22	97780-50510-00	SCREW, TAPPING	4	(5JG5)
23	5BE-25844-01-00	WASHER, LOCK	1	(5JG5)




5JG5100-1350

GENERATOR

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-85560-10-00	BASE ASSY	1	(5JG5)
2	5JG-85550-11-00	ROTOR ASSY	1	(5JG5)
3	90149-06324-00	SCREW	3	(5JG5)
4	90179-10247-00	NUT	1	(5JG5)
5	90201-101J1-00	WASHER, PLATE	1	(5JG5)



5BE100-8360




HANDLE SWITCH. LEVER

Ref. No.	Part Number	Description	Qty	Remarks
1	5HD-82911-00-00	HOLDER, LEVER 1	1	(5JG5)
2	38V-82913-00-00	HOLDER, LEVER LOWER 1 ...	1	(5JG5)
3	5MV-83912-00-00	LEVER 1	1	(5JG5)
4	90109-06027-00	BOLT	1	(5JG5)
5	95607-06100-00	NUT, U	1	(5JG5)
6	97007-05016-00	BOLT	2	(5JG5)
7	5HD-26337-00-00	BOLT, ADJUSTING	1	(5JG5)
8	5HD-83951-00-00	BOLT, CABLE ADJUSTING ...	1	(5JG5)
9	5HD-26372-00-00	COVER, HANDLE LEVER 1 ...	1	(5JG5)
10	23X-83976-00-00	SWITCH, HANDLE 1	1	(5JG5)
11	583-83981-00-00	LEVER, DECOMPRESSION ...	1	(5JG5)
12	5BE-83913-00-00	COLLAR, LEVER 1	1	(5JG5)
13	98907-05020-00	SCREW, BIND	1	(5JG5)
14	95607-05100-00	NUT, U	1	(5JG5)
15	5BE-82912-00-00	HOLDER, LEVER UPPER 1 ...	1	(5JG5)
16	38V-82913-00-00	HOLDER, LEVER LOWER 1 ...	1	(5JG5)
17	97007-05016-00	BOLT	2	(5JG5)
18	583-26352-00-00	COVER, DECOMPRESSION CABLE	1	(5JG5)



5JG1100-0370




5JG5100-1380

ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-85540-50-00	C.D.I. UNIT ASSY	1	(5JG5)
2	5BE-85546-00-00	BAND	1	(5JG5)
3	5BE-82310-00-00	IGNITION COIL ASSY	1	(5JG5)
4	91317-06016-00	BOLT	2	(5JG5)
5	5BE-82370-00-00	PLUG CAP ASSY	1	(5JG5)
6	5BE-82540-01-00	NEUTRAL SWITCH ASSY	1	(5JG5)
7	93210-21276-00	O-RING	1	(5JG5)
8	90154-05073-00	SCREW, BINDING	2	(5JG5)
9	90464-16061-00	CLAMP	2	(5JG5)
10	90464-13073-00	CLAMP	1	(5JG5)
11	90464-15195-00	CLAMP	1	(5JG5)
12	90460-15126-00	CLAMP, HOSE	1	(5JG5)
13	90464-13077-00	CLAMP	2	(5JG5)
14	90464-15152-00	CLAMP	3	(5JG5)
15	90464-13073-00	CLAMP	1	(5JG5)
16	90464-15195-00	CLAMP	2	(5JG5)
17	90465-13152-00	CLAMP	1	(5JG5)
18	5JG-82509-50-00	WIRE, SUB LEAD	1	(5JG5)

ALTERNATE (CHASSIS)



Ref. No.	Part Number	Description	Qty	Remarks
1	5DH-22212-10-00	SPRING (K=4.6)	1	AP(5JG5)
	5DH-22212-20-00	SPRING (K=4.8)	1	AP(5JG5)
	5DH-22212-30-00	SPRING (K=5.0)	1	AP(5JG5)
	5DH-22212-40-00	SPRING (K=5.2)	1	AP(5JG5)
	5DH-22212-50-00	SPRING (K=5.4)	1	AP(5JG5)
	5DH-22212-60-00	SPRING (K=5.6)	1	AP(5JG5)
	5DH-22212-70-00	SPRING (K=4.4)	1	AP(5JG5)
	5ET-22212-00-00	SPRING (K=APPROX.4.8)	1	AP(5JG5)
	5ET-22212-10-00	SPRING (K=APPROX.5.0)	1	AP(5JG5)
	5ET-22212-20-00	SPRING (K=APPROX.4.6)	1	AP(5JG5)
	5ET-22212-30-00	SPRING (K=APPROX.5.2)	1	AP(5JG5)
	5ET-22212-40-00	SPRING (K=APPROX.5.4)	1	AP(5JG5)
	5ET-22212-50-00	SPRING (K=APPROX.5.6)	1	AP(5JG5)
	2 4SS-23141-10-00	SPRING, FRONT FORK (K=0.38)	2	AP(5JG5)
	4SS-23141-20-00	SPRING, FRONT FORK (K=0.39)	2	AP(5JG5)
	4SS-23141-30-00	SPRING, FRONT FORK (K=0.40)	2	AP(5JG5)
	4SS-23141-40-00	SPRING, FRONT FORK (K=0.41)	2	AP(5JG5)
	4SS-23141-50-00	SPRING, FRONT FORK (K=0.42)	2	AP(5JG5)
	4SS-23141-60-00	SPRING, FRONT FORK (K=0.43)	2	AP(5JG5)
	4SS-23141-70-00	SPRING, FRONT FORK (K=0.44)	2	AP(5JG5)
	5BE-23141-00-00	SPRING, FRONT FORK (K=0.46)	2	AP(5JG5)
	5BE-23141-L0-00	SPRING, FRONT FORK (K=0.45)	2	AP(5JG5)
	5ET-23141-00-00	SPRING (K=APPROX.0.41)	2	AP(5JG5)
	5ET-23141-10-00	SPRING (K=APPROX.0.43)	2	AP(5JG5)
	5ET-23141-20-00	SPRING (K=APPROX.0.40)	2	AP(5JG5)
	5ET-23141-30-00	SPRING (K=APPROX.0.42)	2	AP(5JG5)
	5ET-23141-40-00	SPRING (K=APPROX.0.44)	2	AP(5JG5)
	5GR-23141-00-00	SPRING, FRONT FORK (K=0.47)	2	AP(5JG5)
	3 4SS-23364-L0-00	COLLAR 2	2	UN(5JG5)



5BE100-8390